



GE VERNOVA


# UR Family G30

## Instruction Manual

### Generator Protection System

Product Version: 8.80

Publication Reference: G30-1601-0166-88x-2



## Copyright statement

Copyright © 2026 GE Vernova. All rights reserved.

GridBeats, Universal Relay, Multilin, MiCOM, S1 Agile, P40 Agile, DS Agile, EnerVista, CyberSentry, HardFiber, FlexLogic, FlexElement, FlexCurve, FlexAnalog, FlexInteger and FlexState are trademarks or registered trademarks of GE Vernova

The contents of this manual are the property of GE Vernova. This documentation is provided on license and may not be reproduced in whole or in part without the permission of GE Vernova. The content of this manual is for informational use only and is subject to change without notice.

## Disclaimer

It is the responsibility of the user to verify and validate the suitability of all GE Vernova products. This equipment must be used within its design limits. The proper application including the configuration and setting of this product to suit the power system assets, is the responsibility of the user, who is also required to ensure that all local or regional safety guidelines are adhered to. Incorrect application of this product could risk damage to property, the environment, personal injuries or fatalities and it is the sole responsibility of the person/entity applying and qualifying the product for use.

The content of this document has been developed to provide guidance to properly install, configure and maintain this product for its intended applications. This guidance is not intended to cover every possible contingency that may arise during commissioning, operation, service, or maintenance activities. Should you encounter any circumstances not clearly addressed in this document, please contact your local GE Vernova service site.

It is the sole responsibility of the user to secure their network and associated devices against cybersecurity intrusions or attacks. GE Vernova and its affiliates are not liable for any damages or losses arising from or related to such security intrusion or attacks.

The information contained in this document is subject to change without notice.

## Warranty

GE Vernova warrants most of its manufactured products for 10 years from the date of shipping.

For warranty details including any limitations and disclaimers, see the Terms and Conditions at:

<https://www.gevernova.com/grid-solutions/multilin/warranty.htm>

## Major changes

For information on the updates included in this release of the manual, please refer to the latest release notes.

## Open source licenses

The optional IEC 61850-9-2LE/IEC 61869 Process Bus Modules include open source code. See the UR-OpenSourceLicense folder installed at the root level with the software, such as at C:\Program Files (x86)\GE Power Management\URPC

# Contents

|                  |                                                          |           |
|------------------|----------------------------------------------------------|-----------|
| <b>Chapter 1</b> | <b>Introduction</b>                                      | <b>1</b>  |
| <b>1.1</b>       | <b>Chapter Overview</b>                                  | <b>2</b>  |
| <b>1.2</b>       | <b>Foreword</b>                                          | <b>3</b>  |
| 1.2.1            | Target Audience                                          | 3         |
| 1.2.2            | Typographical conventions                                | 3         |
| 1.2.3            | Nomenclature                                             | 4         |
| <b>1.3</b>       | <b>Cautions, warnings and notes</b>                      | <b>5</b>  |
| 1.3.1            | General Cautions and Warnings                            | 5         |
| <b>1.4</b>       | <b>For Further Assistance</b>                            | <b>8</b>  |
| 1.4.1            | Repairs                                                  | 8         |
| <b>Chapter 2</b> | <b>Product Description</b>                               | <b>9</b>  |
| <b>2.1</b>       | <b>Chapter Overview</b>                                  | <b>10</b> |
| <b>2.2</b>       | <b>Product Overview</b>                                  | <b>11</b> |
| <b>2.3</b>       | <b>Signal processing</b>                                 | <b>17</b> |
| <b>2.4</b>       | <b>Communication Functions</b>                           | <b>19</b> |
| <b>2.5</b>       | <b>Order codes</b>                                       | <b>20</b> |
| 2.5.1            | Order codes for UR                                       | 20        |
| 2.5.2            | Order codes for replacement modules                      | 20        |
| <b>Chapter 3</b> | <b>Specifications</b>                                    | <b>22</b> |
| <b>3.1</b>       | <b>Chapter Overview</b>                                  | <b>23</b> |
| <b>3.2</b>       | <b>Protection elements</b>                               | <b>24</b> |
| 3.2.1            | Percent Differential                                     | 24        |
| 3.2.2            | Restricted ground fault                                  | 24        |
| 3.2.3            | Phase/neutral/ground time overcurrent                    | 25        |
| 3.2.4            | Phase/neutral/ground instantaneous overcurrent           | 25        |
| 3.2.5            | Phase directional overcurrent                            | 26        |
| 3.2.6            | Neutral directional overcurrent                          | 26        |
| 3.2.7            | Negative sequence directional overcurrent                | 27        |
| 3.2.8            | Generator Unbalance                                      | 27        |
| 3.2.9            | Split Phase Protection                                   | 27        |
| 3.2.10           | Sensitive directional power                              | 28        |
| 3.2.11           | Phase undervoltage                                       | 28        |
| 3.2.12           | Auxiliary undervoltage                                   | 28        |
| 3.2.13           | Third Harmonic Neutral Undervoltage                      | 29        |
| 3.2.14           | Phase overvoltage                                        | 29        |
| 3.2.15           | Neutral overvoltage                                      | 29        |
| 3.2.16           | Auxiliary overvoltage                                    | 30        |
| 3.2.17           | Negative sequence overvoltage                            | 30        |
| 3.2.18           | Volts per Herz                                           | 30        |
| 3.2.19           | Transformer Hottest-Spot Temperature                     | 31        |
| 3.2.20           | Transformer Aging Factor                                 | 31        |
| 3.2.21           | Transformer Loss of Life                                 | 31        |
| 3.2.22           | Underfrequency                                           | 31        |
| 3.2.23           | Overfrequency                                            | 32        |
| 3.2.24           | Rate of change of frequency                              | 32        |
| 3.2.25           | Turbine Frequency Out-of-band accumulated operating time | 32        |
| 3.2.26           | Breaker arcing current                                   | 33        |
| 3.2.27           | Synchrocheck                                             | 33        |
| 3.2.28           | Accidental Energization                                  | 33        |

|            |                                         |           |
|------------|-----------------------------------------|-----------|
| 3.2.29     | Loss of Excitation                      | 33        |
| 3.2.30     | Thermal overload                        | 34        |
| 3.2.31     | Trip bus (trip without FlexLogic)       | 34        |
| 3.2.32     | Harmonic detection                      | 34        |
| 3.2.33     | Multi-range signal oscillation detector | 35        |
| <b>3.3</b> | <b>User-programmable elements</b>       | <b>36</b> |
| 3.3.1      | FlexLogic                               | 36        |
| 3.3.2      | FlexCurves                              | 36        |
| 3.3.3      | FlexStates                              | 36        |
| 3.3.4      | FlexElements                            | 36        |
| 3.3.5      | Non-volatile latches                    | 37        |
| 3.3.6      | User-programmable LEDs                  | 37        |
| 3.3.7      | LED test                                | 37        |
| 3.3.8      | User-definable displays                 | 37        |
| 3.3.9      | Control pushbuttons                     | 37        |
| 3.3.10     | User-programmable pushbuttons           | 37        |
| 3.3.11     | Selector switch                         | 38        |
| 3.3.12     | Digital elements                        | 38        |
| <b>3.4</b> | <b>Monitoring</b>                       | <b>39</b> |
| 3.4.1      | Oscillography                           | 39        |
| 3.4.2      | Event recorder                          | 39        |
| 3.4.3      | User-Programmable Fault Report          | 39        |
| 3.4.4      | Data logger                             | 39        |
| <b>3.5</b> | <b>Metering</b>                         | <b>41</b> |
| 3.5.1      | RMS Current: Phase, Neutral and Ground  | 41        |
| 3.5.2      | RMS Voltage                             | 41        |
| 3.5.3      | Real Power (Watts)                      | 41        |
| 3.5.4      | Reactive Power (VARs)                   | 41        |
| 3.5.5      | Apparent Power (VA)                     | 41        |
| 3.5.6      | Watt-hours (Positive and Negative)      | 41        |
| 3.5.7      | VAR-hours (Positive and Negative)       | 41        |
| 3.5.8      | Current Harmonics                       | 42        |
| 3.5.9      | Voltage Harmonics                       | 42        |
| 3.5.10     | Frequency                               | 42        |
| <b>3.6</b> | <b>Power supply</b>                     | <b>43</b> |
| 3.6.1      | Low range                               | 43        |
| 3.6.2      | High range                              | 43        |
| 3.6.3      | All ranges                              | 43        |
| 3.6.4      | Internal fuse                           | 43        |
| 3.6.5      | Supercapacitor                          | 44        |
| <b>3.7</b> | <b>Inputs</b>                           | <b>45</b> |
| 3.7.1      | AC current                              | 45        |
| 3.7.2      | AC voltage                              | 45        |
| 3.7.3      | Frequency                               | 45        |
| 3.7.4      | Contact inputs                          | 45        |
| 3.7.5      | Contact inputs with auto-burnishing     | 46        |
| 3.7.6      | DCMA inputs                             | 46        |
| 3.7.7      | RTD inputs                              | 46        |
| 3.7.8      | IRIG-B input                            | 46        |
| 3.7.9      | Direct Inputs                           | 47        |
| 3.7.10     | Teleprotection                          | 47        |
| <b>3.8</b> | <b>Outputs</b>                          | <b>48</b> |
| 3.8.1      | Form-A relay                            | 48        |
| 3.8.2      | Latching relay                          | 48        |
| 3.8.3      | Form-A monitors                         | 48        |
| 3.8.4      | Form-C and critical failure relay       | 48        |



|                  |                                                   |            |
|------------------|---------------------------------------------------|------------|
| 3.8.5            | Fast Form-C relay                                 | 49         |
| 3.8.6            | Solid-state output relay                          | 49         |
| 3.8.7            | Control power external output                     | 50         |
| 3.8.8            | Direct Outputs                                    | 50         |
| 3.8.9            | DCMA outputs                                      | 50         |
| <b>3.9</b>       | <b>Communication protocols</b>                    | <b>51</b>  |
| <b>3.10</b>      | <b>Inter-relay communications</b>                 | <b>53</b>  |
| 3.10.1           | STP interface options                             | 53         |
| 3.10.2           | Link power budget and maximum optical input power | 53         |
| 3.10.3           | Typical link distance                             | 54         |
| 3.10.4           | Losses and margin                                 | 54         |
| <b>3.11</b>      | <b>CyberSentry security</b>                       | <b>55</b>  |
| <b>3.12</b>      | <b>Graphical front panel</b>                      | <b>56</b>  |
| <b>3.13</b>      | <b>Environmental</b>                              | <b>57</b>  |
| <b>3.14</b>      | <b>Type tests</b>                                 | <b>58</b>  |
| <b>3.15</b>      | <b>Production tests</b>                           | <b>59</b>  |
| <b>3.16</b>      | <b>Approvals</b>                                  | <b>60</b>  |
| <b>3.17</b>      | <b>Maintenance</b>                                | <b>61</b>  |
| <b>Chapter 4</b> | <b>Installation</b>                               | <b>62</b>  |
| <b>4.1</b>       | <b>Chapter Overview</b>                           | <b>63</b>  |
| <b>4.2</b>       | <b>Unpack and inspect</b>                         | <b>64</b>  |
| <b>4.3</b>       | <b>Panel cutouts</b>                              | <b>65</b>  |
| 4.3.1            | Horizontal units                                  | 65         |
| 4.3.2            | Vertical units                                    | 69         |
| <b>4.4</b>       | <b>Rear terminal layout</b>                       | <b>74</b>  |
| <b>4.5</b>       | <b>Wiring</b>                                     | <b>77</b>  |
| 4.5.1            | Typical wiring                                    | 77         |
| 4.5.2            | Dielectric strength                               | 77         |
| 4.5.3            | Control power                                     | 78         |
| 4.5.4            | Non-volatile data storage                         | 79         |
| 4.5.5            | CT/VT modules                                     | 79         |
| 4.5.6            | Process Bus Module for HardFiber                  | 81         |
| 4.5.7            | Contact inputs and outputs                        | 82         |
| 4.5.7.1          | Contact input and output module assignments       | 84         |
| 4.5.7.2          | Contact input and output module wiring            | 88         |
| 4.5.7.3          | Contact inputs                                    | 90         |
| 4.5.7.4          | General application considerations                | 91         |
| 4.5.7.5          | Use of contact inputs with auto-burnishing        | 93         |
| 4.5.7.6          | Use of contact inputs with active impedance       | 94         |
| 4.5.8            | Transducer inputs and outputs                     | 95         |
| 4.5.9            | Communication ports                               | 97         |
| 4.5.9.1          | General grounding considerations                  | 97         |
| 4.5.9.2          | RS232 port                                        | 99         |
| 4.5.9.3          | RS485 port                                        | 100        |
| 4.5.9.4          | 100BaseFx fiber optic ports                       | 101        |
| 4.5.9.5          | IRIG-B                                            | 101        |
| <b>4.6</b>       | <b>Inter-relay communications</b>                 | <b>103</b> |
| 4.6.1            | ESD Protection Guidelines                         | 103        |
| 4.6.2            | Direct input and output communications            | 103        |
| 4.6.3            | Fiber LED and ELED transmitters                   | 106        |
| 4.6.4            | Fiber laser transmitters                          | 106        |
| 4.6.5            | RS422 interface                                   | 107        |
| 4.6.5.1          | Two-channel application via multiplexers          | 108        |
| 4.6.5.2          | Transmit timing                                   | 109        |
| 4.6.5.3          | Receive timing                                    | 110        |

|             |                                                       |            |
|-------------|-------------------------------------------------------|------------|
| 4.6.6       | RS422 and fiber interface                             | 110        |
| 4.6.7       | IEEE C37.94 interface                                 | 111        |
| 4.6.8       | C37.94SM interface                                    | 114        |
| <b>4.7</b>  | <b>Activate relay</b>                                 | <b>118</b> |
| <b>4.8</b>  | <b>Software installation</b>                          | <b>119</b> |
| 4.8.1       | EnerVista communication overview                      | 119        |
| 4.8.2       | System requirements                                   | 119        |
| 4.8.3       | Installing the software                               | 120        |
| <b>4.9</b>  | <b>Add device to software</b>                         | <b>121</b> |
| 4.9.1       | Set IP address in UR                                  | 121        |
| 4.9.2       | Test Ethernet connection                              | 122        |
| 4.9.3       | Internet Configuration                                | 124        |
| 4.9.4       | Configure serial connection                           | 124        |
| 4.9.5       | Configure Ethernet connection                         | 125        |
| 4.9.6       | Configure modem connection                            | 127        |
| 4.9.7       | Automatic discovery of UR devices                     | 127        |
| <b>4.10</b> | <b>Connect to the relay</b>                           | <b>129</b> |
| 4.10.1      | Connect to the relay in EnerVista                     | 129        |
| 4.10.2      | Use Quick Connect via front RS232 port                | 130        |
| 4.10.3      | Use Quick Connect via front USB port                  | 131        |
| 4.10.4      | Use Quick Connect via a rear Ethernet port            | 131        |
| <b>4.11</b> | <b>Set up CyberSentry and change default password</b> | <b>132</b> |
| <b>4.12</b> | <b>Import settings</b>                                | <b>133</b> |
| 4.12.1      | Import settings from XML file                         | 133        |
| 4.12.2      | Import settings from device files                     | 136        |
| <b>4.13</b> | <b>Connect to substation gateway</b>                  | <b>138</b> |
| 4.13.1      | Files and records                                     | 138        |

## Chapter 5 Interfaces 139

|            |                                            |            |
|------------|--------------------------------------------|------------|
| <b>5.1</b> | <b>Chapter Overview</b>                    | <b>140</b> |
| <b>5.2</b> | <b>EnerVista</b>                           | <b>141</b> |
| 5.2.1      | EnerVista Introduction                     | 141        |
| 5.2.2      | Settings Files                             | 141        |
| 5.2.3      | Event viewing                              | 142        |
| 5.2.4      | File support                               | 142        |
| 5.2.5      | Main window                                | 142        |
| 5.2.6      | Protection summary window                  | 144        |
| 5.2.7      | Settings templates                         | 145        |
| 5.2.7.1    | Enable settings template                   | 145        |
| 5.2.7.2    | Edit settings template                     | 146        |
| 5.2.7.3    | Add password protection                    | 148        |
| 5.2.7.4    | View settings template                     | 148        |
| 5.2.7.5    | Remove settings template                   | 149        |
| 5.2.8      | Securing FlexLogic equations               | 150        |
| 5.2.8.1    | Locking entries in a settings template     | 150        |
| 5.2.8.2    | Locking a settings file to a serial number | 152        |
| 5.2.9      | Settings file traceability                 | 153        |
| 5.2.9.1    | Settings file traceability information     | 154        |
| 5.2.9.2    | Online device traceability information     | 155        |
| 5.2.9.3    | Additional traceability rules              | 155        |
| 5.2.10     | Command line interface                     | 155        |
| <b>5.3</b> | <b>Front panel</b>                         | <b>162</b> |
| 5.3.1      | Basic front panel                          | 162        |
| 5.3.1.1    | Front panel display                        | 163        |
| 5.3.1.2    | Navigation keys                            | 164        |
| 5.3.1.3    | LED indicators                             | 164        |

|            |                                                        |            |
|------------|--------------------------------------------------------|------------|
| 5.3.1.4    | Labeling                                               | 167        |
| 5.3.1.5    | Menu navigation                                        | 168        |
| 5.3.1.6    | Change settings                                        | 169        |
| 5.3.2      | Enhanced front panel                                   | 170        |
| 5.3.2.1    | Enhanced front panel display                           | 172        |
| 5.3.2.2    | Navigation keys                                        | 173        |
| 5.3.2.3    | LED indicators                                         | 173        |
| 5.3.2.4    | Labeling                                               | 175        |
| 5.3.2.5    | Menu navigation                                        | 179        |
| 5.3.2.6    | Change settings                                        | 181        |
| 5.3.3      | Graphical front panel                                  | 182        |
| 5.3.3.1    | Home page                                              | 183        |
| 5.3.3.2    | Rolling mode                                           | 184        |
| 5.3.3.3    | Single-line diagrams                                   | 184        |
| 5.3.3.4    | Single-line diagram example                            | 185        |
| 5.3.3.5    | Single-line diagram editor                             | 189        |
| 5.3.3.6    | Annunciator                                            | 197        |
| 5.3.3.7    | Annunciator editor                                     | 200        |
| 5.3.3.8    | Metering editor                                        | 202        |
| 5.3.3.9    | Configurable navigation editor                         | 203        |
| 5.3.3.10   | Navigation keys                                        | 204        |
| 5.3.3.11   | LED indicators                                         | 204        |
| 5.3.3.12   | Labeling                                               | 206        |
| 5.3.3.13   | Menu navigation                                        | 207        |
| 5.3.3.14   | Change settings                                        | 208        |
| 5.3.3.15   | View actual values                                     | 212        |
| 5.3.4      | Breaker control                                        | 214        |
| 5.3.4.1    | Control mode selection and monitoring                  | 214        |
| 5.3.4.2    | Control of breakers                                    | 214        |
| 5.3.5      | Password control                                       | 215        |
| 5.3.5.1    | Resetting the password in a device without CyberSentry | 216        |
| 5.3.5.2    | Invalid password entry                                 | 217        |
| <b>5.4</b> | <b>Logic diagrams</b>                                  | <b>218</b> |
| <b>5.5</b> | <b>FlexLogic</b>                                       | <b>220</b> |
| 5.5.1      | FlexLogic design using Engineer                        | 220        |
| 5.5.2      | Design logic                                           | 222        |
| 5.5.2.1    | Examples                                               | 222        |
| 5.5.2.2    | Add existing FlexLogic equations                       | 223        |
| 5.5.2.3    | Create logic diagram                                   | 224        |
| 5.5.2.4    | Compiled results and warning messages                  | 228        |
| 5.5.2.5    | Rapidly add logic blocks in sequence                   | 231        |
| 5.5.2.6    | Connect two logic diagrams                             | 231        |
| 5.5.2.7    | Optimize the logic                                     | 232        |
| 5.5.2.8    | Change logic order                                     | 232        |
| 5.5.2.9    | Search logic                                           | 233        |
| 5.5.2.10   | Exclude sheet from compile                             | 233        |
| 5.5.3      | Send file to and from device                           | 234        |
| 5.5.4      | Monitor logic                                          | 234        |
| 5.5.5      | View front panel and print labels                      | 235        |
| 5.5.6      | Generate connectivity report                           | 236        |
| 5.5.7      | Preferences                                            | 236        |
| 5.5.7.1    | View menu                                              | 236        |
| 5.5.7.2    | Logic designer                                         | 236        |
| 5.5.7.3    | Logic monitor                                          | 238        |
| 5.5.7.4    | COMTRADE waveforms                                     | 239        |
| 5.5.8      | Toolbars                                               | 239        |
| 5.5.9      | FlexLogic operands                                     | 243        |
| 5.5.10     | FlexLogic rules                                        | 247        |

|        |                        |     |
|--------|------------------------|-----|
| 5.5.11 | FlexLogic evaluation   | 247 |
| 5.5.12 | FlexLogic example      | 248 |
| 5.5.13 | FlexElement base units | 253 |

---

## **Chapter 6    CyberSecurity** **257**

---

|            |                                                                     |            |
|------------|---------------------------------------------------------------------|------------|
| <b>6.1</b> | <b>Chapter Overview</b>                                             | <b>258</b> |
| <b>6.2</b> | <b>Cybersecurity overview</b>                                       | <b>259</b> |
| <b>6.3</b> | <b>Security setup</b>                                               | <b>260</b> |
| 6.3.1      | Password security                                                   | 260        |
| 6.3.1.1    | Password security settings                                          | 261        |
| 6.3.2      | EnerVista security                                                  | 267        |
| 6.3.3      | CyberSentry security                                                | 267        |
| 6.3.3.1    | CyberSentry user roles                                              | 268        |
| 6.3.3.2    | CyberSentry settings through EnerVista                              | 270        |
| 6.3.3.3    | CyberSentry authentication                                          | 274        |
| 6.3.3.4    | CyberSentry settings through the front panel                        | 275        |
| <b>6.4</b> | <b>IEC62351-9 Encryption for R-GOOSE messages</b>                   | <b>285</b> |
| 6.4.1      | Security References and Acronyms                                    | 285        |
| 6.4.2      | Security Key Management                                             | 285        |
| 6.4.3      | Key Distribution Process                                            | 286        |
| 6.4.3.1    | GDOI GROUPKEY-PULL Security Phases                                  | 286        |
| 6.4.3.2    | Rekeying                                                            | 287        |
| 6.4.3.3    | Security Associations                                               | 287        |
| 6.4.3.4    | UR Supported Encryption and Signature (Hash) Algorithms             | 288        |
| 6.4.3.5    | High Level Sequence of Events for GDOI Pull Exchange                | 288        |
| 6.4.4      | Certificate Management                                              | 288        |
| 6.4.4.1    | Simple Certificate Enrollment Protocol                              | 288        |
| 6.4.4.2    | Online Certificate Status Protocol                                  | 289        |
| 6.4.4.3    | Certificate Security                                                | 290        |
| 6.4.5      | Configuration                                                       | 290        |
| 6.4.6      | Commands                                                            | 295        |
| 6.4.7      | Advanced Configuration and Troubleshooting                          | 297        |
| 6.4.7.1    | Using UR Sample Certificates                                        | 297        |
| 6.4.7.2    | SCEP Server Challenge Password and Fingerprint (Thumbprint) Example | 298        |
| 6.4.7.3    | Use of Pull Exchanges vs. Push Messages                             | 298        |
| 6.4.7.4    | Use of Different Certificate Issuers Between URs and the KDC        | 299        |
| 6.4.7.5    | KDC Security Policy Mismatch with UR R-GOOSE Security Setting       | 299        |
| 6.4.7.6    | KDC Key Generation Policy                                           | 300        |
| 6.4.7.7    | UR Unicast R-GOOSE                                                  | 300        |
| 6.4.7.8    | UR Clock Accuracy                                                   | 300        |
| 6.4.7.9    | Network Maximum Transmission Unit (MTU)                             | 301        |
| 6.4.8      | Status                                                              | 301        |
| 6.4.8.1    | M2M Security Status Certificates                                    | 301        |
| 6.4.8.2    | Syslog Security Events                                              | 303        |
| 6.4.8.3    | UR Self-Tests and Flexlogic Operands                                | 304        |
| 6.4.9      | Secure R-GOOSE Configuration Procedure                              | 307        |
| 6.4.9.1    | Non-Secure R-GOOSE Configuration                                    | 308        |
| 6.4.9.2    | Test Key                                                            | 308        |
| 6.4.9.3    | Certificates                                                        | 308        |
| 6.4.9.4    | UR GDOI Configuration                                               | 310        |
| 6.4.9.5    | KDC Configuration                                                   | 310        |
| 6.4.9.6    | Status of Security Keys in the URs                                  | 310        |
| <b>6.5</b> | <b>RADIUS server configuration</b>                                  | <b>312</b> |

---

## **Chapter 7    Process bus module** **314**

---

|            |                         |            |
|------------|-------------------------|------------|
| <b>7.1</b> | <b>Chapter Overview</b> | <b>315</b> |
|------------|-------------------------|------------|

|            |                                                    |            |
|------------|----------------------------------------------------|------------|
| <b>7.2</b> | <b>Overview</b>                                    | <b>316</b> |
| <b>7.3</b> | <b>Parallel Redundancy Protocol (PRP)</b>          | <b>317</b> |
| <b>7.4</b> | <b>High-availability seamless redundancy (HSR)</b> | <b>319</b> |
| <b>7.5</b> | <b>Process Bus Settings</b>                        | <b>321</b> |
| <b>7.6</b> | <b>SV Stream Configuration</b>                     | <b>327</b> |
| 7.6.1      | SV stream logic                                    | 331        |
| 7.6.2      | Message troubleshooting                            | 332        |
| 7.6.3      | SV quality processing                              | 332        |
| 7.6.4      | SV simulation processing                           | 333        |
| 7.6.5      | SV stream settings                                 | 333        |
| <b>7.7</b> | <b>Remote resources configuration</b>              | <b>344</b> |

---

|                  |                 |            |
|------------------|-----------------|------------|
| <b>Chapter 8</b> | <b>Settings</b> | <b>345</b> |
|------------------|-----------------|------------|

---

|            |                                        |            |
|------------|----------------------------------------|------------|
| <b>8.1</b> | <b>Chapter Overview</b>                | <b>346</b> |
| <b>8.2</b> | <b>Overview</b>                        | <b>347</b> |
| 8.2.1      | Introduction to elements               | 347        |
| 8.2.2      | Base quantities                        | 348        |
| 8.2.3      | Introduction to AC sources             | 349        |
| 8.2.4      | CT/VT configuration                    | 349        |
| <b>8.3</b> | <b>Settings menu</b>                   | <b>351</b> |
| <b>8.4</b> | <b>Product setup</b>                   | <b>355</b> |
| 8.4.1      | Security                               | 355        |
| 8.4.2      | Display properties                     | 355        |
| 8.4.3      | Clear relay records                    | 357        |
| 8.4.4      | Communications                         | 358        |
| 8.4.4.1    | Communications settings menu           | 358        |
| 8.4.4.2    | Serial ports                           | 359        |
| 8.4.4.3    | Network                                | 360        |
| 8.4.4.4    | IPv4 route table                       | 363        |
| 8.4.4.5    | Modbus protocol                        | 363        |
| 8.4.4.6    | Protocols & Authority                  | 364        |
| 8.4.4.7    | DNP protocol                           | 366        |
| 8.4.4.8    | DNP / IEC 60870-5-104 point lists      | 370        |
| 8.4.4.9    | Web server HTTP protocol               | 370        |
| 8.4.4.10   | TFTP protocol                          | 371        |
| 8.4.4.11   | IEC 60870-5-104 protocol               | 372        |
| 8.4.4.12   | IEC 60870-5-103 protocol               | 373        |
| 8.4.4.13   | USB port                               | 377        |
| 8.4.5      | Modbus user map                        | 378        |
| 8.4.6      | Real-time clock                        | 378        |
| 8.4.6.1    | Precision time protocol (1588)         | 380        |
| 8.4.6.2    | SNTP protocol                          | 383        |
| 8.4.6.3    | Local time                             | 384        |
| 8.4.6.4    | PBM PTP                                | 385        |
| 8.4.6.5    | IRIG-B                                 | 389        |
| 8.4.7      | User-programmable Fault reports        | 390        |
| 8.4.8      | Oscillography                          | 391        |
| 8.4.8.1    | Digital channels                       | 392        |
| 8.4.8.2    | Analog channels                        | 393        |
| 8.4.9      | Data logger                            | 394        |
| 8.4.10     | Demand                                 | 395        |
| 8.4.10.1   | Thermal exponential calculation method | 396        |
| 8.4.10.2   | Block Interval calculation method      | 396        |
| 8.4.10.3   | Rolling Demand calculation method      | 397        |
| 8.4.11     | User-programmable LEDs                 | 397        |
| 8.4.11.1   | LED test                               | 398        |
| 8.4.11.2   | Trip and alarm LEDs                    | 400        |

|            |                                                         |            |
|------------|---------------------------------------------------------|------------|
| 8.4.11.3   | User-programmable LED <n>                               | 400        |
| 8.4.11.4   | Event cause LED <n>                                     | 401        |
| 8.4.12     | User-programmable self-tests                            | 402        |
| 8.4.13     | Control pushbuttons                                     | 403        |
| 8.4.14     | User-programmable pushbuttons                           | 403        |
| 8.4.15     | Flex state parameters                                   | 410        |
| 8.4.16     | User-definable displays                                 | 410        |
| 8.4.16.1   | User display <n>                                        | 411        |
| 8.4.17     | Direct Inputs and Outputs                               | 412        |
| 8.4.17.1   | CRC Alarm                                               | 418        |
| 8.4.17.2   | Unreturned messages alarm                               | 419        |
| 8.4.18     | Teleprotection                                          | 420        |
| 8.4.19     | Installation                                            | 421        |
| <b>8.5</b> | <b>System setup</b>                                     | <b>422</b> |
| 8.5.1      | AC inputs                                               | 422        |
| 8.5.1.1    | Current banks                                           | 422        |
| 8.5.1.2    | Voltage banks                                           | 423        |
| 8.5.2      | Power system                                            | 424        |
| 8.5.3      | Signal sources                                          | 427        |
| 8.5.3.1    | User selection of AC parameters for comparator elements | 428        |
| 8.5.3.2    | AC input actual values                                  | 428        |
| 8.5.3.3    | Disturbance detectors (internal)                        | 428        |
| 8.5.3.4    | Example for use of sources                              | 429        |
| 8.5.3.5    | Source switching                                        | 430        |
| 8.5.4      | Transformer                                             | 431        |
| 8.5.4.1    | General Transformer Settings                            | 432        |
| 8.5.4.2    | Windings 1 to 2                                         | 433        |
| 8.5.4.3    | Phase relationships of three-phase transformers         | 435        |
| 8.5.4.4    | Magnitude compensation                                  | 437        |
| 8.5.4.5    | Phase and zero sequence compensation                    | 438        |
| 8.5.4.6    | Magnitude, phase angle, and zero sequence compensation  | 440        |
| 8.5.4.7    | Differential and restraint current calculations         | 441        |
| 8.5.4.8    | Transformer windings between two breakers               | 441        |
| 8.5.4.9    | Transformer thermal inputs                              | 443        |
| 8.5.5      | Breakers                                                | 444        |
| 8.5.5.1    | Control authority                                       | 451        |
| 8.5.5.2    | Dual breaker control logic                              | 452        |
| 8.5.6      | Disconnect switch control                               | 456        |
| 8.5.6.1    | Disconnect switch control logic                         | 463        |
| 8.5.7      | FlexCurves                                              | 467        |
| 8.5.7.1    | FlexCurve configuration with EnerVista software         | 468        |
| 8.5.7.2    | Recloser curve editing                                  | 469        |
| 8.5.7.3    | Standard recloser curves                                | 470        |
| 8.5.8      | PMU instance settings                                   | 474        |
| 8.5.8.1    | Basic configuration                                     | 475        |
| 8.5.8.2    | PMU calibration                                         | 480        |
| 8.5.8.3    | PMU triggering overview                                 | 482        |
| 8.5.8.4    | PMU recording                                           | 489        |
| <b>8.6</b> | <b>FlexLogic settings</b>                               | <b>491</b> |
| 8.6.1      | FlexLogic equation editor                               | 491        |
| 8.6.2      | FlexLogic timers                                        | 491        |
| 8.6.3      | FlexElements                                            | 492        |
| 8.6.3.1    | FlexElement base units                                  | 496        |
| 8.6.4      | Non-volatile latches                                    | 499        |
| <b>8.7</b> | <b>Grouped elements</b>                                 | <b>501</b> |
| 8.7.1      | Setting Group 1                                         | 501        |
| 8.7.2      | Transformer                                             | 501        |
| 8.7.2.1    | Transformer menu                                        | 501        |

|             |                                                                     |            |
|-------------|---------------------------------------------------------------------|------------|
| 8.7.2.2     | Transformer percent differential (ANSI 87T)                         | 502        |
| 8.7.2.3     | Hottest-spot temperature                                            | 507        |
| 8.7.2.4     | Aging Factor                                                        | 508        |
| 8.7.2.5     | Loss of Life                                                        | 509        |
| 8.7.3       | Phase current                                                       | 510        |
| 8.7.3.1     | Inverse TOC curve characteristics                                   | 510        |
| 8.7.3.2     | Phase time overcurrent (ANSI 51P, IEC PTOC)                         | 516        |
| 8.7.3.3     | Phase instantaneous overcurrent (ANSI 50P, IEC PIOC)                | 519        |
| 8.7.3.4     | Phase directional overcurrent (ANSI 67P, IEC PDOC/PTOC)             | 521        |
| 8.7.4       | Neutral Current                                                     | 524        |
| 8.7.4.1     | Neutral time overcurrent (ANSI 51N, IEC PTOC)                       | 525        |
| 8.7.4.2     | Neutral instantaneous overcurrent (ANSI 50N, IEC PIOC)              | 526        |
| 8.7.4.3     | Neutral directional overcurrent (ANSI 67N, IEC PDEF/PTOC)           | 528        |
| 8.7.5       | Ground Current                                                      | 534        |
| 8.7.5.1     | Ground time overcurrent (ANSI 51G, IEC PTOC)                        | 534        |
| 8.7.5.2     | Ground instantaneous overcurrent (ANSI 50G, IEC PIOC)               | 536        |
| 8.7.5.3     | Restricted ground fault (ANSI 87RGF, IEC PNDF)                      | 537        |
| 8.7.6       | Negative sequence current                                           | 544        |
| 8.7.6.1     | Negative sequence directional overcurrent (ANSI 67Q, IEC PDEF/PTOC) | 544        |
| 8.7.7       | Generator unbalance (ANSI 46)                                       | 548        |
| 8.7.8       | Split phase protection (ANSI 50SP)                                  | 551        |
| 8.7.9       | Voltage elements                                                    | 556        |
| 8.7.9.1     | Voltage elements menu                                               | 556        |
| 8.7.9.2     | Undervoltage inverse time curves                                    | 557        |
| 8.7.9.3     | Overvoltage inverse time curves                                     | 558        |
| 8.7.9.4     | Phase undervoltage (ANSI 27P, IEC PTUV)                             | 559        |
| 8.7.9.5     | Phase overvoltage (ANSI 59P, IEC PTOV)                              | 561        |
| 8.7.9.6     | Neutral overvoltage (ANSI 59N, IEC PTOV)                            | 563        |
| 8.7.9.7     | Negative-sequence overvoltage (ANSI 59Q, IEC PTOV)                  | 564        |
| 8.7.9.8     | Auxiliary undervoltage (ANSI 27X, IEC PTUV)                         | 565        |
| 8.7.9.9     | Auxiliary overvoltage (ANSI 59X, IEC PTOV)                          | 567        |
| 8.7.9.10    | Volts per hertz (ANSI 24, IEC PVPH)                                 | 568        |
| 8.7.10      | Loss of excitation (ANSI 40)                                        | 573        |
| 8.7.11      | Accidental energization (ANSI 50/27)                                | 575        |
| 8.7.12      | Power                                                               | 577        |
| 8.7.12.1    | Sensitive directional power (ANSI 32)                               | 577        |
| 8.7.13      | Stator ground                                                       | 581        |
| 8.7.13.1    | Third harmonic neutral undervoltage (ANSI 27TN)                     | 581        |
| <b>8.8</b>  | <b>Control elements</b>                                             | <b>584</b> |
| 8.8.1       | Trip Bus                                                            | 584        |
| 8.8.2       | Setting groups                                                      | 586        |
| 8.8.3       | Selector Switch                                                     | 588        |
| 8.8.4       | Underfrequency (ANSI 81U)                                           | 595        |
| 8.8.5       | Overfrequency (ANSI 81O)                                            | 596        |
| 8.8.6       | Frequency rate of change (ANSI 81R)                                 | 597        |
| 8.8.7       | Frequency out-of-band accumulation                                  | 599        |
| 8.8.8       | Synchrocheck (ANSI 25)                                              | 601        |
| 8.8.8.1     | Notes on the synchrocheck function                                  | 606        |
| 8.8.9       | Digital elements                                                    | 608        |
| 8.8.10      | Digital counters                                                    | 612        |
| 8.8.11      | Multi-range signal oscillation detector (MSOD)                      | 614        |
| <b>8.9</b>  | <b>Monitoring elements</b>                                          | <b>619</b> |
| 8.9.1       | Monitoring elements menu                                            | 619        |
| 8.9.2       | Breaker arcing current                                              | 619        |
| 8.9.3       | VT fuse failure                                                     | 622        |
| 8.9.4       | Thermal overload protection (ANSI 49)                               | 623        |
| <b>8.10</b> | <b>Inputs/outputs</b>                                               | <b>627</b> |
| 8.10.1      | Contact inputs                                                      | 627        |

|             |                                        |            |
|-------------|----------------------------------------|------------|
| 8.10.2      | Virtual inputs                         | 629        |
| 8.10.3      | Contact outputs                        | 630        |
| 8.10.3.1    | Non-latching contact outputs (H)       | 630        |
| 8.10.3.2    | Latching contact outputs               | 632        |
| 8.10.4      | Virtual outputs                        | 635        |
| 8.10.5      | Resetting                              | 635        |
| 8.10.6      | Direct inputs and outputs              | 636        |
| 8.10.6.1    | Direct inputs                          | 636        |
| 8.10.6.2    | Direct outputs                         | 637        |
| 8.10.6.3    | Application examples                   | 637        |
| 8.10.7      | Teleprotection                         | 641        |
| 8.10.7.1    | Teleprotection inputs                  | 641        |
| 8.10.7.2    | Teleprotection outputs                 | 642        |
| 8.10.7.3    | Teleprotection input/output processing | 642        |
| <b>8.11</b> | <b>Transducer inputs/outputs</b>       | <b>643</b> |
| 8.11.1      | DCmA inputs                            | 643        |
| 8.11.2      | DCmA outputs                           | 644        |
| 8.11.3      | DCmA application examples              | 646        |
| 8.11.4      | RTD inputs                             | 647        |
| <b>8.12</b> | <b>Testing</b>                         | <b>650</b> |
| 8.12.1      | IED mode config                        | 650        |
| 8.12.2      | IED mode process                       | 652        |
| 8.12.3      | Force contact inputs                   | 654        |
| 8.12.4      | Force contact outputs                  | 655        |
| <b>8.13</b> | <b>Simulation</b>                      | <b>656</b> |
| 8.13.1      | Subscribe to simulated values          | 656        |
| 8.13.2      | Publish simulated values               | 658        |
| <b>8.14</b> | <b>Process Bus Settings</b>            | <b>660</b> |
| <b>8.15</b> | <b>SV stream settings</b>              | <b>666</b> |

## Chapter 9 Actual Values 676

|            |                               |            |
|------------|-------------------------------|------------|
| <b>9.1</b> | <b>Chapter Overview</b>       | <b>677</b> |
| <b>9.2</b> | <b>Actual Values Menu</b>     | <b>678</b> |
| <b>9.3</b> | <b>Front panel</b>            | <b>679</b> |
| <b>9.4</b> | <b>Status</b>                 | <b>681</b> |
| 9.4.1      | IED                           | 681        |
| 9.4.2      | Contact inputs                | 681        |
| 9.4.3      | Virtual inputs                | 681        |
| 9.4.4      | RxGOOSE boolean inputs        | 681        |
| 9.4.5      | RxGOOSE DPS inputs            | 682        |
| 9.4.6      | Teleprotection inputs         | 682        |
| 9.4.7      | Contact Outputs               | 682        |
| 9.4.8      | Virtual outputs               | 682        |
| 9.4.9      | RxGOOSE status                | 682        |
| 9.4.10     | RxGOOSE statistics            | 683        |
| 9.4.11     | Fixed GOOSE                   | 683        |
| 9.4.12     | Digital counters              | 684        |
| 9.4.13     | Breaker status                | 685        |
| 9.4.14     | Selector switches             | 685        |
| 9.4.15     | Flex states                   | 686        |
| 9.4.16     | Ethernet                      | 686        |
| 9.4.17     | Real time clock synchronizing | 686        |
| 9.4.18     | Direct inputs                 | 688        |
| 9.4.19     | Direct devices status         | 689        |
| 9.4.20     | EGD protocol status           | 689        |
| 9.4.21     | Teleprotection channel tests  | 690        |



|                   |                                                |            |
|-------------------|------------------------------------------------|------------|
| 9.4.22            | Remaining connection status                    | 690        |
| 9.4.23            | Parallel Redundancy Protocol (PRP)             | 691        |
| 9.4.24            | TxGOOSE status                                 | 693        |
| 9.4.25            | Protocol                                       | 693        |
| <b>9.5</b>        | <b>Metering</b>                                | <b>694</b> |
| 9.5.1             | Metering conventions                           | 694        |
| 9.5.2             | Transformer                                    | 697        |
| 9.5.3             | Split phase                                    | 698        |
| 9.5.4             | Sources                                        | 699        |
| 9.5.4.1           | Phase current metering                         | 699        |
| 9.5.4.2           | Ground current metering                        | 700        |
| 9.5.4.3           | Phase voltage metering                         | 700        |
| 9.5.4.4           | Auxiliary voltage metering                     | 701        |
| 9.5.4.5           | Power metering                                 | 701        |
| 9.5.4.6           | Energy metering                                | 702        |
| 9.5.4.7           | Frequency metering                             | 703        |
| 9.5.4.8           | Current harmonics and THD metering             | 703        |
| 9.5.4.9           | Voltage harmonics and THD metering             | 704        |
| 9.5.5             | Synchrocheck                                   | 705        |
| 9.5.6             | Tracking frequency                             | 705        |
| 9.5.7             | Frequency rate of change                       | 706        |
| 9.5.8             | Frequency out-of-band accumulation             | 706        |
| 9.5.9             | FlexElements                                   | 706        |
| 9.5.10            | RxGOOSE analogs                                | 709        |
| 9.5.11            | Sensitive directional power                    | 709        |
| 9.5.12            | Stator ground                                  | 710        |
| 9.5.13            | Volts per hertz                                | 710        |
| 9.5.14            | Restricted ground fault                        | 710        |
| 9.5.15            | Transducer inputs and outputs                  | 711        |
| 9.5.16            | Harmonic detection                             | 711        |
| 9.5.17            | Station Battery Voltage                        | 711        |
| 9.5.18            | Multi-range signal oscillation detector (MSOD) | 712        |
| <b>9.6</b>        | <b>Remote resources</b>                        | <b>713</b> |
| <b>9.7</b>        | <b>Process Bus Module</b>                      | <b>714</b> |
| 9.7.1             | General status                                 | 714        |
| 9.7.2             | RxSV status                                    | 714        |
| 9.7.3             | Clock synchronizing                            | 716        |
| 9.7.4             | PRP                                            | 718        |
| 9.7.5             | HSR                                            | 720        |
| <b>9.8</b>        | <b>Records</b>                                 | <b>721</b> |
| 9.8.1             | User programmable fault reports                | 721        |
| 9.8.2             | Event records                                  | 721        |
| 9.8.2.1           | Enhanced and basic front panels                | 721        |
| 9.8.2.2           | Graphical front panel                          | 722        |
| 9.8.3             | Oscillography                                  | 723        |
| 9.8.4             | Data logger                                    | 724        |
| 9.8.5             | Breaker maintenance                            | 724        |
| <b>9.9</b>        | <b>Product information</b>                     | <b>726</b> |
| 9.9.1             | Model information                              | 726        |
| 9.9.2             | Firmware revisions                             | 727        |
| <b>Chapter 10</b> | <b>Commands and targets</b>                    | <b>729</b> |
| <b>10.1</b>       | <b>Chapter Overview</b>                        | <b>730</b> |
| <b>10.2</b>       | <b>Commands menu</b>                           | <b>731</b> |
| 10.2.1            | Virtual inputs                                 | 731        |
| 10.2.2            | Clear records                                  | 731        |

|             |                                                 |            |
|-------------|-------------------------------------------------|------------|
| 10.2.3      | Set date and time                               | 732        |
| 10.2.4      | Relay maintenance                               | 733        |
| 10.2.5      | Security                                        | 735        |
| <b>10.3</b> | <b>Targets menu</b>                             | <b>736</b> |
| 10.3.1      | Target messages                                 | 736        |
| 10.3.2      | Relay self-tests                                | 736        |
| 10.3.3      | Major self-test error messages                  | 737        |
| 10.3.4      | Minor self-test error messages                  | 737        |
| 10.3.5      | Instantaneous protection elements trip security | 740        |
| 10.3.6      | HardFiber major self-test error messages        | 740        |
| 10.3.7      | HardFiber minor self-test error messages        | 741        |

## **Chapter 11 Application of settings 742**

|             |                                                      |            |
|-------------|------------------------------------------------------|------------|
| <b>11.1</b> | <b>Chapter Overview</b>                              | <b>743</b> |
| <b>11.2</b> | <b>Setting example</b>                               | <b>744</b> |
| 11.2.1      | In-zone transformer with VT on the high-voltage side | 744        |
| 11.2.2      | In-zone transformer with VT on the low-voltage side  | 745        |
| 11.2.3      | No in-zone transformer                               | 747        |
| <b>11.3</b> | <b>Application of generator settings</b>             | <b>749</b> |
| 11.3.1      | System setup                                         | 749        |
| 11.3.2      | Power System                                         | 750        |
| 11.3.3      | Signal sources                                       | 750        |
| 11.3.4      | Generator unbalance                                  | 751        |
| 11.3.5      | Loss of excitation                                   | 751        |
| 11.3.6      | Reverse power                                        | 752        |
| 11.3.7      | System backup overcurrent                            | 753        |
| 11.3.8      | Overexcitation                                       | 754        |
| 11.3.9      | Inputs/Outputs                                       | 756        |
| 11.3.10     | Frequency                                            | 757        |
| 11.3.11     | Accidental energization                              | 758        |
| 11.3.12     | Flexlogic                                            | 758        |

## **Chapter 12 Theory of Operation 760**

|             |                                       |            |
|-------------|---------------------------------------|------------|
| <b>12.1</b> | <b>Chapter Overview</b>               | <b>761</b> |
| <b>12.2</b> | <b>Current directional protection</b> | <b>762</b> |
| <b>12.3</b> | <b>CT saturation detection</b>        | <b>764</b> |

## **Chapter 13 Commissioning 766**

|             |                                                          |            |
|-------------|----------------------------------------------------------|------------|
| <b>13.1</b> | <b>Chapter Overview</b>                                  | <b>767</b> |
| <b>13.2</b> | <b>Overview</b>                                          | <b>768</b> |
| <b>13.3</b> | <b>Testing underfrequency and overfrequency elements</b> | <b>769</b> |

## **Chapter 14 Maintenance 771**

|             |                                  |            |
|-------------|----------------------------------|------------|
| <b>14.1</b> | <b>Chapter Overview</b>          | <b>772</b> |
| <b>14.2</b> | <b>Monitoring</b>                | <b>773</b> |
| 14.2.1      | Devices with Site Targets        | 773        |
| 14.2.2      | Data with Modbus Analyzer        | 773        |
| <b>14.3</b> | <b>General maintenance</b>       | <b>776</b> |
| <b>14.4</b> | <b>Files and Settings</b>        | <b>777</b> |
| 14.4.1      | Retrieve files                   | 777        |
| 14.4.2      | CyberSentry security event files | 777        |
| 14.4.3      | Convert device settings          | 778        |
| 14.4.4      | Copy settings to other device    | 780        |

|             |                                    |            |
|-------------|------------------------------------|------------|
| 14.4.5      | Export settings                    | 780        |
| 14.4.6      | Compare settings                   | 781        |
| 14.4.7      | Back up and restore settings       | 783        |
| 14.4.7.1    | Back up settings                   | 783        |
| 14.4.7.2    | Restore settings                   | 785        |
| 14.4.8      | Upgrade software                   | 788        |
| 14.4.9      | Upgrade firmware                   | 789        |
| 14.4.10     | Uninstall and clear files and data | 791        |
| <b>14.5</b> | <b>Replace module</b>              | <b>793</b> |
| <b>14.6</b> | <b>Battery</b>                     | <b>796</b> |
| 14.6.1      | Replace battery                    | 796        |
| 14.6.2      | Dispose of battery                 | 797        |
| <b>14.7</b> | <b>Repairs</b>                     | <b>798</b> |
| <b>14.8</b> | <b>Storage and disposal</b>        | <b>799</b> |

---

## **Chapter 15 Appendices** **800**

---

|             |                           |            |
|-------------|---------------------------|------------|
| <b>15.1</b> | <b>Abbreviations</b>      | <b>801</b> |
| <b>15.2</b> | <b>FlexLogic Operands</b> | <b>810</b> |
| <b>15.3</b> | <b>FlexAnalog items</b>   | <b>811</b> |
| <b>15.4</b> | <b>Version history</b>    | <b>812</b> |



## CHAPTER 1

# INTRODUCTION

---

# 1.1      **CHAPTER OVERVIEW**

---

This chapter provides a general introduction to the instruction manual.

This chapter contains the following sections:

|                              |   |
|------------------------------|---|
| Chapter Overview             | 2 |
| Foreword                     | 3 |
| Cautions, warnings and notes | 5 |
| For Further Assistance       | 8 |

## 1.2 FOREWORD

---

This technical manual provides a functional and technical description of the relay, as well as a comprehensive set of instructions for using it. The level at which this manual is written assumes that you are already familiar with protection engineering and have experience in this discipline. The description of principles and theory is limited to that which is necessary to understand the product. For further details on general protection engineering theory, we refer you to the publication, Protection and Automation Application Guide, which is available online.

We have attempted to make this manual as accurate, comprehensive and user-friendly as possible. However we cannot guarantee that it is free from errors. Nor can we state that it cannot be improved. We would therefore be very pleased to hear from you if you discover any errors, or have any suggestions for improvement. Our policy is to provide the information necessary to help you safely specify, engineer, install, commission, maintain, and eventually dispose of this product. We consider that this manual provides the necessary information, but if you believe that more details are needed, please contact us.

---

### 1.2.1 TARGET AUDIENCE

This manual is aimed towards all professionals charged with installing, commissioning, maintaining, troubleshooting, or operating any of the products within the specified product range. This includes installation and commissioning personnel as well as engineers who will be responsible for operating the product.

The level at which this manual is written assumes that installation and commissioning engineers have knowledge of handling electronic equipment. Also that system and protection engineers have a thorough knowledge of protection systems and associated equipment.

---

### 1.2.2 TYPOGRAPHICAL CONVENTIONS

The following typographical conventions are used throughout this manual.

- Description of software menu items, buttons, labels or hardware keys and buttons written in bold type and colored in Vernova dark green.  
For example: Select **Save** from the file menu
- The names for special keys, appear in in upper case bold type and colored in Vernova dark green.  
For example: **ENTER**
- Filenames, paths, code, and text that appears on a command line interface use the courier font  
For example: `Example\File.text`
- Special terminology is written with leading capitals  
For example: Line Differential Relay
- If reference is made to the relay's internal settings database, the menu items are written in bold italics  
For example: ***SECURITY***
- Menu paths are shown with > separators. This applies to both software menu paths and relay menu paths  
For example: ***SETTINGS > SYSTEM SETUP > AC INPUTS*** (for relay path), or **File > Save** (for software path)
- Setting values are written with the courier font and are italicized  
For example: `Enabled`
- The products, use FlexLogic operands. FlexLogic operands are written in dark Vernova green uppercase courier font  
For example: `PUSHBUTTON 1 ON`
- Sometimes it is beneficial to emphasize some words. Depending on the case in question, this may be done with bold, italic or upper case font attributes.
- Notes are written in italic in, and are surrounded by a border.  
For example:

*Note:*  
*This is a note*

---

### 1.2.3 NOMENCLATURE

Due to the technical nature of this manual, many special terms, abbreviations and acronyms are used throughout the manual. Some of these terms are well-known industry-specific terms while others may be special product-specific terms used by GE Vernova. The first instance of any acronym or term used in a particular section is explained.

We would like to highlight the following variations of nomenclature however:

- The word *relay* and *IED* (Intelligent Electronic Device) are both used to describe the protection device. The term *IED* is associated with the IEC61850 standard, whereas the term *relay* is the long-used traditional term. It may also be referred to simply as the *device* or the *product*.
- American English and spelling is used throughout this manual.
- The term 'Earth' and American term 'Ground' are equivalent. You may find either used in the manual.
- When depicting a generic instance of a number of items, this manual uses either 'x', the # symbol or <n> where n can be any integer.



## 1.3 CAUTIONS, WARNINGS AND NOTES

Before attempting to install or use the device, review all safety indicators in this document to help prevent injury, equipment damage, or downtime.

### 1.3.1 GENERAL CAUTIONS AND WARNINGS

The following general safety precautions and warnings apply.



**Caution:**

Before attempting to use the equipment, it is important that all danger and caution indicators are reviewed.  
If the equipment is used in a manner not specified by the manufacturer or functions abnormally, proceed with caution. Otherwise, the protection provided by the equipment may be impaired and can result in impaired operation and injury.



**Warning:**

Hazardous voltages can cause shock, burns or death.



**Caution:**

Installation/service personnel must be familiar with general device test practices, electrical awareness and safety precautions must be followed.  
Before performing visual inspections, tests, or periodic maintenance on this device or associated circuits, isolate or disconnect all hazardous live circuits and sources of electric power.



**Warning:**

Failure to shut equipment off prior to removing the power connections could expose you to dangerous voltages causing injury or death.  
Ensure that all connections to the product are correct so as to avoid accidental risk of shock and/or fire, for example from high voltage connected to low voltage terminals.



**Caution:**

Follow the requirements of this manual, including adequate wiring size and type, terminal torque settings, voltage, current magnitudes applied, and adequate isolation/clearance in external wiring from high to low voltage circuits.

Use the device only for its intended purpose and application.

Ensure that all ground paths are un-compromised for safety purposes during device operation and service.

All recommended equipment that should be grounded and must have a reliable and un-compromised grounding path for safety purposes, protection against electromagnetic interference and proper device operation.

Equipment grounds should be bonded together and connected to the facility's main ground system for primary power.

Keep all ground leads as short as possible.

In addition to the safety precautions mentioned all electrical connections made must respect the applicable local jurisdiction electrical code.

It is recommended that a field external switch, circuit breaker be connected near the equipment as a means of power disconnect. The external switch or circuit breaker is selected in accordance with the power rating.

This product itself is not Personal Protective Equipment (PPE). However, it can be used in the computation of site specific Arc Flash analysis when the arc flash option is ordered. If a new appropriate Hazard Reduction Category code for the installation is determined, user should follow the cautions mentioned in the arc flash installation section.

The critical failure relay must be connected to annunciate the status of the device for ALL applications. This is particularly important for when the Arc Flash option is ordered.

Ensure that the control power applied to the device, the AC current, and voltage input match the ratings specified on the relay nameplate. Do not apply current or voltage in excess of the specified limits.

Only qualified personnel are to operate the device. Such personnel must be thoroughly familiar with all safety cautions and warnings in this manual and with applicable country, regional, utility, and plant safety regulations.



**Warning:**

Hazardous voltages can exist in the power supply and at the device connection to current transformers, voltage transformers, control, and test circuit terminals. Make sure all sources of such voltages are isolated prior to attempting work on the device.

Hazardous voltages can exist when opening the secondary circuits of live current transformers. Make sure that current transformer secondary circuits are shorted out before making or removing any connection to the current transformer (CT) input terminals of the device.



**Caution:**

For tests with secondary test equipment, ensure that no other sources of voltages or currents are connected to such equipment and that trip and close commands to the circuit breakers or other switching apparatus are isolated, unless this is required by the test procedure and is specified by appropriate utility/plant procedure.

When the device is used to control primary equipment, such as circuit breakers, isolators, and other switching apparatus, all control circuits from the device to the primary equipment must be isolated while personnel are working on or around this primary equipment to prevent any inadvertent command from this device. Use an external disconnect to isolate the mains voltage supply.



**Warning:**

LED transmitters are classified as IEC 60825-1 Accessible Emission Limit (AEL) Class 1M. Class 1M devices are considered safe to the unaided eye. Do not view directly with optical instruments.

*Note:*

*To ensure the settings file inside the relay is updated, wait 30 seconds after a setpoint change before cycling power. This product is rated to Class A emissions levels and is to be used in Utility, Substation Industrial environments. Not to be used near electronic devices rated for Class B levels.*

---

## 1.4 FOR FURTHER ASSISTANCE

---

For product support, contact us as follows:

### GE Vernova

650 Markland Street

Markham, Ontario

Canada L6C 0M1

Worldwide telephone: +1 905 927 7070

Europe/Middle East/Africa telephone: +34 94 485 88 54

North America toll-free: 1 800 547 8629

Fax: +1 905 927 5098

Worldwide e-mail: [ga.support@gevernova.com](mailto:ga.support@gevernova.com)

Website: <https://www.gevernova.com>

---

### 1.4.1 REPAIRS

The firmware and software can be upgraded without return of the device to the factory.

For issues not solved by troubleshooting, the process to return the device to the factory for repair is as follows:

- Contact a GE Vernova Grid Solutions Technical Support Center. Contact information is found in the first chapter.
- Obtain a Return Materials Authorization (RMA) number from the Technical Support Center.
- Verify that the RMA and Commercial Invoice received have the correct information.
- Tightly pack the unit in a box with bubble wrap, foam material, or styrofoam inserts or packaging peanuts to cushion the item(s). You may also use double boxing whereby you place the box in a larger box that contains at least 5 cm of cushioning material.
- Ship the unit by courier or freight forwarder, along with the Commercial Invoice and RMA, to the factory.
- Customers are responsible for shipping costs to the factory, regardless of whether the unit is under warranty.
- Fax a copy of the shipping information to the GE Vernova Grid Solutions service department.

Use the detailed return procedure outlined at

<https://www.gevernova.com/grid-solutions/return-procedures>

The current warranty and return information are outlined at

<https://www.gevernova.com/grid-solutions/multilin/warranty>

## CHAPTER 2

# PRODUCT DESCRIPTION

---

## 2.1 CHAPTER OVERVIEW

---

This chapter contains the following sections:

|                         |    |
|-------------------------|----|
| Chapter Overview        | 10 |
| Product Overview        | 11 |
| Signal processing       | 17 |
| Communication Functions | 19 |
| Order codes             | 20 |

## 2.2 PRODUCT OVERVIEW

The G30 is part of the Universal Relay (UR) family of products. It is a microprocessor-based relay that provides protection, monitoring, control, and recording functions for AC generators driven by steam, gas, or hydraulic turbine. Current, voltage, and frequency protection are provided along with fault diagnostics.

Voltage and current metering are built into the relay as standard features. Parameters are available as total waveform root mean square (RMS) magnitude, or as fundamental frequency only RMS magnitude and angle (phasor).

Diagnostic features include:

- An event recorder capable of storing 1024 time-tagged events
- Oscillography capable of storing up to 64 records with programmable trigger, content, and sampling rate
- The internal clock used for time-tagging can be synchronized with an IRIG-B signal, using the Simple Network Time Protocol (SNTP) over the Ethernet port, or using the Precision Time Protocol (PTP). This precise time stamping allows the sequence of events to be determined throughout the system.
- Events can also be programmed (via FlexLogic equations) to trigger oscillography data capture that can be set to record the measured parameters before and after the event for viewing on a computer.

These tools significantly reduce troubleshooting time and simplify report generation in the event of a system fault.

Several options are available for communication.

- An RS232 port (or a USB port with the graphical front panel) is provided for connection with a PC to program settings and monitor actual values.
- All serial ports support the Modbus RTU protocol.
- A rear RS485 port allows independent access by operators and engineering staff. It can be connected to system computers with baud rates up to 115.2 kbps.
- The RS485 interface also supports DNP, IEC 60870-5-103 and IEC 60870-5-104, whereby only one of these can be enabled at any time. When the IEC 60870-5-103 protocol is chosen, the RS485 port has a fixed even parity and the baud rate can be either 9.6 kbps or 19.2 kbps.
- The 100Base-FX or 100Base-TX Ethernet interface provides fast, reliable communications in noisy environments.
- The Ethernet port supports IEC 61850, Modbus/TCP, TFTP, and PTP (according to IEEE Std. 1588-2008 or IEC 61588), and it allows access to the relay via any standard web browser.
- The Ethernet port supports the IEC 60870-5-104 protocol
- The Ethernet port supports the Parallel Redundancy Protocol (PRP) of IEC 62439-3 (clause 4, 2012) when purchased as an option.
- GOOSE and secure Routable GOOSE (R-GOOSE) are supported with software options.
- Process Bus GOOSE is supported with a hardware module and software options for applicable relays

Settings and actual values can be accessed from the front panel or EnerVista software.

The Product uses flash memory technology that allows field upgrading of both firmware and software as new features are added.

With a Process Bus Module that supports IEC 61850-9-2LE and IEC 61869, PRP is supported on two Ethernet ports to IEC 62439, and High-availability Seamless Redundancy (HSR) is supported on four Ethernet ports for dual HSR ring architecture.


The relay supports the following ANSI functions (American National Standards Institute)

### ANSI codes

| ANSI code | Function        | ANSI code | Function                 |
|-----------|-----------------|-----------|--------------------------|
| 24        | Volts per hertz | 51N       | Neutral time overcurrent |

| ANSI code | Function                            | ANSI code | Function                                      |
|-----------|-------------------------------------|-----------|-----------------------------------------------|
| 25        | Synchrocheck                        | 51PV      | Phase time overcurrent with voltage restraint |
| 27P       | Phase undervoltage                  | 59N       | Neutral overvoltage                           |
| 27TN      | Third harmonic neutral undervoltage | 59P       | Phase overvoltage                             |
| 27X       | Auxiliary undervoltage              | 59X       | Auxiliary overvoltage                         |
| 32        | Sensitive directional power         | 59_2      | Negative-sequence overvoltage                 |
| 40        | Loss of excitation                  | 67_2      | Negative-sequence directional overcurrent     |
| 46        | Generator unbalance                 | 67N       | Neutral directional overcurrent               |
| 49        | Thermal overload protection         | 67P       | Phase directional overcurrent                 |
| 50G       | Ground instantaneous overcurrent    | 81O       | Overfrequency                                 |
| 50N       | Neutral Instantaneous Overcurrent   | 81R       | Rate of change frequency                      |
| 50P       | Phase instantaneous overcurrent     | 81U       | Underfrequency                                |
| 50SP      | Split phase protection              | 87RGF     | Restricted ground fault                       |
| 50/27     | Accidental energization             | 87GT      | Generator/transformer differential            |
| 51G       | Ground time overcurrent             |           |                                               |

The following single-line diagrams illustrates the relay functionality using American National Standards Institute (ANSI) device numbers.



830723A5.CDR

Figure 1: Single-line diagram PTS on transformer HV side







Figure 2: Single-line diagram PTS on transformer LV side (protection assigned to generator neutral CTS)



**Figure 3: Single-line diagram, no transformer**

#### Other device functions

| Function                          | Function                                      |
|-----------------------------------|-----------------------------------------------|
| Breaker Arcing Current ( $I^2t$ ) | Modbus user map                               |
| Breaker Control                   | Non-Volatile Latches                          |
| Contact Inputs (up to 120)        | Non-Volatile Selector Switch                  |
| Contact Outputs (up to 72)        | Oscillography                                 |
| Control Pushbuttons               | Percent differential                          |
| CT failure detector               | Setting Groups (6)                            |
| CyberSentry Security              | Time Synchronization over IRIG-B or IEEE 1588 |
| Data Logger                       | Time Synchronization over SNTP                |
| Digital Counters (8)              | Transducer Inputs/Outputs                     |
| Digital Elements (96)             | Transformer aging factor                      |
| Direct Inputs/Outputs (32)        | Transformer hottest-spot temperature          |
| Disconnect Switches               | Transformer loss-of-life                      |

| Function                                             | Function                        |
|------------------------------------------------------|---------------------------------|
| DNP 3.0 or IEC 60870-5-104 protocol                  | Trip bus                        |
| Ethernet Global Data protocol                        | User-definable Displays         |
| Event Recorder                                       | User-programmable fault reports |
| FlexElements (16)                                    | User-programmable LEDs          |
| FlexLogic Equations                                  | User-definable pushbuttons      |
| IEC 60870-5-103 Communications                       | User-programmable Self-Tests    |
| IEC 61850 Communications                             | Virtual Inputs (128)            |
| IEC 62351-9 Data and Communications Security         | Virtual Outputs (256)           |
| Metering: Current, Voltage, Power, Energy, Frequency | VT Fuse Failure                 |
| Modbus communications                                |                                 |

### Number of elements per feature


| Feature                      | No. | Feature                           | No. |
|------------------------------|-----|-----------------------------------|-----|
| CT Banks                     | 4   | Neutral Directional OC            | 2   |
| VT Banks                     | 2   | Neutral Overvoltage               | 3   |
| # of DSPs                    | 2   | Neutral Instantaneous Overcurrent | 1   |
| Accidental Energization      | 1   | Neutral Time Overcurrent          | 2   |
| Auxiliary Overvoltage        | 3   | Non Volatile Latches              | 16  |
| Auxiliary Undervoltage       | 3   | Oscillography                     | 1   |
| Basic UR relay features      | 1   | Over Under Frequency Accumulation | 1   |
| Breaker Arcing Current (I2t) | 2   | Overfrequency                     | 4   |
| Breaker Control              | 2   | Phase Directional                 | 1   |
| Breaker switch               | 8   | Phase Instantaneous Overcurrent   | 12  |
| Change Phase Rotation        | 1   | Phase Overvoltage                 | 3   |
| Contact Inputs               | 120 | Phase Time Overcurrent            | 6   |
| Contact Outputs              | 72  | Phase Undervoltage                | 3   |
| CT Fail                      | 4   | Precision Time Protocol (1588)    | 3   |
| Current CT settings          | 6   | Restricted Ground Fault           | 4   |
| Current Unbalance            | 1   | Security                          | 1   |
| Digital Counters             | 8   | Selector Switch                   | 2   |
| Digital Elements             | 96  | Sensitive Directional Power       | 2   |
| Platform Direct I/O          | 64  | Setting Groups                    | 6   |
| Disturbance Detection        | 4   | Simple Network Time Protocol      | 1   |
| EGD Protocol                 | 1   | Sources                           | 4   |
| Energy Metering              | 4   | Split Phase Protection            | 1   |
| Event Recorder               | 1   | Saturation detector               | 1   |
| Field Resources              | 1   | Synchrocheck                      | 4   |

| Feature                                        | No. | Feature                                                                 | No. |
|------------------------------------------------|-----|-------------------------------------------------------------------------|-----|
| FlexElements                                   | 16  | Teleprotection I/O                                                      | 1   |
| FlexLogic Equations                            | 1   | Thermal Overload Protection                                             | 2   |
| Frequency Rate of Change                       | 4   | Third Harmonic Neutral Undervoltage                                     | 1   |
| Generator Unbalance                            | 1   | Transducer I/O                                                          | 1   |
| Ground Instantaneous Overcurrent               | 1   | DCMA inputs                                                             | 24  |
| Ground Time Overcurrent                        | 1   | Transformer Percent Differential                                        | 1   |
| Harmonic Detection                             | 4   | Transformer windings                                                    | 2   |
| IEC 61850 Communications                       | 1   | Transformer Thermal Model<br>(Hottest spot, Aging Factor, Loss of life) | 1   |
| IEC 61850 Remote I/O (Fixed GOOSE/GSSE/GOOSE)  | 1   | Trip Bus                                                                | 6   |
| RxGOOSE                                        | 64  | Underfrequency                                                          | 6   |
| RxGOOSE BOOLEAN                                | 256 | User Programmable Fault Report                                          | 2   |
| RxGOOSE DPS                                    | 16  | User Programmable LEDs                                                  | 48  |
| RxGOOSE I/O States                             | 1   | User Programmable Pushbuttons                                           | 48  |
| RxGOOSE Status                                 | 64  | Control PBs                                                             | 3   |
| IEC103 Communications                          | 1   | User-definable displays                                                 | 16  |
| Loss of Excitation                             | 1   | Virtual Inputs                                                          | 128 |
| Modbus Communications                          | 1   | Virtual Outputs                                                         | 256 |
| Modbus User Map                                | 1   | Volts Per Hertz                                                         | 2   |
| Multirange Signal Oscillation Detection (MSOD) | 2   | VT Fuse Failure                                                         | 4   |
| Negative Sequence Directional OC               | 2   |                                                                         |     |
| Negative Sequence Overvoltage                  | 3   |                                                                         |     |

## 2.3 SIGNAL PROCESSING

The relays are microprocessor-based protection devices that are designed to measure power system conditions directly via CT and VT inputs and via other sources of information, such as analog inputs, communications inputs, and contact inputs. The following figure shows the overall signal processing in URs.

An analog low pass anti-aliasing filter with a 3 dB corner frequency is set at 2.4 kHz and is used for current and voltage analog filtering as well as signal conditioning. The same filtering is applied for phase, ground currents, phase-to-phase (when applicable), and auxiliary voltages. The 2.4 kHz cut-off frequency applies to both 50 and 60 Hz applications and fixed in the hardware, and thus is not dependent on the system nominal frequency setting.



**Figure 4: UR signal processing**

The relay samples its AC signals at 64 samples per cycle, that is, at 3840 Hz in 60 Hz systems, and 3200 Hz in 50 Hz systems. The sampling rate is adjusted dynamically to the actual system frequency by an accurate and fast frequency tracking system.

The analog/digital converter has the following ranges of AC signals:

Voltages

$$\pm\sqrt{2} \cdot 260(\text{V})$$

Currents

$$\pm\sqrt{2} \cdot 46\text{rated}(\text{A})$$

Current harmonics are estimated based on raw samples with the use of the full-cycle Fourier filter. Harmonics 2nd through 25th are estimated.

True RMS value for the current is calculated on a per-phase basis. The true RMS can be used for demand recording or as an input signal to Time Overcurrent function, if the latter is intended for thermal protection. The true RMS is calculated as per the widely accepted definition:

$$I_{RMS(t)} = \sqrt{\frac{1}{T} \int_{(t-T)}^t i^2(t) dt}$$

RMS values include harmonics, inter-harmonics, DC components, and so on, along with fundamental frequency values. The true RMS value reflects thermal effects of the current and is used for the thermal related monitoring and protection functions.

Protection and control functions respond to phasors of the fundamental and/or harmonic frequency components (magnitudes and angles), with an exception for some functions that have an option for RMS or fundamental measurements, or some function responding to RMS only. This type of response is explained typically in each element's section in this instruction manual.

Currents are pre-filtered using a Finite Impulse Response (FIR) digital filter. The filter is designed to reject DC components and low-frequency distortions, without amplifying high-frequency noise. This filter is referred to as a modified MIMIC filter, which provides excellent filtering and overall balance between speed and accuracy of filtering. The filter is cascaded with the full-cycle Fourier filter for the current phasor estimation.

Voltages are pre-filtered using a patented FIR digital filter. The filter has been optimized to reject voltage-transformer-specific distortions, such as Capacitive Voltage Transformer (CVT) noise and high-frequency oscillatory components. The filter is cascaded with the half-cycle Fourier filter for the voltage phasor estimation.

The URs measure power system frequency using the Clarke transformation by estimating the period of the waveform from two consecutive zero-crossings in the same direction (negative-to-positive). Voltage or current samples are pre-filtered using a Finite Impulse Response (FIR) digital filter to remove high frequency noise contained in the signal. The period is used after several security conditions are met, such as true RMS signal must be above 6% nominal for a certain time. If these security conditions are not met, the last valid measurement is used for a specific time after which the UR reverts to nominal system frequency.

Synchrophasors are calculated using a patented convolution integral algorithm. This algorithm allows use of the same time-stamped samples, which are used for protection and taken at the same sampling frequency. This allows URs to use one sampling clock for both protection algorithms and synchrophasors.

Synchrophasors on firmware versions 7.23 and up have been tested and certified to meet IEEE C37.118-2011 and C37.118.1a-2014 standards for both metering and protection classes with outputs available up to 60 synchrophasors per second for the metering class and 120 synchrophasors per second for the protection class. Synchrophasors measurement is also available via IEC 61850-90-5 protocol.

The contact inputs threshold is settable in the firmware with 17, 33, 84, and 166 V DC settings available. Inputs are scanned every 0.5 ms and can be conditioned for the critical applications, using debounce time timer, settable from 0.0 to 16.0 ms. Contact inputs with auto-burnishing are available as well, when external contacts are exposed to the contamination in a harsh industrial environment.

All measured values are available in the UR metering section on the front panel and via communications protocols. Measured analog values and binary signals can be captured in COMTRADE format with sampling rates from 8 to 64 samples per power cycle. Analog values can be captured with the Data Logger, allowing much slower rates extended over a long period of time.

Other advanced UR order code options are available to support IEC 61850 (including fast GOOSE, ICD/CID/IID files, and so on), IEEE 1588 (IEEE C37.238 power profile) based time synchronization, CyberSentry (advanced cyber security), the Parallel Redundancy Protocol (PRP), IEC 60870-5-103, and so on.

---

## 2.4 COMMUNICATION FUNCTIONS

---

The UR family supports an array of communication ports and protocols to allow connection to equipment such as personal computers, remote terminal units (RTUs), supervisory control and data acquisition (SCADA) masters, and programmable logic controllers. These communication features can be selected as options in the order codes.

Relay communication is a very extensive subject, requiring a significant amount of documentation. Because of this, we supply a separate Communications Guide, which is applicable to all models within the UR product family. The Communications Guide is a major part of the overall documentation of each product model.

Prior to this version, the product manuals themselves contained a large part of the communication documentation. With this version, much of the theoretical information has been moved from this product manual into the Communications Guide. Only communication information pertaining directly to front panel settings remains in this product manual. For further information, we refer you to the Communications Guide.

Due to the extensiveness of IEC61850 documentation, all IEC61850 information has been moved into the Communications Guide, including the settings.

## 2.5 ORDER CODES

The order code is on the product label and indicates the product options applicable.

The relay is available as a 19-inch rack horizontal mount or reduced-size ( $\frac{3}{4}$ ) vertical unit. It consists of the following modules:

- Power supply
- CPU
- CT/VTs
- Contact inputs and outputs
- Transducer inputs and outputs
- Inter-relay communications.

Module options are specified at the time of ordering.

The order codes shown here are subject to change without notice. See the web page for the product for the latest options.

The letters in the top row of the table correspond to slots in the UR chassis, for example slot F, H, or U.

The R-GOOSE protocol described in IEC 61850-8-1 is available through the IEC 61850 software option. R-GOOSE security requires the CyberSentry software option.

*Note:*

*Process Bus GOOSE requires an IEC 61850-9-2LE / IEC 61869 Process Bus Module, as well as IEC 61850, PRP, and IEEE 1588 software options. This is not available for all UR models*

For Japanese, the settings display in Japanese on the graphical front panel, while the keys printed on the panel are in English.

### 2.5.1 ORDER CODES FOR UR

The data items are kept in files attached to this PDF. Depending on the file type, the files may be opened using Microsoft Excel, or free web-based software such as Google Sheets, or PDF viewer capable of opening attachments, such as Adobe Acrobat Reader or Nitro PDF.

Please note that this manual must be opened with a PDF viewer capable of opening attachments, such as Adobe Acrobat Reader or Nitro PDF. Browsers like Microsoft Edge or Google Chrome do not support PDF attachments, although Firefox does. If using Nitro PDF, attachments are shown in the Attachment Pane. To show or hide the Attachments pane, look in the sidebar and click the Attachments tab.

An **Open File** dialog box may open with a warning message about potential harm from programs, macros or viruses. The files supplied do not contain any harmful content, and may be safely opened.

If using Adobe Acrobat Reader, click on the button below to open the spreadsheet. Some older versions of Adobe Acrobat Reader have a bug and do not support this button functionality. If the button does not work, upgrade your Adobe Acrobat Reader for free, to the latest version.

**Order Code G30 88x**

### 2.5.2 ORDER CODES FOR REPLACEMENT MODULES

Replacement modules can be ordered separately. When ordering a replacement CPU module or front panel, provide the serial number of your existing unit.

Not all replacement modules apply to the relay described in this manual.



The order codes shown here are subject to change without notice. See the web page for the product for the latest options.

Please note that this manual must be opened with Adobe Acrobat Reader to allow access to the attached spreadsheet. This program is freely available on the Adobe website. The spreadsheets may be opened using free web-based software such as Google Sheets.

An Open File dialogue box may open with a warning message about potential harm from programs, macros or viruses. The files supplied do not contain any harmful content, and may be safely opened.

*Note:*

*Note: The SL and TL power supply options are only available as a special option. Please contact GE Vernova for more information*

## CHAPTER 3

# SPECIFICATIONS

---

## 3.1 CHAPTER OVERVIEW

---

This chapter contains the following sections:

|                            |    |
|----------------------------|----|
| Chapter Overview           | 23 |
| Protection elements        | 24 |
| User-programmable elements | 36 |
| Monitoring                 | 39 |
| Metering                   | 41 |
| Power supply               | 43 |
| Inputs                     | 45 |
| Outputs                    | 48 |
| Communication protocols    | 51 |
| Inter-relay communications | 53 |
| CyberSentry security       | 55 |
| Graphical front panel      | 56 |
| Environmental              | 57 |
| Type tests                 | 58 |
| Production tests           | 59 |
| Approvals                  | 60 |
| Maintenance                | 61 |

## 3.2 PROTECTION ELEMENTS

The operating times include the activation time of a trip rated form-A output contact unless otherwise indicated. FlexLogic operands of a given element are 4 ms faster. Take this into account when using FlexLogic to interconnect with other protection or control elements of the relay, building FlexLogic equations, or interfacing with other intelligent electronic devices (IEDs) or power system devices via communications or different output contacts. If not specified, the operate times given here are for a 60 Hz system at nominal system frequency. Operate times for a 50 Hz system are 1.2 times longer. Timer Accuracy is specified as a percentage of the total operating time that is the sum of the Operate Time and settable Pickup Delay.

### 3.2.1 PERCENT DIFFERENTIAL

| PERCENT DIFFERENTIAL           |                                                                                |
|--------------------------------|--------------------------------------------------------------------------------|
| Characteristic:                | Differential restraint pre-set                                                 |
| Number of zones:               | 1                                                                              |
| Minimum pickup:                | 0.05 to 1.00 pu in steps of 0.001                                              |
| Slope 1 range:                 | 15 to 100% in steps of 1%                                                      |
| Slope 2 range:                 | 20 to 100% in steps of 1%                                                      |
| Kneepoint 1:                   | 1.0 to 2.0 pu in steps of 0.001                                                |
| Kneepoint 2:                   | 2.0 to 30.0 pu in steps of 0.001                                               |
| 2nd harmonic inhibit level:    | 1.0 to 40.0% in steps of 0.1                                                   |
| 2nd harmonic inhibit function: | Adaptive, Traditional, Disabled                                                |
| 2nd harmonic inhibit mode:     | Per-phase, 2-out-of-3, Average, 1-out-of-3                                     |
| 5th harmonic inhibit range:    | 1.0 to 40.0% in steps of 0.1                                                   |
| <b>Operate times</b>           |                                                                                |
| Harmonic inhibits selected:    | 20 to 30 ms at 60 Hz (see NOTE)                                                |
|                                | 20 to 35 ms at 50 Hz (see NOTE)                                                |
| No harmonic inhibits selected: | 5 to 20 ms (see NOTE)                                                          |
| Level accuracy:                | ±0.5% of reading or ±1% of rated (whichever is greater) for two windings setup |

**Note:**

Protection and control elements have additional operating time delay of up to 3 ms if the product is ordered with an IEC 61850-9-2LE / IEC 61869 Process Bus Module (order code 85, 86, 87).

### 3.2.2 RESTRICTED GROUND FAULT

| RESTRICTED GROUND FAULT |                                                         |
|-------------------------|---------------------------------------------------------|
| Pickup:                 | 0.005 to 30.000 pu in steps of 0.001                    |
| Dropout:                | 97 to 98% of pickup                                     |
| Slope:                  | 0 to 100% in steps of 1%                                |
| <b>Level accuracy</b>   |                                                         |
| 0.1 to 2.0 x CT rating: | ±0.5% of reading or ±1% of rated (whichever is greater) |
| >2.0 x CT rating:       | ±1.5% of reading                                        |
| Pickup delay:           | 0 to 600.00 s in steps of 0.01                          |
| Dropout delay:          | 0 to 600.00 s in steps of 0.01                          |
| Operate time:           | <2 power system cycles (see NOTE 1)                     |

**Note:**

Protection and control elements have additional operating time delay of up to 3 ms if the product is ordered with an IEC 61850-9-2LE / IEC 61869 Process Bus Module (order code 85, 86, 87).

### 3.2.3 PHASE/NEUTRAL/GROUND TIME OVERCURRENT

| PHASE/NEUTRAL/GROUND TOC                     |                                                                                                                                                                                                                                                                                      |
|----------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Current                                      | Phasor or RMS                                                                                                                                                                                                                                                                        |
| Pickup level (Phase and Neutral)             | 0.020 to 30.000 pu in steps of 0.001                                                                                                                                                                                                                                                 |
| Pickup level (Ground and Sensitive Ground)   | 0.0020 to 30.000 pu in steps of 0.001.<br>Note: A module with sensitive ground can only measure current up to 4.6 pu.                                                                                                                                                                |
| Pickup level (Process Bus Module, ground)    | 0.005 to 30.000 pu in steps of 0.001                                                                                                                                                                                                                                                 |
| Dropout level                                | 97% of pickup                                                                                                                                                                                                                                                                        |
| <b>Level accuracy</b>                        |                                                                                                                                                                                                                                                                                      |
| 0.1 to 2.0 x CT rating                       | ±0.5% of reading or ±0.4% of rated (whichever is greater)                                                                                                                                                                                                                            |
| >2.0 x CT rating                             | ±1.5% of reading                                                                                                                                                                                                                                                                     |
| Timing characteristics                       | IEEE Moderately/Very/Extremely Inverse; IEC (and BS) A/B/C and Short Inverse; GE IAC Inverse, Short/Very/ Extremely Inverse; I2t; FlexCurves™ (programmable); (Curve multiplier 0.00 to 600.00 in steps of 0.01 s)<br>Definite Time (Time delay = 0.00 to 600.00 in steps of 0.01 s) |
| Reset type:                                  | Instantaneous/Timed (per IEEE)                                                                                                                                                                                                                                                       |
| Curve timing accuracy at 1.03 to 20 x pickup | ±3.5% of operate time or ±½ cycle (whichever is greater) from pickup to operate (see NOTE 1)                                                                                                                                                                                         |
| Voltage restraint                            | Modifies pickup current for voltage in the range of $0.1 < V < 0.9 V_T$<br>Nominal in a fixed linear relationship                                                                                                                                                                    |

**Note:**

Protection and control elements have additional operating time delay of up to 3 ms if the product is ordered with an IEC 61850-9-2LE / IEC 61869 Process Bus Module (order code 85, 86, 87).

### 3.2.4 PHASE/NEUTRAL/GROUND INSTANTANEOUS OVERCURRENT

| PHASE/NEUTRAL/GROUND IOC                      |                                                                                                                       |
|-----------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|
| Pickup level Pickup level (Phase and Neutral) | 0.020 to 30.000 pu in steps of 0.001                                                                                  |
| Pickup level (Ground and Sensitive Ground)    | 0.0020 to 30.000 pu in steps of 0.001.<br>Note: A module with sensitive ground can only measure current up to 4.6 pu. |
| Pickup level (Process Bus Module, ground)     | 0.005 to 30.000 pu in steps of 0.001                                                                                  |
| Dropout level                                 | 97% of pickup                                                                                                         |
| <b>Level accuracy</b>                         |                                                                                                                       |
| 0.1 to 2.0 x CT rating                        | ±0.5% of reading or ±0.4% of rated (whichever is greater)                                                             |
| >2.0 x CT rating                              | ±1.5% of reading                                                                                                      |
| Overreach                                     | <2%                                                                                                                   |
| Pickup delay                                  | 0.00 to 600.00 s in steps of 0.01                                                                                     |
| Reset delay                                   | 0.00 to 600.00 s in steps of 0.01                                                                                     |

| PHASE/NEUTRAL/GROUND IOC |                                                                                                                                                                               |
|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Operate time             | <16 ms at 3 × pickup at 60 Hz (Phase IOC) (see NOTE 1)<br><20 ms at 3 × pickup at 60 Hz (Neutral IOC) (see NOTE 1)<br><25 ms at 3 × pickup at 60 Hz (Ground IOC) (see NOTE 1) |
| Timer accuracy           | ±3.5% of operate time or ±1/4 cycle (whichever is greater)                                                                                                                    |

### 3.2.5 PHASE DIRECTIONAL OVERCURRENT

| PHASE DIRECTIONAL OVERCURRENT              |                                                                                                                          |
|--------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
| Relay connection                           | 90° (quadrature)                                                                                                         |
| Quadrature voltage                         | ABC phase seq.: phase A (VBC), phase B (VCA), phase C (VAB); ACB phase seq.: phase A (VCB), phase B (VAC), phase C (VBA) |
| Polarizing voltage threshold               | 0.004 to 3.000 pu in steps of 0.001                                                                                      |
| Current sensitivity threshold              | 0.05 pu                                                                                                                  |
| Characteristic angle                       | 0 to 359° in steps of 1                                                                                                  |
| Angle accuracy                             | ±2°                                                                                                                      |
| <b>Operation time (FlexLogic operands)</b> |                                                                                                                          |
| Tripping (reverse load, forward fault)     | <12 ms, typically (see NOTE 1)                                                                                           |
| Blocking (forward load, reverse fault)     | <8 ms, typically (see NOTE 1)                                                                                            |

**Note:**

Protection and control elements have additional operating time delay of up to 3 ms if the product is ordered with an IEC 61850-9-2LE / IEC 61869 Process Bus Module (order code 85, 86, 87).

### 3.2.6 NEUTRAL DIRECTIONAL OVERCURRENT

| NEUTRAL DIRECTIONAL OVERCURRENT |                                                                              |
|---------------------------------|------------------------------------------------------------------------------|
| Directionality:                 | Co-existing forward and reverse                                              |
| Polarizing:                     | Voltage, Current, Dual, Dual-V, Dual-I                                       |
| Polarizing voltage              | V <sub>0</sub> or VX                                                         |
| Polarizing current              | IG                                                                           |
| Operating current               | I <sub>0</sub>                                                               |
| Level sensing                   | $3 \times ( I_0  - K \times  I_1 )$ , IG Independent for forward and reverse |
| Restraint, K                    | 0.000 to 0.500 in steps of 0.001                                             |
| Characteristic angle            | –90 to 90° in steps of 1                                                     |
| Limit angle                     | 40 to 90° in steps of 1, independent for forward and reverse                 |
| Angle accuracy                  | ±2°                                                                          |
| Offset impedance                | 0.00 to 250.00 Ω in steps of 0.01                                            |
| Pickup level                    | 0.002 to 30.000 pu in steps of 0.01                                          |
| Dropout level                   | 97 to 98%                                                                    |
| Operation time                  | <16 ms at 3 × pickup at 60 Hz (see NOTE 1)                                   |

**Note:**

Protection and control elements have additional operating time delay of up to 3 ms if the product is ordered with an IEC 61850-9-2LE / IEC 61869 Process Bus Module (order code 85, 86, 87).

### 3.2.7 NEGATIVE SEQUENCE DIRECTIONAL OVERCURRENT

| NEGATIVE SEQUENCE DIRECTIONAL OVERCURRENT |                                                              |
|-------------------------------------------|--------------------------------------------------------------|
| Directionality:                           | Co-existing forward and reverse                              |
| Polarizing:                               | Voltage                                                      |
| Polarizing voltage                        | V <sub>2</sub>                                               |
| Operating current                         | I <sub>2</sub>                                               |
| Level sensing zero-sequence               | $ I_0  - K \times  I_1 $                                     |
| Level sensing negative-sequence           | $ I_2  - K \times  I_1 $                                     |
| Restraint, K                              | 0.000 to 0.500 in steps of 0.001                             |
| Characteristic angle                      | 0 to 90° in steps of 1                                       |
| Limit angle                               | 40 to 90° in steps of 1, independent for forward and reverse |
| Angle accuracy                            | ±2°                                                          |
| Offset impedance                          | 0.00 to 250.00 Ω in steps of 0.01                            |
| Pickup level                              | 0.002 to 30.000 pu in steps of 0.01                          |
| Dropout level                             | 97%                                                          |
| Operation time                            | <16 ms at 3 × pickup at 60 Hz (see NOTE 1)                   |

### 3.2.8 GENERATOR UNBALANCE

| GENERATOR UNBALANCE                     |                                                         |
|-----------------------------------------|---------------------------------------------------------|
| Gen. nominal current:                   | 0.000 to 1.250 pu in steps of 0.001                     |
| Stages:                                 | 2 (I <sub>2t</sub> with linear reset and definite time) |
| Pickup level:                           | 0.00 to 100.00% in steps of 0.01                        |
| Dropout level:                          | 97 to 98% of pickup                                     |
| Level accuracy at 0.1 to 2 x CT rating: | ±0.5% of reading or 1% of rated (whichever is greater)  |
| Level accuracy at > 2.0 x CT rating:    | ±1.5% of reading                                        |
| Time dial (K-value):                    | 0.00 to 100.00 in steps of 0.01                         |
| Pickup delay:                           | 0.0 to 1000.0 s in steps of 0.1                         |
| Reset delay:                            | 0.0 to 1000.0 s in steps of 0.1                         |
| Timer accuracy:                         | ±3% of operate time or ±20 ms, whichever is greater     |
| Operate time:                           | <50 ms at 60 Hz                                         |

### 3.2.9 SPLIT PHASE PROTECTION

| SPLIT PHASE PROTECTION |                                                         |
|------------------------|---------------------------------------------------------|
| Operating quantity:    | Split phase CT current biased by generator load current |
| Pickup level:          | 0.020 to 1.500 pu in steps of 0.001                     |
| Dropout level:         | 97 to 98% of pickup                                     |
| Level accuracy:        | ±0.5% of reading or ±1% of rated                        |
| Pickup delay:          | 0.000 to 65.535 s in steps of 0.001                     |

**SPLIT PHASE PROTECTION**

|                 |                                                                   |
|-----------------|-------------------------------------------------------------------|
| Timer accuracy: | $\pm 3\%$ of operate time or $\pm 5$ cycles, whichever is greater |
| Operate time:   | $< 5$ cycles at 1.10 x pickup at 60 Hz                            |

**3.2.10 SENSITIVE DIRECTIONAL POWER****SENSITIVE DIRECTIONAL POWER**

|                       |                                                                                |
|-----------------------|--------------------------------------------------------------------------------|
| Measured power        | 3-phase, true RMS                                                              |
| Number of stages      | 2                                                                              |
| Characteristic angle  | 0 to 359° in steps of 1                                                        |
| Calibration angle     | 0.00 to 0.95° in steps of 0.05                                                 |
| Minimum power         | -3.300 to 3.300 pu in steps of 0.001                                           |
| Pickup level accuracy | $\pm 1\%$ or $\pm 0.001$ pu, whichever is greater                              |
| Hysteresis            | 2% or 0.001 pu, whichever is greater                                           |
| Pickup delay          | 0 to 600.00 s in steps of 0.01                                                 |
| Timer accuracy        | $\pm 3\%$ of operate time or $\pm 1/4$ cycle (whichever is greater)            |
| Operate time          | $< 50$ ms (plus up to 5 ms with Process Bus Module with order code 85, 86, 87) |

**3.2.11 PHASE UNDERVOLTAGE****PHASE UNDERVOLTAGE**

|                                            |                                                                                                                                                                                                                          |
|--------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Voltage                                    | Phasor only                                                                                                                                                                                                              |
| Pickup level                               | 0.004 to 3.000 pu in steps of 0.001                                                                                                                                                                                      |
| Dropout level                              | 102% of pickup                                                                                                                                                                                                           |
| Level accuracy                             | $\pm 0.5\%$ of reading from 10 to 208 V                                                                                                                                                                                  |
| Timing characteristics                     | GE IAV Inverse (Curve multiplier 0.00 to 600.00 in steps of 0.01 s)<br>Definite Time (Time delay = 0.00 to 600.00 in steps of 0.01 s)<br>FlexCurves (programmable, Curve multiplier = 0.00 to 600.00 in steps of 0.01 s) |
| Reset delay                                | 0 to 600.00 s in steps of 0.01 s                                                                                                                                                                                         |
| Curve timing accuracy at $< 0.90$ x pickup | $\pm 3.5\%$ of operate time or $\pm 1/2$ cycle (whichever is greater) from pickup to operate                                                                                                                             |
| Operate time                               | $< 30$ ms at 0.9 pickup at 60 Hz for Definite Time mode                                                                                                                                                                  |

**3.2.12 AUXILIARY UNDERVOLTAGE****AUXILIARY UNDERVOLTAGE**

|                        |                                                                                                                                                                                                                          |
|------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pickup level           | 0.004 to 3.000 pu in steps of 0.001                                                                                                                                                                                      |
| Dropout level          | 103% of pickup                                                                                                                                                                                                           |
| Level accuracy         | $\pm 0.5\%$ of reading from 10 to 208 V                                                                                                                                                                                  |
| Timing characteristics | GE IAV Inverse (Curve multiplier 0.00 to 600.00 in steps of 0.01 s)<br>Definite Time (Time delay = 0.00 to 600.00 in steps of 0.01 s)<br>FlexCurves (programmable, Curve multiplier = 0.00 to 600.00 in steps of 0.01 s) |
| Reset delay            | 0 to 600.00 s in steps of 0.01 s                                                                                                                                                                                         |



| AUXILIARY UNDERVOLTAGE                         |                                                                                              |
|------------------------------------------------|----------------------------------------------------------------------------------------------|
| Curve timing accuracy at $<0.90 \times$ pickup | $\pm 3.5\%$ of operate time or $\pm 1/2$ cycle (whichever is greater) from pickup to operate |
| Operate time                                   | $<30$ ms at $0.9$ pickup at $60$ Hz for Definite Time mode                                   |

### 3.2.13 THIRD HARMONIC NEUTRAL UNDERVOLTAGE

| THIRD HARMONIC NEUTRAL UNDERVOLTAGE |                                                                |
|-------------------------------------|----------------------------------------------------------------|
| Operating quantity:                 | 3rd harmonic of auxiliary undervoltage                         |
| Undervoltage Pickup level:          | $0.0010$ to $3.0000$ pu in steps of $0.0001$                   |
| Undervoltage Dropout level:         | $102$ to $103\%$ of pickup                                     |
| Undervoltage Accuracy:              | $\pm 2\%$ of reading from $1$ to $50$ V                        |
| Power Pickup level                  | $0.000$ to $1.250$ pu in steps of $0.001$                      |
| Power Dropout level:                | $97$ to $98\%$ of pickup                                       |
| Power Accuracy:                     | $\pm 5\%$ or $\pm 0.01$ pu, whichever is greater               |
| Undervoltage Inhibit Level:         | $0.000$ to $1.250$ pu in steps of $0.001$ pu                   |
| Undervoltage Inhibit Accuracy:      | $\pm 0.5\%$ of reading from $10$ to $208$ V                    |
| Pickup delay:                       | $0$ to $600.00$ s in steps of $0.01$                           |
| Timer accuracy:                     | $\pm 3\%$ of operate time or $\pm 20$ ms, whichever is greater |
| Operate time:                       | $<30$ ms at $0.9 \times$ pickup at $60$ Hz                     |

### 3.2.14 PHASE OVERVOLTAGE

| PHASE OVERVOLTAGE                             |                                                                                                                                                                                                                                            |
|-----------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Voltage                                       | Phasor only                                                                                                                                                                                                                                |
| Pickup level                                  | $0.004$ to $3.000$ pu in steps of $0.001$                                                                                                                                                                                                  |
| Dropout level                                 | $98\%$ of pickup                                                                                                                                                                                                                           |
| Level accuracy                                | $\pm 0.5\%$ of reading from $10$ to $208$ V                                                                                                                                                                                                |
| Timing characteristics                        | GE IAV Inverse (Curve multiplier $0.00$ to $600.00$ in steps of $0.01$ s)<br>Definite Time (Time delay = $0.00$ to $600.00$ in steps of $0.01$ s)<br>FlexCurves (programmable, Curve multiplier = $0.00$ to $600.00$ in steps of $0.01$ s) |
| Reset delay                                   | $0$ to $600.00$ s in steps of $0.01$ s                                                                                                                                                                                                     |
| Curve timing accuracy at $>1.1 \times$ pickup | $\pm 3.5\%$ of operate time or $\pm 1$ cycle (whichever is greater) from pickup to operate                                                                                                                                                 |
| Operate time                                  | $<30$ ms at $1.1 \times$ pickup at $60$ Hz for Definite Time mode                                                                                                                                                                          |

### 3.2.15 NEUTRAL OVERVOLTAGE

| NEUTRAL OVERVOLTAGE |                                                                               |
|---------------------|-------------------------------------------------------------------------------|
| Pickup level        | $0.004$ to $3.000$ pu in steps of $0.001$                                     |
| Dropout level       | $97\%$ of pickup                                                              |
| Level accuracy      | $\pm 0.5\%$ of reading from $10$ to $208$ V                                   |
| Pickup delay        | $0.00$ to $600.00$ s in steps of $0.01$ (definite time) or user-defined curve |
| Reset delay         | $0.00$ to $600.00$ s in steps of $0.01$                                       |

| NEUTRAL OVERVOLTAGE                           |                                                                                            |
|-----------------------------------------------|--------------------------------------------------------------------------------------------|
| Curve timing accuracy at $>1.1 \times$ pickup | $\pm 3.5\%$ of operate time or $\pm 1$ cycle (whichever is greater) from pickup to operate |
| Operate time                                  | $<30$ ms at $1.10 \times$ pickup at 60 Hz                                                  |

### 3.2.16 AUXILIARY OVERVOLTAGE

| AUXILIARY OVERVOLTAGE                                      |                                                                                                                                                                                                                            |
|------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pickup level                                               | 0.004 to 3.000 pu in steps of 0.001                                                                                                                                                                                        |
| Dropout level                                              | 97% of pickup                                                                                                                                                                                                              |
| Level accuracy                                             | $\pm 0.5\%$ of reading from 10 to 208 V                                                                                                                                                                                    |
| Timing characteristics                                     | Definite Time (Time delay = 0.00 to 600.00 in steps of 0.01 s);<br>GE IAV Inverse (Curve multiplier= 0.00 to 600.00 in steps of 0.01 s);<br>FlexCurves (programmable, Curve multiplier= 0.00 to 600.00 in steps of 0.01 s) |
| Reset delay                                                | 0.00 to 600.00 s in steps of 0.01                                                                                                                                                                                          |
| Curve timing accuracy at $>1.1 \times$ pickup              | $\pm 3.5\%$ of operate time or $\pm 1$ cycle (whichever is greater) from pickup to operate                                                                                                                                 |
| Operate time                                               | $<30$ ms at $1.10 \times$ pickup at 60 Hz for Definite Time mode                                                                                                                                                           |
| Operate time when 20 Hz injection is performed (G60 only): | 8 power system cycles                                                                                                                                                                                                      |

### 3.2.17 NEGATIVE SEQUENCE OVERVOLTAGE

| NEGATIVE SEQUENCE OVERVOLTAGE |                                                                |
|-------------------------------|----------------------------------------------------------------|
| Pickup level:                 | 0.004 to 1.250 pu in steps of 0.001                            |
| Dropout level:                | 97% of pickup                                                  |
| Level accuracy:               | $\pm 0.5\%$ of reading from 10 to 208 V                        |
| Pickup delay:                 | 0 to 600.00 s in steps of 0.01                                 |
| Reset delay:                  | 0 to 600.00 s in steps of 0.01                                 |
| Timer accuracy:               | $\pm 3\%$ of operate time or $\pm 20$ ms, whichever is greater |
| Operate time:                 | $<30$ ms at $1.10 \times$ pickup at 60 Hz                      |

### 3.2.18 VOLTS PER HERTZ

| VOLTS PER HERTZ        |                                                                                                                                                                       |
|------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Voltage                | Phase-to-phase or phase-to-ground, phasor only                                                                                                                        |
| Pickup level           | 0.80 to 4.00 in steps of 0.01 pu V/Hz                                                                                                                                 |
| Dropout level          | 98% of pickup                                                                                                                                                         |
| Level accuracy         | $\pm 0.02$ pu                                                                                                                                                         |
| Pickup delay           | 0 to 600.00 s in steps of 0.01                                                                                                                                        |
| Timing characteristics | Inverse A, B, and C, FlexCurves A, B, C, and D (Curve multiplier 0.00 to 600.00 in steps of 0.01 s)<br>Definite Time (Time delay = 0.00 to 600.00 in steps of 0.01 s) |
| Reset delay            | 0.0 to 1000.0 s in steps of 0.1                                                                                                                                       |

| VOLTS PER HERTZ |                                                                                                                             |
|-----------------|-----------------------------------------------------------------------------------------------------------------------------|
| Timer accuracy  | $\pm 3\%$ of operate time or $\pm 3$ cycles (whichever is greater) for values greater than $1.1 \times$ pickup (see NOTE 1) |

**Note:**

Protection and control elements have additional operating time delay of up to 3 ms if the product is ordered with an IEC 61850-9-2LE / IEC 61869 Process Bus Module (order code 85, 86, 87).

### 3.2.19 TRANSFORMER HOTTEST-SPOT TEMPERATURE

| TRANSFORMER HOTTEST SPOT TEMPERATURE |                               |
|--------------------------------------|-------------------------------|
| Operating quantity:                  | Computed temperature in °C    |
| Pickup level:                        | 50 to 300°C in steps of 1     |
| Dropout level:                       | 1°C below pickup              |
| Pickup delay:                        | 0 to 30000 min. in steps of 1 |

### 3.2.20 TRANSFORMER AGING FACTOR

| TRANSFORMER AGING FACTOR |                                         |
|--------------------------|-----------------------------------------|
| Operating quantity:      | Computed aging acceleration factor (pu) |
| Pickup level:            | 1 to 10 pu in steps of 0.1              |
| Pickup delay:            | 0 to 30000 min. in steps of 1           |

### 3.2.21 TRANSFORMER LOSS OF LIFE

| TRANSFORMER LOSS OF LIFE |                                                         |
|--------------------------|---------------------------------------------------------|
| Operating quantity:      | Computed accumulated transformer loss of life, in hours |
| Pickup level:            | 0 to 500000 hours in steps of 1                         |

### 3.2.22 UNDERFREQUENCY

| UNDERFREQUENCY                                                                                                                                    |                                                                                                                           |
|---------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|
| Minimum signal                                                                                                                                    | 0.10 to 1.25 pu in steps of 0.01                                                                                          |
| Pickup level                                                                                                                                      | 20.00 to 70.00 Hz in steps of 0.01                                                                                        |
| Dropout level                                                                                                                                     | pickup + 0.03 Hz                                                                                                          |
| Level accuracy                                                                                                                                    | $\pm 0.001$ Hz                                                                                                            |
| Time delay                                                                                                                                        | 0 to 65.535 s in steps of 0.001                                                                                           |
| Timer accuracy:                                                                                                                                   | $\pm 3\%$ of operate time or $\pm 1/4$ cycle (whichever is greater)                                                       |
| Operate time                                                                                                                                      | typically 4 cycles at 0.1 Hz/s change<br>typically 3.5 cycles at 0.3 Hz/s change<br>typically 3 cycles at 0.5 Hz/s change |
| Typical times are average operate times including variables, such as frequency change instance, and test method, and can vary by $\pm 0.5$ cycles |                                                                                                                           |

### 3.2.23 OVERFREQUENCY

| OVERFREQUENCY                                                                                                                                |                                                                                                                           |
|----------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|
| Pickup level                                                                                                                                 | 20.00 to 70.00 Hz in steps of 0.01                                                                                        |
| Dropout level                                                                                                                                | pickup - 0.03 Hz                                                                                                          |
| Level accuracy                                                                                                                               | ±0.001 Hz                                                                                                                 |
| Time delay                                                                                                                                   | 0 to 65.535 s in steps of 0.001                                                                                           |
| Timer accuracy:                                                                                                                              | ±3% of operate time or ±1/4 cycle (whichever is greater)                                                                  |
| Operate time                                                                                                                                 | typically 4 cycles at 0.1 Hz/s change<br>typically 3.5 cycles at 0.3 Hz/s change<br>typically 3 cycles at 0.5 Hz/s change |
| Typical times are average operate times including variables, such as frequency change instance, and test method, and can vary by ±0.5 cycles |                                                                                                                           |

### 3.2.24 RATE OF CHANGE OF FREQUENCY

| RATE OF CHANGE OF FREQUENCY                                                                                                                  |                                                                                                                |
|----------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|
| df/dt trend                                                                                                                                  | increasing, decreasing, bi-directional                                                                         |
| df/dt pickup level                                                                                                                           | 0.10 to 15.00 Hz/s in steps of 0.01                                                                            |
| df/dt dropout level                                                                                                                          | 96% of pickup                                                                                                  |
| df/dt level accuracy                                                                                                                         | 80 mHz/s or 3.5%, whichever is greater (up to df/dt trend of 10 Hz/s)                                          |
| Overvoltage supervision                                                                                                                      | 0.100 to 3.000 pu in steps of 0.001                                                                            |
| Overcurrent supervision                                                                                                                      | 0.020 to 30.000 pu in steps of 0.001                                                                           |
| Pickup delay                                                                                                                                 | 0 to 65.535 s in steps of 0.001                                                                                |
| Reset delay                                                                                                                                  | 0 to 65.535 s in steps of 0.001                                                                                |
| Timer accuracy:                                                                                                                              | ±3% of operate time or ±1/4 cycle (whichever is greater)                                                       |
| Operate time                                                                                                                                 | typically 9.5 cycles at 2 × pickup<br>typically 8.5 cycles at 3 × pickup<br>typically 6.5 cycles at 5 × pickup |
| Typical times are average operate times including variables, such as frequency change instance, and test method, and can vary by ±0.5 cycles |                                                                                                                |

### 3.2.25 TURBINE FREQUENCY OUT-OF-BAND ACCUMULATED OPERATING TIME

| TURBINE FREQUENCY OUT-OF-BAND (OOB) ACCUMULATED OPERATING TIME |                                                    |
|----------------------------------------------------------------|----------------------------------------------------|
| Frequency OOB accumulation:                                    | 7 sets; 20 to 70 Hz in steps of 0.01               |
| Frequency OOB accumulation pickup:                             | 1 to 65536 s in steps of 1                         |
| Frequency OOB accumulator preset:                              | 1 to 65536 s in steps of 1                         |
| Level accuracy:                                                | ±0.01 Hz                                           |
| Minimum volt/amp supervision:                                  | 0.1 to 1.25 pu of V <sub>1</sub> or I <sub>1</sub> |
| Timer accuracy of accumulation:                                | ±1% or 1 second, whichever is greater              |

### 3.2.26 BREAKER ARCING CURRENT

| BREAKER ARCING CURRENT            |                                                                 |
|-----------------------------------|-----------------------------------------------------------------|
| Principle                         | accumulates breaker duty ( $I^2t$ ) and measures fault duration |
| Initiation:                       | programmable per phase from any FlexLogic operand               |
| Compensation for auxiliary relays | 0 to 65.535 s in steps of 0.001                                 |
| Alarm threshold                   | 0 to 50000 kA <sup>2</sup> -cycle in steps of 1                 |
| Fault duration accuracy           | 0.25 of a power cycle                                           |
| Availability:                     | 1 per CT bank with a minimum of 2                               |

### 3.2.27 SYNCHROCHECK

| SYNCHROCHECK                            |                                                                                     |
|-----------------------------------------|-------------------------------------------------------------------------------------|
| Max voltage difference                  | 0 to 400000 V in steps of 1                                                         |
| Max angle difference                    | 0 to 100° in steps of 1                                                             |
| Max frequency difference                | 0.005 to 2.000 Hz in steps of 0.001                                                 |
| Hysteresis for max frequency difference | 0.000 to 0.100 Hz in steps of 0.001                                                 |
| Dead source function                    | None, LV1 & DV2, DV1 & LV2, DV1 or DV2, DV1 xor DV2, DV1 & DV2 (L = Live, D = Dead) |
| S-CLS MAX dF                            | 0.100 to 10.000 Hz in steps of 0.001                                                |
| S-CLS MIN dF                            | 0.005 to 1.000 Hz in steps of 0.001                                                 |
| V2 MAG CORR FACTOR                      | 0.10 to 10.00 in steps of 0.01                                                      |
| V2 ANGLE SHIFT                          | -180° to +180° in steps of 1°                                                       |
| PHASE SELECT                            | Auto, VAG, VBG, VCG, VAB, VBC, VCA                                                  |

### 3.2.28 ACCIDENTAL ENERGIZATION

| ACCIDENTAL ENERGIZATION                    |                                     |
|--------------------------------------------|-------------------------------------|
| Operating condition:                       | Overcurrent                         |
| Arming condition:                          | Undervoltage and/or Machine Offline |
| Overcurrent Pickup level:                  | 0.020 to 3.000 pu in steps of 0.001 |
| Overcurrent Dropout level:                 | 97 to 98% of pickup                 |
| Level accuracy from 0.1 to 2.0 ´ CT rating | ±0.5% of reading                    |
| Undervoltage Pickup level:                 | 0.004 to 3.000 pu in steps of 0.001 |
| Undervoltage Dropout level:                | 102 to 103% of pickup               |
| Undervoltage Level accuracy                | ±0.5% of reading 10 to 208 V        |
| Operate Time:                              | <30 ms at 1.10 x pickup at 60 Hz    |

### 3.2.29 LOSS OF EXCITATION

| LOSS OF EXCITATION   |                                         |
|----------------------|-----------------------------------------|
| Operating condition: | Positive-sequence impedance             |
| Characteristic:      | 2 independent offset mho circles        |
| Circle Center:       | 0.10 to 300.0 W (sec.) in steps of 0.01 |

| LOSS OF EXCITATION                 |                                                     |
|------------------------------------|-----------------------------------------------------|
| Circle Radius:                     | 0.10 to 300.0 W (sec.) in steps of 0.01             |
| Circle Angle                       | 75° to +75° in steps of 1°                          |
| Reach accuracy:                    | ±3%                                                 |
| Undervoltage supervision level:    | 0.000 to 1.250 pu in steps of 0.001                 |
| Undervoltage supervision accuracy: | ±0.5% of reading from 10 to 208 V                   |
| Pickup delay:                      | 0 to 65.535 s in steps of 0.001                     |
| Timer accuracy:                    | ±3% of operate time or ±20 ms, whichever is greater |
| Operate time:                      | <50 ms                                              |

### 3.2.30 THERMAL OVERLOAD

| THERMAL OVERLOAD            |                                                                                                        |
|-----------------------------|--------------------------------------------------------------------------------------------------------|
| Thermal overload curves     | IEC 255-8 curve                                                                                        |
| Base current                | 0.20 to 3.00 pu in steps of 0.01                                                                       |
| Overload (k) factor         | 0.2 to 4 pu in steps of 0.05                                                                           |
| Alarm level                 | 0.2 to 1.0 pu in steps of 0.1                                                                          |
| Trip time constant          | 0 to 999 min. in steps of 0.1                                                                          |
| Reset time constant         | 0 to 999 min. in steps of 0.1                                                                          |
| Minimum reset time          | 0 to 999 min. in steps of 0.1                                                                          |
| Timer accuracy (cold curve) | ±100 ms or 2%, whichever is greater                                                                    |
| Timer accuracy (hot curve)  | ±500 ms or 2%, whichever is greater for $I_p < 0.9 \times k \times I_b$ and $I / (k \times I_b) > 1.1$ |

### 3.2.31 TRIP BUS (TRIP WITHOUT FLEXLOGIC)

| TRIP BUS (TRIP WITHOUT FLEXLOGIC) |                                    |
|-----------------------------------|------------------------------------|
| Number of elements                | 6                                  |
| Number of inputs                  | 16                                 |
| Operate time                      | <2 ms at 60 Hz                     |
| Timer accuracy                    | ±3% or 10 ms, whichever is greater |

### 3.2.32 HARMONIC DETECTION

| HARMONIC DETECTION    |                                                                                                                         |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------|
| Number of elements    | 4                                                                                                                       |
| Pickup threshold      | 2.0 to 100.0% of $I(f_1)$ (current fundamental frequency phasor) in steps of 0.1%                                       |
| Pickup level accuracy |                                                                                                                         |
| Harmonics             | With $I(f_1)$ from 0.4 to $2.0 \times CT$ rating: ±2% of reading or ±1% of 100%, whichever is greater                   |
| THD                   | With $I(f_1)$ from 0.4 to $2.0 \times CT$ rating: ±2% of reading or ±1% of 100% per each harmonic, whichever is greater |
| Pickup delay          | 0 to 600.00s in steps of 0.01                                                                                           |
| Timer accuracy        | ±3% of delay setting or ±1/4 cycle (whichever is greater) from pickup to operate                                        |

**HARMONIC DETECTION**

|                |                               |
|----------------|-------------------------------|
| Operating time | <10 ms at 2 × pickup at 60 Hz |
|----------------|-------------------------------|

**Note:**

Accuracy of the DC measurement depends on the duration and content of the DC component, compared to the fundamental frequency current. It also depends on the source of the signal. DSP or HardFiber transducers can saturate and cause higher error than stated here, while with an MU-320 merging unit as a source, it meets the accuracy stated here due to immunity of the MU-320 to saturation.

**3.2.33 MULTI-RANGE SIGNAL OSCILLATION DETECTOR****MULTI-RANGE SIGNAL OSCILLATOR DETECTOR**

|                                                   |                                                                                                                                                                                                                                                                                                                                                                                                            |
|---------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Number of elements                                | 2                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Input signal to detector</b>                   |                                                                                                                                                                                                                                                                                                                                                                                                            |
| For frequency band I to III                       | Source Voltage Va Mag, Vb Mag, Vc Mag, V1 Mag, Source Current Ia, Mag, Ib Mag, Ic Mag, I1 Mag, Source Real 3-phase Power and Source Reactive 3-phase Power                                                                                                                                                                                                                                                 |
| For frequency band IV                             | Source Voltages (samples) Va, Vb, Vc, Vx, V_clarke, or Source Currents: Ia, Ib, Ic, In, I_clarke                                                                                                                                                                                                                                                                                                           |
| Minimum pickup of Mag_osc                         | 0.02 to 10.00 pu for alarm and 0.05 to 10.00 pu for trip in steps of 0.01 pu                                                                                                                                                                                                                                                                                                                               |
| Pickup level accuracy                             | ±5% of reading or 5% of rated (whichever is greater) for oscillation signal >0.1 pu                                                                                                                                                                                                                                                                                                                        |
| Pickup delay                                      | Definite time: 0 to 600.00 s in steps of 0.01 s                                                                                                                                                                                                                                                                                                                                                            |
| Time accuracy:                                    | ±3% or ±20 ms, whichever is greater                                                                                                                                                                                                                                                                                                                                                                        |
| Operate time: ±3% or ±20 ms, whichever is greater | <p>Typical operating time of <math>2/f_{osc} + 0.04</math> s without damping ratio supervision</p> <p>Typical operating time of <math>3/f_{osc} + \max(0.02, 0.25/f_{osc})</math> s with damping ratio supervision</p> <p>The operating time is dependent on the oscillation inception point, the oscillation frequency and the magnitude of the oscillation, and therefore can vary from these values</p> |

### 3.3 USER-PROGRAMMABLE ELEMENTS

#### 3.3.1 FLEXLOGIC

| FLEXLOGIC            |                                                                                                                                                  |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| Programming language | Reverse Polish Notation with graphical visualization (keypad programmable)                                                                       |
| Lines of code        | 1024                                                                                                                                             |
| Internal variables   | 64                                                                                                                                               |
| Supported operations | NOT, XOR, OR (2 to 16 inputs), AND (2 to 16 inputs), NOR (2 to 16 inputs), NAND (2 to 16 inputs), latch (reset-dominant), edge detectors, timers |
| Inputs:              | any logical variable, contact, or virtual input                                                                                                  |
| Number of timers     | 64                                                                                                                                               |
| Pickup delay         | 0 to 60000 (ms, sec., min.) in steps of 1                                                                                                        |
| Dropout delay        | 0 to 60000 (ms, sec., min.) in steps of 1                                                                                                        |
| Timer accuracy       | ±0.1% of operate time or ±1/8 cycle, whichever is greater                                                                                        |

#### 3.3.2 FLEXCURVES

| FLEXCURVES     |                             |
|----------------|-----------------------------|
| Number         | 4 (A through D)             |
| Reset points   | 40 (0 through 1 of pickup)  |
| Operate points | 80 (1 through 20 of pickup) |
| Time delay     | 0 to 65535 ms in steps of 1 |

#### 3.3.3 FLEXSTATES

| FLEXSTATES      |                                                               |
|-----------------|---------------------------------------------------------------|
| Number          | up to 256 logical variables grouped under 16 Modbus addresses |
| Programmability | any logical variable, contact, or virtual input               |

#### 3.3.4 FLEXELEMENTS

| FLEXELEMENTS             |                                                             |
|--------------------------|-------------------------------------------------------------|
| Number of elements:      | 16                                                          |
| Operating signal         | any analog actual value, or two values in differential mode |
| Operating signal mode    | signed or absolute value                                    |
| Operating mode           | level, delta                                                |
| Comparator direction     | over, under                                                 |
| Pickup level             | –90.000 to 90.000 pu in steps of 0.001                      |
| Hysteresis               | 0.1 to 50.0% in steps of 0.1                                |
| Delta dt                 | 20 ms to 60 days                                            |
| Pickup and dropout delay | 0.000 to 65.535 s in steps of 0.001                         |



### 3.3.5 NON-VOLATILE LATCHES

| NON-VOLATILE LATCHES |                                                      |
|----------------------|------------------------------------------------------|
| Type                 | set-dominant or reset-dominant                       |
| Number               | 16 (individually programmed)                         |
| Output               | stored in non-volatile memory                        |
| Execution sequence   | as input prior to protection, control, and FlexLogic |

### 3.3.6 USER-PROGRAMMABLE LEDS

| USER-PROGRAMMABLE LEDs (Enhanced and basic front panels) |                                                      |
|----------------------------------------------------------|------------------------------------------------------|
| Number:                                                  | 48 plus trip and alarm                               |
| Programmability                                          | from any logical variable, contact, or virtual input |
| Reset mode                                               | self-reset or latched                                |

### 3.3.7 LED TEST

| LED TEST              |                                                       |
|-----------------------|-------------------------------------------------------|
| Initiation            | from any contact input or user-programmable condition |
| Number of tests       | 3, interruptible at any time                          |
| Duration of full test | approximately 3 minutes                               |
| Test sequence 1       | all LEDs on                                           |
| Test sequence 2       | all LEDs off, one LED at a time on for 1 s            |
| Test sequence 3       | all LEDs on, one LED at a time off for 1 s            |

### 3.3.8 USER-DEFINABLE DISPLAYS

| USER-DEFINABLE DISPLAYS (Enhanced and basic front panels) |                                                                   |
|-----------------------------------------------------------|-------------------------------------------------------------------|
| Number of displays                                        | 16                                                                |
| Lines of display                                          | 2 × 20 alphanumeric characters                                    |
| Parameters                                                | up to 5, any Modbus register addresses                            |
| Invoking and scrolling                                    | keypad, or any user-programmable condition, including pushbuttons |

### 3.3.9 CONTROL PUSHBUTTONS

| CONTROL PUSHBUTTONS (Enhanced and basic front panels) |                          |
|-------------------------------------------------------|--------------------------|
| Number of pushbuttons                                 | 7                        |
| Operation                                             | drive FlexLogic operands |

### 3.3.10 USER-PROGRAMMABLE PUSHBUTTONS

| CONTROL PUSHBUTTONS (Enhanced and basic front panels) |                                                                                                                                                                                                    |
|-------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Number of pushbuttons                                 | 12 on basic front panel<br>16 on enhanced horizontal front panel<br>6 on enhanced vertical front panel<br>48 on graphical front panel (8 physical pushbuttons, 40 graphical interface pushbuttons) |
| Mode                                                  | self-reset, latched                                                                                                                                                                                |

**CONTROL PUSHBUTTONS (Enhanced and basic front panels)**

|                 |                                  |
|-----------------|----------------------------------|
| Display message | 2 lines of 20 characters each    |
| Drop-out timer  | 0.00 to 60.00 s in steps of 0.05 |
| Autoreset timer | 0.2 to 600.0 s in steps of 0.1   |
| Hold timer      | 0.0 to 10.0 s in steps of 0.1    |

**3.3.11 SELECTOR SWITCH****SELECTOR SWITCH**

|                      |                                                                                                |
|----------------------|------------------------------------------------------------------------------------------------|
| Number of elements   | 2                                                                                              |
| Upper position limit | 1 to 7 in steps of 1                                                                           |
| Selecting mode       | time-out or acknowledge                                                                        |
| Time-out timer       | 3.0 to 60.0 s in steps of 0.1                                                                  |
| Control inputs       | step-up and 3-bit                                                                              |
| Power-up mode        | restore from non-volatile memory or synchronize to a 3-bit control input or synch/restore mode |

**3.3.12 DIGITAL ELEMENTS****DIGITAL ELEMENTS**

|                     |                                         |
|---------------------|-----------------------------------------|
| Number of elements: | 96                                      |
| Operating signal    | any FlexLogic operand                   |
| Pickup delay        | 0.000 to 999999.999 s in steps of 0.001 |
| Dropout delay       | 0.000 to 999999.999 s in steps of 0.001 |
| Timing accuracy     | ±3% or ±4 ms, whichever is greater      |

## 3.4 MONITORING

### 3.4.1 OSCILLOGRAPHY

| OSCILLOGRAPHY     |                                                                                                                                                                                                         |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Number of records | 3 to 64, configurable                                                                                                                                                                                   |
| Sampling rate     | 8, 16, 32, or 64 samples per power cycle, configurable                                                                                                                                                  |
| Triggers          | any FlexLogic operand, configurable                                                                                                                                                                     |
| Trigger position  | 0 to 100%, configurable                                                                                                                                                                                 |
| Recorded data     | raw AC input channels<br>up to 127 configured digital channels (+ 1 trigger operand), representing any FlexLogic operand<br>up to 32 configured analog channels, representing any measured analog value |
| Data storage      | in non-volatile memory                                                                                                                                                                                  |
| Format:           | COMTRADE IEEE C37.111 (1999 or 2013)                                                                                                                                                                    |

### 3.4.2 EVENT RECORDER

| EVENT RECORDER |                                     |
|----------------|-------------------------------------|
| Capacity       | 1024 events                         |
| Time-tag       | to 1 microsecond                    |
| Triggers       | any FlexLogic operand, configurable |
| Data storage   | in non-volatile memory              |

### 3.4.3 USER-PROGRAMMABLE FAULT REPORT

| FAULT REPORT         |                           |
|----------------------|---------------------------|
| Number of elements:  | 2                         |
| Pre-fault trigger:   | any FlexLogic operand     |
| Fault trigger:       | any FlexLogic operand     |
| Recorder quantities: | 32 (any FlexAnalog value) |

### 3.4.4 DATA LOGGER

| DATA LOGGER                                                     |                                                   |
|-----------------------------------------------------------------|---------------------------------------------------|
| Number of channels                                              | 1 to 16                                           |
| Parameters                                                      | any available analog actual value                 |
| Sampling rate                                                   | 15 to 3600000 ms in steps of 1                    |
| Trigger                                                         | any FlexLogic operand                             |
| Mode                                                            | continuous or triggered                           |
| Storage capacity: 1-second rate:<br>(NN is dependent on memory) | 01 channel for NN days<br>16 channels for NN days |

| DATA LOGGER                                                      |                                                   |
|------------------------------------------------------------------|---------------------------------------------------|
| Storage capacity: 60-minute rate:<br>(NN is dependent on memory) | 01 channel for NN days<br>16 channels for NN days |

## 3.5 METERING

### 3.5.1 RMS CURRENT: PHASE, NEUTRAL AND GROUND

| RMS CURRENT: PHASE, NEUTRAL, AND GROUND |                                                            |
|-----------------------------------------|------------------------------------------------------------|
| Accuracy at 0.1 to 2.0 × CT rating      | ±0.25% of reading or ±0.1% of rated (whichever is greater) |
| Accuracy at > 2.0 × CT rating           | ±1.0% of reading                                           |

### 3.5.2 RMS VOLTAGE

| VOLTAGE   |                                   |
|-----------|-----------------------------------|
| Accuracy: | ±0.5% of reading from 10 to 208 V |

### 3.5.3 REAL POWER (WATTS)

| REAL POWER (WATTS)                                             |                                                                   |
|----------------------------------------------------------------|-------------------------------------------------------------------|
| Accuracy at 0.1 to 1.5 x CT rating and 0.8 to 1.2 x VT rating: | ±1.0% of reading at $-1.0 \leq PF < -0.8$ and $0.8 < PF \leq 1.0$ |

### 3.5.4 REACTIVE POWER (VARs)

| REACTIVE POWER (VARs)                                          |                                             |
|----------------------------------------------------------------|---------------------------------------------|
| Accuracy at 0.1 to 1.5 x CT rating and 0.8 to 1.2 x VT rating: | ±1.0% of reading at $-0.2 \leq PF \leq 0.2$ |

### 3.5.5 APPARENT POWER (VA)

| APPARENT POWER (VA)                                            |                  |
|----------------------------------------------------------------|------------------|
| Accuracy at 0.1 to 1.5 x CT rating and 0.8 to 1.2 x VT rating: | ±1.0% of reading |

### 3.5.6 WATT-HOURS (POSITIVE AND NEGATIVE)

| WATT-HOURS (POSITIVE AND NEGATIVE) |                           |
|------------------------------------|---------------------------|
| Accuracy                           | ±2.0% of reading          |
| Range                              | ±0 to $1 \times 10^6$ MWh |
| Parameters                         | three-phase only          |
| Update rate                        | 50 ms                     |

### 3.5.7 VAR-HOURS (POSITIVE AND NEGATIVE)

| VAR-HOURS (POSITIVE AND NEGATIVE) |                             |
|-----------------------------------|-----------------------------|
| Accuracy                          | ±2.0% of reading            |
| Range                             | ±0 to $1 \times 10^6$ Mvarh |
| Parameters                        | three-phase only            |
| Update rate                       | 50 ms                       |

### 3.5.8 CURRENT HARMONICS

| CURRENT HARMONICS                 |                                                                                                                            |
|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| Harmonics (2nd to 25th harmonic): | per phase, displayed as a % of I(f1) (current fundamental frequency phasor)                                                |
| THD                               | per phase, displayed as a % of I(f1)                                                                                       |
| Accuracy Harmonics:               | with I(f1) 0.4 to 2.0 × CT rating: ±2% of reading or ±1% of 100%, whichever is greater                                     |
| Accuracy THD:                     | with I(f1) from 0.4 to 2.0 × CT rating: ±2% of reading or ±1% of 100% per each harmonic, whichever is greater              |
| Accuracy applies to:              | 2nd to 17th harmonic including THD with a regular CT/VT module                                                             |
|                                   | 2nd to 13th harmonic including THD with a Process Bus Module (order code 85, 86, 87) when anti-aliasing filter is enabled  |
|                                   | 2nd to 16th harmonic including THD with a Process Bus Module (order code 85, 86, 87) when anti-aliasing filter is disabled |
|                                   | 2nd to 15th harmonic including THD with a HardFiber Process Bus Module (order code 81)                                     |

### 3.5.9 VOLTAGE HARMONICS

| VOLTAGE HARMONICS                 |                                                                                                                            |
|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| Harmonics (2nd to 25th harmonic): | per phase, displayed as a % of V(f1) (voltage fundamental frequency phasor)                                                |
| THD                               | per phase, displayed as a % of V(f1)                                                                                       |
| Accuracy Harmonics:               | with V(f1) 25 to 208 V: ±2% of reading or ±1% of 100%, whichever is greater                                                |
| Accuracy THD:                     | with V(f1) 25 to 208 V: ±2% of reading or ±1% of 100% per each harmonic, whichever is greater                              |
| Accuracy applies to:              | 2nd to 25th harmonic including THD with a regular CT/VT module                                                             |
|                                   | 2nd to 10th harmonic including THD with a Process Bus Module (order code 85, 86, 87) when anti-aliasing filter is enabled  |
|                                   | 2nd to 16th harmonic including THD with a Process Bus Module (order code 85, 86, 87) when anti-aliasing filter is disabled |
|                                   | 2nd to 15th harmonic including THD with a HardFiber Process Bus Module (order code 81)                                     |

### 3.5.10 FREQUENCY

| FREQUENCY                                |                                                                   |
|------------------------------------------|-------------------------------------------------------------------|
| Accuracy for input at V = 0.8 to 1.2 pu  | ±0.001 Hz (when voltage signal is used for frequency measurement) |
| Accuracy for input at I = 0.1 to 0.25 pu | ±0.02 Hz (when current signal is used for frequency measurement)  |
| Accuracy for input at I > 0.25 pu        | ±0.005 Hz (when current signal is used for frequency measurement) |

## 3.6 POWER SUPPLY

### 3.6.1 LOW RANGE

| LOW RANGE                                   |                                 |
|---------------------------------------------|---------------------------------|
| Nominal DC voltage                          | 24 to 48 V                      |
| Minimum DC voltage                          | 20 V                            |
| Maximum DC voltage                          | 75 V for SL power supply module |
| Voltage loss hold-up                        | 200 ms duration at maximum load |
| <i>Note:</i><br><i>Low range is DC only</i> |                                 |

### 3.6.2 HIGH RANGE

| HIGH RANGE           |                                 |
|----------------------|---------------------------------|
| Nominal DC voltage   | 125 to 250 V                    |
| Minimum DC voltage   | 88 V                            |
| Maximum DC voltage   | 300 V                           |
| Nominal AC voltage   | 100 to 240 V at 50/60 Hz        |
| Minimum AC voltage   | 88 V at 25 to 100 Hz            |
| Maximum AC voltage   | 265 V at 25 to 100 Hz           |
| Voltage loss hold-up | 200 ms duration at maximum load |

### 3.6.3 ALL RANGES

| ALL RANGES                                                              |                                       |
|-------------------------------------------------------------------------|---------------------------------------|
| Volt withstand                                                          | 2 × Highest Nominal Voltage for 10 ms |
| Power consumption typical                                               | 15 to 20 W/VA                         |
| Power consumption maximum                                               | 45 W/VA                               |
| <i>Note:</i><br><i>Contact factory for exact order code consumption</i> |                                       |

### 3.6.4 INTERNAL FUSE

| INTERNAL FUSE              |                           |
|----------------------------|---------------------------|
| Rating (low range)         | 8 A / 250 V               |
| Rating (high range)        | 4 A / 250 V               |
| Interrupting capacity (AC) | 100 000 A RMS symmetrical |
| Interrupting capacity (DC) | 10 000 A                  |

---

**3.6.5      SUPERCAPACITOR**

| Supercapacitor                   |                 |
|----------------------------------|-----------------|
| Hold-up time for real-time clock | 25 days at 25°C |



## 3.7 INPUTS

### 3.7.1 AC CURRENT

| AC CURRENT                                     |                                                                                                                                                           |
|------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| CT rated primary                               | 1 to 50000 A                                                                                                                                              |
| CT rated secondary                             | 1 or 5 A by connection                                                                                                                                    |
| Relay burden                                   | < 0.2 VA at rated secondary                                                                                                                               |
| Conversion range (Standard CT):                | 0.02 to 46 × CT rating RMS symmetrical                                                                                                                    |
| Conversion range (Sensitive Ground CT module): | 0.002 to 4.6 × CT rating RMS symmetrical                                                                                                                  |
| Current withstand:                             | 20 ms at 250 times rated<br>1 sec at 100 times rated<br>continuous 4x Inom<br>URs equipped with 24 CT inputs have a maximum operating temperature of 50°C |
| Short circuit rating                           | 150000 RMS symmetrical amperes, 250 V maximum (primary current to external CT)                                                                            |

### 3.7.2 AC VOLTAGE

| AC VOLTAGE         |                                                                |
|--------------------|----------------------------------------------------------------|
| VT rated secondary | 25.0 to 240.0 V                                                |
| VT ratio           | 1.00 to 24000.00                                               |
| Relay burden       | < 0.25 VA at 120 V                                             |
| Conversion range   | 1 to 275 V                                                     |
| Voltage withstand  | continuous at 260 V to neutral<br>1 min/hr at 420 V to neutral |

### 3.7.3 FREQUENCY

| FREQUENCY                         |                            |
|-----------------------------------|----------------------------|
| Nominal frequency setting         | 25 to 60 Hz                |
| Sampling frequency                | 64 samples per power cycle |
| Tracking frequency range with DSP | 3 to 70 Hz                 |

### 3.7.4 CONTACT INPUTS

| CONTACT INPUTS                               |                         |
|----------------------------------------------|-------------------------|
| Dry contacts                                 | 1000 Ω maximum          |
| Wet contacts                                 | 300 V DC maximum        |
| Selectable thresholds                        | 17 V, 33 V, 84 V, 166 V |
| Tolerance                                    | ±10%                    |
| Contacts per common return (standard module) | 4                       |
| Contacts per common return (6Y I/O module)   | 2                       |

| CONTACT INPUTS                            |                                |
|-------------------------------------------|--------------------------------|
| Recognition time                          | < 1 ms                         |
| Debounce time                             | 0.0 to 16.0 ms in steps of 0.5 |
| Continuous current draw (standard module) | 4 mA (when energized)          |
| Continuous current draw (6Y I/O module)   | 2 mA (when energized)          |

### 3.7.5 CONTACT INPUTS WITH AUTO-BURNISHING

| CONTACT INPUTS WITH AUTO-BURNISHING |                                |
|-------------------------------------|--------------------------------|
| Dry contacts                        | 1000 $\Omega$ maximum          |
| Wet contacts                        | 300 V DC maximum               |
| Selectable thresholds               | 17 V, 33 V, 84 V, 166 V        |
| Tolerance                           | $\pm 10\%$                     |
| Contacts per common return          | 2                              |
| Recognition time                    | < 1 ms                         |
| Debounce time                       | 0.0 to 16.0 ms in steps of 0.5 |
| Continuous current draw             | 4 mA (when energized)          |
| Auto-burnish impulse current        | 50 to 70 mA                    |
| Duration of auto-burnish impulse    | 25 to 50 mS                    |

### 3.7.6 DCMA INPUTS

| DCMA INPUTS           |                                                                              |
|-----------------------|------------------------------------------------------------------------------|
| Current input (mA DC) | 0 to -1, 0 to +1, -1 to +1, 0 to 5, 0 to 10, 0 to 20, 4 to 20 (programmable) |
| Input impedance       | 379 $\Omega \pm 10\%$                                                        |
| Conversion range      | -1 to + 20 mA DC                                                             |
| Accuracy              | $\pm 0.2\%$ of full scale                                                    |
| Type                  | Passive                                                                      |

### 3.7.7 RTD INPUTS

| RTD INPUTS      |                                                                        |
|-----------------|------------------------------------------------------------------------|
| Types (3-wire)  | 100 $\Omega$ Platinum, 100 and 120 $\Omega$ Nickel, 10 $\Omega$ Copper |
| Sensing current | 5 mA                                                                   |
| Range           | -50 to +250°C                                                          |
| Accuracy        | $\pm 2^\circ\text{C}$                                                  |
| Isolation       | 36 V pk-pk                                                             |

### 3.7.8 IRIG-B INPUT

| IRIG-B INPUT           |                          |
|------------------------|--------------------------|
| IRIG formats accepted: | B000...B007, B120...B127 |
| IRIG control bits      | IEEE Std C37.118.1-2011  |

| IRIG-B INPUT              |                 |
|---------------------------|-----------------|
| Amplitude modulation      | 1 to 10 V pk-pk |
| DC shift operating range: | 0 to 10 V DC    |
| TTL logic low             | 0.0 to 0.8 V DC |
| TTL logic high            | 2.0 to 5.0 V DC |
| Input impedance           | 50 k $\Omega$   |
| Isolation                 | 2 kV            |

### 3.7.9 DIRECT INPUTS

| DIRECT INPUTS                                      |                                                       |
|----------------------------------------------------|-------------------------------------------------------|
| Input points:                                      | 3264256                                               |
| Remote devices:                                    | 16                                                    |
| Default states on loss of comms:                   | On, Off, Latest/Off, Latest/On                        |
| Ring configuration:                                | Yes, No                                               |
| Data rate:                                         | 64 or 128 kbps                                        |
| CRC:                                               | 32-bit                                                |
| CRC alarm responding to:                           | Rate of messages failing the CRC                      |
| CRC alarm monitoring message count:                | 10 to 10000 in steps of 1                             |
| CRC alarm threshold:                               | 1 to 1000 in steps of 1                               |
| Unreturned message alarm responding to:            | Rate of unreturned messages in the ring configuration |
| Unreturned message alarm monitoring message count: | 10 to 10000 in steps of 1                             |
| Unreturned message alarm threshold:                | 1 to 1000 in steps of 1                               |

### 3.7.10 TELEPROTECTION

| TELEPROTECTION                   |                                |
|----------------------------------|--------------------------------|
| Input points:                    | 16                             |
| Remote devices:                  | 3                              |
| Default states on loss of comms: | On, Off, Latest/Off, Latest/On |
| Ring configuration:              | No                             |
| Data rate:                       | 64 or 128 kbps                 |
| CRC:                             | 32-bit                         |

## 3.8 OUTPUTS

### 3.8.1 FORM-A RELAY

| FORM-A RELAY                                     |                                                                 |
|--------------------------------------------------|-----------------------------------------------------------------|
| Make and carry for 0.2 s                         | 30 A as per ANSI C37.90                                         |
| Carry continuous                                 | 6 A                                                             |
| Break (DC inductive, L/R = 40 ms)                | 1 A at 24V<br>0.5 A at 48 V<br>0.3 A at 125 V<br>0.2 A at 250 V |
| Operate time                                     | < 4 ms                                                          |
| Contact material                                 | silver alloy                                                    |
| Contacts per common return (6Y I/O module)       | 2                                                               |
| Contacts with voltage monitoring (6Y I/O module) | 2                                                               |

| 6Y FORM-A VOLTAGE MONITOR |                        |
|---------------------------|------------------------|
| Applicable voltage        | approx. 15 to 250 V DC |
| Carry continuous          | approx. 2mA            |

### 3.8.2 LATCHING RELAY

| LATCHING RELAY                          |                                                                 |
|-----------------------------------------|-----------------------------------------------------------------|
| Make and carry for 0.2 s                | 30 A as per ANSI C37.90                                         |
| Carry continuous                        | 6 A as per IEEE C37.90                                          |
| Break (DC resistive as per IEC 61810-1) | 6 A at 24V<br>1.6 A at 48 V<br>0.4 A at 125 V<br>0.2 A at 250 V |
| Operate time                            | 6ms (Typical) <10ms (maximum)                                   |
| Contact material                        | Silver alloy                                                    |
| Control                                 | Separate operate and reset inputs                               |
| Control mode                            | Operate-dominant or reset-dominant                              |

### 3.8.3 FORM-A MONITORS

| FORM-A MONITORS               |                        |
|-------------------------------|------------------------|
| <b>FORM-A VOLTAGE MONITOR</b> |                        |
| Applicable voltage            | approx. 15 to 250 V DC |
| Trickle current               | approx. 1 to 2.5 mA    |
| <b>FORM-A CURRENT MONITOR</b> |                        |
| Threshold current             | approx. 80 to 100 mA   |

### 3.8.4 FORM-C AND CRITICAL FAILURE RELAY

| FORM-A RELAY             |                         |
|--------------------------|-------------------------|
| Make and carry for 0.2 s | 30 A as per ANSI C37.90 |

| FORM-A RELAY                      |                                                                 |
|-----------------------------------|-----------------------------------------------------------------|
| Carry continuous                  | 8 A                                                             |
| Break (DC inductive, L/R = 40 ms) | 1 A at 24V<br>0.5 A at 48 V<br>0.3 A at 125 V<br>0.2 A at 250 V |
| Operate time                      | < 8 ms                                                          |
| Contact material                  | silver alloy                                                    |

### 3.8.5 FAST FORM-C RELAY

| FORM-A RELAY                                                                                                        |                                                                                                             |
|---------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|
| Make and carry                                                                                                      | 0.1A max (resistive load)                                                                                   |
| Minimum load impedance (2 W resistor)                                                                               | 20 K $\Omega$ at 250 V DC<br>5 K $\Omega$ at 120 V DC<br>2 K $\Omega$ at 48 V DC<br>2 K $\Omega$ at 24 V DC |
| Minimum load impedance (1 W resistor)                                                                               | 50 K $\Omega$ at 250 V DC<br>2 K $\Omega$ at 120 V DC<br>2 K $\Omega$ at 48 V DC<br>2 K $\Omega$ at 24 V DC |
| <i>Note:</i><br>Values for 24 V and 48 V are the same due to a required 95% voltage drop across the load impedance. |                                                                                                             |
| Operate time                                                                                                        | < 0.6 ms                                                                                                    |
| Internal Limiting Resistor                                                                                          | 100 $\Omega$ , 2 W                                                                                          |

### 3.8.6 SOLID-STATE OUTPUT RELAY

| SOLID-STATE OUTPUT RELAY                                                         |                          |
|----------------------------------------------------------------------------------|--------------------------|
| Operate and release time                                                         | <100 $\mu$ s             |
| Maximum voltage                                                                  | 265 V DC                 |
| Maximum leakage current in off state (excluding voltage monitor circuit current) | 100 $\mu$ A              |
| Maximum continuous current                                                       | 5 A at 45°C; 4 A at 65°C |
| Make and carry (for 0.2 s)                                                       | 30 A as per ANSI C37.90  |
| Make and carry (for 0.03 s)                                                      | 300 A                    |

#### Breaking Capacity

| Specification           | UL 508                                                 | Utility application<br>(autoreclose scheme)                             | Industrial application                                 |
|-------------------------|--------------------------------------------------------|-------------------------------------------------------------------------|--------------------------------------------------------|
| Operations per interval | 5000 operations,<br>1 second on,<br>9 seconds off      | 5 operations,<br>0.2 seconds on,<br>0.2 seconds off,<br>within 1 minute | 10000 operations,<br>0.2 seconds on,<br>30 seconds off |
|                         | 1000 operations,<br>0.5 seconds on,<br>0.5 seconds off |                                                                         |                                                        |

| Specification                    | UL 508               | Utility application<br>(autoreclose scheme) | Industrial application |
|----------------------------------|----------------------|---------------------------------------------|------------------------|
| Break capability (0 to 250 V DC) | 3.2 A at L/R = 10 ms | 10 A at L/R = 40 ms                         | 10 A at L/R = 40 ms    |
|                                  | 1.6 A at L/R = 20 ms |                                             |                        |
|                                  | 0.8 A<br>L/R = 40 ms |                                             |                        |

### 3.8.7 CONTROL POWER EXTERNAL OUTPUT

| CONTROL POWER EXTERNAL OUTPUT (For dry contact input) |                      |
|-------------------------------------------------------|----------------------|
| Capacity                                              | 100 mA DC at 48 V DC |
| Isolation                                             | ±300 Vpk             |

### 3.8.8 DIRECT OUTPUTS

| DIRECT OUTPUTS |         |
|----------------|---------|
| Output points  | 3264356 |

### 3.8.9 DCMA OUTPUTS

| DCMA OUTPUTS                                 |                                                                                                                                   |
|----------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| Range                                        | –1 to 1 mA, 0 to 1 mA, 4 to 20 mA                                                                                                 |
| Max. load resistance                         | 12 kΩ for –1 to 1 mA range<br>12 kΩ for 0 to 1 mA range<br>600 Ω for 4 to 20 mA range                                             |
| Accuracy:                                    | ±0.75% of full-scale for 0 to 1 mA range<br>±0.5% of full-scale for –1 to 1 mA range<br>±0.75% of full-scale for 0 to 20 mA range |
| 99% Settling time to a step change           | 100 ms                                                                                                                            |
| Isolation                                    | 1.5 kV                                                                                                                            |
| Driving signal                               | any FlexAnalog quantity                                                                                                           |
| Upper and lower limit for the driving signal | –90 to 90 pu in steps of 0.001                                                                                                    |

## 3.9 COMMUNICATION PROTOCOLS

| IEC 61850 |                                                                                                                 |
|-----------|-----------------------------------------------------------------------------------------------------------------|
| IEC 61850 | Supports IEC 61850 Editions 1.0 and 2.0. See the UR Family Communications Guide and its conformance statements. |

| RS232 (Enhanced and basic front panels) |                       |
|-----------------------------------------|-----------------------|
| Front port                              | 19.2 kbps, Modbus RTU |

| USB (Graphical front panel) |                |
|-----------------------------|----------------|
| Front port                  | USB 2.0 type B |

| RS485            |                                                    |
|------------------|----------------------------------------------------|
| 1 rear port      | up to 115 kbps, Modbus RTU, DNP 3, IEC 60870-5-103 |
| Typical distance | 1200 m                                             |
| Isolation        | 2 kV, isolated together at 36 Vpk                  |

| FIBER ETHERNET PORT                                               |         |
|-------------------------------------------------------------------|---------|
| Operates with 50/125 $\mu$ m and 62.5/125 $\mu$ m multimode fiber |         |
| <b>Parameters (100 Mb multimode)</b>                              |         |
| Wavelength                                                        | 1310 nm |
| Connector                                                         | LC      |
| Transmit power                                                    | −20 dBm |
| Receiver sensitivity                                              | −30 dBm |
| Power budget                                                      | 10 dB   |
| Maximum input power                                               | −14 dBm |
| Typical distance                                                  | 2 km    |
| Full duplex                                                       | yes     |
| Redundancy                                                        | yes     |

| ETHERNET   |                                            |
|------------|--------------------------------------------|
| Modes      | 10 Mb, 10/100 Mb (auto-detect)             |
| Connector  | RJ45                                       |
| Cable type | CAT 5 or CAT 6 Shielded twisted Pair (STP) |

| SIMPLE NETWORK TIME PROTOCOL (SNTP) |                  |
|-------------------------------------|------------------|
| Clock synchronization error         | <10 ms (typical) |

| PRECISION TIME PROTOCOL (PTP) PTP IEEE Std 1588-2008 (version 2) |                                    |
|------------------------------------------------------------------|------------------------------------|
| Power Profile (PP)                                               | as per IEEE Standard PC37.238-2017 |

**PRECISION TIME PROTOCOL (PTP) PTP IEEE Std 1588-2008 (version 2)**

|       |                                                                                                                                  |
|-------|----------------------------------------------------------------------------------------------------------------------------------|
| Clock | Slave-only ordinary clock when using station bus Ethernet interface.<br>Boundary clock when using process bus Ethernet interface |
|-------|----------------------------------------------------------------------------------------------------------------------------------|

**PARALLEL REDUNDANCY PROTOCOL (PRP) (IEC 62439-3 CLAUSE 4, 2012)**

|                     |                    |
|---------------------|--------------------|
| Ethernet ports used | 2 and 3            |
| Networks supported  | 10/100 Mb Ethernet |

**PROCESS BUS MODULE (NON-HARDFIBER)**

|                                       |                                                                                                                                                                         |
|---------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Ethernet ports                        | 2 x 1000Base-SX, 1 Gbps LC connectors,<br>4 x 1000Base-SX (1 Gbps) + 4 x 100Base-FX (100 Mbps) LC connectors<br>4 x 100Base-FX, LC connectors                           |
| Number of sampled value (SV) streams: | Up to 8                                                                                                                                                                 |
| SV subscription profiles              | IEC 61850-9-2LE (1 ASDU only) or IEC 61869-9 (1 or 2 ASDUs)                                                                                                             |
| <b>Sampling Rate</b>                  |                                                                                                                                                                         |
| IEC 61850-9-2                         | 4800 Hz (80 samples/cycle) fixed for 60 Hz - Protection class<br>4000 Hz (80 samples/cycle) fixed for 50 Hz - Protection class                                          |
| IEC 61869-9                           | 4800 Hz for 60/50 Hz - Protection class                                                                                                                                 |
| GOOSE support                         | P1 class 1 TxGOOSE, and 8 RxGOOSE                                                                                                                                       |
| Network Config modes:                 | IEC 62439-3:2012 PRP (ports 1 and 2)<br>IEC 62439-3:2012 HSR (ports 1 and 2)<br>IEC 62439-3:2012<br>Dual HSR (ports 1 and 2, 5 and 6); or Point-to-Point (ports 1 to 8) |
| Time synchronization                  | IEC 61850-9-3 PTPv2 Utility profile<br>PTPv2/PP (IEEE C37.238-2017 over Process Bus Module<br>PTPv2/PP (IEEE C37.238-2017; or IRIG-B over CPU for PTP master            |
| Time synchronization mode:            | Slave-only, master-slave on Process Bus Module, and slave-only on CPU                                                                                                   |
| Simulation mode:                      | Supported for both GOOSE and SV                                                                                                                                         |
| Test mode (test, test/block)          | Supported for both GOOSE and SV                                                                                                                                         |
| <b>OTHER</b>                          |                                                                                                                                                                         |
| Other protocols                       | TFTP, SFTP, HTTP, IEC 60870-5-104, Ethernet Global Data (EGD), IEEE C37.118                                                                                             |



## 3.10 INTER-RELAY COMMUNICATIONS

### 3.10.1 STP INTERFACE OPTIONS

| SHIELDED TWISTED-PAIR INTERFACE OPTIONS                                                                                                        |                  |
|------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| Interface type                                                                                                                                 | Typical distance |
| RS422                                                                                                                                          | 1200 m           |
| <i>Note:</i><br><i>RS422 distance is based on transmitter power and does not take into consideration the clock source provided by the user</i> |                  |

### 3.10.2 LINK POWER BUDGET AND MAXIMUM OPTICAL INPUT POWER

#### LINK POWER BUDGET AND MAXIMUM OPTICAL INPUT POWER

| Emitter, fiber type         | Cable type             | Transmit power | Received sensitivity | Power budget | Maximum optical input power |
|-----------------------------|------------------------|----------------|----------------------|--------------|-----------------------------|
| 820 nm, multimode           | 62.5/125 $\mu\text{m}$ | -16 dBm        | -32 dBm              | 16 dBm       | -8 dBm                      |
|                             | 50/125 $\mu\text{m}$   | -20 dBm        |                      | 12 dBm       |                             |
| 1300 nm, multimode          | 62.5/125 $\mu\text{m}$ | -16 dBm        | -32 dBm              | 16 dBm       | -8 dBm                      |
|                             | 50/125 $\mu\text{m}$   | -20 dBm        |                      | 12 dBm       |                             |
| 1300 nm, single mode        | 9/125 $\mu\text{m}$    | -15 dBm        | -32 dBm              | 17 dBm       | -8 dBm                      |
| 1300 nm, laser, single mode | 9/125 $\mu\text{m}$    | 0 dBm          | -34 dBm              | 34 dBm       | -8 dBm                      |
| 1550 nm, laser single mode  | 9/125 $\mu\text{m}$    | 5 dBm          | -34 dBm              | 39 dBm       | -10 dBm                     |

The following specifications apply to filter interface modules implemented before January 2012:

| Emitter, fiber type        | Transmit power | Received sensitivity | Power budget | Maximum optical input power |
|----------------------------|----------------|----------------------|--------------|-----------------------------|
| 820 nm LED, multimode      | -20 dBm        | -30 dBm              | 10 dB        | -7.6 dBm                    |
| 1300 nm LED, multimode     | -21 dBm        | -30 dBm              | 9 dB         | -11 dBm                     |
| 1300 nm ELED, single mode  | -23 dBm        | -32 dBm              | 9 dB         | -14 dBm                     |
| 1300 nm Laser, single mode | -1 dBm         | -30 dBm              | 29 dB        | -14 dBm                     |
| 1550 nm Laser, single mode | +5 dBm         | -30 dBm              | 35 dB        | -14 dBm                     |

*Note:*

*The power budgets are calculated from the manufacturer's worst-case transmitter power and worst case receiver sensitivity.*

**Note:**

The power budgets for the 1300 nm ELED are calculated from the manufacturer's transmitter power and receiver sensitivity at ambient temperature. At extreme temperatures these values deviate based on component tolerance. On average, the output power decreases as the temperature is increased by a factor of 1 dB / 5 °C.

**3.10.3 TYPICAL LINK DISTANCE**

| Emitter, fiber type        | Cable type  | Connector type | Typical distance |               |
|----------------------------|-------------|----------------|------------------|---------------|
|                            |             |                | Before Jan 2012  | From Jan 2012 |
| 820 nm LED, multimode      | 62.5/125 µm | ST             | 1.65 km          | 2 km          |
|                            | 50/125 µm   | ST             | 1.65 km          | 2 km          |
| 1300 nm LED, multimode     | 62.5/125 µm | ST             | 4 km             | 5 km          |
|                            | 50/125 µm   | ST             | 4 km             | 5 km          |
| 1300 nm ELED, single mode  | 9/125 µm    | ST             | 11.4 km          | 20 km         |
| 1300 nm laser, single mode | 9/125 µm    | ST             | 64 km            | 65 km         |
| 1550 nm laser, single mode | 9/125 µm    | ST             | 105 km           | 125 km        |

**Note:**

Typical distances listed are based on the following assumptions for system loss. As actual losses vary from one installation to another, the distance covered by your system can vary.

**3.10.4 LOSSES AND MARGIN**

| CONNECTOR LOSSES (Total at both ends) |               |
|---------------------------------------|---------------|
| ST connector                          | 0.7 dB (each) |

| FIBER LOSSES        |                                                  |
|---------------------|--------------------------------------------------|
| 820 nm multimode    | 3 dB/km                                          |
| 1300 nm multimode   | 1 dB/km                                          |
| 1300 nm single mode | 0.35 dB/km                                       |
| 1550 nm single mode | 0.25 dB/km                                       |
| Splice losses       | one splice every 2 km at 0.05 dB loss per splice |

| SYSTEM MARGIN                                                                                                      |       |
|--------------------------------------------------------------------------------------------------------------------|-------|
| Additional loss added to calculations to compensate for all other losses                                           | 3 dB  |
| Compensated difference in transmitting and receiving (channel asymmetry) channel delays using GPS satellite clock: | 10 ms |

3.11 CYBERSENTRY SECURITY

| OPTIONS          |                  |
|------------------|------------------|
| Software options | Level 1, Level 2 |

## 3.12 GRAPHICAL FRONT PANEL

| DISPLAY            |                                                                                                                                                                                                                                                                                                                                                                               |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Type               | Color graphical back-lit LCD display                                                                                                                                                                                                                                                                                                                                          |
| Size               | 7 inches (17.8 cm)                                                                                                                                                                                                                                                                                                                                                            |
| Resolution         | 800 by 480 pixels                                                                                                                                                                                                                                                                                                                                                             |
| Pages              | 5 single-line diagram pages with controls, status, and metering values<br>Up to 8 annunciator pages with total of 96 annunciator windows<br>1 phasor metering page for each AC Source<br>5 tabular metering pages with dynamic metering and status<br>Event records page with dynamic update<br>Product information page<br>Settings, actual values, error messages (targets) |
| LED INDICATORS     |                                                                                                                                                                                                                                                                                                                                                                               |
| Functions          | 5 device status indicators<br>9 event cause indicators<br>8 user-programmable pushbutton indicators                                                                                                                                                                                                                                                                           |
| PUSHBUTTONS        |                                                                                                                                                                                                                                                                                                                                                                               |
| Type               | membrane                                                                                                                                                                                                                                                                                                                                                                      |
| Functions          | 5 bottom Tab pushbuttons and 1 Home pushbutton for page recall<br>4 directional, 1 ENTER, and 1 ESCAPE pushbutton element selection<br>10 side pushbuttons for power system element control<br>RESET pushbutton                                                                                                                                                               |
| INGRESS PROTECTION |                                                                                                                                                                                                                                                                                                                                                                               |
| IP code            | IP40 front (IP54 front with IP54 mounting collar accessory)<br>IP10 back (IP20 back with IP20 cover accessory)                                                                                                                                                                                                                                                                |

### 3.13 ENVIRONMENTAL

| AMBIENT TEMPERATURES                                                                                                                                                                                                                                                                         |              |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------|
| Maximum operating range                                                                                                                                                                                                                                                                      | –40 to 85°C  |
| Continuous operating range                                                                                                                                                                                                                                                                   | –40 to 60°C* |
| <p><i>Note:</i><br/> <i>*Based on IEC 60068-2-1 and IEC 60068-2-2, Variant Bd and Ad for 16 hrs. The UR can operate up to a surrounding ambient of 85°C, however operating outside the recommended continuous temperature range for extended periods can result in MTBF degradation.</i></p> |              |
| <p><i>Note:</i><br/> <i>LCD contrast and performance will degrade below -20C. Contrast and performance will return to normal once temperature returns above -20C.</i></p>                                                                                                                    |              |
| Ideal Storage Temperature Range                                                                                                                                                                                                                                                              | 15°C to 27°C |

| HUMIDITY                           |                                                                                        |
|------------------------------------|----------------------------------------------------------------------------------------|
| Humidity                           | Operating up to 95% (non-condensing) at 55°C (as per IEC 60068-2-30 variant 1, 6 days) |
| Ideal Storage Humidity Range       | 30% to 60%                                                                             |
| Relative Humidity (RH) Air Quality | Proper ventilation is recommended                                                      |

| OTHER                                        |                                                                                                                                                                                                                  |
|----------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Altitude                                     | 2000 m (maximum)                                                                                                                                                                                                 |
| Pollution degree                             | II                                                                                                                                                                                                               |
| Overvoltage category                         | II                                                                                                                                                                                                               |
| Ingress protection                           | IP20 front, IP10 back (basic front panel and Rev. 1 enhanced front panel)<br>IP40 front, IP10 back (Rev. 2 enhanced front panel)<br>IP54 front with IP54 mounting collar accessory (Rev. 2 enhanced front panel) |
| Ingress protection with IP20 cover accessory | IP20 back                                                                                                                                                                                                        |
| Noise                                        | 0 dB                                                                                                                                                                                                             |

## 3.14 TYPE TESTS

| Test                                | Reference standard               | Test level                                                                                                                                           |
|-------------------------------------|----------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| Dielectric voltage withstand        | EN 60255-5*                      | 2.2 kV                                                                                                                                               |
| Impulse voltage withstand           | EN 60255-51*                     | 5 kV                                                                                                                                                 |
| Damped oscillatory                  | IEC 61000-4-18 / IEC 60255-26-1  | 2.5 kV CM, 1 kV DM                                                                                                                                   |
| Electrostatic discharge             | EN 61000-4-2 / IEC 60255-26-2    | Level 3                                                                                                                                              |
| RF immunity                         | EN 61000-4-3 / IEC 60255-26-3    | Level 3                                                                                                                                              |
| Fast transient disturbance          | EN 61000-4-4 / IEC 60255-26-4    | Class A and B                                                                                                                                        |
| Surge immunity                      | EN 61000-4-5 / IEC 60255-26-5    | Level 3 and 4                                                                                                                                        |
| Conducted RF immunity               | EN 61000-4-6 / IEC 60255-26-6    | Level 3                                                                                                                                              |
| Power frequency immunity            | EN 61000-4-7* / IEC 60255-26-7   | Class A and B                                                                                                                                        |
| Voltage interruption and ripple DC  | IEC 60255-11                     | 12% ripple, 200 ms interrupts                                                                                                                        |
| Radiated and conducted emissions    | CISPR11 / CISPR22 / IEC 60255-25 | Class A                                                                                                                                              |
| Sinusoidal vibration                | IEC 60255-21-1                   | Class 1                                                                                                                                              |
| Shock and bump                      | IEC 60255-21-2                   | Class 1                                                                                                                                              |
| Seismic                             | IEC 60255-21-3                   | Class 1                                                                                                                                              |
| Power magnetic immunity             | IEC 61000-4-8                    | Level 5                                                                                                                                              |
| Pulse magnetic immunity             | IEC 61000-4-9                    | Level 4                                                                                                                                              |
| Damped magnetic immunity            | IEC 61000-4-10                   | Level 4                                                                                                                                              |
| Voltage dip and interruption        | IEC 61000-4-11                   | 0, 40, 70, 80% dips; 250 / 300 cycle interrupts                                                                                                      |
| Damped oscillatory                  | IEC 61000-4-12*                  | 2.5 kV CM, 1 kV DM                                                                                                                                   |
| Conducted RF immunity, 0 to 150 kHz | IEC 61000-4-16                   | Level 4                                                                                                                                              |
| Voltage ripple                      | IEC 61000-4-17                   | 15% ripple                                                                                                                                           |
| Ingress protection                  | IEC 60529*                       | IP20 front, IP10 back                                                                                                                                |
| Cold                                | IEC 60068-2-1                    | −40°C for 16 hours                                                                                                                                   |
| Hot                                 | IEC 60068-2-2                    | 85°C for 16 hours                                                                                                                                    |
| Humidity                            | IEC 60068-2-30                   | 6 days, variant 1                                                                                                                                    |
| Damped oscillatory                  | IEEE/ANSI C37.90.1               | 2.5 kV, 1 MHz                                                                                                                                        |
| RF immunity                         | IEEE/ANSI C37.90.2               | 20 V/m, 80 MHz to 1 GHz                                                                                                                              |
| Safety                              | UL 508                           | e83849 NKCR                                                                                                                                          |
|                                     |                                  | Section 43 - Temperature test<br>Energization of Contact Inputs and/or Contact Outputs for continuous duty is not to exceed a total of 31 W of power |
| Safety                              | UL C22.2-14                      | e83849 NKCR7                                                                                                                                         |
| Safety                              | UL 1053                          | e83849 NKCR                                                                                                                                          |
| Safety                              | IEC 60255-27                     | Insulation: class 1, Pollution degree: 2, Over voltage cat II                                                                                        |

\*Not tested by third party

### 3.15 PRODUCTION TESTS

| OPTIONS |                                                                                                        |
|---------|--------------------------------------------------------------------------------------------------------|
| Thermal | Products go through an environmental test based upon an Accepted Quality Level (AQL) sampling process. |

## 3.16 APPROVALS

| Compliance | Applicable council directive | According to           |
|------------|------------------------------|------------------------|
| CE         | Low voltage directive        | EN 60255-5             |
|            | EMC directive                | EN 60255-26 / EN 50263 |
|            |                              | EN 61000-6-5           |
| C-UL-US    | ---                          | UL 508                 |
|            |                              | UL 1053                |
|            |                              | C22.2 No. 14           |



---

## 3.17 MAINTENANCE

---

### MOUNTING

Attach mounting brackets using 2.3 Nm  $\pm$ 0.23 Nm of torque (20 inch-pounds  $\pm$ 2 inch-pounds).

### CLEANING

Normally, cleaning is not required. When dust has accumulated on the front panel display, wipe with a dry cloth.

*Note:*

*To avoid deterioration of electrolytic capacitors, power up units that are stored in a de-energized state once per year, for one hour continuously*

## CHAPTER 4

# INSTALLATION

---

## 4.1 CHAPTER OVERVIEW

---

This chapter contains the following sections:

|                                                |     |
|------------------------------------------------|-----|
| Chapter Overview                               | 63  |
| Unpack and inspect                             | 64  |
| Panel cutouts                                  | 65  |
| Rear terminal layout                           | 74  |
| Wiring                                         | 77  |
| Inter-relay communications                     | 103 |
| Activate relay                                 | 118 |
| Software installation                          | 119 |
| Add device to software                         | 121 |
| Connect to the relay                           | 129 |
| Set up CyberSentry and change default password | 132 |
| Import settings                                | 133 |
| Connect to substation gateway                  | 138 |

---

## 4.2 UNPACK AND INSPECT

---

1. Open the package and check that the following items have been delivered along with the device itself:
  - a. Mounting screws
  - b. Certificate of Calibration
  - c. Test Report
  - d. EC Declaration of Conformity
  - e. Front panel label package
2. Inspect the device for physical damage.
3. View the rear nameplate and verify that the correct model has been delivered. The model order code is at the top right of the nameplate.
4. For any issues, contact GE as outlined in the For Further Assistance section in chapter 1.

Instruction manuals and software are not normally delivered with the device. You will need to download all relevant documentation and software from the GE website, unless you have specifically ordered printed copies of the documentation. You will need the following:

- GE Vernova EnerVista™ software and documentation
- Instruction Manual
- UR Family Communications Guide

**Note:**

*The instruction manual outlines how to install, configure, and use the unit.*

**Note:**

*The communications guide is for advanced use with communication protocols.*

**Note:**

*The warranty is included at the end of this instruction manual and on the GE Vernova website.*

---

## 4.3 PANEL CUTOUTS

---

This section does not apply to the HardFiber products. Please see the dedicated instruction manual for further information.

Install the relay in an indoor environment within the environmental specifications. The relay complies with Pollution Category II, which means installation in an office, laboratory, or testing environment.

---

### 4.3.1 HORIZONTAL UNITS

The product is available as a 19-inch rack horizontal mount unit with a removable front panel. The front panel is specified as enhanced, basic, or graphical at the time of ordering. The enhanced and graphical front panels have additional user-programmable pushbuttons and LED indicators, while the basic front panel has additional user-programmable pushbuttons.

The modular design allows the relay to be upgraded and repaired by qualified service personnel. The front panel is hinged to allow access to the modules. The front panel is itself removable to allow mounting on doors with limited rear depth and for upgrading.

The enhanced horizontal front panel is also referred to as the IP54 Front Panel or Enhanced Front Panel Rev. 2. This panel uses a screw instead of a knob to close the panel. It conforms to an IP54 rating with the IP54 mounting collar purchased separately. The IP54 mounting collar can be used in panel-mount installations, not 19-inch rack-mount installations. The IP54 mounting collar cannot be used with Rev. 1 enhanced front panels.

The case dimensions are shown in the following figures, along with panel cutout details for panel mounting. When planning the location of your panel cutout, ensure that provision is made for the front panel to swing open without interference to or from adjacent equipment.

Mount the relay such that the front panel sits semi-flush with the panel or switchgear door, allowing the operator access to the keypad and the front communications port.




Figure 5: Horizontal dimensions (Rev. 1 enhanced front panel)




Figure 6: Horizontal dimensions (Rev. 2 enhanced front panel)




Figure 7: Horizontal mounting (enhanced and graphical front panels)




Figure 8: Horizontal dimensions and mounting (basic front panel)





Figure 9: Horizontal dimensions (graphical front panel)





NOTES

1. INSPECT THE COLLAR BEFORE INSTALLATION, VERIFY GASKET IS ADHERED TO THE METAL ON ALL SIDES
2. MAKE SURE THE RELAY IS POSITIONED CENTER TO THE CUT OUT
3. INSTALL IP-54 COLLAR, CONFIRM THE GASKET PROPERLY MATES WITH THE PANEL ON ALL SIDES  
SECURE USING #8-32 HEX NUT AT 6 PLACES.

842497A1.cdr

**Figure 10: Horizontal dimensions (IP54 mounting collar)**


### 4.3.2 VERTICAL UNITS

The relay is also available as a reduced size ( $\frac{3}{4}$ ) vertical mount unit, with a removable front panel. The front panel is specified as enhanced or basic at the time of ordering. The enhanced front panel contains additional user-programmable pushbuttons and LED indicators, while the basic front panel has additional user-programmable pushbuttons.

The modular design allows the relay to be upgraded and repaired by qualified service personnel. The front panel is hinged to allow easy access to the modules. The front panel is itself removable to allow mounting on doors with limited rear depth and for upgrading.


The case dimensions are shown in the following figures, along with panel cutout details for panel mounting. When planning the location of your panel cutout, ensure that provision is made for the front panel to swing open without interference to or from adjacent equipment.

Mount the relay such that the front panel sits semi-flush with the panel or switchgear door, allowing the operator access to the keypad and the communications port.



843809A2.cdr

**Figure 11: Vertical dimensions and mounting (enhanced front panel)**




843755A4.CDR

**Figure 12: Vertical dimensions and mounting (basic front panel)**

For side-mounting devices with the enhanced front panel, see the following documents:


- GEK-113180 — UR-Series UR-V Side-Mounting Front Panel Assembly Instructions
- GEK-113181 — Connecting a Remote UR-V Enhanced Front Panel to a Vertical UR Device Instruction Sheet
- GEK-113182 — Connecting a Remote UR-V Enhanced Front Panel to a Vertically-Mounted Horizontal UR Device Instruction Sheet

For side-mounting devices with the basic front panel, use the following figures:



843757A2.cdr


Figure 13: Vertical side-mounting installation (basic front panel)



**Figure 14: Vertical side-mounting rear dimensions (basic front panel)**

## 4.4 REAR TERMINAL LAYOUT

The rear terminals depend on the order code. An example is shown here.



**Figure 15: Example of rear panel layout**



**Warning:**

Do not touch any rear terminals while the relay is energized, else death or serious injury can result from electrical shock.

**Note:**

Small form-factor pluggable ports (SFPs) are pluggable transceivers. They transmit, receive, and convert electrical signals to optical signals and vice-versa. Supplied with the device, they are inserted into the Ethernet ports on the CPU and/or Process Bus modules. A photo in the Maintenance chapter shows this plug-in device. Do not use non-validated transceivers or install validated transceivers in the wrong Ethernet slot, else damage can occur.


**Note:**

When using a copper SFP with a Process Bus Module, always use Shielded Twisted Pair Ethernet Cable. We recommend limiting the length of the cable to three meters (9.8 feet) and confining it within one bay/cubicle.

**Note:**

When using a Process Bus Module, to view if the SFP is 100 Mbps or 1 Gbps, enter the IP address of the device in a web browser and access **Process Card Menu > Process Card SFP Information**.

Terminal number assignments are three characters long and assigned by module slot position, row number, and column letter. Two-slot wide modules take their slot designation from the first slot position (nearest to CPU module), indicated by an arrow on the terminal block. The figure shows an example of rear terminal assignments.




842761A2.CDR

**Figure 16: Example of modules in F and H slots**

The torque used to connect the screws that connect the terminal blocks (top screws a, b, c) and the metal plates over empty slots to the chassis is 9 inch-pounds (1Nm). For the screws used to wire the terminal blocks (rows 1 to 8), use  $19 \pm 1$  inchpounds ( $2.1 \pm 0.1$  Nm).

The CPU module type depends on order code. During manufacturing, the power supply and CPU modules are installed in slots B and D of the chassis with 13 inch-pounds (1.47 Nm) of torque on the screws at the top and bottom of the modules. Wire connections to these two modules at 13 inch-pounds (1.47 Nm).



**Figure 17: CPU modules and power supply**

The following figure shows the optical connectors for CPU modules.



**Figure 18: LC fiber connector (left) and ST fiber connector (right)**

Speeds for the LC connections on non-HardFiber Process Bus Modules are as follows:

- Order code 85 — 1000Base-SX ports 1a and 1b, or ports 3a and 3b
- Order code 86 — 1000Base-SX ports 1a, 1b, 3a, 3b; 100Base-FX ports 2a, 2b, 4a, 4b
- Order code 87 — 100Base-FX ports 1a, 1b, 2a, 2b, 3a, 3b, 4a, 4b



# 4.5 WIRING

## 4.5.1 TYPICAL WIRING

For Sampled Value (SV) applications using a Process Bus Module (order code 85, 86, 87) with IIRIG-B for synchronization, follow the recommended cables and grounding connections outlined here and later.




Figure 19: Typical wiring diagram (T module shown for CPU)

## 4.5.2 DIELECTRIC STRENGTH

Dielectric strength is the maximum electric strength that can be sustained without breakdown. It is measured in volts.

The table shows the dielectric strength of the UR-series module hardware.

### Dielectric strength of UR modules

| Module type | Module function | Terminals              |         | Dielectric strength    |
|-------------|-----------------|------------------------|---------|------------------------|
|             |                 | From                   | To      |                        |
| 1           | Power supply    | High (+); Low (+); (-) | Chassis | 2000 V AC for 1 minute |

| Module type | Module function                | Terminals                                  |         | Dielectric strength    |
|-------------|--------------------------------|--------------------------------------------|---------|------------------------|
|             |                                | From                                       | To      |                        |
| 1           | Power supply                   | 48 V DC (+) and (–)                        | Chassis | 2000 V AC for 1 minute |
| 1           | Power supply                   | Relay terminals except terminals 8a and 8b | Chassis | 2000 V AC for 1 minute |
| 2           | Reserved                       | N/A                                        | N/A     | N/A                    |
| 3           | Reserved                       | N/A                                        | N/A     | N/A                    |
| 4           | Digital contact inputs/outputs | All                                        | Chassis | 2000 V AC for 1 minute |
| 5           | Analog inputs/outputs          | All except 8b                              | Chassis | < 50 V DC              |
| 6           | Digital contact inputs/outputs | All                                        | Chassis | 2000 V AC for 1 minute |
| 7           | RS422                          | All except 6a, 7b, 8a                      | Chassis | < 50 V DC              |
| 8           | CT/VT                          | All                                        | Chassis | 2000 V AC for 1 minute |
| 9           | CPU                            | All                                        | Chassis | 2000 V AC for 1 minute |

**Note:**

Filter networks and transient protection clamps are used in the hardware to prevent damage caused by high peak voltage transients, radio frequency interference (RFI), and electromagnetic interference (EMI). These protective components can be damaged by application of the ANSI/IEEE C37.90 specified test voltage for longer than the specified minute.

### 4.5.3 CONTROL POWER

Power supplied to the relay must be connected to the matching power supply range of the relay. If incorrect voltage is applied or voltage is applied to the wrong terminals, damage can occur.

The device contains electrolytic capacitors. These capacitors are well-known to deteriorate over time if voltage is not applied periodically. Deterioration can be avoided by powering up the relay at least once a year.

The power supply module is ordered with one of two possible voltage ranges, and the device can be ordered with or without a redundant power supply module option. Each range has a dedicated input connection for proper operation. The ranges are as follows:

- Low (LO) range — 24 to 48 V (DC only) nominal
- High (HI) range — 125 to 250 V nominal

The power supply module provides power to the relay and supplies power for dry contact input connections.

The SL and SH power supply modules also provide an auxiliary 48 V DC power for dry contact input connections and a critical failure relay. The critical failure relay is a form-C device that is energized once control power is applied and the relay has successfully booted up with no critical self-test failures. If ongoing self-test diagnostic checks detect a critical failure (see the Self-Test Errors section) or control power is lost, the relay de-energizes.

**Note:**

The TH and TL models do not have the auxiliary 48 V DC.

**Warning:**

Connect all wires at the back of a UR before connecting to power, else death or serious injury can result from electrical shock.

To connect power to the relay:

1. Locate the power supply module in the first slot, slot B, on the back of the device
2. Connect the three wires to the terminals, or connect two to the terminals and the third to the ground screw. 14 gauge stranded wire with disconnect devices is recommended. Use 13 inch-pounds torque.
3. Connect all wires to the relay before turning on power.

For high-reliability systems, the device has a redundant option in which two power supplies are placed in parallel on the bus. If one of the power supplies becomes faulted, the second power supply assumes the full load of the relay without any interruptions. Each power supply has a green LED on the front of the module to indicate that it is functional. The critical fail relay of the module also indicates a faulted power supply.

An LED on the front of the control power module shows the status of the power supply, as outlined in the table.

| LED indication | Power supply        |
|----------------|---------------------|
| Continuous on  | OK                  |
| On/off cycling | Failure             |
| Off            | Failure or no power |




Figure 20: Control power connection

#### 4.5.4 NON-VOLATILE DATA STORAGE

Non-volatile data is temporary data required after a power cycle for relay state, such as latch status before reboot. The relay saves this data in non-volatile storage every two minutes or when a state change occurs.

If a state change occurs just before a power down (less than two minutes) and the relay power is cycled, some temporary data can be saved and the prior state is retained at power up. Otherwise, a two-minute powered on period after a state change ensures that all temporary state changes required after reboot have been saved. A command also is available to initiate saving of data in the compact flash memory using [Commands > Relay Maintenance > Save Volatile Data](#).

#### 4.5.5 CT/VT MODULES

*Note:*

Verify that the connection made to the relay terminals for nominal current of 1 A or 5 A matches the secondary rating of the connected CTs. Unmatched CTs can result in equipment damage or inadequate protection.

The CT and VT inputs are analog current transformer and voltage transformer signals used to monitor AC power lines. The UR-series of relays support 1 A and 5 A CTs. A CT/VT module can have current or voltage inputs on channels 1 through 4 inclusive, or channels 5 through 8 inclusive. Channels 1, 2, 3 and 4 are intended for connection to phase A, B, C and another quantity respectively. The same applies for channels 5, 6, 7 and 8. Channels 4 and 8 are intended for connection to a single-phase source. For voltage inputs, these channels are labeled as auxiliary voltage (VX). For current inputs, these channels are intended for connection to a CT between system neutral and ground, and are labeled as ground current (IG).

Size 12 American Wire Gauge (AWG) is commonly used to connect to the module; the maximum size is 10 AWG.


CT/VT modules can be ordered with a standard ground current input that is the same as the phase current input. Each AC current input has an isolating transformer and an automatic shorting mechanism that shorts the input when the module is withdrawn from the chassis. There are no internal ground connections on the current inputs. Current transformers with 1 to 50000 A primaries and 1 A or 5 A secondaries can be used.

For some UR models, CT/VT modules with a sensitive ground input are also available. The ground CT input of the sensitive ground modules is 10 times more sensitive than the ground CT input of standard CT/VT modules. However, the phase CT inputs and phase VT inputs are the same as those of regular CT/VT modules.


CT/VT modules have enhanced diagnostics, which can automatically detect hardware failure and take the relay out of service. CT connections for both ABC and ACB phase rotations are identical, as shown in the Typical Wiring Diagram.

The phase voltage channels are used for most metering and protection purposes. The auxiliary voltage channel is used as input for the synchrocheck and volts-per-hertz features, which are optional features for some UR models.

When using a zero-sequence core balance CT to detect ground fault current, its placement is shown as follows. You should use twisted-pair cabling on a zero-sequence CT.



**Figure 21: Zero-sequence core balance CT installation**



842766A4.CDR

Figure 22: CT/VT module wiring

**Note:**  
 The tilde sign (~) represents the slot position, because this will be different for different configurations.

### 4.5.6 PROCESS BUS MODULE FOR HARDFIBER

The relay can be ordered with a process bus interface module to interface with the HardFiber Process Bus System, or HardFiber Brick, allowing bidirectional IEC 61850 fiber-optic communications with up to eight HardFiber Bricks. The HardFiber system integrates seamlessly with the existing UR-series applications, including protection functions, FlexLogic, metering, and communications.

This process bus system offers the following benefits:

- Reduces labor associated with design, installation, and testing of protection and control applications using the UR by reducing the number of individual copper terminations
- Integrates seamlessly with existing UR applications, since the IEC 61850 process bus interface module replaces the traditional CT/VT modules
- Communicates using open standard IEC 61850 messaging

For details on the HardFiber system, see its Instruction Manual.

### 4.5.7 CONTACT INPUTS AND OUTPUTS

With the exception of the high density modules, which have 36 terminal connections, all contact input/output modules have 24 terminal connections. The connections are arranged typically as three terminals per row, with eight rows in total. A given row of three terminals can be used for the outputs of one relay. For example, for form-C relay outputs, the terminals connect to the normally open (NO), normally closed (NC), and common contacts of the relay. For a form-A output, there are options of using current or voltage detection for feature supervision, depending on the module ordered. The terminal configuration for contact inputs is different for the two applications.

The contact inputs are grouped with a common return. The input/output modules have three versions of grouping: four inputs per common return, five inputs per common return on a high-density module (6W and 6X), and two inputs per common return. When a contact input/output module is ordered, four inputs per common is used. If the inputs must be isolated per row, then two inputs per common return are selected (4D module). If the space limitation in the relay requires use of a high density input module (6W), five inputs share one common return and the module has six banks of inputs.

A high density I/O module (6Y) is available with two inputs sharing one common return. This module has six groups of two inputs i.e., a total of twelve contact inputs.

This module also provides station battery DC voltage measurement through two contact inputs: Contact Input 9 (x13a) and Contact Input 11 (x16a). The measured DC voltage value is available as a Flex-Analog and as an Actual Value. The positive terminal of the station battery should be connected directly to the Contact Input 9 or 11, and the negative terminal should be connected to the common return.

A Single setting **STATION BATTERY NOM VOLTAGE** is provided for Contact Inputs 9 and 11 to convert the measured DC voltage to pu values, for the use by the FlexElement. If the setting **STATION BATTERY NOM VOLTAGE** is set to 0V then the station battery voltage measurement functionality is not available. In this case, contact inputs 9 and 11 can be used as regular contact inputs with their ON and OFF operands evaluated based on the setting **lps x13a,x15a,x16a,x18a THRESHOLD**. For more detail see the Contact Inputs section in the Settings Chapter.

The tables and diagrams that follow illustrate the module types and contact arrangements, which can be ordered for the relay. Since an entire row is used for a single contact output, the name is assigned using the module slot position and row number. However, since there are two contact inputs per row, these names are assigned by module slot position, row number, and column position.

Some form-A / solid-state relay outputs include circuits to monitor the DC voltage across the output contact when it is open, and the DC current through the output contact when it is closed. Each of the monitors contains a level detector whose output is set to logic ON = 1 when the current in the circuit is above the threshold setting. The voltage monitor is set to ON = 1 when there is a voltage across the open contact. The detector allows a current of about 1 to 2.5 mA except for the 6Y module type outputs, which allow 2mA. The current monitor is set to ON = 1 when the current flowing through the closed contact exceeds about 80 to 100 mA. The voltage monitor is intended to check the health of the overall trip circuit. The current monitor can be used to seal-in the output contact until an external contact has interrupted current flow. If enabled, the current monitoring can be used as a seal-in signal to ensure that the form-A contact does not attempt to break the energized inductive coil circuit and weld the output contacts.

Block diagrams are shown as follows for form-A and solid-state relay outputs with optional voltage monitor, optional current monitor, and with no monitoring. The actual values shown for contact output 1 are the same for all contact outputs. With the exception of the 6Y module type, Form-A contact output with or without a current or voltage monitoring option is not polarity sensitive. For the 6Y module type, polarity must be followed to properly monitor the voltage.

The polarity shown in the figure is required for solid-state contact output connection.




Figure 23: Form-A and solid-state contact outputs with voltage and current monitoring




Figure 24: 6Y I/O module contact inputs and outputs

The operation of voltage and current monitors is reflected with the corresponding FlexLogic operands (CONT OP # VON, CONT OP # VOFF, and CONT OP # ION) that can be used in protection, control, and alarm logic. The typical application of the voltage monitor is breaker trip circuit integrity monitoring; a typical application of the current monitor is seal-in of the control command.

See the Digital Elements section of chapter 5 for an example of how form-A and solid-state relay contacts can be applied for breaker trip circuit integrity monitoring.

**Warning:**

**Consider relay contacts unsafe to touch when the unit is energized. Death or serious injury can result from touching live relay contacts.**

### USE OF FORM-A AND SOLID-STATE RELAY OUTPUTS IN HIGH-IMPEDANCE CIRCUITS

For form-A and solid-state relay output contacts internally equipped with a voltage measuring circuit across the contact, the circuit has an impedance that can cause a problem when used in conjunction with external high-input impedance monitoring equipment, such as modern relay test set trigger circuits. These monitoring circuits can continue to read the form-A contact as being closed after it has closed and subsequently opened, when measured as an impedance.

The solution is to use the voltage measuring trigger input of the relay test set, and connect the form-A contact through a voltage-dropping resistor to a DC voltage source. If the 48 V DC output of the power supply is used as a source, a 500  $\Omega$ , 10 W resistor is appropriate. In this configuration, the voltage across either the form-A contact or the resistor can be used to monitor the state of the output.

**Note:**

Where a tilde “~” symbol appears, substitute the slot position of the module. Where a number sign “#” appears, substitute the contact number.

When current monitoring is used to seal-in the form-A and solid-state relay contact outputs, give the FlexLogic operand driving the contact output a reset delay of 10 ms to prevent damage of the output contact (in situations when the element initiating the contact output is bouncing, at values in the region of the pickup value).

For high-density input/output modules 6W, 6X and 6Y, use the following guidelines to connect. The new I/O modules use pin type terminal blocks instead of the current ring type. The new terminals are required to achieve higher I/O count per module.

- 12 to 24 AWG (3.3 mm<sup>2</sup> to 0.2 mm<sup>2</sup>), single wire termination
- 16 to 24 AWG (1.31 mm<sup>2</sup> to 0.2 mm<sup>2</sup>), multiple wire termination with matching wire sizes and stranding. Two wires maximum per circuit
- Suggested wiring screw tightening torque is a minimum 4.43 in-lb (0.5 Nm) and maximum 5.31 in-lb (0.6 Nm)
- Minimum suggested temperature rating for the conductors is 75°C
- Wire type: copper

For module types 67, 6A, 6B, 6C, 6D, 6E, 6F, 6G, 6H, 6K, 6L, 6M, 6N, 6P, 6R, 6S, 6T, 6U, 6V, 4A, 4B, 4C, 4D, and 4L, use the following guidelines to connect:

- 12 to 24 AWG (3.3 mm<sup>2</sup> to 0.2 mm<sup>2</sup>)
- Wiring screw tightening torque is 19 inch-pounds, (2.15 Nm)
- Minimum suggested temperature rating for the conductors is 75°C
- Wire type: copper

#### 4.5.7.1 CONTACT INPUT AND OUTPUT MODULE ASSIGNMENTS

| ~4A module          |                 | ~4B module          |                 | ~4C module          |             | ~4D module          |          |
|---------------------|-----------------|---------------------|-----------------|---------------------|-------------|---------------------|----------|
| Terminal assignment | Output or input | Terminal assignment | Output or input | Terminal assignment | Output      | Terminal assignment | Output   |
| ~1                  | Not Used        | ~1                  | Not Used        | ~1                  | Not Used    | ~1a, ~1c            | 2 Inputs |
| ~2                  | Solid-State     | ~2                  | Solid-State     | ~2                  | Solid-State | ~2a, ~2c            | 2 Inputs |
| ~3                  | Not Used        | ~3                  | Not Used        | ~3                  | Not Used    | ~3a, ~3c            | 2 Inputs |
| ~4                  | Solid-State     | ~4                  | Solid-State     | ~4                  | Solid-State | ~4a, ~4c            | 2 Inputs |
| ~5                  | Not Used        | ~5                  | Not Used        | ~5                  | Not Used    | ~5a, ~5c            | 2 Inputs |
| ~6                  | Solid-State     | ~6                  | Solid-State     | ~6                  | Solid-State | ~6a, ~6c            | 2 Inputs |
| ~7                  | Not Used        | ~7                  | Not Used        | ~7                  | Not Used    | ~7a, ~7c            | 2 Inputs |
| ~8                  | Solid-State     | ~8                  | Solid-State     | ~8                  | Solid-State | ~8a, ~8c            | 2 Inputs |



| ~4L module          |                 | 67 module           |                 | ~6A module          |                 | ~6B module          |                 |
|---------------------|-----------------|---------------------|-----------------|---------------------|-----------------|---------------------|-----------------|
| Terminal assignment | Output or input | Terminal assignment | Output or input | Terminal assignment | Output or input | Terminal assignment | Output or input |
| ~1                  | 2 Outputs       | ~1                  | Form-A          | ~1                  | Form-A          | ~1                  | Form-A          |
| ~2                  | 2 Outputs       | ~2                  | Form-A          | ~2                  | Form-A          | ~2                  | Form-A          |
| ~3                  | 2 Outputs       | ~3                  | Form-A          | ~3                  | Form-C          | ~3                  | Form-C          |
| ~4                  | 2 Outputs       | ~4                  | Form-A          | ~4                  | Form-C          | ~4                  | Form-C          |
| ~5                  | 2 Outputs       | ~5                  | Form-A          | ~5a, ~5c            | 2 Inputs        | ~5                  | Form-C          |
| ~6                  | 2 Outputs       | ~6                  | Form-A          | ~6a, ~6c            | 2 Inputs        | ~6                  | Form-C          |
| ~7                  | 2 Outputs       | ~7                  | Form-A          | ~7a, ~7c            | 2 Inputs        | ~7a, ~7c            | 2 Inputs        |
| ~8                  | Not Used        | ~8                  | Form-A          | ~8a, ~8c            | 2 Inputs        | ~8a, ~8c            | 2 Inputs        |

| ~6C module          |        | ~6D module          |          | ~6E module          |                 | ~6F module          |             |
|---------------------|--------|---------------------|----------|---------------------|-----------------|---------------------|-------------|
| Terminal assignment | Output | Terminal assignment | Output   | Terminal assignment | Output or input | Terminal assignment | Output      |
| ~1                  | Form-C | ~1a, ~1c            | 2 Inputs | ~1                  | Form-C          | ~1                  | Fast Form-C |
| ~2                  | Form-C | ~2a, ~2c            | 2 Inputs | ~2                  | Form-C          | ~2                  | Fast Form-C |
| ~3                  | Form-C | ~3a, ~3c            | 2 Inputs | ~3                  | Form-C          | ~3                  | Fast Form-C |
| ~4                  | Form-C | ~4a, ~4c            | 2 Inputs | ~4                  | Form-C          | ~4                  | Fast Form-C |
| ~5                  | Form-C | ~5a, ~5c            | 2 Inputs | ~5a, ~5c            | 2 Inputs        | ~5                  | Fast Form-C |
| ~6                  | Form-C | ~6a, ~6c            | 2 Inputs | ~6a, ~6c            | 2 Inputs        | ~6                  | Fast Form-C |
| ~7                  | Form-C | ~7a, ~7c            | 2 Inputs | ~7a, ~7c            | 2 Inputs        | ~7                  | Fast Form-C |
| ~8                  | Form-C | ~8a, ~8c            | 2 Inputs | ~8a, ~8c            | 2 Inputs        | ~8                  | Fast Form-C |

| ~6G module          |                 | ~6H module          |                 | ~6K module          |             | ~6L module          |                 |
|---------------------|-----------------|---------------------|-----------------|---------------------|-------------|---------------------|-----------------|
| Terminal assignment | Output or input | Terminal assignment | Output or input | Terminal assignment | Output      | Terminal assignment | Output or input |
| ~1                  | Form-A          | ~1                  | Form-A          | ~1                  | Form-C      | ~1                  | Form-A          |
| ~2                  | Form-A          | ~2                  | Form-A          | ~2                  | Form-C      | ~2                  | Form-A          |
| ~3                  | Form-A          | ~3                  | Form-A          | ~3                  | Form-C      | ~3                  | Form-C          |
| ~4                  | Form-A          | ~4                  | Form-A          | ~4                  | Form-C      | ~4                  | Form-C          |
| ~5a, ~5c            | 2 Inputs        | ~5                  | Form-A          | ~5                  | Fast Form-C | ~5a, ~5c            | 2 Inputs        |
| ~6a, ~6c            | 2 Inputs        | ~6                  | Form-A          | ~6                  | Fast Form-C | ~6a, ~6c            | 2 Inputs        |
| ~7a, ~7c            | 2 Inputs        | ~7a, ~7c            | 2 Inputs        | ~7                  | Fast Form-C | ~7a, ~7c            | 2 Inputs        |
| ~8a, ~8c            | 2 Inputs        | ~8a, ~8c            | 2 Inputs        | ~8                  | Fast Form-C | ~8a, ~8c            | 2 Inputs        |

| ~6M module          |                 | ~6N module          |                 | ~6P module          |                 | ~6R module          |                 |
|---------------------|-----------------|---------------------|-----------------|---------------------|-----------------|---------------------|-----------------|
| Terminal assignment | Output or input | Terminal assignment | Output or input | Terminal assignment | Output or input | Terminal assignment | Output or input |
| ~1                  | Form-A          | ~1                  | Form-A          | ~1                  | Form-A          | ~1                  | Form-A          |
| ~2                  | Form-A          | ~2                  | Form-A          | ~2                  | Form-A          | ~2                  | Form-A          |


| ~6M module          |                 | ~6N module          |                 | ~6P module          |                 | ~6R module          |                 |
|---------------------|-----------------|---------------------|-----------------|---------------------|-----------------|---------------------|-----------------|
| Terminal assignment | Output or input | Terminal assignment | Output or input | Terminal assignment | Output or input | Terminal assignment | Output or input |
| ~3                  | Form-C          | ~3                  | Form-A          | ~3                  | Form-A          | ~3                  | Form-C          |
| ~4                  | Form-C          | ~4                  | Form-A          | ~4                  | Form-A          | ~4                  | Form-C          |
| ~5                  | Form-C          | ~5a, ~5c            | 2 Inputs        | ~5                  | Form-A          | ~5a, ~5c            | 2 Inputs        |
| ~6                  | Form-C          | ~6a, ~6c            | 2 Inputs        | ~6                  | Form-A          | ~6a, ~6c            | 2 Inputs        |
| ~7a, ~7c            | 2 Inputs        | ~7a, ~7c            | 2 Inputs        | ~7a, ~7c            | 2 Inputs        | ~7a, ~7c            | 2 Inputs        |
| ~8a, ~8c            | 2 Inputs        | ~8a, ~8c            | 2 Inputs        | ~8a, ~8c            | 2 Inputs        | ~8a, ~8c            | 2 Inputs        |

| ~6S module          |                 | ~6T module          |                 | ~6U module          |          | ~6V module          |           |
|---------------------|-----------------|---------------------|-----------------|---------------------|----------|---------------------|-----------|
| Terminal assignment | Output or input | Terminal assignment | Output or input | Terminal assignment | Output   | Terminal assignment | Output    |
| ~1                  | Form-A          | ~1                  | Form-A          | ~1                  | Form-A   | ~1                  | Form-A    |
| ~2                  | Form-A          | ~2                  | Form-A          | ~2                  | Form-A   | ~2                  | Form-A    |
| ~3                  | Form-C          | ~3                  | Form-A          | ~3                  | Form-A   | ~3                  | Form-C    |
| ~4                  | Form-C          | ~4                  | Form-A          | ~4                  | Form-A   | ~4                  | 2 Outputs |
| ~5                  | Form-C          | ~5a, ~5c            | 2 Inputs        | ~5                  | Form-A   | ~5a, ~5c            | 2 Inputs  |
| ~6                  | Form-C          | ~6a, ~6c            | 2 Inputs        | ~6                  | Form-A   | ~6a, ~6c            | 2 Inputs  |
| ~7a, ~7c            | 2 Inputs        | ~7a, ~7c            | 2 Inputs        | ~7a, ~7c            | 2 Inputs | ~7a, ~7c            | 2 Inputs  |
| ~8a, ~8c            | 2 Inputs        | ~8a, ~8c            | 2 Inputs        | ~8a, ~8c            | 2 Inputs | ~8a, ~8c            | 2 Inputs  |


| ~6W module          |                 | ~6X module          |                 | ~6Y module          |                 |
|---------------------|-----------------|---------------------|-----------------|---------------------|-----------------|
| Terminal assignment | Output or input | Terminal assignment | Output or input | Terminal assignment | Output or input |
| ~1a                 | Input           | ~1a, ~2a            | Form-A          | ~1a                 | Input           |
| ~2a                 | Input           | ~3a, ~4a            | Form-A          | ~3a                 | Input           |
| ~3a                 | Input           | ~5a, ~6a            | Form-A          | ~4a                 | Input           |
| ~4a                 | Input           | ~7a, ~8a            | Form-A          | ~6a                 | Input           |
| ~5a                 | Input           | ~9a, ~10a           | Form-A          | ~7a                 | Input           |
| ~7a                 | Input           | ~11a, ~12a          | Form-A          | ~9a                 | Input           |
| ~8a                 | Input           | ~13a, ~14a          | Form-A          | ~10a                | Input           |
| ~9a                 | Input           | ~15a, ~16a          | Form-A          | ~12a                | Input           |
| ~10a                | Input           | ~17a, ~18a          | Form-A          | ~13a                | Input           |
| ~11a                | Input           | ~1b, ~2b            | Form-A          | ~15a                | Input           |
| ~13a                | Input           | ~3b, ~4b            | Form-A          | ~16a                | Input           |
| ~14a                | Input           | ~5b, ~6b            | Form-A          | ~18a                | Input           |
| ~15a                | Input           | ~7b, ~8b            | Form-A          | ~1b, ~3b            | Form-A          |
| ~16a                | Input           | ~9b, ~10b           | Form-A          | ~2b, ~3b            | Form-A          |
| ~17a                | Input           | ~11b, ~12b          | Form-A          | ~4b, ~6b            | Form-A          |
| ~1b                 | Input           | ~13b, ~14b          | Form-A          | ~5b, ~6b            | Form-A          |
| ~2b                 | Input           | ~15b, ~16b          | Form-A          | ~7b, ~9b            | Form-A          |

| ~6W module          |                 | ~6X module          |                 | ~6Y module          |                 |
|---------------------|-----------------|---------------------|-----------------|---------------------|-----------------|
| Terminal assignment | Output or input | Terminal assignment | Output or input | Terminal assignment | Output or input |
| ~3b                 | Input           | ~17b, ~18b          | Form-A          | ~8b, ~9b            | Form-A          |
| ~4b                 | Input           |                     |                 | ~10b, ~12b          | Form-A          |
| ~5b                 | Input           |                     |                 | ~11b, ~12b          | Form-A          |
| ~7b                 | Input           |                     |                 | ~13b, ~14b          | Form-A          |
| ~8b                 | Input           |                     |                 | ~15b, ~16b          | Form-A          |
| ~9b                 | Input           |                     |                 | ~17b, ~18b          | Form-A          |
| ~10b                | Input           |                     |                 |                     |                 |
| ~11b                | Input           |                     |                 |                     |                 |
| ~13b                | Input           |                     |                 |                     |                 |
| ~14b                | Input           |                     |                 |                     |                 |
| ~15b                | Input           |                     |                 |                     |                 |
| ~16b                | Input           |                     |                 |                     |                 |
| ~17b                | Input           |                     |                 |                     |                 |


#### 4.5.7.2 CONTACT INPUT AND OUTPUT MODULE WIRING



**Figure 25: Contact input and output module wiring (Sheet 1 of 3)**



842763A2.CDR



859759A3.VSD

Figure 27: Contact input and output module wiring (Sheet 3 of 3)


**Note:**  
Observe the polarity shown in the figures for all contact input and output connections.

### 4.5.7.3 CONTACT INPUTS

A dry contact has one side connected to terminal B3b. This is the positive 48 V DC voltage rail supplied by the power supply module. The other side of the dry contact is connected to the required contact input terminal. Each contact input group has its own common (negative) terminal that must be connected to the DC negative terminal (B3a) of the power supply module. When a dry contact closes, a current of 1 to 3 mA flows through the associated circuit.

A wet contact has one side connected to the positive terminal of an external DC power supply. The other side of this contact is connected to the required contact input terminal. If a wet contact is used, then the negative side of the external source must be connected to the relay common (negative) terminal of each contact group. The maximum external source voltage for this arrangement is 300 V DC.

The voltage threshold at which each group of four contact inputs detects a closed contact input is programmable as 17 V DC for 24 V sources, 33 V DC for 48 V sources, 84 V DC for 110 to 125 V sources, and 166 V DC for 250 V sources.



827741A5.CDR

Figure 28: Dry and wet contact input connections

**Note:**

Where a tilde “~” symbol appears, substitute the slot position of the module


**Note:**

There is no provision in the relay to detect a DC ground fault on 48 V DC control power external output. We recommend using an external DC supply.

#### 4.5.7.4 GENERAL APPLICATION CONSIDERATIONS

Contacts outputs of protective relays, auxiliary contacts from breakers, disconnectors and other devices are connected generally to contacts inputs of protective relays. In some situations, the contact outputs of some protective relays can have high impedance connected across it. When such a contact output is connected across a relay contact input, it can spuriously operate the relay input even when the output is open, if there is a substantial distributed capacitance (represented by C1) present in the wiring between the output and the relay input, and the debounce time setting in the relay is low enough. This false assertion of the contact input, when there is inadvertent ground present at the DC positive terminal, can be prevented by inserting a resistor across the input.

The following figure shows a typical DC circuit, with battery ground detection, of contact input. The contact output has parallel impedance across it (represented by R1).




**Figure 29: Typical contact input DC circuit**

The presence of the impedance path (R1) across the contact output allows the stray (distributed) capacitance C1 to charge as shown, thus developing a voltage across the contact input enough to momentarily operate the input while the capacitance discharges in the presence of DC ground on the positive terminal of the battery.

The duration of the discharge depends on the value of the distributed capacitance, the initial voltage of the distributed capacitance, and the input impedance of the contact input. If the duration is greater than the debounce time setting, then the contact input operates.

The application example that follows describes how to mitigate this issue by connecting a resistor across the contact input, as shown in the next figure, or by adjusting the debounce time setting to a value greater than the discharge time to prevent spurious operation of the contact input only if the voltage (with output open) across the contact input due to trickle current is less than the threshold voltage. This operation of contact inputs also can be prevented by using the Auto-Burnish contact inputs or contact inputs with active impedance.



**Figure 30: Contact input connected to a contact output with resistor (R2) across the input**

### Application example

This example is for illustrative purposes only and the calculations present the worst-case scenario. In practice, the value of debounce time can be lower.

Contact input ON state impedance used in the calculation of the discharge period is based on the following table.

| Battery voltage (V) | Input impedance (kΩ) |
|---------------------|----------------------|
| 130                 | 50                   |
| 250                 | 97                   |

Assumptions:

- Debounce time setting = 2 ms
- Stray capacitance = 0.1 μF.
- Initial voltage across the stray capacitance "Vinitial" = 19 V (Vthreshold - 65 V), where Vthreshold = 84 V. The initial voltage Vinitial depends on values of impedance of R1 and contact inputs when the contact input is OFF (non-activated state).

Therefore, the discharge time constant ( $\tau$ ) =  $50 \text{ k}\Omega * 0.1 \text{ }\mu\text{F} = 5 \text{ ms}$ .

The discharge period t is calculated from the following equation:

$$V_{\text{threshold}} = (V_{\text{batt}} - V_{\text{initial}}) * e^{(-t/\tau)}$$

$$84 = -149 * e^{(t/0.005)}$$

$$T = -0.005 * \ln(84/149) = 0.0029 \text{ s}$$

Therefore, in this example the contact inputs operate.

To prevent this operation, the debounce time must be increased to 4 ms (set debounce time as per the following table) or insert a resistor less than or equal to "R" as calculated later.

| Stray capacitance (μF) | Battery voltage (V) | Debounce time (ms) |
|------------------------|---------------------|--------------------|
| 0.05                   | 130                 | 2                  |
| 0.1                    | 130                 | 4                  |
| 0.2                    | 130                 | 4                  |
| 0.05                   | 250                 | 3                  |



| Stray capacitance (μF) | Battery voltage (V) | Debounce time (ms) |
|------------------------|---------------------|--------------------|
| 0.1                    | 250                 | 6*                 |
| 0.2                    | 250                 | 11                 |

\* Default debounce time on contact inputs is 6 ms

The value of this resistor "R" is calculated as follows:

1. Determine the minimum voltage (V threshold) required to turn on the input. This is determined by direct measurement or referenced in the input specifications.
2. Calculate the resistance necessary to limit the voltage to 1/3 V threshold (when the contact is OFF, the non-activated state) as follows:

$$R = (V_{\text{threshold}} / 3) / (2 \text{ mA})$$

The 2 mA current is used in case the contact input is connected across the GE Form A contact output with voltage monitoring. Otherwise use the amperage of the active circuit connected to the contact input when its contact output is open and the voltage across the contact input is third trigger threshold to calculate the resistor value.

3. When the contact is ON (operate state), the battery voltage appears across the resistor. The wattage rating of the resistor is then:

$$PR = 1.3 * (V_{\text{batt}})^2 / R \text{ Watts}$$

4. Applying the following equation to our example:

$$R = 84 \text{ V} / 3 * (1 / 2 \text{ mA}) = 14 \text{ k}\Omega$$

$$PR = 1.57 \text{ Watts Eq. 3-4}$$

5. Calculating the voltage across the contact input with the Burden Resistor, Voltage across the contact Input:

$$V_{\text{resistor}} = 2 \text{ mA} * 14 \text{ Kohm} = 28 \text{ V}$$


$$V_{\text{resistor}} < \text{contact input threshold (84 V)}$$

In conclusion, in this example, the contact input does NOT operate falsely with the Burden Resistor across its input AND when a battery ground is present.

#### 4.5.7.5 USE OF CONTACT INPUTS WITH AUTO-BURNISHING

The contact inputs sense a change of state of the external device contact based on the measured current. When external devices are located in a harsh industrial environment (either outdoor or indoor), their contacts can be exposed to various types of contamination. Normally, there is a thin film of insulating sulfidation, oxidation, or contaminates on the surface of the contacts, sometimes making it difficult or impossible to detect a change of state. This film must be removed to establish circuit continuity — an impulse of higher than normal current can accomplish this.

The contact inputs with auto-burnish create a high current impulse when the threshold is reached to burn off this oxidation layer as a maintenance to the contacts. Afterwards the contact input current is reduced to a steady-state current. The impulse has a five-second delay after a contact input changes state.




**Figure 31: Current through contact inputs with auto-burnishing**

Regular contact inputs limit current to less than 3 mA to reduce station battery burden. In contrast, contact inputs with auto-burnishing allow currents up to 50 to 70 mA at the first instance when the change of state is sensed. Then, within 25 to 50 ms, this current is slowly reduced to 3 mA as indicated. The 50 to 70 mA peak current burns any film on the contacts, allowing for proper sensing of state changes. If the external device contact is bouncing, the auto-burnishing starts when external device contact bouncing is over.

Another important difference between the auto-burnishing input module and the regular input modules is that only two contact inputs have common ground, as opposed to four contact inputs sharing one common ground (see the Contact Input and Output Module Wiring diagrams). This is beneficial when connecting contact inputs to separate voltage sources. Consequently, the threshold voltage setting is also defined per group of two contact inputs.

The auto-burnish feature can be disabled or enabled using the DIP switches found on each daughter card. There is a DIP switch for each contact, for a total of 16 inputs.



**Figure 32: Auto-burnish DIP switches**

The auto-burnish circuitry has an internal fuse for safety purposes. During regular maintenance, check the auto-burnish functionality using an oscilloscope.

#### 4.5.7.6 USE OF CONTACT INPUTS WITH ACTIVE IMPEDANCE

Contact inputs can be susceptible to parasitic capacitance, caused by long cable runs affected by switching surges from external circuits. This can result in inadvertent activation of contact inputs with the external contact open. In this case, GE recommends using the contact I/O module with active impedance circuit.

Active impedance contact input can tolerate external cable capacitance of up to 0.2  $\mu\text{F}$ , without entering the ON state for more than 2 ms. The contact input debounce time can still be set above 2 ms for added security to prevent contact input activations caused by external transient ON states.

An active impedance contact input is normally in Low impedance mode during OFF contact state (non-activated condition). During Low impedance state, contact input impedance is maintained at 10 K Ohms impedance to allow fast discharge of the stray capacitance of the long cables.

When the contact input voltage exceeds the set threshold, active impedance maintains 10 K Ohms impedance. If voltage starts rapidly decreasing, this indicates that stray capacitance is being discharged through the contact input. If, however, voltage stabilizes above the set threshold, the input impedance is switched to High impedance mode of 100 K Ohms. This value reduces the input current to <3 mA, and contact input switches to the ON state (operated state).

The figure shows the active impedance contact input V-I characteristic. Different thresholds with their corresponding characteristics are shown by color. The contact input is in the ON (operated) state if the input voltage is to the right of the colored threshold band (+/-10% tolerance), and the contact input is in the OFF (non-activated) state when input voltage is to the left of the band. A contact input is in LOW state during non-operated system condition, and actively switches to HIGH state upon detection of input voltage above the settable threshold.




Figure 33: Active impedance contact input V-I characteristic

#### 4.5.8 TRANSDUCER INPUTS AND OUTPUTS

Transducer input modules receive input signals from external DCmA output transducers (DCmA In) or resistance temperature detectors (RTDs). Hardware and software are provided to receive signals from these external transducers and convert these signals into a digital format for use as required.

Transducer output modules provide DC current outputs in several standard DCmA ranges. Software is provided to configure virtually any analog quantity used in the relay to drive the analog outputs.

Each transducer input/output module has 24 terminal connections. These connections are arranged as three terminals per row over eight rows. A given row can be used for either inputs or outputs, with terminals in column "a" having positive polarity and terminals in column "c" having negative polarity. Since an entire row is used for a single input/output channel, the name of the channel is assigned using the module slot position and row number.

Each module also requires that a connection from an external ground bus be made to terminal 8b. The current outputs require a twisted-pair shielded cable, where the shield is grounded at one end only. The following figure illustrates the transducer module types (5A, 5C, 5D, 5E, and 5F) and channel arrangements that can be ordered for the relay.

**Note:**

Where a tilde "~" symbol appears, substitute the slot position of the module.

|     |       |             |            |
|-----|-------|-------------|------------|
| ~1a | +     | dcmA In ~1  | 5A         |
| ~1c | -     |             |            |
| ~2a | +     | dcmA In ~2  |            |
| ~2c | -     |             |            |
| ~3a | +     | dcmA In ~3  |            |
| ~3c | -     |             |            |
| ~4a | +     | dcmA In ~4  |            |
| ~4c | -     |             |            |
| ~5a | +     | dcmA Out ~5 |            |
| ~5c | -     |             |            |
| ~6a | +     | dcmA Out ~6 |            |
| ~6c | -     |             |            |
| ~7a | +     | dcmA Out ~7 |            |
| ~7c | -     |             |            |
| ~8a | +     | dcmA Out ~8 |            |
| ~8c | -     |             |            |
| ~8b | SURGE |             | ANALOG I/O |

|     |        |                |            |
|-----|--------|----------------|------------|
| ~1a | Hot    | RTD ~1         | 5C         |
| ~1c | Comp   |                |            |
| ~1b | Return | for RTD ~1& ~2 |            |
| ~2a | Hot    | RTD ~2         |            |
| ~2c | Comp   |                |            |
| ~3a | Hot    | RTD ~3         |            |
| ~3c | Comp   |                |            |
| ~3b | Return | for RTD ~3& ~4 |            |
| ~4a | Hot    | RTD ~4         |            |
| ~4c | Comp   |                |            |
| ~5a | Hot    | RTD ~5         |            |
| ~5c | Comp   |                |            |
| ~5b | Return | for RTD ~5& ~6 |            |
| ~6a | Hot    | RTD ~6         |            |
| ~6c | Comp   |                |            |
| ~7a | Hot    | RTD ~7         |            |
| ~7c | Comp   |                |            |
| ~7b | Return | for RTD ~7& ~8 |            |
| ~8a | Hot    | RTD ~8         |            |
| ~8c | Comp   |                |            |
| ~8b | SURGE  |                | ANALOG I/O |

|     |        |                |            |
|-----|--------|----------------|------------|
| ~1a | Hot    | RTD ~1         | 5D         |
| ~1c | Comp   |                |            |
| ~1b | Return | for RTD ~1& ~2 |            |
| ~2a | Hot    | RTD ~2         |            |
| ~2c | Comp   |                |            |
| ~3a | Hot    | RTD ~3         |            |
| ~3c | Comp   |                |            |
| ~3b | Return | for RTD ~3& ~4 |            |
| ~4a | Hot    | RTD ~4         |            |
| ~4c | Comp   |                |            |
| ~5a | +      | dcmA Out ~5    |            |
| ~5c | -      |                |            |
| ~6a | +      | dcmA Out ~6    |            |
| ~6c | -      |                |            |
| ~7a | +      | dcmA Out ~7    |            |
| ~7c | -      |                |            |
| ~8a | +      | dcmA Out ~8    |            |
| ~8c | -      |                |            |
| ~8b | SURGE  |                | ANALOG I/O |

|     |        |                |            |
|-----|--------|----------------|------------|
| ~1a | +      | dcmA In ~1     | 5E         |
| ~1c | -      |                |            |
| ~2a | +      | dcmA In ~2     |            |
| ~2c | -      |                |            |
| ~3a | +      | dcmA In ~3     |            |
| ~3c | -      |                |            |
| ~4a | +      | dcmA In ~4     |            |
| ~4c | -      |                |            |
| ~5a | Hot    | RTD ~5         |            |
| ~5c | Comp   |                |            |
| ~5b | Return | for RTD ~5& ~6 |            |
| ~6a | Hot    | RTD ~6         |            |
| ~6c | Comp   |                |            |
| ~7a | Hot    | RTD ~7         |            |
| ~7c | Comp   |                |            |
| ~7b | Return | for RTD ~7& ~8 |            |
| ~8a | Hot    | RTD ~8         |            |
| ~8c | Comp   |                |            |
| ~8b | SURGE  |                | ANALOG I/O |

|     |       |            |            |
|-----|-------|------------|------------|
| ~1a | +     | dcmA In ~1 | 5F         |
| ~1c | -     |            |            |
| ~2a | +     | dcmA In ~2 |            |
| ~2c | -     |            |            |
| ~3a | +     | dcmA In ~3 |            |
| ~3c | -     |            |            |
| ~4a | +     | dcmA In ~4 |            |
| ~4c | -     |            |            |
| ~5a | +     | dcmA In ~5 |            |
| ~5c | -     |            |            |
| ~6a | +     | dcmA In ~6 |            |
| ~6c | -     |            |            |
| ~7a | +     | dcmA In ~7 |            |
| ~7c | -     |            |            |
| ~8a | +     | dcmA In ~8 |            |
| ~8c | -     |            |            |
| ~8b | SURGE |            | ANALOG I/O |

842764A1.CDR

**Figure 34: Transducer input/output module wiring**

The following figure show how to connect RTDs.





Figure 35: RTD connections

## 4.5.9 COMMUNICATION PORTS

### 4.5.9.1 GENERAL GROUNDING CONSIDERATIONS

When using RJ45 Copper connection the cable must be shielded twisted pair Ethernet cable.

If not using a Process Bus Module (order code 85, 86, 87), the following cable and ground connection is appropriate.



**Figure 36: CPU module wiring for IRIG-B without Process Bus Module**

For Sampled Value (SV) applications using a Process Bus Module with order code 85, 86, or 87 with IRIG-B for synchronization, follow the recommended cables and grounding connections. If using a Process Bus Module and IRIG-B as the synchronizing source, we recommend moving the grounding from the IRIG-B generator to UR terminal D4a in order to better protect the IRIG-B input from long bursts of transient noise.





Figure 37: CPU module wiring when using a Process Bus Module

#### 4.5.9.2 RS232 PORT

On the enhanced and basic front panels is a nine-pin RS232C serial port for programming with a computer. All that is required to use this interface is a computer running the EnerVista UR Setup software provided with the relay.

Cabling for the RS232 port is shown in the following figure for the nine-pin connector on the UR and nine or 25-pin connector on a computer.

The baud rate for this port can be set, with a default of 115200 bps.



**Figure 38: RS232 front panel port connection**

#### 4.5.9.3 RS485 PORT

RS485 data transmission and reception are accomplished over a single twisted-pair wire with transmit and receive data alternating over the same two wires.

Through the use of the port, continuous monitoring and control from a remote computer, SCADA system, or Power Line Carrier (PLC) is possible.

To minimize errors from noise, the use of shielded twisted-pair wire is recommended. Correct polarity must be observed. For instance, the relays must be connected with all RS485 “+” terminals connected together, and all RS485 “-” terminals connected together. Though data is transmitted over a two-wire twisted pair, all RS485 devices require a shared reference, or common voltage. This common voltage is implied to be a power supply common. Some systems allow the shield (drain wire) to be used as common wire and to connect directly to the relay COM terminal (#3); others function correctly only if the common wire is connected to the COM terminal, but insulated from the shield.

To avoid loop currents, ground the shield at only one point. If other system considerations require the shield to be grounded at more than one point, install resistors (typically 100 ohms) between the shield and ground at each grounding point. Each relay needs to be daisy-chained to the next one in the link. A maximum of 32 relays can be connected in this manner without exceeding driver capability. For larger systems, additional serial channels must be added. It is also possible to use commercially available repeaters to have more than 32 relays on a single channel. Avoid star or stub connections entirely.

Lightning strikes and ground surge currents can cause large momentary voltage differences between remote ends of the communication link. For this reason, surge protection devices are provided internally at both communication ports. An isolated power supply with an optocoupled data interface also acts to reduce noise coupling. To ensure maximum reliability, ensure that all equipment has similar transient protection devices installed. Terminate both ends of the RS485 circuit with an impedance as shown in the figure.






Figure 39: RS485 serial connection


#### 4.5.9.4 100BASEFX FIBER OPTIC PORTS

The fiber-optic communication ports allow for fast and efficient communications between relays at 100 Mbps. Optical fiber can be connected to the relay supporting a wavelength of 1310 nm in multimode.

Ensure that the dust covers are installed when the fiber is not in use. Dirty or scratched connectors can lead to high losses on a fiber link.

#### 4.5.9.5 IRIG-B

There is a round IRIG-B connector at the back of the CPU module, marked "IN." Use is optional. IRIG-B is a standard time code format that allows stamping of events to be synchronized among connected devices. The IRIG-B code allows time accuracies of up to 100 ns. The GE MultiSync 100 1588 GPS Clock as well as third-party equipment are available for generating the IRIG-B signal. This equipment can use a global positioning system (GPS) satellite system to obtain the time reference so that devices at different geographic locations can be synchronized. The IRIG time code formats are serial, pulse width-modulated codes that can be either DC level shifted or amplitude modulated (AM). Using IRIG-B input, the relay operates an internal oscillator with 1  $\mu$ s resolution and accuracy.



**Figure 40: Options for IRIG-B connection**

**Note:**

*Using an amplitude-modulated receiver causes errors up to 1 ms in event time stamping.*

---

## 4.6 INTER-RELAY COMMUNICATIONS

---

### 4.6.1 ESD PROTECTION GUIDELINES

Optical cables and transceivers are very sensitive to electrostatic discharge. You can easily damage the modules if you don't handle them correctly. This section provides some guidelines for handling such equipment to prevent damage.

#### Handling Optical Fiber Cables

- Before connecting cables, discharge any static on you by touching a grounded object.
- Use ESD-Safe Gloves.
- Avoid direct contact with fiber ends. This also prevents contamination.
- If using shielded optical cables, ensure the shield is properly grounded to prevent charge buildup.
- Avoid Rubbing or Sliding Cables on Surfaces. This can generate static charges that may discharge into connected transceivers.
- Avoid dragging or dropping cables on non-ESD surfaces.
- When cleaning fiber optics, use ESD-safe cleaning tools.

#### Handling Optical Transceivers

- Before handling the transceiver, you must discharge all static electricity on you.
- Use a wrist strap, ensuring that it has good contact with your skin and it is well grounded.
- Avoid Touching Electrical Contacts. Never touch the connector pins.
- When installing or removing transceivers, use an ESD-safe grounding tool if available.

#### Installation/Testing & Maintenance


- Power down the equipment before installing or removing transceivers.
- Before connecting cables or transceivers, discharge any static on you, by touching a grounded object.
- Use properly-grounded ESD Tools. If tools (such as fiber cleavers or splicers) are required, ensure they are ESD-compliant.
- Avoid hot-swapping in ESD-Prone environments
- Unless explicitly supported by the equipment, do not exchange optical modules while the device is powered.
- Ensure that ESD protection is included in any test setups involving optical transceivers.

---

### 4.6.2 DIRECT INPUT AND OUTPUT COMMUNICATIONS


The direct inputs and outputs feature makes use of the type 7 series of communications modules and allows direct messaging between UR devices. The communications modules are outlined in the table later in this section.

The communications channels are normally connected in a ring configuration, as shown in the following figure. The transmitter of one module is connected to the receiver of the next module. The transmitter of this second module is then connected to the receiver of the next module in the ring. This is continued to form a communications ring. The figure illustrates a ring of four UR-series relays with the following connections: UR1-Tx to UR2-Rx, UR2-Tx to UR3-Rx, UR3-Tx to UR4-Rx, and UR4-Tx to UR1-Rx. A maximum of 16 URs can be connected in a single ring.




**Figure 41: Direct input and output single-channel connection**

Inter-relay communication (IRC) modules with the C37.94 protocol are designed for back-to-back communication connections, so the ring configuration shown in the previous figure does not apply. To establish inter-relay communication in more than two URs, you need to have a two-channel IRC module and enable the DIRECT I/O CHANNEL CROSSOVER setting in all relays, as shown in the next figure. This configuration can be expanded to 16 URs, and this configuration does not provide a redundancy ring since both channels are made into a single ring by the channel crossover function. The clock is supplied typically by multiplexer (MUX) and all URs are in Loop Timing Mode. If there is no MUX, then UR1 and UR3 can be in Internal Timing Mode and UR2 and UR4 can be in Loop Timing Mode. That is, connected channels must have opposite timing modes.




**Figure 42: Ring configuration for C37.94 module**

The interconnection for dual-channel type 7 communications modules is shown as follows. Two-channel modules allow for a redundant ring configuration. That is, two rings can be created to provide an additional independent data path. The required connections are: UR1-Tx1 to UR2-Rx1, UR2-Tx1 to UR3-Rx1, UR3-Tx1 to UR4-Rx1, and UR4-Tx1 to UR1-Rx1 for the first ring; and UR1-Tx2 to UR4-Rx2, UR4-Tx2 to UR3-Rx2, UR3-Tx2 to UR2-Rx2, and UR2-Tx2 to UR1-Rx2 for the second ring.



**Figure 43: Direct input and output dual-channel connection**

The following figure shows the connection for three UR-series relays using two independent communication channels. UR1 and UR3 have single type 7 communication modules; UR2 has a dual-channel module. The two communication channels can be of different types, depending on the type 7 modules used. To allow the direct input and output data to cross-over from channel 1 to channel 2 on UR2, set the ***DIRECT I/O CHANNEL CROSSOVER*** setting to *Enabled* on UR2. This forces UR2 to forward messages received on Rx1 out Tx2, and messages received on Rx2 out Tx1.



**Figure 44: Direct input and output single/dual channel combination connection**

The inter-relay communications modules are available with several interfaces and some are outlined here in more detail. Those that apply depend on options purchased. The options are outlined in the Inter-Relay Communications section of the Order Code tables in Chapter 2. All of the fiber modules use ST type connectors.

### 4.6.3 FIBER LED AND ELED TRANSMITTERS

The following figure shows the configuration for the 7A, 7B, 7C, 7H, 7I, and 7J fiber-only modules.




Figure 45: LED and ELED fiber modules

### 4.6.4 FIBER LASER TRANSMITTERS

The following figure shows the configuration for the 72, 73, 7D, and 7K fiber-laser modules.





Figure 46: Laser fiber modules

The following figure shows configuration for the 2I and 2J fiber-laser modules.



**Figure 47: 2I and 2J laser fiber modules**



**Warning:**  
Do not look into the output of any fiber transmitter. This could cause serious eye injury.

*Note:*

*When using a laser Interface, attenuators can be necessary to ensure that you do not exceed the maximum optical input power to the receiver*

#### 4.6.5 RS422 INTERFACE

The RS422 inter-relay communications module is module 7M, which also has a dual-clock. The module can be configured to run at 64 or 128 kbps. You should use AWG 24 twisted shielded pair cable should for external connections. This modules is protected by an optically-isolated surge suppression device.

The shield pins (6a and 7b) are connected internally to the ground pin (8a). Proper shield termination is as follows:

- Site 1 — Terminate shield to pins 6a or 7b or both
- Site 2 — Terminate shield to COM pin 2b

The clock terminating impedance should be matched with the impedance of the line.

The following figure shows the typical pin interconnection between two single-channel RS422 interfaces installed in slot W. All pin interconnections are to be maintained for a connection to a multiplexer.




Figure 48: Typical pin interconnection between two RS422 interfaces

#### 4.6.5.1 TWO-CHANNEL APPLICATION VIA MULTIPLEXERS

The RS422 interface can be used for single-channel or two-channel applications over SONET/SDH or multiplexed systems. When used in single-channel applications, the RS422 interface links to higher-order systems in a typical way, observing transmit (Tx), receive (Rx), and send timing (ST) connections. However, when used in two-channel applications, certain criteria must be followed since there is one clock input for the two RS422 channels. The system functions correctly when the following connections are observed and your data module has a terminal timing feature. Terminal timing is a common feature in most synchronous data units that allows the module to accept timing from an external source. Using the terminal timing feature, two-channel applications can be achieved if these connections are followed: the send timing outputs from the multiplexer (data module 1) connects to the clock inputs of the UR RS422 interface in the usual way. In addition, the send timing outputs of data module 1 are also paralleled to the terminal timing inputs of data module 2. By using this configuration, the timing for both data modules and both UR RS422 channels is derived from a single clock source. As a result, data sampling for both of the UR RS422 channels is synchronized via the send timing leads on data module 1, shown as follows. If the terminal timing feature is not available or this type of connection is not wanted, the G.703 interface is a viable option that does not impose timing restrictions.






Figure 49: Timing configuration for RS422 two-channel, three-terminal application

Data module 1 provides timing to the RS422 interface via the ST(A) and ST(B) outputs. Data module 1 also provides timing to data module 2 TT(A) and TT(B) inputs via the ST(A) and AT(B) outputs. The data module pin numbers have been omitted in the figure because they vary by manufacturer.

#### 4.6.5.2 TRANSMIT TIMING

The RS422 interface accepts one clock input for transmit timing. It is important that the rising edge of the 64 kHz transmit timing clock of the multiplexer interface is sampling the data in the center of the transmit data window. Therefore, it is important to confirm clock and data transitions to ensure proper system operation. For example, the following figure shows the positive edge of the Tx clock in the center of the Tx data bit.




Figure 50: Clock and data transitions

4.6.5.3 RECEIVE TIMING

The RS422 interface utilizes NRZI-MARK modulation code and therefore does not rely on an Rx clock to recapture data. NRZI-MARK is an edge-type, invertible, self-clocking code.

To recover the Rx clock from the data-stream, an integrated digital phase lock loop (DPLL) circuit is utilized. The DPLL is driven by an internal clock, which is 16-times over-sampled, and uses this clock along with the data-stream to generate a data clock that can be used as the serial communication controller (SCC) receive clock.

4.6.6 RS422 AND FIBER INTERFACE

The following figure shows the combined RS422 plus fiberoptic interface configuration at 64 K baud. The 7L, 7M, 7N, 7P, and 74 modules are used in two-terminal with a redundant channel or three-terminal configurations where channel 1 is employed via the RS422 interface (possibly with a multiplexer) and channel 2 via direct fiber.

AWG 20 to 24 twisted shielded pair wiring is recommended for external RS422 connections. Ground the shield only at one end. For the direct fiber channel, address power budget issues properly.

*Note:*  
When using a laser interface, attenuators can be necessary to ensure that you do not exceed maximum optical input power to the receiver.

|    |                 |                                         |     |
|----|-----------------|-----------------------------------------|-----|
| 7M | Clock channel 1 | +                                       | ~1a |
|    |                 | -                                       | ~1b |
|    | Common          | COM                                     | ~2b |
|    | RS422 channel 1 | Tx -                                    | ~3b |
|    |                 | Rx -                                    | ~3a |
|    |                 | Tx +                                    | ~2a |
|    |                 | Rx +                                    | ~4b |
|    |                 | Shield                                  | ~6a |
|    | Fiber channel 2 | <div><div>Tx2</div><div>Rx2</div></div> |     |
|    | Surge           |                                         | ~8a |

842777A4

Figure 51: RS422 and fiber interface connection

## 4.6.7 IEEE C37.94 INTERFACE

IEEE C37.94 is a standard interface between teleprotection equipment and digital multiplexers.

The IEEE C37.94 modules of the UR family are designed to interface with IEEE C37.94-compliant digital multiplexers or an IEEE C37.94-compliant interface converter for use with direct input and output applications. The IEEE C37.94 standard defines a point-to-point optical link for synchronous data between a multiplexer and a teleprotection device. Data speed is typically 64 kbps, but the standard provides for speeds up to 64n kbps, where  $n = 1, 2, \dots, 12$ .

The data frames and rates comply with a valid G.704 pattern as specified by the International Telecommunications Union (ITU-T). The frame comprises 256 bits and is repeated at a frame rate of 8000 Hz, with a resultant bit rate of 2048 kbps.

The specifications for the module are as follows:


- Fiber-optic cable type — 50 nm or 62.5  $\mu\text{m}$  core diameter optical fiber
- Fiber-optic mode — multimode
- Fiber-optic cable length — up to 2 km
- Fiber-optic connector — type ST
- Wavelength — 820  $\pm 40$  nm
- Connection — as per all fiber-optic connections, a Tx-to-Rx connection is required

The following C37.94 modules are available:

| Module | Description                                                              |
|--------|--------------------------------------------------------------------------|
| 2A     | 1300 nm single-mode, ELED, 1-channel, 64 kbps                            |
| 2B     | 1300 nm single-mode, ELED, 2-channel, 64 kbps                            |
| 2G     | 820 nm multimode LED, 1-channel, 128 kbps                                |
| 2H     | 820 nm multimode LED, 2-channel, 128 kbps                                |
| 2I     | Channel 1 multimode, 64/128 kbps* + Channel 2 1300 nm single mode, laser |
| 2J     | Channel 1 multimode, 64/128 kbps* + Channel 2 1550 nm single mode, laser |
| 76     | 820 nm multimode LED, 1-channel, 64 kbps                                 |
| 77     | 820 nm multimode LED, 2-channel, 64 kbps                                 |


\* For direct I/O, configurable between 64 and 128 kbps

The UR-series C37.94 module can be connected directly to any compliant digital multiplexer that supports the IEEE C37.94 standard. The figure shows the concept.



**Figure 52: IEEE C37.94 connection to compliant digital multiplexer**

The UR-series C37.94 communication module can be connected to the electrical interface (G.703, RS422, or X.21) of a non-compliant digital multiplexer via an optical-to-electrical interface converter that supports the IEEE C37.94 standard. The following figure shows the concept.




**Figure 53: IEEE C37.94 connection to non-compliant digital multiplexer**

In 2008, GE Grid Solutions released revised modules 76 and 77 for C37.94 communication to enable multi-ended fault location functionality with firmware 5.60 release and higher. Revised 76 and 77 modules can be identified with "Rev D" or "Rev E" printed on it and must be used on all ends of of relay communication for two and three terminal applications with firmware 5.6 or higher.

It is possible to mix newer Rev D or Rev E modules with older Rev C modules with any firmware revision.

The UR-series C37.94 communication module has six switches to set the clock configuration. The following figure shows the functions of these control switches.




**Figure 54: Clock configuration switches**

For the internal timing mode, the system clock is generated internally. Therefore, set the timing switch selection to internal timing for relay 1 and loop timed for relay 2. There must be only one timing source configured.

For the looped timing mode, the system clock is derived from the received line signal. Therefore, set the timing selection to loop timing mode for connections to higher order systems.

To remove the IEEE C37.94 communications module cover and set the switches:


1. With power to the relay off, remove the IEEE C37.94 module (type 2I, 2J, 76, or 77 module) as follows. Record the original location of the module to help ensure that the same or replacement module is inserted into the correct slot.
2. Simultaneously pull the ejector/inserter clips located at the top and bottom of each module in order to release the module for removal.
3. Remove the module cover screw.
4. Remove the top cover by sliding it towards the rear and then lift it upwards.
5. Set the timing selection switches (channels 1 and 2) to the required timing modes (see description earlier).
6. Replace the top cover and the cover screw.
7. Re-insert the IEEE C37.94 module. Take care to ensure that the correct module type is inserted into the correct slot position. The ejector/inserters located at the top and at the bottom of each module must be in the disengaged position as the module is inserted smoothly into the slot. Once the clips have cleared the raised edge of the chassis, engage the clips simultaneously. When the clips have locked into position, the module is inserted fully.



831774A3.CDR

**Figure 55: IEEE C37.94 timing selection switch setting**

Modules shipped since January 2012 have status LEDs that indicate the status of the DIP switches, as shown in the following figure.



842837A1.cdr

**Figure 56: Status LEDs**

The clock configuration LED status is as follows:

- Flashing green — loop timing mode while receiving a valid data packet
- Flashing yellow — internal mode while receiving a valid data packet
- Solid red — (switch to) internal timing mode while not receiving a valid data packet

The link/activity LED status is as follows:

- Flashing green — FPGA is receiving a valid data packet
- Solid yellow — FPGA is receiving a "yellow bit" and remains yellow for each "yellow bit"
- Solid red — FPGA is not receiving a valid packet or the packet received is invalid


#### 4.6.8 C37.94SM INTERFACE

The IEEE C37.94SM communication modules are designed to interface with modified IEEE C37.94 compliant digital multiplexers or IEEE C37.94 compliant interface converters that have been converted from 820 nm multimode fiber optics to 1300 nm ELED single-mode fiber optics. The IEEE C37.94 standard defines a point-to-point optical link for synchronous data between a multiplexer and a teleprotection device. This data is typically 64 kbps, but the standard provides for speeds up to 64n kbps, where  $n = 1, 2, \dots, 12$ . The UR-series C37.94SM communication module is 64 kbps only with  $n$  fixed at 1. The frame is a valid ITU-recommended G.704 pattern from the standpoint of framing and data rate. The frame is 256 bits and is repeated at a frame rate of 8000 Hz, with a resultant bit rate of 2048 kbps.

The specifications for the module are as follows:


- Emulated IEEE standard — Emulates C37.94 for  $1 \times 64$  kbps optical fiber interface (modules set to  $n = 1$  or 64 kbps)
- Fiber-optic cable type — 9/125  $\mu\text{m}$  core diameter optical fiber
- Fiber-optic mode — Single-mode, ELED compatible with HP HFBR-1315T transmitter and HP HFBR-2316T receiver
- Fiber-optic cable length — Up to 11.4 km
- Fiber-optic connector — Type ST
- Wavelength —  $1300 \pm 40$  nm
- Connection — As per all fiber-optic connections, a Tx-to-Rx connection is required

The UR-series C37.94SM communication module can be connected directly to any compliant digital multiplexer that supports C37.94SM, as shown.



**Figure 57: C37.94SM fiber interface to digital multiplexer**

It also can be connected directly to any other UR-series relay with a C37.94SM module, as shown.




**Figure 58: C37.94SM fiber interface to another UR**

In 2008, GE Grid Solutions released revised modules 2A and 2B for C37.94SM communication to enable multi-ended fault location functionality with firmware 5.60 release and higher. All modules 2A and 2B shipped since the change support this feature and are fully backward compatible with firmware releases below 5.60. For customers using firmware release 5.60 and higher, the module can be identified with "Rev D" printed on it and is to be used on

all ends of relay communication for two and three terminal applications. Failure to use it at all ends results in intermittent communication alarms. For customers using firmware revisions below 5.60, it is not required to match the revision of the modules installed.

The UR-series C37.94SM module has six switches that are used to set the clock configuration. The following figure shows the functions of these control switches.




**Figure 59: Switches**

For the internal timing mode, the system clock is generated internally. Therefore, set the timing switch selection to internal timing for relay 1 and loop timed for relay 2. There must be only one timing source configured.

For the looped timing mode, the system clock is derived from the received line signal. Therefore, set the timing selection to loop timing mode for connections to higher-order systems.

To remove the C37.94SM communications module cover and set the switches:


1. With power to the relay off, remove the C37.94SM module (module 2A or 2B) as follows. Record the original location of the module to help ensure that the same or replacement module is inserted into the correct slot.
2. Simultaneously pull the ejector/inserter clips located at the top and at the bottom of each module in order to release the module for removal.
3. Remove the module cover screw.
4. Remove the top cover by sliding it towards the rear and then lift it upwards.
5. Set the timing selection switches (channels 1 and 2) to the required timing modes (see description earlier).
6. Replace the top cover and the cover screw.
7. Re-insert the C37.94SM module. Take care to ensure that the correct module type is inserted into the correct slot position. The ejector/inserter clips located at the top and at the bottom of each module must be in the disengaged position as the module is inserted smoothly into the slot. Once the clips have cleared the raised edge of the chassis, engage the clips simultaneously. When the clips have locked into position, the module is inserted fully.



831774A3.CDR

**Figure 60: C37.94SM timing selection switch setting**

Modules shipped since January 2012 have status LEDs that indicate the status of the DIP switches, as shown in the following figure.



842837A1.cdr

**Figure 61: Status LEDs**

The clock configuration LED status is as follows:

- Flashing green — loop timing mode while receiving a valid data packet
- Flashing yellow — internal mode while receiving a valid data packet
- Solid red — (switch to) internal timing mode while not receiving a valid data packet



The link/activity LED status is as follows:

- Flashing green — FPGA is receiving a valid data packet
- Solid yellow — FPGA is receiving a "yellow bit" and remains yellow for each "yellow bit"
- Solid red — FPGA is not receiving a valid packet or the packet received is invalid

---

## 4.7 ACTIVATE RELAY

---

The relay is in the default "Not Programmed" state when it leaves the factory. When the relay is powered up, the "Trouble" LED is on and the "In Service" LED is off. This "Not programmed state is evident on the screen display.

The relay in the "Not Programmed" state blocks all output relays from activating. This conditions remains until the relay is explicitly put into "Programmed" state.

The relay can be activated either directly using the front panel or alternatively with the EnerVista software.

To activate the relay using the front panel:

1. Press the **MENU** key until the **SETTINGS** header flashes momentarily and the **PRODUCT SETUP** message displays.
2. Press the right arrow until the SECURITY message displays.
3. Press the down arrow until the INSTALLATION message displays.
4. Press the right arrow until the RELAY SETTINGS: *Not Programmed* message displays
5. After the **RELAY SETTINGS** *Not Programmed* message displays, press a VALUE key to change the selection to "Programmed."
6. Press the **ENTER** key to save the change.
7. When the *NEW SETTING HAS BEEN STORED* message appears, the relay is in the "Programmed" state and the **In Service** LED turns on.

To activate the relay using EnerVista software:


1. Navigate to **Settings > Product Setup > Installation** and change the Relay Settings field to "Programmed."
2. Save the change.

## 4.8 SOFTWARE INSTALLATION

### 4.8.1 ENERVISTA COMMUNICATION OVERVIEW

The EnerVista UR Setup software communicates to the relay via the front panel RS232 or USB port or the rear RS485 / Ethernet ports.

To communicate via the RS232 port, use a standard straight-through serial cable. Connect the DB-9 male end to the relay and the DB-9 or DB-25 female end to the computer COM2 port as described in the CPU Communication Ports section earlier in this chapter.



842759A2.CDR

**Figure 62: Relay communication options**

To communicate through the relay's rear RS485 port from a computer RS232 port, the RS232/RS485 converter box is required. This device (catalog number F485) connects to the computer using a straight-through serial cable. A shielded twisted-pair wire (20, 22, or 24 AWG) connects the F485 converter to the rear communications port. The converter terminals (+, -, GND) are connected to the communication module (+, -, COM) terminals. See the CPU Communication Ports section in chapter 3 for details. The line is terminated with an R-C network (that is, 120  $\Omega$ , 1 nF) as described in this chapter.

### 4.8.2 SYSTEM REQUIREMENTS

The relay front panel or the EnerVista UR Setup software can be used to communicate with the relay. The software interface is the preferred method to edit settings and view actual values because the computer monitor can display more information.

The minimum system requirements for the EnerVista software are as follows:

- Intel Pentium processor (dual core) or (recommended) Core Duo
- One of the following operating systems in the required EnerVista language, such as English or French:
  - Windows 10
  - Windows Server 2008 Release 2 with Service Pack 1 (64-bit)
  - Windows Server 2012 Release 2 (64-bit)
  - Windows Server 2016
- 1 GB free hard drive space
- 2 GB RAM
- 1280 x 800 display screen

---

### 4.8.3 INSTALLING THE SOFTWARE

After ensuring that the requirements for using EnerVista UR Setup software are met, there are three ways to install the software:

- Download EnerVista Launchpad software from <https://www.gevernova.com/grid-solutions/multilin> and install it
- Download the EnerVista UR Setup software from <https://www.gevernova.com/grid-solutions/multilin> and install it

Install on a computer that has an operating system in the required language, for example a German operating system for use with EnerVista software in German.

The software can be installed on one computer and used by one user, unless permission is granted otherwise.

To install the software:

1. Click the **Install Now** button and follow the instructions.
2. When installation is complete, start the EnerVista Launchpad application.
3. Click the **IED Setup** section of the Launch Pad window.
4. In the EnerVista Launch Pad window, click the **Add Product** button and select the appropriate product as follows.
5. Select the product and click the **Add Now** button
6. Follow the instructions in the wizard to complete the process. The files are installed in the directory indicated, and the installation program automatically creates icons and adds an entry to the Windows start menu.
7. For non-English software, configure the language for the front panel in the EnerVista software under **Settings > Product Setup > Display Properties**. User-entered strings are not translated, for example relay names, so setting the language now ensures that the names are entered/displayed in the required language. For the EnerVista software language, access the **View > Language** menu item.

## 4.9 ADD DEVICE TO SOFTWARE

You connect remotely to the relay through the rear RS485 or Ethernet port with a computer running the EnerVista UR Setup software. The relay also can be accessed locally with a computer through the front panel RS232 or USB port or the rear Ethernet port using the Quick Connect feature.

The following procedures are outlined:

- Add device for serial access; see the Configure Serial Connection section
- Add device for the rear Ethernet port; see the Configure Ethernet Connection section
- Add device for access using a modem; see the Configure Modem Connection section
- Connect locally with a computer through either the front RS232 or USB port or rear Ethernet port
- Discover automatically UR devices within a network; see the Automatic Discovery of UR Devices section

Devices in the Device Setup window are listed in the order entered.

Devices in the main software window are listed alphabetically. Use the Device Name to order them as required, for example B30 Odessa, B30 Truro, B90, T35.

You cannot import a file to add a device to the software. You can import settings as outlined at the end of the chapter. The Quick Connect button also can be used to add devices. The device is added to a Quick Connect menu item in the Online Window area, cannot be moved from it to another grouping, and needs to be renamed in the Device Setup window. GE instead recommends using the Device Setup window to add devices, as outlined here.

### 4.9.1 SET IP ADDRESS IN UR

The UR family supports the use of subnetworks as documented in RFC 950, which divides class-based networks into subnetworks (non-CIDR). The classes and IP address ranges are defined as follows.

| Classes | IP address range             | Default subnet mask address | UR devices     |
|---------|------------------------------|-----------------------------|----------------|
| A       | 1.0.0.0 to 127.255.255.255   | 255.0.0                     | 65,535 or more |
| B       | 128.0.0.0 to 191.255.255.255 | 255.255.0.0                 | 255 to 65,534  |
| C       | 192.0.0.0 to 23.255.255.255  | 255.255.255.0               | 0 to 254       |
| D       | 224.0.0.0 to 239.255.255.255 | (Reserved for multicasting) |                |
| E       | 240.0.0.0 to 255.255.255.255 | (Reserved)                  |                |

Both network and subnet addresses are contained within a range. The number of hosts determines the class and addresses as follows:

- Class A 255.0.0.0 — The first octet (255) specifies the network, the second to fourth octets (0) specify the subnet and host. Use this class when you have more than 65,535 hosts (UR devices).
- Class B 255.255.0.0 — The first two octets (255) specify the network, the third octet (0) specifies the subnet, and the fourth octet (0) specifies the host. Use this class when you have 255 to 65,534 hosts (UR devices).
- Class C 255.255.255.0 — The first three octets (255) specify the network and the last octet (0) specifies the subnet and host. Use this class when you have up to 254 hosts (UR devices).

An example of implementation is one computer and one UR device. Because there is one UR device, class C addressing is required. So we use UR 192.167.2.x with subnet mask 255.255.255.0 and computer 192.167.3.x with subnet mask 255.255.255.0.

For older, non-CIDR routing protocols, such as RIP version 1, follow these restrictions:

- Identical subnet masks — Use a single mask for all subnets within a network
- Contiguous subnets — The subnets must be contiguous and not split among networks. The subnets cannot pass traffic through other networks.

The IP and subnet addresses need to be added to the UR for Ethernet communication.

For serial communication, for example using any front RS232 port and the Quick Connect feature, the addresses are not required, but typically they are entered to add/configure devices for regular use.


To add the IP addresses:

1. On the front of the UR, press the **MENU** key until the **SETTINGS** menu displays.
2. Navigate to one of the ports under **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > NETWORK > NETWORK PORT > PRT IP ADDRESS**.
3. Enter an IP address and press the **ENTER** key to save the value.
4. In the same menu, select the **PRT SUBNET IP MASK** setting. Enter a subnet IP address. Press the **ENTER** key to save the value.
5. When connecting through an Ethernet network, also configure the gateway address under **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > IPv4 ROUTE TABLE > DEFAULT IPv4 ROUTE GATEWAY ADDRESS**. Press the **ENTER** key to save the value.

If using a blue or grey Ethernet cable, skip the rest of this section. If this connection is to be permanent, always use shielded twisted pair (STP) cable.

If using an orange cross-over Ethernet cable, the computer needs to be set up as follows.

1. Use an orange Ethernet cross-over cable to connect the computer to the rear Ethernet port. In case you need it, the following figure shows the pinout for an Ethernet cross-over cable.



842799A1.CDR

**Figure 63: Ethernet cross-over cable PIN layout**

2. Navigate to the menu where you can set the IP properties
3. Enter an IP address with the first three numbers the same as the IP address of the relay and the last number different (in this example, 1.1.1.2).
4. Enter a subnet mask equal to the one set in the relay (in this example, 255.0.0.0).
5. Confirm the values.

## 4.9.2 TEST ETHERNET CONNECTION

1. Open a Windows console window, for example by selecting Start > Run from the Windows Start menu and typing `cmd` or clicking the **Start** button and entering `cmd`.
2. Type ping followed by a space, followed by the relevant IP address. (in this example, the IP address is 1.1.1.1)

```
C:\WINNT>ping 1.1.1.1
```

3. If the connection is successful, the system returns four replies similar to the following:

```
Pinging 1.1.1.1 with 32 bytes of data:
Reply from 1.1.1.1: bytes=32 time<10ms TTL=255
Reply from 1.1.1.1: bytes=32 time<10ms TTL=255
Reply from 1.1.1.1: bytes=32 time<10ms TTL=255
Reply from 1.1.1.1: bytes=32 time<10ms TTL=255
Ping statistics for 1.1.1.1:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip time in milliseconds:
Minimum = 0ms, Maximum = 0ms, Average = 0 ms
```

**Note:**

*Note that the values for time and TTL vary depending on local network configuration.*

4. If the following sequence of messages appears when entering the `C:\WINNT>ping 1.1.1.1` command:
 

```
Pinging 1.1.1.1 with 32 bytes of data:
Request timed out.
Request timed out.
Request timed out.
Request timed out.
Ping statistics for 1.1.1.1:
Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
Approximate round trip time in milliseconds:
Minimum = 0ms, Maximum = 0ms, Average = 0 ms
Pinging 1.1.1.1 with 32 bytes of data:
Verify the physical connection between the relay and the computer, check the programmed IP address then repeat step 2.
```
5. If the following sequence of messages appears when entering the `C:\WINNT>ping 1.1.1.1` command:
 

```
Pinging 1.1.1.1 with 32 bytes of data:
Hardware error.
Hardware error.
Hardware error.
Hardware error.
Ping statistics for 1.1.1.1:
Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
Approximate round trip time in milliseconds:
Minimum = 0ms, Maximum = 0ms, Average = 0 ms
Pinging 1.1.1.1 with 32 bytes of data:
Verify the physical connection between the relay and the computer, check the programmed IP address, then repeat step 2.
```
6. If the following sequence of messages appears when entering the `C:\WINNT>ping 1.1.1.1` command:
 

```
Pinging 1.1.1.1 with 32 bytes of data:
Destination host unreachable.
Destination host unreachable.
Destination host unreachable.
Destination host unreachable.
Ping statistics for 1.1.1.1:
Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
Approximate round trip time in milliseconds:
Minimum = 0ms, Maximum = 0ms, Average = 0 ms
Pinging 1.1.1.1 with 32 bytes of data:
Verify the IP address is programmed in the local computer by entering the ipconfig command in the command window. The IP configuration should look similar to this:

Windows IP Configuration
Ethernet adapter <F4FE223E-5EB6-4BFB-9E34-1BD7BE7F59FF>:
Connection-specific DNS suffix. . :
IP Address. . . . . : 0.0.0.0
Subnet Mask . . . . . : 0.0.0.0
Default Gateway . . . . . :
Ethernet adapter Local Area Connection:
Connection-specific DNS suffix . . :
IP Address. . . . . : 1.1.1.2
Subnet Mask . . . . . : 255.0.0.0
Default Gateway . . . . . :
```

### 4.9.3 INTERNET CONFIGURATION

1. Start your internet browse.
2. Select the UR device from the EnerVista Launchpad to start EnerVista UR Setup.
3. Click the Quick Connect button to open the window.
4. Select the Ethernet interface and enter the IP address assigned to the relay, then click the Connect button. The EnerVista UR Setup software creates a site named “Quick Connect” with a corresponding device also named “Quick Connect” and displays them on the left side of the screen.
5. Expand the sections to view data directly from the device.

Each time that the EnerVista UR Setup software is initialized, click the Quick Connect button to establish direct communications to the relay. This ensures that configuration of the EnerVista UR Setup software matches the relay model number.

---

### 4.9.4 CONFIGURE SERIAL CONNECTION


Two options are possible: local connection between computer and front RS232 port, and remote connection using the rear RS485 terminals.

If using Windows 10 and a GE USB-to-Serial Cable Converter (part number 0100-0001) connected between a USB port on the computer and the front serial port on the UR, use the Prolific driver version 3.2.0.0 from the Internet.

To use the RS485 terminals at the back of the relay, a GE Grid Solutions F485 converter (or compatible RS232-to-RS485 converter) is required. See the F485 instruction manual for details.

1. Connect the computer to the F485 and the F485 to the RS485 terminal on the back of the UR device. Or connect the computer to the RS232 port on the front of the relay.
2. Start the EnerVista UR Setup software, or in EnerVista Launchpad select the UR device to start the software.
3. Click the **Device Setup** button. The window opens.
4. Click the **Add Site** button. A new category is added. Enter a site name in the **Site Name** field. Optionally add a short description of the site. This example uses `Location 1` as the site name.
5. Click the **Add Device** button. A new device is added.
6. Enter a name in the **Device Name** field, up to 16 characters, and optionally add a description of the site. The **Color** option is for the text in the device list in the Online Window.
7. Select `Serial` from the **Interface** drop-down list. Interface parameters display that must be entered for serial communications. Try to load automatically the fields by clicking the **Read Order Code** button.





852022A1

**Figure 64: Configuring serial communication**

8. Enter the COM port used by the computer, the baud rate, and parity settings from the front panel **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > SERIAL PORTS** menu, and the relay slave address setting from the front panel **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > MODBUS PROTOCOL > MODBUS SLAVE ADDRESS** menu in their respective fields.

**Baud Rate** — Typically 19200 bits per second (bps) for RS232, and higher for RS485. Both modems need to use the same rate, meaning at the computer and the relay ends.

**Parity** — Set to None if unsure

**Bits** — Set to 8 if unsure

**Stop Bits** — Set to 1 if unsure

**Post Terminal Window** — Enable this option if you have a Schweitzer Engineering (SEL) SEL-203x Communications Processor, such as an SEL-2030 or SEL-2032. This option enables display of a terminal window to allow interaction with the other device.

9. Click the **Read Order Code** button to connect to the relay and upload the order code to the EnerVista software. If a communications error occurs, ensure that the EnerVista software serial communications values entered in the previous step correspond to the relay setting values, and also ensure that the same IP address is not assigned to multiple ports.
10. Click the **OK** button when the relay order code has been received. The new site and device are added to the Online Window.
11. The device has now been configured for serial communications.


#### 4.9.5 CONFIGURE ETHERNET CONNECTION

You connect the Ethernet cable, define a site in the software, then add the relay as a device for the site.

The Ethernet cable can be connected from the relay to an Ethernet network or directly to the computer. If this connection is to be permanent, always use shielded twisted pair (STP) cable.

The computer and UR device must be on the same subnet.

1. Connect the Ethernet network cable and any SFP supplied with the relay to the Ethernet port on the CPU module at the back of the device.
2. Start the EnerVista UR Setup software, or in EnerVista Launchpad select the UR device to start the software.
3. Click the **Device Setup** button. The window opens.
4. Click the **Add Site** button. A new category is added. Enter a site name in the **Site Name** field. Optionally add a short description of the site. This example uses `Location 1` as the site name.
5. Click the **Add Device** button. A new device is added.
6. Enter a name in the **Device Name** field, up to 16 characters, and optionally add a description of the site. The **Color** option is for the text in the device list in the Online Window.
7. Select *Ethernet* from the Interface drop-down list. This displays a number of interface parameters that must be entered for Ethernet functionality.



852023A1

**Figure 65: Configuring Ethernet communication**

8. Enter the relay IP Address, which can be viewed on the device front panel under **SETTINGS > PRODUCT SETUP COMMUNICATIONS > NETWORK > NETWORK PORT > PRT IP ADDRESS**. Once the IP address is entered, try to load automatically the fields by clicking the **Read Order Code** button.
9. Enter the relay Slave address and Modbus Port address values from the settings in the front panel **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > MODBUS PROTOCOL** menu.
10. If using a gateway to connect to the device, select **Yes** from the drop-down list.
11. Click the **Read Order Code** button to connect to the device and upload the order code. If the device was entered already, a message displays "Device 'x' is also using IP address...." If a

communications error occurs, ensure that the values entered in the previous steps correspond to the relay setting values, and also ensure that the same IP address is not assigned to multiple ports.

- Click the **OK** button when the relay order code has been received. The new site and device are added to the Online Window.

The device has now been configured for Ethernet communications.

---

### 4.9.6 CONFIGURE MODEM CONNECTION

A modem connection allows a computer to communicate with a UR device over phone lines. Two modems are required. One modem is connected to the UR device, either by connecting the serial cable to the front panel port or through a RS485 box to the rear terminals of the UR device. The second modem is connected to the computer that initiates the connection.

To add a UR device for modem connections:

- Connect the modems to the computer and UR.
- Start the EnerVista UR Setup software, or in EnerVista Launchpad select the UR device to start the software.
- Click the **Device Setup** button. The window opens.
- Click the **Add Site** button. A new category is added. Enter a site name in the **Site Name** field. Optionally add a short description of the site, such as the address or intersection.
- Click the **Add Device** button. A new device is added.
- Enter a name in the **Device Name** field, up to 16 characters, and optionally add a description of the site. The **Color** is for the text in the device list in the Online Window.
- Select "Modem" from the **Interface** drop-down list. This displays a number of interface parameters that must be entered.
- Select "Generic Modem" from the **Modem Name** drop-down list, then enter the phone number to dial to establish communication with the remote modem.  
**Post Terminal Window** — Enable this option if you have a Schweitzer Engineering (SEL) SEL-203x Communications Processor, such as an SEL-2030 or SEL-2032. It enables display of a terminal window to allow interaction with the other device.
- Once the phone number is entered, try to load automatically the device information by clicking the Read Order Code button.
- Click the **OK** button when the relay order code has been received. The new device is added to the Online window.

The UR device has now been added to the software.

---

### 4.9.7 AUTOMATIC DISCOVERY OF UR DEVICES

The EnerVista UR Setup software can find and communicate to all UR-family devices located on an Ethernet network.

Using the **Discover** button in the **Device Setup** window, a single click of the mouse triggers the software to detect any URs located on the network. This is done by searching a range of IP addresses based on the subnet mask of the computer.

When a UR device is detected, the EnerVista UR Setup software proceeds to configure all settings and order code options in the window. This feature allows the user to identify and interrogate all UR devices at a location.

Examples of address ranges are as follows:

**Example 1: Host IP address is 3.94.247.10 with a subnet mask of 255.255.252.0**

Host's subnet is 3.94.244.0

Possible IP addresses in this subnet are:

- 3.94.244.1 to 254
- 3.94.245.1 to 254
- 3.94.246.1 to 254
- 3.94.247.1 to 254

The discover function scans all those possible IP addresses to detect UR relays.

### **Example 2: Host IP address is 3.94.247.145 with a subnet mask of 255.255.252.128**

Host's subnet is 3.94.247.128

Possible IP addresses in this subnet are:

- 3.94.247.128 to 3.94.248.254

The discover function scans all those possible IP addresses to detect UR relays.

To automatically add UR devices:

1. In the EnerVista software, click the **Device Setup** button. The window opens.
2. Click the **Discover** button. The software searches for UR devices on the computer subnet and adds any found to the Online Window area. If a required device is not found, add it manually as outlined earlier.

---

## 4.10 CONNECT TO THE RELAY

---

There are four ways to connect to the device, as follows:

- RS232 or USB port (outlined here)
- RS485 port
- Ethernet port (outlined here)
- LAN

When unable to connect because of an access violation, access **Device Setup** and refresh the order code for the device.

When unable to connect, ensure that the same IP address is not assigned to multiple ports, for example under **Settings > Product Setup > Communications > Network**.

If still unable to connect, try unplugging and replugging the Ethernet connection. If that does not work, try to ping the device from the computer, and if unsuccessful, restart the computer.


When multiple computers are connected to a relay, EnerVista settings windows are not updated automatically. They are refreshed when re-opened. If a user changes a setting on one computer, the other users need to refresh the display by closing and opening the settings window to see the change. To ensure that current settings are always viewed, close settings windows when not in use so that they are up-to-date when next accessed.

---

### 4.10.1 CONNECT TO THE RELAY IN ENERVISTA

To access the relay in EnerVista:

1. Open the **Settings > Product Setup > Display Properties** window as shown. The window opens with a status indicator on the lower left of the EnerVista UR Setup window.



842743A4

2. If the status indicator is red, verify that the Ethernet network cable is properly connected to the Ethernet port on the back of the relay and that the relay has been properly set up for communication.
3. If a relay icon appears in place of the status indicator, then a report (such as an oscillography or event record) is open. Close the report to re-display the green status indicator.
4. The Display Properties settings can now be viewed, edited, or printed.

### Quick action hot links

The EnerVista UR Setup software has several quick action buttons to provide instant access to several functions that are performed often when using URs. From the online window, users can select the relay to interrogate from a pull-down window, then click the button for the action to perform. The following quick action functions are available:

- View the event record
- View the last recorded oscillography record
- View the protection summary
- View all of the metering values
- View the status of all inputs and outputs
- Generate a service report

### 4.10.2 USE QUICK CONNECT VIA FRONT RS232 PORT

This feature applies to the enhanced and basic front panels.

To connect to the UR from a computer using a serial cable:

1. Connect an RS232 serial cable to the computer and the front panel RS232 port. For example, use a USB-to-serial RS232 DB9M converter cable when connecting to the USB port on the computer. If using Windows 10

and a GE USB-to-Serial Cable Converter (part number 0100-0001) connected between a USB port on the computer and the front serial port on the UR, use the Prolific driver version 3.2.0.0 from the Internet.

2. Start the EnerVista UR Setup software, or in EnerVista Launchpad select the UR device to start the software.
3. Click the **Quick Connect** button. The window opens.
4. Select the serial Interface and the communications port from the drop-down lists, then click **Connect**. The COM Port is that of the computer.
5. The EnerVista software creates a site named "Quick Connect" with a corresponding device also named "Quick Connect" and displays them in the Online Window. Expand the sections to view data directly from the UR device. Use the **Device Setup** button to change the site name.

Each time that the EnerVista UR Setup software is initialized, click the **Quick Connect** button to establish direct communications to the relay. This ensures that configuration of the EnerVista UR Setup software matches the relay model number.

---

### 4.10.3 USE QUICK CONNECT VIA FRONT USB PORT

This feature applies to the graphical front panel.

To connect to the UR from a computer using a USB cable:

1. Connect the cable to the computer and the front panel USB port (square connector).
2. Start the EnerVista UR Setup software, or in EnerVista Launchpad select the UR device to start the software.
3. Click the **Quick Connect** button to open the window.
4. Select the USB Interface and the **GE Virtual Serial Port** driver from the drop-down list, then click **Connect**. If the GE driver does not display, it means that the USB cable was connected on Windows 10 when upgrading the UR software. You need to re-install the EnerVista software with the USB cable disconnected.
5. The EnerVista software creates a site named "Quick Connect" with a corresponding device also named "Quick Connect" and displays them in the Online Window. Expand the sections to view data directly from the UR device. Use the Device Setup button to change the site name.

Each time that the EnerVista UR Setup software is initialized, click the **Quick Connect** button to establish direct communications to the relay. This ensures that configuration of the EnerVista UR Setup software matches the relay model number.

---

### 4.10.4 USE QUICK CONNECT VIA A REAR ETHERNET PORT

To connect to a UR using an Ethernet cable:

1. In the EnerVista software, click the **Quick Connect** button. The window opens
2. Select the Ethernet interface and enter the IP address assigned to the relay, then click the **Connect** button. The EnerVista UR Setup software creates a site named "Quick Connect" with a corresponding device also named "Quick Connect" and displays them in the Online Window.
3. Expand the sections to view data directly from the relay. Use the **Device Setup** button to change the site name.

Each time that the EnerVista software is initialized, click the **Quick Connect** button to establish direct communications to the relay. This ensures that configuration of the EnerVista UR Setup software matches the relay model number.

---

## 4.11 SET UP CYBERSENTRY AND CHANGE DEFAULT PASSWORD

---

If and when first using CyberSentry security, use the following procedure for set up.

1. Log in to the relay as Administrator by using the VALUE keys on the front panel or through EnerVista connected serially (so that no IP address is required). If logging in through EnerVista choose Device authentication (see figure). Enter the default password `ChangeMe1#`. Note that the **LOCK SETTINGS** setting needs to be disabled (default) in the **SETTINGS > PRODUCT SETUP > SECURITY > SUPERVISORY** menu.
2. Enable the Supervisor role if you have a need for it.
3. Make any required changes in configuration, such as setting a valid IP address for communication over Ethernet.
4. Log out of the Administrator account by choosing None.

Next, device or server authentication can be chosen on the login screen, but the choice is available only in EnerVista. Use Device authentication to log in using the five pre-configured roles (Administrator, Supervisor, Engineer, Operator, Observer, or Administrator and Supervisor when Device authentication is disabled). When using a serial connection, only Device authentication is supported. When Server authentication is required, characteristics for communication with a RADIUS server must be configured on the UR. This is possible only through the EnerVista software. The RADIUS server itself also must be configured. At the end of this instruction manual, the appendix called RADIUS Server Configuration gives an example of how to set up a simple RADIUS server. Once both the RADIUS server and the parameters for connecting the UR to the server have been configured, you can choose Server authentication on the login screen of EnerVista.

During the commissioning phase, you have the option to bypass the use of passwords. Do so by enabling the Bypass Access setting under **Settings > Product Setup > Security > Supervisory**. Be sure to disable this bypass setting after commissioning the device.

You can change the password for any role either from the front panel or through EnerVista. If using EnerVista, navigate to **Settings > Product Setup > Security**. Change the Local Administrator Password, for example. We strongly recommend that the password for the Administrator be changed from the default. Changing the passwords for the other three roles is optional.



## 4.12 IMPORT SETTINGS

The options are:

- Import settings from XML or CID file — Import all settings or a group of settings from an XML or CID file to a device in the Offline Window area. Examples are Control elements, FlexLogic operands, and System Setup settings. This feature uses a built-in import/export tool.
- Import settings from device files — Import a URS, IID, or CID file to a device in the Offline Window area.

### 4.12.1 IMPORT SETTINGS FROM XML FILE

All settings, groups of settings, and/or individual settings can be imported, such as System Setup, FlexLogic operands, inputs/outputs, protection, and Control elements. A built-in import/export tool is used.

Note the following behavior:

- Available in English only
- Works in the Offline Window area
- Supports older firmware versions too, such as 6.x
- Import must be to same version, such as 8.03 to 8.03
- Except for B90, import can be to a different product, such as L90 to D60; order codes do not need to match
- Setting must exist in target device
- Complete single-line diagram can be imported, not parts of it
- Engineer function/menu item is not included
- Order codes must match when applying settings from the Offline Window area to a live device in the Online Window area. For example, settings from a C30 in the Offline Window area cannot be applied directly to a live C60 device.

*Note:*

*A B90 device can import settings only from another B90 device*

For information on exporting, see the Maintenance chapter.

Features in the tool include:

- Ability to perform global import (**Import All** button), by current window (**Import** button), or individual setting (right-click)
- Can import from a different dataset, such as from Dataset 3 to Dataset 2
- When a setting is not present in the target device, it cannot be selected/activated for the import device and the **Import** button is inactive
- Use the search box at the top-left to locate setting names and values, highlighted in blue
- Use the **Compare by Lines** and **Compare VOs** drop-down lists to sort display of FlexLogic equations
- Use the **Left Entry From / Left Entry To** boxes to display select rows
- Enable the **Synchronous Scrolling** check box to lock scrolling for target and import devices
- Add rows by right-clicking; validation is done later by the software
- Use the **Comparison Report** button to view quickly all differences, whether saved or not
- Use the **Target Device Report** to view quickly the imported settings, whether saved or not
- Click the **Save** button to save imports, otherwise none are

The following procedures outline how to import settings, apply to a live device, compare settings, and view imported settings.


To import settings:

1. In EnerVista, right-click the device in the Offline Window area and select the Import Settings option. A window opens. If the device is not listed in the Offline Window area, right-click it in the Online Window area and select the **Add Device to Offline Window** option.
2. Select the XML file to import, and click the **Open** button. When the firmware versions differ, a message displays and the file cannot be imported.

When the firmware versions match, a window opens that compares existing and import settings. Existing settings are on the left, and settings to be imported are on the right. The window for FlexLogic operands differs, allowing more granularity.


When the order codes of the existing and imported setting files do not match, but both devices share the same function(s), then the comparison list shows the common settings instead of all the settings. For example, the distance protection function exists both in L90 and D60. The software allows importing L90 distance protection to D60 distance, and vice versa.

With successful launch, the device with the settings to be imported displays on the right, and the targeted device to receive these settings is on the left. The differences are highlighted in orange. When check boxes are deselected on the right side, it means that there are no differences or that settings are not present in the target device. (For a summary, click the **Comparison Report** button at the top-right, as outlined in the next procedure.)



852744A1

- Review the settings, either in the main window or using the Comparison Report.  
If required, deselect any settings on the right side that are no longer wanted for import.  
If required, copy any setting in the import device by right-clicking the value, selecting the Copy option, and Pasting it in the target setting field. Or select the **Import** option.
- To filter FlexLogic operands, click the **Compare by Lines / Compare VOs** button to toggle.  
**Compare by Lines** — Displays FlexLogic operands 1 to 1024.  
**Compare VOs** — For virtual outputs, enable the check boxes of those wanted, for both the import and target devices.
- To import the settings for the window currently active, click the **Import** button. Or to import all settings, click the **Import All** button. The settings are imported, as shown in green.



- If required, to undo an import, click the **Undo Import** button. Or, to undo an import and to refresh all entries to their original state, click the **Restore** button.
- To save the changes, click the **Save** button and confirm at the prompt. Or to cancel all changes, click the **Cancel** button. The window closes.

To apply the settings to a live device:

- Drag-and-drop the device entry from the Offline Window area to an entry in the Online Window area. Individual settings also can be dragged and dropped. The order codes must match.

To compare settings:

- Click the **Comparison Report** button at the top-right of the window. This displays a summary of activity and includes following settings: different, missing, imported, and invalid.

**Number of Differences** — The number of settings in the target device having setting values different from the import device

**Number of Missing Settings** — The number of settings that are not found in the target device settings

**Number of Settings Imported** — The number of settings imported in the target device

**Number of Invalid Settings** — The number of settings that are same in both devices but the import device setting value is not within range (out-of-range) of the target device setpoint range. For example, a 'FuncName Block' setting is available in both import and target devices. The import device 'FuncName Block' setting is configured as '87L TRIP OPIOC 1 OP,' however operand '87L TRIP OPIOC 1 OP' is not within the range of the target device.

- To save the display as an HTML file, click the **Save to File** button.

To view imported settings on the target device:

- Click the **Target Device Report** button at the top-right of the window.  
 When no settings have been imported yet, the window shows basic information about the receiving device, such as order code.

When settings have been imported, whether saved or not, a report displays. It is a comparison of the target device before and after import.

For invalid settings for the target device, a message displays, they are highlighted in red in the main window, and they are listed in red at the bottom of the window. This means that the target device does not have the feature and cannot accept the settings. In the example shown, the device does not have bus functions, so the settings are invalid. Scroll through the list to review the invalid settings. Note that the sets of invalid setting groups are highlighted in red on the left side of the window (not shown).

| Setting Name            | Value              | Value                                  | Setting Name            |
|-------------------------|--------------------|----------------------------------------|-------------------------|
| ^ Trip Bus 1 Function   | Enabled            | Enabled                                | Trip Bus 1 Function ^   |
| Trip Bus 1 Block        | OFF                | OFF                                    | Trip Bus 1 Block        |
| Trip Bus 1 Pickup Delay | 0.00 s             | 0.00 s                                 | Trip Bus 1 Pickup Delay |
| Trip Bus 1 Reset Delay  | 0.00 s             | 0.00 s                                 | Trip Bus 1 Reset Delay  |
| Trip Bus 1 Input 1      | BUS 1 OP           | BUS 1 OP                               | Trip Bus 1 Input 1      |
| Trip Bus 1 Input 2      | OFF                | OFF                                    | Trip Bus 1 Input 2      |
| Trip Bus 1 Input 3      | OFF                | OFF                                    | Trip Bus 1 Input 3      |
| Trip Bus 1 Input 4      | OFF                | OFF                                    | Trip Bus 1 Input 4      |
| Trip Bus 1 Input 5      | OFF                | OFF                                    | Trip Bus 1 Input 5      |
| Trip Bus 1 Input 6      | OFF                | OFF                                    | Trip Bus 1 Input 6      |
| Trip Bus 1 Input 7      | OFF                | OFF                                    | Trip Bus 1 Input 7      |
| Trip Bus 1 Input 8      | OFF                | OFF                                    | Trip Bus 1 Input 8      |
| Trip Bus 1 Input 9      | OFF                | OFF                                    | Trip Bus 1 Input 9      |
| ^ Trip Bus 1 Input 10   | OFF                | OFF                                    | Trip Bus 1 Input 10 ^   |
| Error Screen Name       | Error Setting Name | Error Message                          | Original Value          |
| Trip Bus                | Trip Bus 1 Input 1 | Flexlogic value (BUS 1 OP) is invalid. | OFF                     |
| Trip Bus                | Trip Bus 2 Input 1 | Flexlogic value (BUS 2 OP) is invalid. | OFF                     |
| Trip Bus                | Trip Bus 3 Input 1 | Flexlogic value (BUS 3 OP) is invalid. | OFF                     |

852746A1

To save the display as an HTML file, click the **Save to File** button.

## 4.12.2 IMPORT SETTINGS FROM DEVICE FILES

The following file types can be imported:

- URS — UR settings file (firmware version 7.3x or earlier)
- IID — Instantiated IED capability description file — Actual settings on UR
- CID — Configured IED description file — Settings sent to the UR (may or may not be actual settings). When using IEC 61850, network settings can also be configured by accepting a CID file that includes them, as long as the IP address of at least one port is manually configured in the relay before the CID file is sent and the IP address matches that in the file. The import is done in the Offline Window area.

To import a settings file:

1. In the Offline Window area, right-click the device and select the Add Device from File option. The device is that from which you want to import settings.
2. If required, change the Files of type drop-down list.

Select the file to import.

To apply the settings to a live device:

1. Drag-and-drop the device entry from the Offline Window area to its entry in the Online Window area. Individual settings also can be dragged and dropped. The order codes must match.

This is what happens:

- CID — For version 7.30 or later, a new URS file generates and moves into a new device folder, generating SCL files from the new URS file. Files in the folder have new time stamps. The CID file retains its time stamp.
- URS — When not using IEC 61850 and the version is lower than 7.30, the file is added and the time stamp is unchanged. When clicking on the tree element, a device folder is created, the original file moves into it, and the time stamp is on the URS file is retained.

When version is 7.30 or later, with IEC61850 is us, the file is added and the time stamp is unchanged. When clicking on the tree element, a device folder is created, the original file moves into it, SCL files are generated there, and the "Last modified" time stamp on the URS file changes.

## 4.13 CONNECT TO SUBSTATION GATEWAY

A D400 Substation Gateway can be used to collect data from UR devices in a local area network (LAN). It collects metering, status, event, and fault report data from serial or LAN-based intelligent substation devices, and it pre-processes the data. The D400 supports up to 16 serial and eight network connections, with multiple devices possible on each serial connection. Up to 10 concurrent file transfer sessions are possible, meaning data for up to 10 URs can be transferred at the same time and any additional IEDs are queued on a first-come-first-served basis. The D400 can then upload files to a demilitarized zone (DMZ) server at the enterprise level.

Setup is as follows. For UR devices with the CyberSentry software option, when there is a need to retrieve periodically the logs from the UR securely without a human interface, the following approach can be used. See the D400 manual for configuration details to achieve it. A UR in the substation can authenticate a user either connecting to a RADIUS server or on the device itself. This depends on the user name used for authentication on a connection. The D400 connects to the UR device using an Ethernet, USB, or serial port on the UR. At the other end, the cable attaches to the rear of D400. Use the D400 software to configure a serial or network communication/connection for the UR, then to configure the IED device blocks/clients for the UR, and then to configure record retrieval. Once configured, the UR and D400 use a keyfile authentication mechanism to establish communication.

For UR devices with the IEC 61850 software option, also use the D400 IEC 61850 Loader software.

When a D400 detects new files available for download from a UR, it connects to the UR and reads the files via Secure File Transfer Protocol (SFTP) protocol. The following files can be transferred:

- Oscillography files
- Event records
- Log files
- Configuration (setting) files

The D400 information is viewable in its software and in a web browser.

*Note:*

*The D400 is discontinued and no longer offered. The G500 is a replacement to the D400, where the same file retrieval services and cybersecurity connection can be used.*

### 4.13.1 FILES AND RECORDS

Oscillography files are stored in COMTRADE format in the D400 folder system using the UR site and device name.

Event records are stored as the EVT.TXT file in the D400 folder system using the UR site and device name.

Log files can be retrieved for UR 7.0 and later. The following file types are possible, stored in the D400 folder system using the UR site and device name:

- `factory_event.txt` — Information about change methods and origins. Saved with a "\_YYMMDDhhmmss" retrieval time stamp, for example `FACTORY_EVENT_170525183124.TXT`.
- `setting_changes.log` — Information on what settings have been changed. Saved with a "\_YYMMDDhhmmss" retrieval time stamp, for example `SETTING_CHANGES_170525183124.TXT`.

Setting files are the configuration/settings files in the IEC 61850 SCL/IID format. The `ur.iid` file is saved with a "\_YYMMDDhhmmss" retrieval time stamp, for example `ur_170525183124.iid`. It is stored in the D400 folder system using the UR site and device name.

## CHAPTER 5

# INTERFACES

---

# 5.1      CHAPTER OVERVIEW

---

This chapter contains the following sections:

|                  |     |
|------------------|-----|
| Chapter Overview | 140 |
| EnerVista        | 141 |
| Front panel      | 162 |
| Logic diagrams   | 218 |
| FlexLogic        | 220 |



---

## 5.2 ENERVISTA

---

### 5.2.1 ENERVISTA INTRODUCTION

The EnerVista UR Setup software provides a single facility to configure, monitor, maintain, and troubleshoot relays connected over local or wide-area networks. It can be used while disconnected (offline) or connected (online) to a relay. In offline mode, you can create settings files for eventual downloading to the device. In online mode, communication with the device is real-time.

The EnerVista UR Setup software is provided with every UR relay. This chapter outlines the EnerVista software interface. The EnerVista Setup help file in the software also provides details for getting started and using the software interface.

---

### 5.2.2 SETTINGS FILES

The EnerVista software supports the following ways of handling changes to relay settings:

- In offline mode (relay disconnected) to create or edit relay settings files for later transfer to relays
- While connected to a relay to modify relay settings, and then save the settings to the relay
- Create/edit settings files and then write them to the relay while connected to the relay

See the back up section in the Maintenance chapter for instructions on how to create a settings file either offline or online.

Settings files are organized on the basis of file names assigned by the user. A settings file contains data pertaining to the following types of relay settings:

- Device definition
- Product setup
- System setup (not in C30, D60)
- FlexLogic
- Grouped elements (not in C30, D60)
- Control elements
- Inputs/outputs
- Remote resources
- Testing

Factory default values are supplied and can be restored after any changes.

The following communications settings are not transferred to the relay with settings files:

- Modbus Slave Address
- Modbus TCP Port Number
- RS485 COM2 Baud Rate
- RS485 COM2 Parity
- COM2 Minimum Response Time
- COM2 Selection
- RRTD Slave Address
- RRTD Baud Rate
- IP Address (see end of previous chapter for information)
- IP Subnet Mask
- IP Routing

When a settings file is loaded to a relay that is in-service, the following sequence occurs:

1. The relay takes itself out of service.
2. The relay issues a `UNIT NOT PROGRAMMED` major self-test error.
3. The relay closes the critical fail contact.

The Maintenance chapter outlines how to use a settings file in the `.urs` format for backup and restore.

### 5.2.3 EVENT VIEWING

In online or offline mode, you can view and analyze data generated by triggered parameters as follows:

- **Event recorder** — The event recorder captures contextual data associated with the last 1024 events, listed chronologically from most recent to oldest. Event records are viewable at software and device-specific levels. Access this under **Admin > Event Log > View**.
- **Oscillography** — The oscillography waveform traces and digital states are used to provide a visual display of power system and relay operation data captured during specific triggered events. Access this latter under **Actual Values > Records > Event Record**.

The following table outlines some software-level entries.

| Event                                                                                                                             | Description                                                                                                             |
|-----------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| EnerVista UR Setup SESSION STARTED                                                                                                | The EnerVista software was launched                                                                                     |
| Language was changed                                                                                                              | The user changed the software language using the <b>View &gt; Language</b> menu item                                    |
| DEFAULT USERS CREATED                                                                                                             | The user management window was launched using the <b>Admin &gt; User Management</b> menu item                           |
| : Successful upload of firmware<br>END<br>Firmware verified<br>Firmware uploaded<br>Firmware erased<br>START: Upload new firmware | The firmware on a device was upgraded                                                                                   |
| EnerVista UR Setup EVENT LOG CLEARED                                                                                              | The event record was cleared. All event records were deleted using the <b>Admin &gt; Event Log &gt; Clear</b> menu item |

### 5.2.4 FILE SUPPORT

The following support applies, where the Settings List is at the bottom left and the Site List is at the top left of the EnerVista window.

- **Execution** — Any EnerVista UR Setup file that is opened launches the application or provides focus to the already opened application. If the file was a settings file (has a `.urs` extension) that had been removed from the Settings List navigation menu, it is added back to the menu.
- **Drag and Drop** — The device settings and individual settings can be dragged and dropped between the Online and Offline Window areas. Also, any Windows Explorer directory folder is a file drag source and drop target.

New files that are dropped into the Offline Window are added to the tree, which is automatically sorted alphabetically with respect to settings file names. In the Online Window, files or individual menu items that are dropped in the selected device menu are sent automatically to the online device.

### 5.2.5 MAIN WINDOW

The EnerVista UR Setup software window has the following components:

1. Title bar that shows the pathname of the active data view or the name of the software

2. Main window menu bar
3. Main window toolbar
4. Site list / online window area
5. Settings list / offline window area
6. Software windows, with common toolbar
7. Settings file data view windows, with common toolbar
8. Workspace area with data view tabs
9. Status bar
10. Quick action hot links




Figure 66: EnerVista UR Setup software window

When the Offline Window has devices saved to it, it includes a **Reserved** entry with spare settings when customer-specific functions are provided on a UR.





Figure 67: Reserved settings

### 5.2.6 PROTECTION SUMMARY WINDOW

The Protection Summary is a graphical user interface to manage elements, such as enabling and disabling them. Access it under **Settings > Protection Summary**. See the Settings chapter for information on use.



852664A1

Figure 68: Protection Summary interface (B30 example shown)

## 5.2.7 SETTINGS TEMPLATES

Settings file templates simplify the configuration and commissioning of multiple relays that protect similar assets. An example is a substation that has 10 similar feeders protected by 10 UR F60 relays. In these situations, typically 90% or greater of the settings are identical among devices.

The templates allow engineers to configure and test these common settings, then lock them so that they are not available to users. For example, locked settings can be hidden from view for field engineers, allowing them to quickly identify and concentrate on specific settings.

The remaining settings (typically 10% or less) can be specified as editable and made available to field engineers installing the devices. These are settings such as protection element pickup values and CT and VT ratios.

The settings template mode allows the user to define which settings are visible in the software. Settings templates can be applied to both settings files (settings file templates) and online devices (online settings templates). The functionality is identical for both purposes.

Settings file conversion from previous firmware versions is supported.

*Note:*

*Note: Template mode is available in the English software only.*

### 5.2.7.1 ENABLE SETTINGS TEMPLATE

The settings file template feature is disabled by default. It can be enabled in offline or online mode.

In offline mode:

1. Locate the settings file in the Offline Window area of the EnerVista UR Setup software. If not there, a file can be added from an online device by right-clicking it and selecting the **Add Device to Offline Window** option.
2. In the Offline Window area, right-click the selected device or settings file and select the **Template Mode > Create Template** option.

The settings file template is now enabled and the file menus display in light blue. The settings file is now in template editing mode. To undo the action, select **Template Mode > Remove Template**

In online mode:

1. Locate the device in the Online Window area of the EnerVista UR Setup software.
2. Right-click the device and select the **Template Mode > Create Template option**. The software prompts for a template password. This password is required to use the template feature and must be at least four characters in length.
3. Enter and re-enter the new password, then click OK to continue.


The online settings template is now enabled. The device is now in template editing mode.

### 5.2.7.2 EDIT SETTINGS TEMPLATE

The settings template editing feature allows you to specify which settings are available for viewing and modification in EnerVista UR Setup. By default, all settings except the FlexLogic equation editor settings are locked.

1. With the template already enabled, locate the device or settings file in the Online or Offline Window area in the software.
2. Right-click the device or file and select the **Template Mode > Edit Template** option to verify or place the device in template editing mode (check mark beside option). If prompted, enter the template password then click **OK**.
3. Open the relevant settings window that contains settings to be specified as viewable.


By default, all settings are specified as locked and displayed against a gray background. The icon on the upper right of the settings window indicates that the EnerVista software is in EDIT mode. The following example shows the phase time overcurrent settings window in Edit mode.



852506A1

**Figure 69: Settings template with all settings specified as locked**

1. Specify the settings to make viewable by clicking them. They will show with a yellow background



852507A1

**Figure 70: Settings template with two settings specified as editable**

2. Click the **Save** button to save changes to the settings template.
3. Continue through any other settings window to specify all viewable settings.

The next time that the device/settings are accessed, only those specified as viewable/editable display in the menu hierarchy.

### 5.2.7.3 ADD PASSWORD PROTECTION

We recommend that you save templates with password protection to maximize security. When templates are created for online settings, the password is added during the initial template creation step. It does not need to be added after the template is created.

To add password protection to a settings file template:

1. In the Offline Window area, right-click the device and select the **Template Mode > Password Protect Template** option. The software prompts for a template password. This password must be at least four characters in length.
2. Enter and re-enter the new password, then click **OK** to continue.

The settings file template is now secured with password protection.

### 5.2.7.4 VIEW SETTINGS TEMPLATE


Once all necessary settings are specified for viewing, users are able to view the settings template on the online device or settings file. There are two ways to specify the settings view with the settings template feature:

- Display only those settings available for editing
- Display all settings, with settings not available for editing grayed-out


To display settings available for editing:

1. Right-click the device in the Online or Offline Window area and apply the template by selecting the **Template Mode > View In Template Mode** option.
2. Enter the template password if prompted, then click **OK** to apply the template.

Once the template has been applied, users are limited to view and edit the settings specified by the template. The effect of applying the template to the phase time overcurrent settings is shown.



Phase time overcurrent settings window without template applied.




Phase time overcurrent window with template applied via the **Template Mode > View In Template Mode** command. The template specifies that only the **Pickup** and **Curve** settings be available.

842858A1.CDR


**Figure 71: Applying templates using the View in Template Mode command**

Viewing the settings in template mode also modifies the settings menu, showing only the settings categories that contain





Typical settings tree view without template applied.



Typical settings tree view with template applied via the **Template Mode > View In Template Mode** command.


842860A1.CDR

**Figure 72: Applying templates using the View in Template Mode settings command**


To display settings available for editing and settings locked by the template:

1. Right-click the device in the Online or Offline Window area and apply the template by selecting the **Template Mode > View All Settings** option.
2. Enter the template password then click **OK** to apply the template.

Once the template has been applied, users are limited to edit the settings specified by the template, but all settings are shown. The effect of applying the template to the phase time overcurrent settings is shown as follows.



Phase time overcurrent settings window without template applied.



Phase time overcurrent window with template applied via the **Template Mode > View All Settings** command. The template specifies that only the **Pickup** and **Curve** settings be available.

842859A1.CDR

**Figure 73: Applying templates using the View All Settings command**

### 5.2.7.5 REMOVE SETTINGS TEMPLATE

Once a settings template is removed, it cannot be reapplied and a new settings template needs to be defined before use.

1. Right-click the device in the Online or Offline Window area and select the **Template Mode > Remove Template** option.
2. Enter the template password if prompted and click **OK** to continue.
3. The EnerVista software removes all template information and all settings are available. Confirm that you want to remove the template by clicking **Yes**.

The EnerVista software removes all template information and all settings are available.

## 5.2.8 SECURING FLEXLOGIC EQUATIONS

The UR allows users to secure some or all FlexLogic equations, preventing unauthorized viewing or modification of critical FlexLogic applications. This is accomplished using the settings template feature to lock individual entries within FlexLogic equations.


Secured FlexLogic equations remain secure when files are sent to and retrieved from any UR-series device.

Locking can be tied to the serial number too.

### 5.2.8.1 LOCKING ENTRIES IN A SETTINGS TEMPLATE

To lock individual entries of a FlexLogic equation:

1. Right-click the settings file or online device and select the **Template Mode > Create Template** item to enable the settings template feature.
2. If prompted, enter the template password.
3. Select the **FlexLogic > FlexLogic Equation Editor** settings menu item. By default, all FlexLogic entries are specified as viewable and display against a yellow background. The icon on the upper right of the window also indicates that EnerVista UR Setup is in EDIT mode.
4. Specify the entries to lock by clicking them. The locked entries display a gray background as shown in the example.



**Figure 74: Locking FlexLogic equation entries in Edit Mode**

5. Click the Save button to save and apply changes to the settings template.
6. Select the **Template Mode > View In Template Mode** option to view the template.
7. Optionally apply a password to the template by right-clicking the device and selecting the **Template Mode > Password Protect Template** option.

Once the template has been applied, users are limited to view and edit the FlexLogic entries not locked by the template. The effect of applying the template to the FlexLogic entries is shown here.

FlexLogic Equation Editor // F60 Feeder.urs : C:\Documents and Settings\All Users\Documents...

Save

Restore

Default

Reset

VIEW ALL

mode

| FLEXLOGIC ENTRY    | TYPE                  | SYNTAX               |
|--------------------|-----------------------|----------------------|
| View Graphic       | View                  | View                 |
| FlexLogic Entry 1  | Virtual Inputs On     | Close HMI On (V11)   |
| FlexLogic Entry 2  | Virtual Inputs On     | Close SCADA On (V12) |
| FlexLogic Entry 3  | Contact Inputs On     | Manual Close On(H5A) |
| FlexLogic Entry 4  | OR                    | 3 Input              |
| FlexLogic Entry 5  | Assign Virtual Output | = Close 52-1 (V01)   |
| FlexLogic Entry 6  | Contact Inputs On     | 52-1 Closed On(H5C)  |
| FlexLogic Entry 7  | Contact Inputs On     | 52-1 Rack In On(H6A) |
| FlexLogic Entry 8  | AND                   | 2 Input              |
| FlexLogic Entry 9  | Protection Element    | PHASE IOC1 OP        |
| FlexLogic Entry 10 | Protection Element    | PHASE IOC1 OP        |
| FlexLogic Entry 11 | Protection Element    | GROUND IOC1 OP       |
| FlexLogic Entry 12 | Protection Element    | NEUTRAL IOC1 OP      |
| FlexLogic Entry 13 | OR                    | 4 Input              |
| FlexLogic Entry 14 | AND                   | 2 Input              |
| FlexLogic Entry 15 | Assign Virtual Output | = Trip 52-1 (V02)    |
| FlexLogic Entry 16 | Protection Element    | ANY MAJOR ERROR      |
| FlexLogic Entry 17 | POSITIVE ONE SHOT     | 1 Input              |

F60 Feeder.urs FlexLogic

Screen ID: 171

FlexLogic Equation Editor // F60 Feeder.urs : C:\Documents and Settings\All Users\Documents...

Save

Restore

Default

Reset

VIEW

mode

| FLEXLOGIC ENTRY    | TYPE                  | SYNTAX               |
|--------------------|-----------------------|----------------------|
| View Graphic       | View                  | View                 |
| FlexLogic Entry 1  | Virtual Inputs On     | Close HMI On (V11)   |
| FlexLogic Entry 2  | Virtual Inputs On     | Close SCADA On (V12) |
| FlexLogic Entry 3  | Contact Inputs On     | Manual Close On(H5a) |
| FlexLogic Entry 4  | OR                    | 3 Input              |
| FlexLogic Entry 5  | Assign Virtual Output | = Close 52-1 (V01)   |
| FlexLogic Entry 6  | Locked                | Locked               |
| FlexLogic Entry 7  | Locked                | Locked               |
| FlexLogic Entry 8  | Locked                | Locked               |
| FlexLogic Entry 9  | Locked                | Locked               |
| FlexLogic Entry 10 | Locked                | Locked               |
| FlexLogic Entry 11 | Locked                | Locked               |
| FlexLogic Entry 12 | Locked                | Locked               |
| FlexLogic Entry 13 | Locked                | Locked               |
| FlexLogic Entry 14 | Locked                | Locked               |
| FlexLogic Entry 15 | Locked                | Locked               |
| FlexLogic Entry 16 | Protection Element    | ANY MAJOR ERROR      |
| FlexLogic Entry 17 | POSITIVE ONE SHOT     | 1 Input              |
| FlexLogic Entry 18 | Protection Element    | ANY MAJOR ERROR      |

F60 Feeder.urs FlexLogic

Screen ID: 171


Typical FlexLogic™ entries without template applied.

Typical FlexLogic™ entries locked with template via the **Template Mode > View In Template Mode** command.

842861A1.CDR

Figure 75: Locking FlexLogic entries through settings templates

The FlexLogic entries are also shown as locked in the graphical view and on the front panel display.




852518A1

Figure 76: Secured FlexLogic in graphical view

### 5.2.8.2 LOCKING A SETTINGS FILE TO A SERIAL NUMBER

A settings file and associated FlexLogic equations also can be locked to a UR serial number. Once FlexLogic entries in a settings file have been secured, use the following procedure to lock the settings file to a serial number. A serial number is viewable under **Actual Values > Product Info > Model Information**, the inside front panel, and the rear of the device.

1. Right-click the setting file in the Offline Window area and select the **Edit Device Properties** item. The window opens.



852520A2


**Figure 77: Settings file properties window**

2. Enter the serial number of the relay to lock to the settings file in the **Serial # Lock** field.
3. Click the OK button to apply the change. The serial number is not validated. The settings file and corresponding secure FlexLogic equations are now locked to the device specified by the serial number.

### 5.2.9 SETTINGS FILE TRACEABILITY

A traceability feature for settings files allows the user to quickly determine if the settings in a device have been changed since the time of installation from a settings file. When a settings file is transferred to a device, the date, time, and serial number are sent back to the EnerVista Setup and added to the settings file on the local computer. This information can be compared with the relay actual values at any later date to determine if security has been compromised.

The traceability information is only included in the settings file if a complete settings file is either transferred to the device or obtained from the device. Any partial settings transfers by way of drag and drop do not add the traceability information to the settings file.



842864A3


Figure 78: Settings file traceability

With reference to the above figure, the traceability feature is used as follows.

- The transfer date of a settings file is logged in the relay and can be viewed in the EnerVista software or the front panel display. Likewise, the transfer date of a settings file saved to a local computer is logged in the EnerVista software.
- Comparing the dates stored in the relay and on the settings file at any time in the future indicates if any changes have been made to the relay configuration since the settings file was saved.

### 5.2.9.1 SETTINGS FILE TRACEABILITY INFORMATION

The serial number and file transfer date are saved in the settings files when they are sent to a device. The serial number and file transfer date are included in the settings file device definition within the EnerVista UR Setup.



842863A1.CDR

Figure 79: Device definition showing traceability data

This information is also available in printed settings file reports as shown in the example. A report is generated by right-clicking and selecting the **Print Settings** option.




Figure 80: Settings file report showing traceability data

### 5.2.9.2 ONLINE DEVICE TRACEABILITY INFORMATION

The serial number and file transfer date are available for an online device through the actual values. Select the **Actual Values > Product Info > Model Information** menu item within the EnerVista online window as shown in the example.




Figure 81: Traceability data in Actual Values window

This information is also available from the front panel display through the following actual values:

**ACTUAL VALUES > PRODUCT INFO > MODEL INFORMATION > SERIAL NUMBER**

**ACTUAL VALUES > PRODUCT INFO > MODEL INFORMATION > LAST SETTING CHANGE**

### 5.2.9.3 ADDITIONAL TRACEABILITY RULES

The following additional rules apply for the traceability feature:

- If the user changes any settings within the settings file in the offline window, then the traceability information is removed from the settings file
- If the user creates a new settings file, then no traceability information is included in the settings file
- If the user converts an existing settings file to another revision, then any existing traceability information is removed from the settings file
- If the user duplicates an existing settings file, then any traceability information is transferred to the duplicate settings file

## 5.2.10 COMMAND LINE INTERFACE

SetupCLI is a command line interface to communicate with the EnerVista UR Setup software. Commands can be sent from a DOS prompt or a Windows batch file.

The interface is installed with the EnerVista software. Its default location is similar to `C:\Program Files\EnerVista\Tools\SetupCLI`

The EnerVista software needs to be installed on a computer to run the command line interface. The command line interface does not provide a remote connection to a computer running the EnerVista software.

Items to note are as follows:

- It works with EnerVista UR Setup version 6.10 and later
- It is available in English only
- The graphical user interface of the software is not available concurrently with the command line interface
- It does not support concurrent commands
- It has limited functionality with CyberSentry
- It does not interface with UR Engineer
- It does not work when EnerVista UR Setup security is enabled, meaning when login is required


The command syntax is as follows:

- Options enclosed in [ ] are optional
- Values enclosed in < > are replaced with your own values
- <Application> is replaced with the EnerVista software to receive the command. Use "URPC" for EnerVista UR Setup.
- <device> is the UR device name, as displayed in the Device Name field of the Device Setup window and listed in the Online Window. Use quotes with spaces, such as "B30 Belfort".
- "-s" can be used with any command to suppress error messages
- All commands, their return codes, and error description are logged in the file `C:\ProgramData\EnerVista\Tools\SetupCLI\SetupCLI.log`
- When the Supervisor account is enabled, the LOCK SETTINGS setting must be disabled (default) before the putsettings, inservice, or reboot command can be used. This setting cannot be changed using the command line interface.
- Use quotes (") to enclose any parameter containing a space
- Commands, options, and parameters are case sensitive
- All commands have a return code of 0-255. 0 indicates success and 1-255 indicate different errors
- If SetupCLI is automated (in a batch file), make sure that only a single batch is running at a time. SetupCLI does not support concurrent operations.

To run the command line interface:

1. In Windows, click the **Start** button, enter `cmd`, and press the **Enter** key. After prompting for permission, the Windows command window opens.
2. Enter `SetupCLI` followed by the action to execute. An example of use is to enter `SetupCLI -h` to display help, specifically the commands and explanations outlined here.





**Figure 82: Command line interface run in the command window**

#### **SetupCLI -h**

Display help.

It displays the content outline here.

#### **SetupCLI <Application> start [-c] [-s]**

Launch application with name <Application>.

To start in client mode, which is the graphical user interface, include option '-c'. Before use, the software must be idle without any windows open. Any activity or open windows can cause unexpected behavior. When in client mode, do not use Launchpad's Site Management feature.

To suppress errors, include option -s.

Example: SetupCLI URPC start -c

#### **SetupCLI <Application> exit [-s]**

Exit application with name <Application>.

Example: SetupCLI URPC exit

#### **SetupCLI <Application> login -d <device> [-A <authentication type>] [-a <account>] -w <password> [-s]**

Authenticate with device <device> using password <password>.

**For non-CyberSentry devices:** set <authentication type> to "traditional". Note that <authentication type> defaults to traditional if not specified.

Set <account> to COMMANDS or SETTINGS. If not specified, the SETTINGS account is used.

Example: SetupCLI URPC login -d "C30 Melbourne" -A traditional -a SETTINGS -w lpassword1

Example of a batch file that checks for an error (this batch file uses standard batch file operations to check the return code (ERRORLEVEL) and jump to an error handler):

```
SetupCLI URPC start
SetupCLI URPC login -d demoDevice -a SETTINGS -w WrongPassword -A traditional
IF NOT ERRORLEVEL 0 GOTO FAILED
SetupCLI URPC putsettings -d demoDevice -f "example file.urs"
SetupCLI URPC inservice -d demoDevice
SetupCLI URPC reboot -d demoDevice
SetupCLI URPC exit
exit

:FAILED
echo Please try again
exit
```

**For CyberSentry devices with local authentication:** Set <authentication type> to "local". Set <account> to "Supervisor", "Administrator", "Engineer", "Operator", or "Observer".

**For CyberSentry devices with RADIUS authentication** — Set <authentication type> to "radius". Set <account> to the user's account on the RADIUS server.

### SetupCLI <Application> logout -d <device> [-s]

Log out of device <device>.

Example: SetupCLI URPC logout -d C30

### SetupCLI <Application> getsettings -d <device> -f <File> [-s]

Read settings from device <device> and save them to the .urs file <File>. The <File> must not already exist. The default path to the output file is C:\Users\Public\Public Documents\GE Power Management\URPC\Data

Example: SetupCLI URPC getsettings -d C30 -f "C30 Markham.urs"

Example of a batch file to retrieve a settings file:

```
SetupCLI URPC start
SetupCLI URPC getsettings -d demoDevice -f C:\example.urs
SetupCLI URPC exit
```

Example of a batch file to retrieve a settings file from a relay that requires RADIUS authentication:

```
SetupCLI URPC start
SetupCLI URPC login -d demoDevice -a %1 -w %2 -A radius
SetupCLI URPC getsettings -d demoDevice -f "example file.urs"
SetupCLI URPC logout -d demoDevice
```

```
SetupCLI URPC exit
```

Although a user name and password could have been entered in this batch file, it would have created a security risk. Batch files allow you to pass in runtime parameters and refer to them in your script as %1, %2, and so on. For example, if this file is called example.bat, one calls it as follows: "example.bat MyUserName MyPassword"

### **SetupCLI <Application> putsettings -d <device> -f <File> [-s]**

Write the settings file <File> to the device <device>.

For CyberSentry devices, putsettings is only supported for users with the "Administrator" role.

Example: SetupCLI URPC putsettings -d C30 -f "C30 Markham.urs"

### **SetupCLI <Application> compare -f <File1> -r <File2> -o <OutputFile> [-s]**

Compare settings files <File1> and <File2>, and save output to <OutputFile>.

Example: SetupCLI URPC compare -f may.urs -r september.urs -o compared.txt

Batch file example that retrieves a settings file, compares it with an existing settings file, and opens the resulting comparison file:

```
SetupCLI URPC start
```

```
SetupCLI URPC getsettings -d demoDevice -f devicefile.urs
```

```
SetupCLI URPC compare -f existingfile.urs -r devicefile.urs -o output.txt
```

The output is similar to the following:

```
Comparing settings file aaa.urs : C:\Users\Public\Public Documents\GE Power
Management\URPC\Data\ with bbb.urs : C:\Users\Public\Public Documents\GE Power
Management\URPC\Data\
```

| # | Setting Name            | (Group,Module,Item) | Value   |
|---|-------------------------|---------------------|---------|
| 1 | Default Message Timeout | (1,1,1)             | = 299 s |
| 2 | Default Message Timeout | (1,1,1)             | = 300 s |
| 3 | Flash Message Time      | (1,1,1)             | = 0.9 s |
| 4 | Flash Message Time      | (1,1,1)             | = 1.0 s |

### **SetupCLI <Application> inservice -d <device> [-n] [-s]**

Put the device in service. Include option -n to take the device out of service.

Example: SetupCLI URPC inservice -d C30

### **SetupCLI <Application> reboot -d <device> [-s]**


Reboot the relay <device>. This is necessary after changing IEC 61850 settings and aggregator source settings.

Example: SetupCLI URPC reboot -d "C30\_Instanbul"

**SetupCLI <Application> adddevice -I <IP Address> -S <Slave Address> -P <Modbus Port>**

Connect to a device using its IP address, slave address, and Modbus port. Show the device in the EnerVista interface under the **SetupCLI** Site as `DEV@SETUP_CLI`.

EnerVista UR Setup 7.30 or higher supports this command.



**Figure 83: Device added using IP address**

The device is named as `DEV@SETUP_CLI`, which is used as the device name required by the <device> parameter of other **SetupCLI** commands.

The device name `DEV@SETUP_CLI` is always assigned to the device that is connected most recently by performing '**adddevice**' command. It means that the Application only keeps up to one device named as `DEV@SETUP_CLI`, the '**adddevice**' command disconnects/deletes the device `DEV@SETUP_CLI` that was connected previously by performing '**adddevice**' command.

The device name `DEV@SETUP_CLI` is never used to configure/connect to a device through the graphical user interface.

Example of a batch file using a device IP address to retrieve its settings file:

```
SetupCLI URPC start
SetupCLI URPC adddevice -I 192.168.140.113 -S 113 -P 502
SetupCLI URPC getsettings -d DEV@SETUP_CLI -f C:\example.urs
SetupCLI URPC exit
```

After connecting the device using IP address, the device name `DEV@SETUP_CLI` is used to identify this device in '**getsettings**' command.

Example of a batch file using a device IP address to retrieve a settings file when RADIUS authentication is required:

```
SetupCLI URPC start
SetupCLI URPC adddevice -I 192.168.140.113 -S 113 -P 502
SetupCLI URPC login -d DEV@SETUP_CLI -a %1 -w %2 -A radius
SetupCLI URPC getsettings -d DEV@SETUP_CLI -f "example file.urs"
SetupCLI URPC logout -d DEV@SETUP_CLI
```

SetupCLI URPC exit

DEV@SETUP\_CLI has to be used as the device name in the commands followed by the '**adddevice**' command.

## 5.3 FRONT PANEL

The basic front panel consists of LED panels, an RS232 port, keypad, LCD display, control pushbuttons, and optional user-programmable pushbuttons. The front panel is hinged to allow easy access to removable modules inside the chassis. There is also a removable dust cover that is to be removed when accessing the keypad. The basic front panel is available in either horizontal or vertical format\*. The following figures shows the two types of basic front panel.

**Note:**  
\*Vertical format not available for B90 or N60




Figure 84: Basic horizontal front panel

### 5.3.1 BASIC FRONT PANEL

The basic front panel consists of LED panels, an RS232 port, keypad, LCD display, control pushbuttons, and optional user-programmable pushbuttons. The front panel is hinged to allow easy access to removable modules inside the chassis. There is also a removable dust cover that is to be removed when accessing the keypad. The basic front panel is available in the horizontal format only. The following figures shows the two types of basic front panel.




Figure 85: Basic horizontal front panel

5.3.1.1 FRONT PANEL DISPLAY

Messages display on a back-lit liquid crystal display (LCD) to make them visible under poor lighting conditions. When the keypad and display are not actively being used, the display defaults to user-defined messages. Any high-priority event driven message overrides the default messages.

Up to 20 characters can be used to configure some setting names in the software, while up to 12 characters display on the front panel. A tilde (~) symbol is used for the twelfth character on the front panel when a name extends beyond the 12 character limit. An example is shown for a Virtual Input.



Figure 86: Tilde symbols displays with names 12 or more characters long

The front panel can be viewed and used in the EnerVista software, for example to view an error message displayed on the front panel or the LEDs. To view the front panel in EnerVista software, click **Actual Values > Front Panel**, then any option.




Figure 87: Front panel use in the software (B30 shown)

### 5.3.1.2 NAVIGATION KEYS

Display messages are organized into pages under the following headings: actual values, settings, commands, and targets.

The **MENU** key navigates through these pages. Each heading page is divided further into further submenus.

The **MESSAGE** keys navigate through the sub-menus. The **VALUE** keys increment or decrement numerical setting values when in programming mode. These keys also scroll through alphanumeric values in the text edit mode. Alternatively, values can be entered with the numeric keypad.

The decimal key initiates and advances to the next character in text edit mode or enters a decimal point.


The **HELP** key can be pressed at any time for context-sensitive help messages.

The **ENTER** key stores setting values.

When entering an IP address on the front panel, key in the first sequence of the number, then press the **•** key for the decimal place. For example, for 127.0.0.1, press 127, then **•**, then 0, then **•**, then 0, then **•**, then 1. To save the address, press the **ENTER** key.

When entering or changing an order code with two lines, press the down arrow to access the second line. On a basic front panel, do this under *ACTUAL VALUES > PRODUCT INFO > MODEL INFORMATION*.

The figure shows the sequence to use to enter a setting. Subsequent sections provide more detail.



**Figure 88: Front panel keypad use (basic front panel shown)**

### 5.3.1.3 LED INDICATORS

The basic front panel consists of three panels with LED indicators, keys, and a communications port. The **RESET** key is used to reset any latched LED indicator or target message, once the condition has been cleared (these latched conditions can also be reset via the *SETTINGS > INPUT/OUTPUTS > RESETTING* menu). The RS232 port is for connection to a computer.

The USER keys are used by the breaker control feature.






Figure 89: LED panel 1

### Status indicators

- **IN SERVICE** — Indicates that control power is applied, all monitored inputs/outputs and internal systems are fine, and the relay is in (online) Programmed mode (under **Settings > Product Setup > Installation**)
- **TROUBLE** — Indicates that the relay has detected an internal problem. Check the self-test messages outlined at the end of the Commands and Targets chapter, and view the event records under Actual Values > Records. For a beta / pre-release, this LED is always on.
- **TEST MODE** — Indicates that the relay is in test mode. For information, see the Testing section in the Settings chapter.
- **TRIP** — Indicates that the selected FlexLogic operand serving as a trip switch has operated. This indicator always latches; initiate the reset command to reset the latch.
- **ALARM** — Indicates that the selected FlexLogic operand serving as an alarm switch has operated. This indicator never latches.
- **PICKUP** — Indicates that an element is picked up. This indicator never latches.

### Event-cause indicators

Event-cause LEDs are turned on or off by protection elements that have their respective target setting selected as either “Enabled” or “Latched.” If a protection element target setting is “Enabled,” then the corresponding event cause LEDs remain on as long as the operand associated with the element remains asserted. If a protection element target setting is “Latched,” then the corresponding event cause LEDs turn on when the operate operand associated with the element is asserted and remains on until the RESET button on the front panel is pressed after the operand is reset.

All elements that are able to discriminate faulted phases can independently turn off or on the phase A, B, or C LEDs. This includes phase instantaneous overcurrent, phase undervoltage, and so on. This means that the phase A, B, and C operate operands for individual protection elements are ORed to turn on or off the phase A, B, or C LEDs.

- **VOLTAGE** — Indicates voltage was involved
- **CURRENT** — Indicates current was involved
- **FREQUENCY** — Indicates frequency was involved
- **OTHER** — Indicates a composite function that is not solely current, voltage, or frequency based (distance or power for example) or a control function (digital element or trip bus for example)
- **PHASE A** — Indicates phase A was involved
- **PHASE B** — Indicates phase B was involved
- **PHASE C** — Indicates phase C was involved
- **NEUTRAL/GROUND** — Indicates that neutral or ground was involved

## User-programmable indicators

The second and third panels provide 48 amber LED indicators whose operation is controlled by the user. Custom labeling can be done.

User customization of LED operation is of maximum benefit in installations where languages other than English are used to communicate with operators. See the User-programmable LEDs section in chapter 5 for the settings used to program the operation of the LEDs on these panels.

| USER-PROGRAMMABLE LEDs |        |        |
|------------------------|--------|--------|
| ■ (1)                  | ■ (9)  | ■ (17) |
| ■ (2)                  | ■ (10) | ■ (18) |
| ■ (3)                  | ■ (11) | ■ (19) |
| ■ (4)                  | ■ (12) | ■ (20) |
| ■ (5)                  | ■ (13) | ■ (21) |
| ■ (6)                  | ■ (14) | ■ (22) |
| ■ (7)                  | ■ (15) | ■ (23) |
| ■ (8)                  | ■ (16) | ■ (24) |

| USER-PROGRAMMABLE LEDs |        |        |
|------------------------|--------|--------|
| ■ (25)                 | ■ (33) | ■ (41) |
| ■ (26)                 | ■ (34) | ■ (42) |
| ■ (27)                 | ■ (35) | ■ (43) |
| ■ (28)                 | ■ (36) | ■ (44) |
| ■ (29)                 | ■ (37) | ■ (45) |
| ■ (30)                 | ■ (38) | ■ (46) |
| ■ (31)                 | ■ (39) | ■ (47) |
| ■ (32)                 | ■ (40) | ■ (48) |

842782A1.CDR

**Figure 90: LED panels 2 and 3 (index template)**

### Default labels for LED panel 2


The default labels are intended to represent the following:

- GROUP 1...6 — The illuminated GROUP is the active settings group
- BREAKER 1(2) OPEN — The breaker is open
- BREAKER 1(2) CLOSED — The breaker is closed
- BREAKER 1(2) TROUBLE — A problem related to the breaker has been detected
- SYNCHROCHECK NO1(10) IN-SYNCH — Voltages have satisfied the synchrocheck element
- RECLOSE ENABLED — The recloser is operational
- RECLOSE DISABLED — The recloser is not operational
- RECLOSE IN PROGRESS — A reclose operation is in progress
- RECLOSE LOCKED OUT — The recloser is not operational and requires a reset

**Note:**

*Firmware revisions 2.9x and earlier support eight user setting groups; revisions 3.0x and higher support six setting groups. For convenience of users using earlier firmware revisions, the relay panel shows eight setting groups. Even though the LEDs have default labels, they are fully user-programmable.*

The relay is shipped with the default label for the LED panel 2. The LEDs, however, are not pre-programmed. To match the pre-printed label, the LED settings must be entered as shown in the 'User-programmable LEDs section'. The LEDs are fully user-programmable. The default labels can be replaced by user-printed labels for both panels as explained in the next section.



| SETTINGS IN USE | BREAKER 1 | SYNCHROCHECK |
|-----------------|-----------|--------------|
| GROUP 1         | OPEN      | NO1 IN-SYNCH |
| GROUP 2         | CLOSED    | NO2 IN-SYNCH |
| GROUP 3         | TROUBLE   |              |
| GROUP 4         |           | RECLOSE      |
| GROUP 5         | BREAKER 2 | ENABLED      |
| GROUP 6         | OPEN      | DISABLED     |
| GROUP 7         | CLOSED    | IN PROGRESS  |
| GROUP 8         | TROUBLE   | LOCKED OUT   |

842784A1.CDR


Figure 91: LED panel 2 (default labels)

5.3.1.4 LABELING

After programming LEDs and pushbuttons under **Settings > Product Setup > User-Programmable Leds** and **User-Programmable Pushbuttons**, labels can be created for the front panel.

To create LED and pushbutton labels for a basic front panel:

1. In the EnerVista software, if the relay is not already listed in the Offline Window area, add it by right-clicking it and selecting the **Add Device to Offline Window** option.
2. Click the **File > Front Panel Report** menu item and select the device.
3. In the Front Panel Report window, double-click an LED or pushbutton slot and type a label. If you need to see the existing front panel remotely, access **Actual Values > Front Panel** for the online device.



852715A1

Figure 92: Basic front panel label designer (LEDs shown)

4. Optionally save the changes by clicking the Save icon on the toolbar.

5. Click the Print icon on the toolbar. Consider printing to PDF format and adjusting the zoom for appropriate label size, then print on a physical printer.
6. Cut labels as a block or individually, for example with scissors or an Exacto knife.
7. If there is a plastic cover over the front panel, remove it by gently pushing in on the right side and lifting off the cover.
8. Remove the plastic cover over the LEDs or pushbutton(s) using a screw driver.
9. Insert the labels.
10. Re-attach the plastic covers.

### 5.3.1.5 MENU NAVIGATION

Press the MENU key to display selections or home page. Each press of the key advances through the following main headings:

- Actual Values
- Settings
- Commands
- Targets
- Factory Service
- User displays (when enabled)

The setting and actual value pages are arranged hierarchically. Header display pages are indicated by two black squares, (■ ■) while sub-header pages are indicated by a single black square (■). The header display pages represent the highest level of the hierarchy and the sub-header display pages fall below this level. Use the down, right, left, and up arrows to navigate the menu. The MESSAGE up and down arrow keys move within a group of headers, sub-headers, setting values, or actual values. Continually pressing the MESSAGE right arrow from a header display displays specific information for the category. Conversely, continually pressing the MESSAGE left arrow from a setting value or actual value display returns to the header display.

Default values are indicated in this instruction manual in mixed case. In the example shown here, the default access level is restricted.

#### Highest level

■ ■ SETTINGS  
■ ■ PRODUCT SETUP



■ SECURITY



#### Lowest level (setting value)

■ ACCESS LEVEL  
■ Restricted



■ ■ SETTINGS  
■ ■ SYSTEM SETUP

#### Example

■ ■ ACTUAL VALUES  
■ ■ STATUS

Press the MENU key until the Actual Values header page appears. This page contains system and relay status information.



■ ■ SETTINGS  
■ ■ PRODUCT SETUP

Press the MENU key until the Settings header page appears. This category contains settings to configure the relay.



■ SECURITY

Press the MESSAGE right arrow once to display the first sub-header (Security).



ACCESS LEVEL:  
RESTRICTED

Press the MESSAGE right arrow once to display the first setting for Security.



■ SECURITY  
■

Press the MESSAGE left arrow to return to the Security heading.



■ DISPLAY  
■ PROPERTIES

Press the MESSAGE down arrow to display the second setting sub-header associated with the Product Setup header.



LANGUAGE:  
English

Press the MESSAGE right arrow once to display the first setting for Display Properties.



■ ■ SETTINGS  
■ ■ SYSTEM SETUP

Press the MESSAGE left arrow to return to the Display Properties page, then again to return to the Product Setup Page. Press the MESSAGE down arrow to move to the next Settings page. This page contains settings for System Setup.

### 5.3.1.6 CHANGE SETTINGS

#### Numerical data

Each numerical setting has its own minimum, maximum, and increment value associated with it. These parameters define what values are acceptable for a setting.

FLASH MESSAGE  
TIME: 10.0 s

For example, select the SETTINGS > PRODUCT SETUP > DISPLAY PROPERTIES > FLASH MESSAGE TIME setting.



MINIMUM: 0.5  
MAXIMUM: 10.0

Press the HELP key to view the minimum and maximum values. Press the key again to view the next context sensitive help message.

Two methods of editing and storing a numerical setting value are available.

- **0 to 9 and decimal point** — The relay numeric keypad works the same as a calculator. A number is entered one digit at a time. The leftmost digit is entered first and the rightmost digit is entered last. Pressing the MESSAGE left arrow or pressing the ESCAPE key, returns the original value to the display.
- **VALUE keys** — The VALUE up arrow increments the displayed value by the step value, up to the maximum value allowed. While at the maximum value, pressing the VALUE up arrow again allows the setting selection to continue upward from the minimum value. The VALUE down arrow decrements the displayed value by the step value, down to the minimum value. While at the minimum value, pressing the VALUE down arrow again allows the setting selection to continue downward from the maximum value.

FLASH MESSAGE  
TIME: 2.5 s

As an example, set the flash message time setting to 2.5 seconds. Press the appropriate numeric keys in the sequence "2 . 5". The display message changes as the digits are being entered.



**NEW SETTING  
HAS BEEN STORED**

Until ENTER is pressed, editing changes are not registered by the relay. Press ENTER to store the new value in memory. This flash message momentarily appears as confirmation of the storing process.

*Note:*

*Numerical values that contain decimal places are rounded-off if more decimal place digits are entered than specified by the step value*

**Enumeration data**

Enumeration settings have data values that are part of a set, whose members are explicitly defined by a name. A set has two or more members.

**ACCESS LEVEL:  
Restricted**

For example, the selections available for ACCESS LEVEL are "Restricted," "Command," "Setting," and "Factory Service."

Enumeration type values are changed using the VALUE keys. The VALUE up arrow displays the next selection while the VALUE down arrow displays the previous selection.

**ACCESS LEVEL:  
Setting**

If the ACCESS LEVEL needs to be "Setting," press the VALUE keys until the proper selection displays. Press HELP at any time for the context sensitive help messages.

**NEW SETTING  
HAS BEEN STORED**

Changes are not registered by the relay until the ENTER key is pressed. Pressing ENTER stores the new value in memory. This flash message momentarily appears as confirmation

**Alphanumeric text**

Text settings have data values that are fixed in length, but user-defined in characters. They can be upper-case letters, lower-case letters, numerals, and a selection of special characters.

There are several places where text messages can be programmed to allow the relay to be customized for specific applications. One example is the Message Scratchpad. Use the following procedure to enter alphanumeric text messages.

For example, enter the text "Breaker #1".


1. Press the decimal point to enter text edit mode.
2. Press the VALUE keys until the character 'B' appears; press the decimal key to advance the cursor to the next position.
3. Repeat step 2 for the remaining characters: r,e,a,k,e,r, #,1.
4. Press ENTER to store the text.
5. If you have any problem, press HELP to view context sensitive help. Flash messages appear sequentially for several seconds each. For the case of a text setting message, pressing HELP displays how to edit and store new values.

---

**5.3.2 ENHANCED FRONT PANEL**

The enhanced front panel consists of LED panels, an RS232 port, keypad, LCD display, control pushbuttons, and optional user-programmable pushbuttons. The front panel is hinged to allow access to removable modules inside the chassis. The enhanced front panel is available in either horizontal or vertical format\*. The following figure shows the horizontal front panel. The following figures shows the two types of enhanced front panel.

**Note:**  
\*Vertical format not available for B90 or N60



**Figure 93: Enhanced horizontal front panel**



**Figure 94: Enhanced vertical front panel**



### 5.3.2.1 ENHANCED FRONT PANEL DISPLAY

Messages display on a back-lit liquid crystal display (LCD) to make them visible under poor lighting conditions. When the keypad and display are not actively being used, the display defaults to user-defined messages. Any high-priority event driven message overrides the default messages.

Up to 20 characters can be used to configure some setting names in the software, while up to 12 characters display on the front panel. A tilde (~) symbol is used for the twelfth character on the front panel when a name extends beyond the 12 character limit. An example is shown for a Virtual Input.



842936A1

Figure 95: Tilde symbols displays with names 12 or more characters long

The front panel can be viewed and used in the EnerVista software, for example to view an error message displayed on the front panel or the LEDs. To view the front panel in EnerVista software, click **Actual Values > Front Panel**, then any option.




Figure 96: Front panel use in the software (B30 shown)



### 5.3.2.2 NAVIGATION KEYS

Display messages are organized into pages under the following headings: actual values, settings, commands, and targets.

The **MENU** key navigates through these pages. Each heading page is divided further into further submenus.

The **MESSAGE** keys navigate through the sub-menus. The **VALUE** keys increment or decrement numerical setting values when in programming mode. These keys also scroll through alphanumeric values in the text edit mode. Alternatively, values can be entered with the numeric keypad.

The decimal key initiates and advances to the next character in text edit mode or enters a decimal point.


The **HELP** key can be pressed at any time for context-sensitive help messages.

The **ENTER** key stores setting values.

When entering an IP address on the front panel, key in the first sequence of the number, then press the **•** key for the decimal place. For example, for 127.0.0.1, press 127, then **•**, then 0, then **•**, then 0, then **•**, then 1. To save the address, press the **ENTER** key.

When entering or changing an order code with two lines, press the down arrow to access the second line. On a basic front panel, do this under *ACTUAL VALUES > PRODUCT INFO > MODEL INFORMATION*.

The figure shows the sequence to use to enter a setting. Subsequent sections provide more detail.



**Figure 97: Front panel keypad use (basic front panel shown)**

### 5.3.2.3 LED INDICATORS

The enhanced front panel display provides five columns of LED indicators. The first column contains 14 status and event-cause LEDs. The next four columns contain the 48 user-programmable LEDs.

The **RESET** key is used to reset any latched LED indicator or target message, once the condition has been cleared (these latched conditions can also be reset via the *SETTINGS > INPUT/OUTPUTS > RESETTING* menu).

The **USER** keys are used by the breaker control feature.



842811A1.CDR

**Figure 98: Typical LED panel for enhanced front panel**

The status indicators in the first column are as follows:

- **IN SERVICE** — Indicates that control power is applied, all monitored inputs/outputs and internal systems are fine, and the relay is in (online) Programmed mode (under [Settings > Product Setup > Installation](#))
- **TROUBLE** — Indicates that the relay has detected an internal problem. Check the self-test messages outlined at the end of the Commands and Targets chapter, and view the event records under [Actual Values > Records](#). For a beta / pre-release, this LED is always on.
- **TEST MODE** — Indicates that the relay is in test mode. For information, see the Testing section in the Settings chapter.
- **TRIP** — Indicates that the selected FlexLogic operand serving as a trip input has operated. Set the operand under [Settings > Product Setup > User-Programmable LEDs > Trip & Alarm LEDs](#). This indicator latches; initiate the reset command to reset the latch.
- **ALARM** — Indicates that the FlexLogic operand serving as an alarm switch has operated. Set the operand under [Settings > Product Setup > User-Programmable LEDs > Trip & Alarm LEDs](#). This indicator never latches.
- **PICKUP** — Indicates that an element is picked up. This indicator never latches.
- The event-cause indicators in the first column are as follows.

Event-cause LEDs are below the status LEDs. They are turned on or off by protection elements that have their respective target setting selected as either “Enabled” or “Latched.” If a protection element target setting is “Enabled,” then the corresponding event-cause LEDs remain on as long as the operand associated with the element remains asserted. If a protection element target setting is “Latched,” then the corresponding event-cause LEDs turn on when the operate operand associated with the element is asserted and remains on until the RESET button on the front panel is pressed after the operand is reset.

All elements that are able to discriminate faulted phases can independently turn off or on the phase A, B, or C LEDs. This includes phase instantaneous overcurrent, phase undervoltage, and so on. This means that the phase A, B, and C operate operands for individual protection elements are ORed to turn on or off the phase A, B, or C LEDs.

- **VOLTAGE** — This LED indicates voltage was involved
- **CURRENT** — This LED indicates current was involved
- **FREQUENCY** — This LED indicates frequency was involved
- **OTHER** — This LED indicates a composite function that is not solely current, voltage, or frequency based (distance or power for example) or a control function (digital element or trip bus for example)
- **PHASE A** — This LED indicates phase A was involved
- **PHASE B** — This LED indicates phase B was involved
- **PHASE C** — This LED indicates phase C was involved
- **NEUTRAL/GROUND** — This LED indicates that neutral or ground was involved

The user-programmable LEDs consist of 48 amber LED indicators in four columns. The operation of these LEDs is user-defined. Support for applying a customized label beside every LED is provided. Default labels are shipped in the label package of every relay, together with custom templates. The default labels can be replaced by user-printed labels. User customization of LED operation is of maximum benefit in installations where languages other than English are used to communicate with operators. See the User-Programmable LEDs section in chapter 5 for the settings used to program the operation of the LEDs on these panels.


### 5.3.2.4 LABELING

The following procedure requires these pre-requisites:

- The UR front panel label cutout sheet (Part number 1006-0047) has been downloaded from <http://www.governova.com/grid-solutions/products/support/ur/URLEDenhanced.doc> and printed
- Small-bladed knife

To create custom LED and pushbuttons labels for the enhanced front panel:

1. Start the EnerVista UR Setup software.
2. If not already copied to the Offline Window area, right-click the online device and select the Add Device to Offline Window option. Click the Receive button in the window that opens to save the settings file to the Offline Window area.
3. Type labels as follows. Select the File > Front Panel Report. The window opens.



852336A2

Figure 99: Enhanced front panel label designer

4. Enter the text to appear next to each LED and above each user-programmable pushbutton in the fields provided. The LED Offsets and Button Offsets buttons move all labels left/right and up/down on the page (they both do the same action, so use either button). The Button Offsets button does not display when there are no pushbuttons to customize.
5. Feed the UR front panel label cutout sheet into a printer and press the Print button in the front panel report window.
6. When printing is complete, fold the sheet along the perforated lines and punch out the labels.
7. Remove the UR label insert tool from the package and bend the tabs as described in the following procedures. These tabs are used for removal of the default and custom LED labels.

**Note:**

Use the tool with the printed side containing the GE Vernova part number facing the user

The label package shipped with every relay contains the three default labels, the custom label template sheet, and the label removal tool.

If the default labels are suitable for your application, insert them in the appropriate slots and program the LEDs to match them. If you require custom labels, use the following procedures to remove the original labels and insert the new ones.

To set up and use the label removal tool:

1. Bend the tabs at the left end of the tool upwards as shown



2. Bend the tab at the center of the tool tail



To remove the LED labels from the relay front panel and insert the custom labels as shown:

1. Use the knife to lift the LED label and slide the label tool underneath. Ensure that the bent tabs are pointing away from the relay.



2. Slide the label tool under the LED label until the tabs snap out as shown. This attaches the label tool to the LED label.



3. Remove the tool and attached LED label as shown.



4. Slide the new LED label inside the pocket until the text is properly aligned with the LEDs, as shown.





To remove the user-programmable pushbutton labels from the front panel and insert the custom labels:

1. Use the knife to lift the pushbutton label and slide the tail of the label tool underneath, as shown. Ensure that the bent tab points away from the relay.



2. Slide the label tool under the user-programmable pushbutton label until the tabs snap out as shown. This attaches the label tool to the user-programmable pushbutton label.



3. Remove the tool and attached user-programmable pushbutton label.



- Slide the new user-programmable pushbutton label inside the pocket until the text is properly aligned with the buttons.



### 5.3.2.5 MENU NAVIGATION

Press the MENU key to display selections or home page. Each press of the key advances through the following main headings:

- Actual Values
- Settings
- Commands

- Targets
- Factory Service
- User displays (when enabled)

The setting and actual value pages are arranged hierarchically. Header display pages are indicated by two black squares, (■ ■) while sub-header pages are indicated by a single black square (■). The header display pages represent the highest level of the hierarchy and the sub-header display pages fall below this level. Use the down, right, left, and up arrows to navigate the menu. The MESSAGE up and down arrow keys move within a group of headers, sub-headers, setting values, or actual values. Continually pressing the MESSAGE right arrow from a header display displays specific information for the category. Conversely, continually pressing the MESSAGE left arrow from a setting value or actual value display returns to the header display.

Default values are indicated in this instruction manual in mixed case. In the example shown here, the default access level is restricted.

**Highest level**

■ ■ SETTINGS  
■ ■ PRODUCT SETUP



■ ■ SETTINGS  
■ ■ SYSTEM SETUP

**Lowest level (setting value)**



■ SECURITY  
■



■ ACCESS LEVEL  
■ Restricted

**Example**

■ ■ ACTUAL VALUES  
■ ■ STATUS

Press the MENU key until the Actual Values header page appears. This page contains system and relay status information.



■ ■ SETTINGS  
■ ■ PRODUCT SETUP

Press the MENU key until the Settings header page appears. This category contains settings to configure the relay.



■ SECURITY  
■

Press the MESSAGE right arrow once to display the first sub-header (Security).



ACCESS LEVEL:  
RESTRICTED

Press the MESSAGE right arrow once to display the first setting for Security.



■ SECURITY  
■

Press the MESSAGE left arrow to return to the Security heading.



■ DISPLAY  
■ PROPERTIES

Press the MESSAGE down arrow to display the second setting sub-header associated with the Product Setup header.



LANGUAGE:  
English

Press the MESSAGE right arrow once to display the first setting for Display Properties.





- ■ SETTINGS
- ■ SYSTEM SETUP

Press the MESSAGE left arrow to return to the Display Properties page, then again to return to the Product Setup Page. Press the MESSAGE down arrow to move to the next Settings page. This page contains settings for System Setup.

### 5.3.2.6 CHANGE SETTINGS

#### Numerical data

Each numerical setting has its own minimum, maximum, and increment value associated with it. These parameters define what values are acceptable for a setting.

**FLASH MESSAGE**  
**TIME: 10.0 s**



**MINIMUM: 0.5**  
**MAXIMUM: 10.0**

For example, select the SETTINGS > PRODUCT SETUP > DISPLAY PROPERTIES > FLASH MESSAGE TIME setting.

Press the HELP key to view the minimum and maximum values. Press the key again to view the next context sensitive help message.

Two methods of editing and storing a numerical setting value are available.

- **0 to 9 and decimal point** — The relay numeric keypad works the same as a calculator. A number is entered one digit at a time. The leftmost digit is entered first and the rightmost digit is entered last. Pressing the MESSAGE left arrow or pressing the ESCAPE key, returns the original value to the display.
- **VALUE keys** — The VALUE up arrow increments the displayed value by the step value, up to the maximum value allowed. While at the maximum value, pressing the VALUE up arrow again allows the setting selection to continue upward from the minimum value. The VALUE down arrow decrements the displayed value by the step value, down to the minimum value. While at the minimum value, pressing the VALUE down arrow again allows the setting selection to continue downward from the maximum value.

**FLASH MESSAGE**  
**TIME: 2.5 s**



**NEW SETTING**  
**HAS BEEN STORED**

As an example, set the flash message time setting to 2.5 seconds. Press the appropriate numeric keys in the sequence "2 . 5". The display message changes as the digits are being entered.

Until ENTER is pressed, editing changes are not registered by the relay. Press ENTER to store the new value in memory. This flash message momentarily appears as confirmation of the storing process.

*Note:*

*Numerical values that contain decimal places are rounded-off if more decimal place digits are entered than specified by the step value*

#### Enumeration data

Enumeration settings have data values that are part of a set, whose members are explicitly defined by a name. A set has two or more members.

**ACCESS LEVEL:**  
**Restricted**

For example, the selections available for ACCESS LEVEL are "Restricted," "Command," "Setting," and "Factory Service."

Enumeration type values are changed using the VALUE keys. The VALUE up arrow displays the next selection while the VALUE down arrow displays the previous selection.

**ACCESS LEVEL:**  
**Setting**

If the ACCESS LEVEL needs to be "Setting," press the VALUE keys until the proper selection displays. Press HELP at any time for the context sensitive help messages.



**NEW SETTING**  
**HAS BEEN STORED**

Changes are not registered by the relay until the ENTER key is pressed. Pressing ENTER stores the new value in memory. This flash message momentarily appears as confirmation

### Alphanumeric text

Text settings have data values that are fixed in length, but user-defined in characters. They can be upper-case letters, lower-case letters, numerals, and a selection of special characters.

There are several places where text messages can be programmed to allow the relay to be customized for specific applications. One example is the Message Scratchpad. Use the following procedure to enter alphanumeric text messages.

For example, enter the text "Breaker #1".


1. Press the decimal point to enter text edit mode.
2. Press the VALUE keys until the character 'B' appears; press the decimal key to advance the cursor to the next position.
3. Repeat step 2 for the remaining characters: r,e,a,k,e,r, #,1.
4. Press ENTER to store the text.
5. If you have any problem, press HELP to view context sensitive help. Flash messages appear sequentially for several seconds each. For the case of a text setting message, pressing HELP displays how to edit and store new values.

---

### 5.3.3 GRAPHICAL FRONT PANEL

The graphical front panel is a hardware option. A relay with a graphical front panel can only be configured with Enervista, so if you order a relay with a graphical front panel, you also need to order EnerVista.

The graphical front panel consists of a USB port, LED panel, color screen display, user-programmable pushbuttons, and navigation keys. The graphical front panel has a seven-inch (17.8 cm) color liquid crystal display (LCD). The display is used to read data, such as metering actual values, alarms, self-test messages, and event records, and for viewing single-line diagrams. Settings can be changed on the front panel, except for the graphical front panel itself and for IEC 61850. The USB port connects to a computer with the EnerVista software and can be used to upgrade the relay and to transfer files and settings. The USB port is the square type B. User-programmable pushbuttons 9 to 40 can be programmed among the 10 pushbuttons on the left and right sides of the display. The graphical front panel is available only in the horizontal format. The following figures shows the graphical front panel.



**Figure 100: Graphical front panel**

Header content varies by page. The home page displays any active icons, such as security status, active setting group, and active target messages. It shows the date and time of the relay. If the relay synchronizes to an external time source via PTP, IRIG-B, SNTP, and so on, the date/time is shown in white, and otherwise in yellow. On pages other than the home page, the header displays the name of the page.

The footer dynamically labels the Tab, or control, pushbuttons immediately below. Page content displays between the header and footer.

### 5.3.3.1 HOME PAGE

Press the **Home** pushbutton to display the root page no matter the state. Any edit, control, or password entry sessions are canceled. The header shows several relay/system status icons. The default content of the home page is the product information page, which you can configure to show the content of any single-line diagram page, annunciator page, metering page, or event records page for example. The Tab pushbuttons on the bottom row each navigate to their page. The home page displays for a user-configured time period, then scrolls through user-configured pages, a feature referred to as rolling.

Holding the **Home** pushbutton for one second displays the product information page. The Home page also can display when settings are saved.



Security indicator, showing how many people are logged in, including local and remote users. The lock is red when one or more users are logged in and otherwise green.



When no users are logged in because login is not required, an icon does not display.



Identifies the active setting group number (not shown)



Displays when an abnormal annunciator alarm is present. Navigate to the Annunciator for details. When there are no such alarms, the icon does not display.

Even when you acknowledge/reset an alarm, the icon displays as long as the condition remains. For example, a breaker trouble alarm displays, you acknowledge it, but the icon remains because the breaker trouble remains.



ActiveTargets: defined targets symbol, where targets are error messages.

View error messages by pressing the Menu Tab pushbutton, then accessing the TARGETS menu. Pressing the RESET button clears those messages that can be.

Configure the home page in the software under **Settings > Product Setup > Graphical Panel > Home Page**. The menu does not display when there is no graphical front panel.




Figure 101: Home page example with default content (product information)

### 5.3.3.2 ROLLING MODE

After a user-defined period of inactivity, the graphical front display rolls among up to 10 user-selected pages. The roll-to-pages are selected in the EnerVista software, with the defaults being the product information page. Each page displays for less than five seconds. Also, the display backlight intensity is lowered after a configurable period to a user-defined level (0, 10, 20, or 30%); lower intensity extends the life of the display.

Configure rolling mode in the software under **Settings > Product Setup > Graphical Panel > Rolling Mode**.

Operation works as follows:

- Press the Home pushbutton or ESCAPE pushbutton twice to cancel rolling, restore full backlight intensity, and return to the Home page
- Press the ENTER, ESCAPE, or a pushbutton to pause rolling once and restore full backlight intensity

Rolling is disabled by setting the delay to 0.

The following buttons display at the top of the window:

- Save — Updates the connected device if online or the open setting file if offline with changes made
- Restore — Undoes changes that have not been saved
- Default — Changes all rolling mode settings to their factory default values
- Reset — Displays factory default values. Previous changes are not lost unless you save the reset window.

### 5.3.3.3 SINGLE-LINE DIAGRAMS


A single-line diagram, or mimic diagram, is a line drawing of elements in an electrical system. The graphical front panel displays up to five single-line diagrams. Each can be configured to show the arrangement of a portion of the

power system, the status of circuit breakers and of ground and disconnect switches, user-programmable pushbuttons, and metering and status values. Each also enables control of the displayed breakers and switches when operand status assigned to the Enable Controls from GFP setting is ON.

One diagram is provided by default, `single_bus_line_dsc.mif`, which can be modified.

Configure the diagrams under **Settings > Product Setup > Graphical Panel > Single Line Diagram Editor**.

Each single-line diagram page has a user-configurable name that appears in the header and in the footer Tab pushbutton label. Factory default names are SLD 1 to SLD 5. Pages that have no configured content have a blank Tab pushbutton label, and the Tab pushbutton does nothing. The label for the current page has a blue background.



859875A1.cdr


**Figure 102: Toolbar options for single-line diagram**

The letters T, S, B, R, and X next to a controllable element have the following meaning. An example (TSB) is shown in the next figure.

- T — The element is “tagged” (irrespective of whether it is tagged from graphical front panel or via IEC 61850). Local and remote control of the device are inhibited, both open and close. Tripping is unaffected unless additional logic has been configured.
- S — The position indication of the device is substituted with a manually entered value
- B — Blocking open/close command is bypassed
- R — Autoreclose is enabled and not blocked
- X — The device is out-of-service and control is not available

#### 5.3.3.4 SINGLE-LINE DIAGRAM EXAMPLE

The following example outlines how to create a circuit breaker diagram, then how to close the second circuit breaker. The figure shows six switches (SW, M), two breakers (CB), feeder (arrow), and ground (lined arrow).



859853A2

Figure 103: Single-line diagram of open circuit breakers

Under **Settings > System Setup > Switches and Breakers**, enable and name the six switches and two breakers. Switch 6, M568G, has the A/3 Pole Opened setting on.

| VIEW ALL mode                   |           |
|---------------------------------|-----------|
| SETTING                         | PARAMETER |
| Breaker 1 Function              | Enabled   |
| Breaker 1 Push Button Control   | Enabled   |
| Breaker 1 Tagging               | Enabled   |
| Breaker 1 Substitution          | Enabled   |
| Breaker 1 Bypass                | Enabled   |
| Breaker 1 AR Block              | Enabled   |
| Breaker 1 Name                  | CB569     |
| Breaker 1 Mode                  | 3-Pole    |
| Breaker 1 Open                  | OFF       |
| Breaker 1 Block Open            | OFF       |
| Breaker 1 Close                 | OFF       |
| Breaker 1 Block Close           | OFF       |
| Breaker 1 Phase A/3-Pole Closed | ON        |
| Breaker 1 Phase A/3-Pole Opened | OFF       |
| Breaker 1 Phase B Closed        | OFF       |

859886A1

| <div> <div>Save</div> <div>Restore</div> <div>Default</div> <div>Reset</div> <div>VIEW ALL mode</div> </div> |           |
|--------------------------------------------------------------------------------------------------------------|-----------|
| SETTING                                                                                                      | PARAMETER |
| Switch 1 Function                                                                                            | Enabled   |
| Switch 1 Name                                                                                                | SW569     |
| Switch 1 Mode                                                                                                | 3-Pole    |
| Switch 1 Open                                                                                                | OFF       |
| Switch 1 Block Open                                                                                          | OFF       |
| Switch 1 Close                                                                                               | OFF       |
| Switch 1 Block Close                                                                                         | OFF       |
| Switch 1 Phase A/3 Pole Closed                                                                               | ON        |
| Switch 1 Phase A/3 Pole Opened                                                                               | OFF       |
| Switch 1 Phase B Closed                                                                                      | OFF       |

859887A1

|                                |         |
|--------------------------------|---------|
| Switch 6 Function              | Enabled |
| Switch 6 Name                  | M568G   |
| Switch 6 Mode                  | 3-Pole  |
| Switch 6 Open                  | OFF     |
| Switch 6 Block Open            | OFF     |
| Switch 6 Close                 | OFF     |
| Switch 6 Block Close           | OFF     |
| Switch 6 Phase A/3 Pole Closed | OFF     |
| Switch 6 Phase A/3 Pole Opened | ON      |
| Switch 6 Phase B Closed        | OFF     |
| Switch 6 Phase B Opened        | OFF     |

859888A1

**Figure 104: Configure Breaker and Switch settings**

In the EnerVista software, open the single-line diagram editor under **Settings > Product Setup > Graphical Panel > Single Line Diagram Editor**.

Add the four switches for the top line by clicking the GE switch symbol in the toolbar, then clicking in the window. (If the UR device is not online, the software attempts to connect.) Right-click to edit properties. Rotate switches SW569 and SW5682 to 270 degrees. Rotate switches 5681 and SW523 to 90 degrees. Ignore the TSB text.

Add the two lower switches. Leave rotation at 0 degrees.

Add the two breakers by clicking the GE breaker symbol in the toolbar, then click in the window. Right-click to edit properties, rotating 90 degrees and setting the color to red (open).

Draw lines to fill in the gaps between the switches and breakers by clicking the line symbol in the toolbar, then clicking and dragging on the canvas to draw a line. Do not draw a single line for the top line, but instead draw several small lines.

Add the feeder arrow head by clicking the symbol in the toolbar, then clicking the end of the line.

Add the ground symbol by clicking the symbol in the toolbar, then clicking the end of the line.

Add three metered values by clicking the M symbol in the toolbar, then clicking near the feeder arrow. Double-click to edit. The three metered values are SRC1 Vag Mag, SRC 1 P, and SRC 1 Q.

Name the page by right-clicking the bottom tab. Here, page 1 is renamed "Milton line M568M."

Note that active symbols in the toolbar display and those that are inactive are greyed-out.

The diagram has been created. Save it by clicking the **Save** button.

Next is to close circuit breaker CB523. This circuit breaker is shown at the top right of the figure. A vertical line means that it is open, and the color can be set as red or green.



On the graphical front panel, press the Home pushbutton, then press the SLDs pushbutton to activate the first single-line diagram page.




Figure 105: Single-line diagram on graphical front panel

Press the Enable Control pushbutton, which displays when the **Settings > Product Setup > Graphical Panel > Home Page > Enable Controls From GFP** setting is configured and its FlexLogic operand is ON. The side pushbutton labels display.





Figure 106: Side pushbutton display on graphical front panel



Press the **CB523** breaker pushbutton. Its menu displays.



**Figure 107: Pushbuttons to control the breaker**

Press the pushbutton to close the breaker, confirming the action at the prompt.

**Note:**

If at the prompt the control action is prevented this is because status of the operand assigned to the **Enable Controls From GFP** setting has changed back to OFF before confirming the prompt action. As a result, the command is not issued, and the screen goes to the top SLD page.

In this diagram, the two circuit breakers have hard-coded actions available to them. No action is possible on the switches.

Observe the USER PB 9 and 10 entries in the earlier figure. As outlined later, these are activated by clicking the PB icon on the software toolbar. These two pushbuttons can be configured under **Settings > Product Setup > User-Programmable Pushbuttons**.

When a breaker is tagged, the letter T displays under the breaker in the diagram. The **Tag** pushbutton shown toggles to **Remove Tag**.

### 5.3.3.5 SINGLE-LINE DIAGRAM EDITOR

Start the application in the EnerVista software under **Settings > Product Setup > Graphical Panel > Single Line Diagram** Editor.

The following buttons display at the top of the window:

- Save — Updates the connected device if online or the open setting file if offline with changes made
- Restore — Undoes changes that have not been saved
- Load — Opens single-line diagram files, which replaces one or all windows with that in the file selected
- Store — Saves all single-line diagrams as a .mif file. Because single-line diagrams are not retained when using the **Convert Device Settings** function, for example when converting in the Offline Window area from version 7.6 to 7.7, GE recommends making backup files using this function.

On the right side of the window is a toolbox containing the components that can be added to the window. These include line, breaker, disconnect, metering value, status value, text, and miscellaneous power system elements. To create the single-line diagram, click the symbol, then click in the window. Once in the window, the component can be positioned and its properties modified. When using the pointing device to position a component, the component can snap to the nearest snap point. Snap points are in a 4 x 4 rectangular grid. The keyboard arrow keys move the selected component(s) in one pixel increments when snap locations are inadequate. Multiple components can be selected and moved or deleted as a group, or copied and pasted to another location. Right- or double-clicking a component opens the properties window.

**Ctrl+A** selects all objects in a diagram.

### Lines

Line components represent power system busses or electrical connections between power system elements. They can also be used as visual dividers and underline.






To add a line component, click it in the toolbox, then click in the window. Double-click a line to open its properties window to set orientation.

### Static symbols

Static symbols depicting power system elements are available. For information, see the ANSI/IEEE 315A and IEC 60617 standards.

Up to 32 static symbols can be used per single-line diagram.

To add a symbol, click it in the toolbox, then click in the window. Double-click the symbol to open its properties window to set orientation.

| Device                            | Symbols                                                                              |
|-----------------------------------|--------------------------------------------------------------------------------------|
| 3W Transformer                    |    |
| 2W Transformer                    |    |
| Rotating machines                 |    |
| Reactor                           |    |
| Ground                            |     |
| Connector, Bus, Feeder, Crossover |    |
| CT                                |    |
| VT / PT                           |  |
| Capacitor                         |  |

859872A1

**Figure 108: IEEE and IEC static symbols****Breaker and disconnect components**

Breaker components and disconnect components are interfaces to the UR breaker control elements and disconnect switch elements. On a UR device they show dynamically the breaker or disconnect status as calculated by the element, and provide means to open, close, tag, bypass interlock, and substitute (force status of) the element. Breaker components in addition provide means to enable/disable breaker autoreclose.

Each breaker and disconnect component can be configured to use UR-style symbols, IEC symbols, or simple square/slash symbols as shown in the following figure. The symbols assume horizontal symbol orientation, red - closed color, and green - open scheme. With vertical orientation, they are rotated 90 degrees.

|                                            | IEEE style<br>(IEEE 315) | IEC Style<br>(IEC 60617) | GE Style |
|--------------------------------------------|--------------------------|--------------------------|----------|
| Disconnect Switch<br>(Open)                |                          |                          |          |
| Disconnect Switch<br>(Intermediate)        |                          |                          |          |
| Disconnect Switch<br>(Closed)              |                          |                          |          |
| Disconnect Switch<br>(Bad Status/Disabled) |                          |                          |          |
| Breaker (Open)                             |                          |                          |          |
| Breaker (Closed)                           |                          |                          |          |
| Breaker (Bad Status/Disabled)              |                          |                          |          |
| Breaker racked-out<br>(Open)               |                          |                          |          |
| Breaker racked-out<br>(Closed)             |                          |                          |          |
| Breaker racked-out<br>(Bad Status)         |                          |                          |          |
| Breaker racked-in<br>(Open)                |                          |                          |          |
| Breaker racked-in<br>(Closed)              |                          |                          |          |
| Breaker racked-in<br>(Bad Status)          |                          |                          |          |

(1) Red/Green color scheme for closed/open is configurable by the user.

(2) 3-position disconnect switches can be represented by grouping two 2-position disconnects switches.

859879A1

**Figure 109: Single-line diagram symbols**

To add a breaker or disconnect component, click it in the toolbox, then click in the window. Up to 10 dynamic components can be added to each single-line diagram.

Breaker and disconnect components have three different parts: label, symbol, and flags. Drag each of its parts to their final locations. Double or right-click any of these parts to open the properties window. Properties that can be

edited are label text, breaker control element or disconnect switch element number, symbol orientation (horizontal or vertical), color scheme (red - closed, or red - open), and assigned side button (if any). If the selected breaker or disconnect element does not exist in the target relay or has not been enabled, then the component is displayed in the graphical front panel and in the drawing edit window in grey. The color scheme selection has no effect when an IEC style symbol is used because IEC style symbols do not use color.

**Symbol orientation**







The figure shows the orientation available for the breaker and disconnect switch (taking Open status as examples). The default position is 0 degrees.

|            |                          | 0 degree | 90 degrees | 180 degrees | 270 degrees |
|------------|--------------------------|----------|------------|-------------|-------------|
| IEEE Style | Disconnect Switch (Open) |          |            |             |             |
|            | Breaker (Open)           |          |            |             |             |
| IEC Style  | Disconnect Switch (Open) |          |            |             |             |
|            | Breaker (Open)           |          |            |             |             |
| GE Style   | Disconnect Switch (Open) |          |            |             |             |
|            | Breaker (Open)           |          |            |             |             |

859768A1



**Figure 110: Single-line diagram symbol orientation**

A question mark displays in a symbol on the graphical front panel when status is bad. The question mark does not rotate with orientation. The following figures show the orientation available for the static components. The default position is 0 degrees.

|                   | 0 degree                                                                            | 90 degrees                                                                          | 180 degrees                                                                           | 270 degrees                                                                           |
|-------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| 3W Transformer    |    |    |     |    |
| 2W Transformer    |    |    | 0 degree                                                                              | 90 degrees                                                                            |
| 3W Transformer    |    |    |     |    |
| 2W Transformer    |    |    | 0 degree                                                                              | 90 degrees                                                                            |
| Rotating machines |    | 0 degree                                                                            | 0 degree                                                                              | 0 degree                                                                              |
| Reactor           |    |    | 0 degree                                                                              | 90 degrees                                                                            |
| Reactor           |  |  |  |  |
| Capacitor         |  |  |  |  |
| Capacitor         |  |  | 0 degree                                                                              | 90 degrees                                                                            |

859770A1

Figure 111: Single-line diagram static symbol orientation (sheet 1 of 2)

|           | 0 degree                                                                            | 90 degrees                                                                          | 180 degrees                                                                          | 270 degrees                                                                          |
|-----------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| Ground    |    |    |   |   |
| Connector |    |    | 0 degree                                                                             | 90 degrees                                                                           |
| Bus       |    |    | 0 degree                                                                             | 90 degrees                                                                           |
| Feeder    |    |    |   |   |
| Crossover |    |    | 0 degree                                                                             | 90 degrees                                                                           |
| CT        |    |    |   |   |
| CT        |   |   |  |  |
| VT / PT   |  |  | 0 degree                                                                             | 90 degrees                                                                           |
| VT / PT   |  |  | 0 degree                                                                             | 90 degrees                                                                           |


859771A1

Figure 112: Single-line diagram static symbol orientation (sheet 2 of 2)

### User-programmable pushbuttons

User-programmable pushbuttons 1 to 8 are physical pushbuttons on the right side of the graphical front panel, numbering down the two columns.

Any remaining user-programmable pushbuttons are programmed among the 10 pushbuttons on the left and right sides of the screen display. They show dynamically and provide a means to perform the same control as the other pushbuttons.



859884A1

**Figure 113: Assigning pushbuttons to the display**

As an example, if you set up a single-line diagram with two breakers and six switches, then eight of the side pushbuttons are used automatically for control of the breakers and switches. Side pushbuttons 9 and 10 are available. In the single-line diagram, let us set side pushbutton 9 to clear event records as follows:

- Show side pushbutton 9 on the graphical front panel — Click the PB symbol in the toolbar, then set Side button 9 to pushbutton 9 in the drop-down list. This pushbutton then displays when appropriate on the right side of the screen display.
- Program event record clearing — Set **Settings > Product Setup > Clear Relay Records > Clear Event Records** to FlexLogic operand PUSHBUTTON 9 ON
- Program pushbutton 9 — Set **Settings > Product Setup > User-Programmable Pushbuttons > Pushbutton 9 Function** to "Self-reset." When pressed, pushbutton 9 clears the event records.


To instead set the second user pushbutton (not a side pushbutton) to clear events, follow the second and third bullet points, selecting settings of PUSHBUTTON 2 ON and Pushbutton 2.

### Metering components

Metering components show dynamically the value of a FlexAnalog operand or actual value. Up to 16 metering components can be added to each single-line diagram.

To add a metering component, click the M symbol in the toolbox, then click in the window. Drag it to its final location. Double-click it to open the properties window. The figure shows the properties that can be edited.





**Figure 114: Metering properties**

### Status components

Status components show dynamically the value of a FlexLogic operand. Up to 16 can be used in a diagram and 30 in all single-line diagrams.

An example is to show the Off or On state of the ANY MAJOR ERROR FlexLogic operand. The name of the operand displays in the single-line diagram editor, then as Off or On on the graphical front panel.

To add a status component, click the S symbol in the toolbox, then click in the window. Drag it to its final location. Double-click it to open the properties window. Properties that can be edited include parameter (any FlexLogic operand), text color background color, and on and off text.

Optionally add a text label to display beside the status.

### Text

Text components show a single line of user-configured text.

Up to 16 text components can be used per single-line diagram.

To add a text component, click the T symbol in the toolbox, then click in the window. Drag it to its final location. Double-click it to open the properties window. Properties that can be edited are text, color, and size.

#### 5.3.3.6 ANNUNCIATOR

An annunciator is a grid of small windows for alarms, actual values, self-test messages, and product information.

The graphical front panel emulates a conventional annunciator panel. The annunciator has 96 windows, each with a description of the alarm condition that lights the window. The windows are arranged in rows and columns of 3 x 4, 4 x 6, or 6 x 8 over several pages. Each window can have up to three lines of configurable text, and one line can instead be a metered value. Normally the window background is dark, and when the configured FlexLogic operand becomes On, the window lights up.

The figure shows that two alarms are active. One alarm is configured red and the other alarm is configured blue. The red alarm type is Self Reset, so the alarm displays in a solid color. The blue alarm type is Acknowledgeable, so the alarm flashes until it is acknowledged, for example by navigating with the arrow keys and pressing the ENTER button. The alarm then remains blue until the trigger condition is eliminated.

| \\Annunciator\Fdr 12 Alarms  |                                         |                                         |                                         | 23-Jun-17 12:35:08 PM |  |
|------------------------------|-----------------------------------------|-----------------------------------------|-----------------------------------------|-----------------------|--|
| Breaker 1<br>Failure         | Breaker 2<br>Failure                    | Autoreclos<br>Lockout                   | Fuse<br>Failure                         |                       |  |
| Setting<br>Group 2<br>Active | Breaker 1<br>Arc Phs A<br>0.000 kA2-cyc | Breaker 1<br>Arc Phs B<br>0.000 kA2-cyc | Breaker 1<br>Arc Phs C<br>0.000 kA2-cyc |                       |  |
| Fault<br>Report              | Breaker 1<br>Flashover                  | Breaker 2<br>Flashover                  |                                         |                       |  |
| M568M Alarms                 | Fdr 12 Alarms                           | Station Alarms                          | Misc Alarms                             | Next                  |  |

859859A1

**Figure 115: 3x4 annunciator page with two active windows**


To display the annunciator, press the Home pushbutton, then the Annunciator Tab pushbutton. If there is one or more window in alarm or requiring reset, the annunciator page showing the first of these opens. Otherwise the first annunciator page opens.

Alarms do not display automatically. Set the Home page and/or rolling pages to display annunciator pages. The Tab pushbutton labels populate with the annunciator pages. The label text for each annunciator page is configurable and displays in the header and Tab label. The current page has a blue Tab label. Tab labels for annunciator pages that have an active window (that is, on, latched, or unacknowledged) are red. Pages where alarms are not triggered have a grey Tab label. Pages that have no configured windows do not have Tab pushbuttons and do not display.

The Up, Down, Left, and Right pushbuttons cause the selection to move one window in the indicated direction. Pressing the Right pushbutton past the last window in a row scrolls the display to any next annunciator page, not the next row. The behavior is similar for the other pushbuttons, for example pressing the Up pushbutton while in the top row goes to any previous page. If no previous page exists, no action occurs.


Annunciator windows are positioned statically, so that all windows are visible no matter their state.

Alarm types of each window can be configured as Self Reset, Latched, or Acknowledgeable. In Self Reset mode, the window lighting follows the state of the configured FlexLogic operand. The self-reset mode alarm sequence conforms to ISA-18.1-1979 (R2004) standard type A 4 5 6.




**Figure 116: Annunciator alarm sequence in Self Reset mode**

Latched mode is intended for transient signals such as trip, and it conforms to ISA-18.1-1979 (R2004) standard type M6.



**Figure 117: Annunciator alarm sequence in Latched mode**

In Acknowledgeable mode, both Off to On and On to Off state changes in the configured operand cause the background to flash; the window must be acknowledged/reset to cancel flashing. This mode conforms to ISA-18.1-1979 (R2004) standard type R-6.



**Figure 118: Annunciator alarm sequence in Acknowledgeable mode**

To reset all annunciator windows:

- In the software, access **Actual Values > Graphical Panel > Annunciator Panel**

To acknowledge/reset all annunciator windows on a page:

- On the graphical front panel with none of the annunciator windows selected, press the **RESET** pushbutton once for acknowledgement and twice for reset. The flashing stops.

To acknowledge an annunciator window:

- On the graphical front panel, press the Up, Down, Left, and Right pushbuttons to select the window, so that it has a yellow outline. Press the RESET or ENTER pushbutton. While a window is selected, if that window has activated since the last restart, the date/time of the last activation of that window displays in the header.

An alarm remains in an alarm state (for example, displays red) when the condition remains. That is, if you acknowledged a flashing alarm but the alarm condition remains, the background color remains red.


The **SETTINGS > INPUTS/OUTPUTS > RESETTING > RESET ANNUNCIATOR** setting can be used to select a FlexLogic operand that when activated acknowledges/resets all annunciator windows.

### 5.3.3.7 ANNUNCIATOR EDITOR

The annunciator editor is used to configure alarms and actual value displays for the graphical front panel.

The path in the EnerVista software is **Settings > Product Setup > Graphical Panel > Annunciator Editor**.

The figure shows the annunciator editor and its preview window. The page name is entered as General at the top right. Acknowledgeable and self-resetting alarms are set for basic functions, such as online/offline, Ethernet ports, unauthorized access/failed logins, and battery failure. The text to display in the annunciator window is entered. The IN SERVICE LED is set to be green because when the device is on, this LED is green. The preview shows what the annunciator looks like with all alarms triggered. The last window is not configured and displays blank/grey. In order for the Ethernet and battery alarms to work, the corresponding self-test alarms have been enabled under **Settings > Product Setup > User-Programmable Self Tests** (not shown). The LEDs can be viewed on the front panel, so adding them to the annunciator is for illustrative purposes only.



**Figure 119: Annunciator editor and preview window**

The three page layouts (3 × 4, 4 × 6, and 6 × 8) select the number of rows x columns of windows that appear in a page. Annunciator window size and text size shrink as the number of annunciator windows in a page increases.

Properties that can be edited include alarm type (acknowledgeable, latched, self-reset), alarm input (any FlexLogic operand), text color, and alarm background color.


The following buttons display at the top of the window:

- **Save** — Updates the connected device if online or the open setting file if offline with changes made
- **Restore** — Undoes changes that have not been saved
- **Default** — Changes all annunciator settings to their factory default values
- **Reset** — Displays factory default values. Previous settings are not lost unless you save the reset window.

### 5.3.3.8 METERING EDITOR

The metering editor is an actual values display tool. It creates pages of actual values for the graphical front panel. There are two types: tables and phasor diagrams. Tabular actual values pages have settings to configure, while phasor actual values pages have no settings. Five tabular metering pages can be configured, while there can be a phasor page for each configured AC source. They display on the graphical front panel using the Metering Tab pushbutton.

The path to the editor is **Settings > Product Setup > Graphical Panel > Metering Editor**.



**Figure 120: Metering editor with preview window**

The inputs are selected at the top. Select from the drop-down list or start typing in the field.

The page, page name, and grid layout are set below the inputs.

Content to display is configured with the cell lines. The content can be actual values, a status indicator, or text.

- Actual value — Select from the FlexAnalog operands applicable to the relay, where a FlexAnalog is an analog parameter
- Status — Select from the FlexLogic operands identified in the Status Inputs at the top of the window. An example is to display text to indicate whether the BATTERY FAIL operand is on or off.
- Text — Enter text to display in the table, for example name of table or column heading

If the metering input is other than OFF, the value of the selected metering input displays, formatted according to the size, text color, units, multiplier, and decimal configuration. Otherwise either the Text or the Off Text displays depending on the value of the operand selected by setting Status Input/Index.

A maximum of eight Status Inputs/Indexes can be used per metering page and 16 in all metering pages.


The following buttons display at the top of the window:

- **Save** — Updates the connected device if online or the open setting file if offline with changes made
- **Restore** — Undoes changes that have not been saved
- **Default** — Changes all actual value settings to their factory default values
- **Reset** — Displays factory default values. Previous settings are not lost unless you save the reset window.

### 5.3.3.9 CONFIGURABLE NAVIGATION EDITOR

Configurable Navigation is a feature that opens specified pages when specific FlexLogic operands are activated. This feature is useful to open the annunciator page containing an annunciator window that has entered its abnormal state.

In the example shown, failure of any of the three Ethernet ports triggers the Product Information page to display. With unauthorized access (such as wrong password), IRIG-B clock failure, or breaker trouble, the Event Records display. When a breaker opens, a single-line diagram displays. For the Ethernet and IRIG-B failure pages to work, these functions also have been enabled under **Settings > Product Setup > User-Programmable Self Tests**. For the breaker trouble, the single-line diagram has been configured.



**Figure 121: Navigation editor**

The path is **Settings > Product Setup > Graphical Panel > Configurable Navigation**.

The settings consist of 64 field pairs, each with a condition and an activation page. The condition selects any FlexLogic operand. The activation page selection is the standard set, such as product information, event records, annunciator pages, and single-line diagrams.

To use the feature, select a CONDITION, select its ACTIVATE PAGE option, then save. When selecting the condition operand, open the drop-down list and start typing in the field to auto-fill. For example, typing F displays FIRST ETHERNET FAIL.



The following buttons display at the top of the window:

- **Save** — Updates the connected device if online or the open setting file if offline with changes made
- **Restore** — Undoes changes that have not been saved
- **Default** — Changes all settings in the window to factory default values
- **Reset** — Displays factory default values. Previous settings are not lost unless you save the reset window

### 5.3.3.10 NAVIGATION KEYS



**Up/Down/Left/Right** — These pushbuttons move the selector among the options on a page. The selection is indicated by a yellow background or a yellow border. On menu pages, the Right pushbutton activates the selected submenu drilling down the menu hierarchy, and the Left pushbutton backs up the menu hierarchy. These pushbuttons have a typematic feature on some pages: after a short pause, the pushbutton repeats as long as it is pressed.



**ENTER** — Activates the selection on the display, for example a submenu, a control, a keypad key, or a setting. Also stores updated settings.



**ESCAPE** — If a setting is open for edit, this pushbutton closes the setting without saving. If an item is selected, this pushbutton deselects it. Otherwise this pushbutton activates the previous page in the page hierarchy.



**RESET** — Clears all latched LED indications and target messages. When a page with acknowledgeable/resettable items is displayed, it instead resets/acknowledges all items on that page, or if an item on that page is selected, it resets/acknowledges that item. If you reset/acknowledge alarms, they stop flashing but remain in the alarm state as long as that state remains. In other words, a red alarm does not switch off just because you acknowledged the alarm.



**Home** — Activates the home page, which is the root page. The page displays product information by default and is configurable.



**Side pushbutton** — Five pushbuttons on the left side of the display and five pushbuttons on the right side of the display. They perform various functions depending on the displayed page, such as switchgear controls. The display dynamically shows its label next to each side pushbutton when the pushbutton has an assigned function. These pushbuttons can also be programmed to function as user-programmable pushbuttons 9 and above.



**Tab pushbutton** — Five pushbuttons under the display. They navigate through the page hierarchy, and on some pages activate other actions. The display footer dynamically labels the page or action that is activated by the Tab pushbutton.



**User-programmable pushbutton** — Eight physical pushbuttons are associated with the first eight user-programmable pushbutton elements. Numbering is down, that is, 1 to 4 down the left column and 5 to 8 down the right column. These elements control a set of FlexLogic operands that can be used to initiate outputs or select modes. Each physical pushbutton has an integrated LED indicator that can be user-configured to display the appropriate status. These pushbuttons have clear covers behind which custom labels can be mounted. A utility is available to print the labels, under **File > Front Panel Report** in the software

### 5.3.3.11 LED INDICATORS


The graphical front panel has 14 LEDs.

- LEDs 1 to 3 are fixed status LEDs
- LED 4 is used for TRIP, but can be triggered by other operands
- LED 5 is used for ALARM, but can be triggered by other operands
- LEDs 6 to 14 are programmable.



### Status indicators

- **IN SERVICE** — Indicates that control power is applied, all monitored inputs/outputs and internal systems are fine, the relay's test mode is disabled, and the relay is in (online) Programmed mode (under **Settings > Product Setup > Installation**)
- **TROUBLE** — Indicates that the relay has detected an internal problem. Check the self-test messages outlined at the end of the Commands and Targets chapter, and view the event records under **Actual Values > Records**. For a beta / pre-release, this LED is always on.
- **TEST MODE** — Indicates that the relay is in Test Blocked (solid) or Test (flashing) mode. For information, see the Testing section in the Settings chapter.
- **TRIP** — Indicates that the selected FlexLogic operand serving as a trip input has operated. Set the operand under **Settings > Product Setup > User-Programmable LEDs > Trip & Alarm LEDs**. This indicator latches; initiate the reset command to reset the latch.
- **ALARM** — Indicates that the selected FlexLogic operand serving as an alarm input has operated. Set the operand under **Settings > Product Setup > User-Programmable LEDs > Trip & Alarm LEDs**.



842813A1

Figure 122: Example of LEDs on graphical front panel

### User-programmable event-cause indicators

Event-cause LEDs are below the status LEDs. They are turned on or off by protection elements that have their respective target setting selected as *Self-Reset* or *Latched*. If set to *Self-Reset*, then the corresponding event cause LED remains on as long as the operand associated with the element remains asserted. If set to *Latched* and asserted, then it remains on until the operand is reset and then a reset command initiated.

All elements that are able to discriminate faulted phases can independently turn on or off the phase A, B, or C LEDs. This includes phase instantaneous overcurrent, phase undervoltage, and so on. This means that the phase

A, B, and C operate operands for individual protection elements are ORed to turn on or off the phase A, B, or C LEDs.

The LEDs have defaults and can be configured to show instead the status of any FlexLogic operand.

The labeling area has a clear cover for custom labels. A utility is available to print stick-on labels, as outlined later in this chapter.

These LEDs are programmed by default as follows:

- PICKUP — LED 6 — Indicates that an element is picked up, and hence a trip can be imminent
- VOLTAGE — LED 7 — Indicates voltage was involved
- CURRENT — LED 8 — Indicates current was involved
- FREQUENCY — LED 9 — Indicates frequency was involved
- OTHER — LED 10 — Indicates a composite function that is not solely current, voltage, or frequency based (distance or power for example) or a control function (digital element or trip bus for example)
- PHASE A — LED 11 — Indicates phase A was involved
- PHASE B — LED 12 — Indicates phase B was involved
- PHASE C — LED 13 — Indicates phase C was involved
- NEUTRAL/GROUND — LED 14 — Indicates that neutral or ground was involved


### 5.3.3.12 LABELING

The relay includes software for labeling the LEDs and pushbuttons on the graphical front panel and a sticker sheet with preprinted and blank labels. The pre-printed labels are on the top-left of the template sheet, and the blank labels are on the bottom-right. Use the pre-printed labels, or use the designer provided in the software and print labels onto the template. One sheet is provided.

The example shows LED labeling, with pushbutton labeling below it (cut off).

To create LED and pushbutton labels for the front panel:

1. In the EnerVista software, in the Online or Offline Window area, access **Settings > Front Panel Label Designer** or **Front Panel Label Designer** (at the product root level). The designer window opens with pre-configured labels.
2. Under **File > Print Setup**, change the page orientation to Landscape.
3. In the label designer window, delete all labels not wanted for printing. This can be done by clicking the **Reset** button to clear all labels, or by selecting each unwanted label and deleting it. Otherwise, all labels displayed print on the template and use up the template. If you make a mistake, exit the window and open it again to view the default labels.
4. Based on the location on the template on which to print, create the labels by typing in the appropriate slots.



**Figure 123: Front panel label designer for graphical front panel**

5. Click the **Print** button in the window and select the printer.
6. Once printed, peel the labels off the template and stick them on the front panel. For the enhanced and graphical front panels, they go over the clear plastic inserts, not under. For the basic front panel, they go under or over the plastic covers.

Any changes are not saved. Each time that the label designer window opens, the original template displays. Any labels deleted are not lost.

### 5.3.3.13 MENU NAVIGATION

Press the MENU key to display selections or home page. Each press of the key advances through the following main headings:

- Actual Values
- Settings
- Commands
- Targets
- Factory Service
- User displays (when enabled)

Access the main menu by pressing the **Home** pushbutton, then the **Menu** Tab pushbutton.

Use the Up and Down arrow pushbuttons to select a submenu, then press the Right or ENTER pushbutton to drill into that submenu. The Left and ESCAPE pushbuttons back up the menu hierarchy.

The **Page Up** and **Page Down** Tab pushbuttons also navigate through the list. When there is only a single page of options, they jump to the first and last entries.

The options displayed depend on order code.




Figure 124: Main menu on graphical front panel


#### 5.3.3.14 CHANGE SETTINGS

When enabling an element in the EnerVista software that outputs to an actual value, the actual values menu is not updated on the graphical front panel via Ethernet connection when that menu is active on the graphical front panel. Navigate out and back into the menu for activation.

##### Numerical data


This example outlines how to change the FLASH MESSAGE TIME setting. Flash messages are status, warning, error, and information messages displayed in response to certain key presses during settings programming. An example is a confirmation message upon saving settings. This setting specifies how long to display the message.

Press the **Menu** pushbutton to display the main menu.




**Figure 125: Main menu**

Use the Up or Down pushbutton to select SETTINGS, then press the Right or ENTER pushbutton.




**Figure 126: Settings menu**

With PRODUCT SETUP selected, press the Right or ENTER pushbutton.



**Figure 127: Product Setup menu**

Use the Up or Down pushbutton to select DISPLAY PROPERTIES, then press the Right or ENTER pushbutton.



**Figure 128: Display Properties menu**


Use the Up or Down pushbutton to select FLASH MESSAGE TIME, then press the Right or ENTER pushbutton. If the relay is configured to require login to edit settings, and the user is not already logged in, the login page displays. When the user has successfully logged in, the setting is opened for edit. As the FLASH MESSAGE TIME setting accepts a numerical value, a keypad displays. The time is to be changed to 4.0 seconds.

The current setting displays. A flashing cursor line marks the insertion point, initially positioned after the last character of the setting. The setting range displays under the text.

Press the <-- **Move Cursor** and **Move Cursor** --> Tab pushbuttons to move the insertion point. Place it after the 2.

Press the Backspace Tab pushbutton to remove the character to the left of the cursor, in this case the 2.

Using the arrow keys, enter another time, for example 4 for four seconds. These Up, Down, Left, and Right pushbuttons move the keypad key selector. Pressing the ENTER pushbutton with the - key selected inverts the sign. Pressing the ENTER pushbutton with the decimal point selected enters that character at the insertion point. Push ENTER now to accept the 4.



**Figure 129: Settings page with numeric keypad**

Press the **Save** Tab pushbutton, which does a range check on the value, saves the setting when valid, closes the page, and displays the previous page.

When a setting is not saved due to an invalid value, a message flashes, for example being out of range. In cases where the relay needs to be restarted for settings to take effect, the flash message advises.

Setting entry can be canceled without impact on the original value by pressing the ESCAPE or **Home** pushbutton.

### Alphanumeric text

Settings that accept alphanumeric values display a keyboard. An example is a pushbutton name.

The **&123** key toggles between text and numbers.

The shift key (up arrow on keyboard) is green upon activation, while the keyboard letters switch to upper case. Double-click the shift key to lock capital lettering, or full capitals.

The globe key (shown greyed-out) toggles the keyboard language between English and another display language selected, for example between English and French. (The second language needs to be activated under **Settings > Product Setup > Display Properties.**)

For Japanese and Chinese, up to 10 characters can be input in a field, not 20.

To add accents, highlight a key and hold the ENTER pushbutton on the graphical front panel. Any special characters associated with the key display.

To avoid conflict with XML programming, do not enter the following characters on the Annunciator and Metering editor panels: " (quotation mark), ' (apostrophe), < (less than), > (greater than), & (ampersand). When used, the text following the character does not display on the Annunciator and Metering panels do not display on the graphical front panel.




Figure 130: Settings page with keyboard and accents

### 5.3.3.15 VIEW ACTUAL VALUES

In addition to data viewable in the **Actual Values** menu on the front panel, phasor diagrams and metered data can be displayed. The metered data can be arranged as a table. The update rate of metered values is 500 ms.

A phasor page for each configured AC Source and up to five user-configurable metering pages can be displayed. The phasor pages are not configurable. Each phasor page shows a phasor plot and numerical values of all currents, voltages, and symmetrical components of a single AC source.

The Annunciator and Metering pages can be configured to display data. Each has a user-configured number of rows and columns. Each cell can include either configurable static text or the value of a selected FlexLogic operand, FlexAnalog operand, or actual value.

To display a metering page, press the **Home** pushbutton, then the **Metering** Tab pushbutton. The first metering page opens, with phasor pages listed before tabular pages. The Tab pushbuttons display any other metering page, as do the Up, Down, Left and Right pushbuttons. The current page is highlighted with a blue Tab pushbutton.

Each phasor page has a name, which consists of the value of the SOURCE NAME # setting appended with "Phasors." Phasor pages that have no configured CTs or VTs do not have a Tab pushbutton, and phasor pages that have no configured cells cannot be displayed.






Figure 131: Phasor display

The configurable name displays in the header and Tab pushbutton label. Factory default names are Page 1, Page 2, and so on.



Figure 132: Metered actual values

The phasor sources are configured under **Settings > System Setup > Signal Sources**. The tables to display the actual values are configured in the software under **Settings > Product Setup > Graphical Panel > Metering Editor**.

### 5.3.4 BREAKER CONTROL

The relay can interface with associated circuit breakers. In many cases the application monitors the state of the breaker, that can be presented on front panel LEDs, along with a breaker trouble indication. Breaker operations can be manually initiated from the front panel keypad or automatically initiated from a FlexLogic operand. A setting is provided to assign names to each breaker; this user-assigned name is for the display of related flash messages. These features are provided for two breakers; the user can use only those portions of the design relevant to a single breaker, which must be breaker 1. It is assumed in the following discussion that the **SETTINGS > SYSTEM SETUP > BREAKERS > BREAKER 1(2) > BREAKER FUNCTION** setting is enabled for each breaker.

#### 5.3.4.1 CONTROL MODE SELECTION AND MONITORING

Installations can require that a breaker be operated in the three-pole only mode (3-pole), or in the one and three-pole (1-pole) mode, selected by setting. If the mode is selected as three-pole, a single input tracks the breaker open or closed position. If the mode is selected as one-pole, all three breaker pole states must be input to the relay. These inputs must be in agreement to indicate the position of the breaker.

For the following discussion it is assumed that the **SETTINGS > SYSTEM SETUP > BREAKERS > BREAKER 1(2) > BREAKER 1(2) PUSH BUTTON CONTROL** setting is enabled for each breaker.

#### 5.3.4.2 CONTROL OF BREAKERS

After a correct command password, you are permitted 30 minutes in which to make any changes. After this 30 minute interval you cannot open or close a breaker via the keypad. The following instructions begin from the not-permitted state.

##### Control of two breakers

For the following setup example, the **Name** field represents the user-programmed variable name.

For this example, the relay is connected and programmed for both breaker 1 and breaker 2. The **USER 1** key performs the selection of which breaker is to be operated by the **USER 2** and **USER 3** keys. The **USER 2** key manually closes the breaker, and the **USER 3** key manually opens the breaker.

|                                                           |                                                                                                                                                                                                                                                     |
|-----------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ENTER COMMAND<br>PASSWORD                                 | This message appears when the <b>USER 1</b> , <b>USER 2</b> , or <b>USER 3</b> key is pressed and a <b>COMMAND PASSWORD</b> is required, that is, if <b>COMMAND PASSWORD</b> is enabled and no commands have been issued within the last 30 minutes |
| PRESS USER 1<br>To select breaker                         | This message appears if the correct password is entered or if none is required. This message displays for 30 seconds or until the <b>USER 1</b> key is pressed again.                                                                               |
| BKR1-(Name) SELECTED<br>USER 2=CLS / USER 3=OP<br><br>(1) | This message displays after the <b>USER 1</b> key is pressed for the second time. Three possible actions can be performed from this state within 30 seconds as per the following items (1), (2) and (3).                                            |
| USER 2 OFF / ON<br>To close BKR1-(Name)<br><br>(2)        | If the <b>USER 2</b> key is pressed, this message appears for 20 seconds. If the <b>USER 2</b> key is pressed again within that time, a signal is created that can be programmed to operate an output relay to close breaker 1.                     |
| USER 3 OFF / ON<br>To open BKR-1(Name)<br><br>(3)         | If the <b>USER 3</b> key is pressed, this message appears for 20 seconds. If the <b>USER 3</b> key is pressed again within that time, a signal is created that can be programmed to operate an output relay to open breaker 1.                      |

BKR2-(Name) SELECTED  
USER 2=CLS / USER 3=OP

If the **USER 1** key is pressed at this step, this message appears showing that a different breaker is selected. Three possible actions can be performed from this state as per (1), (2) and (3). .

Repeatedly pressing the **USER 1** key alternates between available breakers. Pressing keys other than **USER 1, 2, or 3** at any time cancels the breaker control function

### Control of one breaker

For this application, the relay is connected and programmed for breaker 1 only. Operation for this application is identical to that described in the previous section for two breakers.

---

## 5.3.5 PASSWORD CONTROL

The relay supports password entry from a local or remote connection. Local access is defined as access to settings or commands via the front panel. This includes both keypad entry and the RS232 port. Remote access is defined as access to settings or commands via any rear communications port. This includes both Ethernet and RS485 connections.

When entering a settings or command password via EnerVista or any serial interface, you must enter the corresponding connection password. If the connection is to the back of the relay, the remote password must be used. If the connection is to the RS232 port of the front panel, the local password must be used.

There are two user security access levels; 'setting' and 'command', for which you can set a password for each. Use of a password for each level controls whether you can enter commands or change settings. Another option is to specify setting and/or command access for individual user accounts.

### Setting

This allows you to make any changes to any of the setting values:

- Changing any setting
- Test mode operation


### Command

This restricts you from making any settings changes, but allows you to perform the following operations:

- Operating the breakers via front panel keypad
- Changing the state of virtual inputs
- Clearing the event records
- Clearing the oscillography records
- Clearing fault reports
- Changing the date and time
- Clearing the breaker arcing current
- Clearing energy records
- Clearing the data logger
- Clearing the user-programmable pushbutton states

To enter the initial setting or command password:

1. Press the MENU key until the SETTINGS header flashes momentarily and the PRODUCT SETUP message appears on the display.
2. Press the MESSAGE right arrow until the ACCESS LEVEL message appears on the display.
3. Press the MESSAGE down arrow until the CHANGE LOCAL PASSWORDS message appears on the display.
4. Press the MESSAGE right arrow until the CHANGE SETTING PASSWORD or CHANGE COMMAND PASSWORD message appears on the display.



5. After the CHANGE...PASSWORD message appears on the display, press the VALUE up or down arrow to change the selection to "Yes."
6. Press the ENTER key and the display prompts you to ENTER NEW PASSWORD.
7. Type in a password and press the ENTER key.
8. When VERIFY NEW PASSWORD displays, re-type the password and press ENTER



9. When the NEW PASSWORD HAS BEEN STORED message appears, your new Setting (or Command) password is active.

### 5.3.5.1 RESETTING THE PASSWORD IN A DEVICE WITHOUT CYBERSENTRY

#### EnerVista UR Setup

1. In **Settings > Product Setup**, click the CHANGE button for the Command Password or Setting Password.
2. The pop-up states **Password Status: Set**, confirming that the user has previously set a password. Type **ChangeMe1#** in both the **New Password** and **Confirm Password** fields, and press **OK**.
3. If the device has not been logged into using the previously set password, a prompt will request that the previous password should be entered. Do this and press **OK**.
4. A message will appear confirming that this was a valid password - click **OK**.
5. A pop-up will now appear confirming **Password Status: Default** (i.e. the password is reset to the default **ChangeMe1#** and prompting for the new password. Type the new password, confirm it in the next field, then click **OK**.

#### Front panel

1. Press the MENU key until the SETTINGS header flashes momentarily and the PRODUCT SETUP message appears on the display.
2. Press the MESSAGE right arrow until the ACCESS LEVEL message appears on the display.
3. Press the MESSAGE down arrow until the CHANGE LOCAL PASSWORDS message appears on the display.
4. Press the MESSAGE right arrow until the CHANGE SETTING PASSWORD or CHANGE COMMAND PASSWORD message appears on the display.
5. After the CHANGE...PASSWORD message appears on the display, press the VALUE up or down arrow to change the selection to "Yes".
6. Type "ChangeMe1#" and press the ENTER key. This will clear the current password and make **ChangeMe1#** the password.
7. The display will prompt you to ENTER CURRENT PASSWORD. Type in a new password and press the ENTER key.

### 5.3.5.2 INVALID PASSWORD ENTRY

By default, when an incorrect Command or Setting password has been entered via the front panel three times within five minutes, the LOCAL ACCESS DENIED FlexLogic operand is set to **On** and the relay does not allow settings or command level access via the front panel for five minutes.

By default, when an incorrect Command or Setting password has been entered via any external communications interface three times within five minutes, the REMOTE ACCESS DENIED FlexLogic operand is set to **On** and the relay does not allow settings or command access via the any external communications interface for five minutes. The REMOTE ACCESS DENIED FlexLogic operand is set to **Off** after five minutes for a Command password or 30 minutes for a Settings password.

These default settings can be changed in EnerVista under **Settings > Product Setup > Security**.

## 5.4 LOGIC DIAGRAMS

Logic diagrams in this instruction manual provide an overview of function and settings. A logic diagram is based on

- Inputs-on the left side, which are setting and operands
- Logical gates, which is Boolean algebra to combine logical lines using AND, OR, NOT, and other gates to get a new logical state
- Logical operators, which are timers, one-shot operations, latches, and so on
- Outputs-on the right side, which are products of the manipulations with inputs, logical gates, and logical operators to produce new operands and define the output state of the element


True and false values are denoted by 1 and 0 respectively. A function usually is high/on/enabled when 1.

Reading from right to left in the following diagram, the TRIP BUS 1 OP and TRIP BUS 1 PKP FlexLogic operands on the right side are triggered when either the settings or reset latch in the middle of the diagram is triggered. When this applies, the TRIP BUS 1 OP operand is triggered after the delay set by the **TRIP BUS 1 PICKUP DELAY** or **TRIP BUS 1 RESET DELAY** setting, while the TRIP BUS 1 PKP operand initiates immediately. The settings or reset latch in the middle of the diagram is triggered as follows.

- For the reset, one of three conditions are required to meet the OR requirement shown at the bottom left. That is, the **TRIP BUS 1 LATCHING** setting must be 0=Disabled (which is negated by the NOT function to become 1=Enabled), output from the TRIP BUS 1 RESET FlexLogic operand must be 1, or output from the RESET OP FlexLogic operand must be 1.
- For the settings, one of 16 input conditions at the top left must be met for the OR, the **TRIP BUS 1 FUNCTION** must be Enabled, and the TRIP BUS 1 BLOCK output must output as 0, which is then negated/reversed by NOT to become 1.

### Logic diagram symbols

| Symbol           | Description                                                                |
|------------------|----------------------------------------------------------------------------|
| = Off            | Output from FlexLogic operand, so user-defined                             |
| = Enabled        | 1 = Enabled and 0 = Disabled                                               |
| OR               | Any function input on the left side satisfies the condition                |
| AND              | All functions input on the left side are required to satisfy the condition |
| ○                | Not. Negates/reverses the output, for example 0 becomes 1.                 |
| ●                | Connection                                                                 |
| S, R             | Set, Reset                                                                 |
| T <sub>PKP</sub> | Timer pickup. Triggered by the settings latch in the diagram               |
| T <sub>RST</sub> | Timer reset. Triggered by the reset latch in the diagram.                  |



842023A1.CDR

Figure 133: Logic diagram

---

## 5.5 FLEXLOGIC

---

### 5.5.1 FLEXLOGIC DESIGN USING ENGINEER

The IED internally uses the FlexLogic equations. EnerVista Engineer provides a graphical way to design the logic. When the user presses “compile” in Logic Designer, the software converts the graphical logic into equations and updates the FlexLogic Equations.

There are two ways to create, edit and maintain the FlexLogic equations:

- Using the FlexLogic Equation Editor available at **FlexLogic > FlexLogic Equation Editor**
- Using the Logic Designer available at **Engineer > Logic Designer**

*Note:*

*EnerVista Engineer is only available through the offline window of the EnerVista UR Setup. FlexLogic Equation Editor and Logic Designer are designed to be mutually exclusive as using them interchangeably to create, edit and maintain the FlexLogic equations may cause inconsistencies in the resulting equations. We recommend using only one of the two methods throughout the process.*


Parts of EnerVista Viewpoint Engineer software are integrated in the EnerVista UR Setup software. Engineer can be used to create and modify FlexLogic that is used by a device, such as to monitor output, monitor triggers, and create self-tests.

Features include:

- Automatically displays existing FlexLogic
- Drag-and-drop interface
- Open multiple tabs and edit simultaneously
- Display symbols in IEC, ISO, or UR formats
- Export a diagram as BMP file or copy it to the clipboard for import into other applications
- Scale and print files in various paper sizes
- Works with all UR firmware versions

The figure shows an example where several inputs are used to trigger an output. With the OR function, any one of the inputs can trigger the output.





**Figure 134: Inputs triggering output in Engineer**

The process is as follows:

- Modify or create a logic diagram in the Offline Window area of the EnerVista UR Setup software
- Compile it and troubleshoot any errors
- The logic populates automatically into the FlexLogic Equation Editor
- Upload the file to the live device
- Monitor the output

This section explains how to use Engineer. It outlines the following topics:

- Design logic
- Send file to and from device
- Monitor logic
- View front panel
- Generate connectivity report
- Preferences
- Toolbars

## 5.5.2 DESIGN LOGIC

FlexLogic can be created with a block diagram. Note that although work is completed in the Offline Window area of the software, communication occurs with the online device, for example when switching to monitoring mode.


The following procedures are outlined:

- Examples
- Add existing FlexLogic equations
- Create a logic diagram/sheet
- Rapidly add logic blocks in sequence
- Connect two logic diagrams/sheets
- Optimize the logic
- Change logic order
- Search logic
- Exclude sheet from compile

### 5.5.2.1 EXAMPLES

The symbols are displayed in the UR format.

#### Create oscillography trigger every three minutes




**Figure 135: Three-minute timer turns on LED for 10 seconds**

Preparation — Under **Settings > Inputs/Outputs > Virtual Outputs**, the first and second virtual outputs are named *OscTrigger*

Top logic — Three-minute timer trigger

Bottom logic — Turn on LED 1 for 10 seconds when the trigger starts

#### Create data logger trigger every seven minutes




**Figure 136: Seven-minute timer turns on LED for 10 seconds**

Preparation — Under **Settings > Inputs/Outputs > Virtual Outputs**, virtual outputs 3 and 4 are named *DLTrigger*

Top logic — Seven-minute timer trigger

Bottom logic — Turn on LED 9 for 10 seconds when the trigger starts

#### Create events every minute, then every 100 ms



**Figure 137: One-minute timer turns on LED and creates events every 100 ms**

Preparation — Under **Settings > Inputs/Outputs > Virtual Outputs**, virtual output 5 is named *EVStart*, 6 is named *EVTriggered*, and 7 is named *EVMakeEvent*

Top logic — One-minute timer trigger

Middle logic — Turn on LED 17 for 10 seconds when trigger starts

Bottom logic — Create events at 100 ms intervals for the same 10 second period

#### 5.5.2.2 ADD EXISTING FLEXLOGIC EQUATIONS

A logic diagram can be created using existing FlexLogic equations (this section) or by creating new ones (next section).

**Note:**

*FlexLogic Equation Editor and Logic Designer are designed to be mutually exclusive as using them interchangeably to create, edit and maintain the FlexLogic equations may cause inconsistencies in the resulting equations. We recommend using only one of the two methods throughout the process.*

To create a logic diagram using existing FlexLogic equations:


- In the Offline Window area, modify the FlexLogic for the device under **FlexLogic > FlexLogic Equation Editor**. If the device is not listed, right-click the device in the Online Window area and select the **Add Device to Offline Window** option. Upon saving the modified FlexLogic, a yellow icon appears for the device in the Offline Window area to indicate that the logic differs from the Online device.
- In the Offline Window area, access **Engineer** for the device, then **Logic Designer**. The logic opens.
- Click the **Edit > Auto Populate Workbook** menu item. If the software prompts if you want to keep or discard existing sheets, either is acceptable, with the older excluded sheeted being denoted by brackets, such as < Sheet 1 >. The logic displays in the various tabs. The FlexLogic created in the equation editor appears in Sheet 1, for example.

### 5.5.2.3 CREATE LOGIC DIAGRAM

Upon access of the Logic Designer, the FlexLogic equations of the device display. You can create new logic in new sheets or modify the ones that display.

This procedure uses input / output logic as an example.


1. In the Offline Window area, access **Engineer** for the device, then **Logic Designer**. If the device is not listed, right-click the device in the Online Window area and select the **Add Device to Offline Window** option.



**Figure 138: Access Engineer in the Offline Window area**


A default block diagram opens that shows 48 inputs (boxes) and 48 user-programmable LEDs (circles).

For the graphical front panel, no LEDs can be added to the window and the LEDs are removed when opening any existing files. For these existing files with the LEDs removed, save the file without them.




**Figure 139: Default view of FlexLogic designer**

- Optionally delete the default logic diagram by right-clicking its tab at the bottom of the window and selecting **Delete**.
- To add a blank sheet, click **Edit > Add Sheet**. A new tab displays. Or use the last tab displayed, which is a blank sheet.
- Optionally right-click the new tab and rename it.
- Add the input blocks to the logic diagram. For example, click the **I/O Tokens** tab on the right, click the **Input** element, then click in the logic sheet to add it.
- Double-click the block on the sheet to configure it, selecting from the two drop-down lists. The figure shows that virtual input 61 is being added. The **View Associated Screen** button opens its settings window.




**Figure 140: Configuring an input block**

7. Add the output blocks to the logic diagram. For example, click the **I/O Tokens** tab, click the **Virtual Output** element, then click in the logic sheet to add it. Double-click the block on the sheet to configure it. For the name, make it unique. The figure shows virtual output 61 is being added, with a suffix of "io" added to the name to make it unique. Note that the outline color of a block is red until it is configured, and that this properties window varies by block and the selectable options by order code.




**Figure 141: Configuring an output block**

8. Connect the input blocks to the output blocks by drawing a line as follows. Click at the end of one block and drag the line to the next block. Or click the Drawing Tools tab, then select the **Line** option. The cursor needs to be at the connection point to end the line, not elsewhere on the block. Note that the outline color is no longer red on the blocks.




**Figure 142: Completed inputs and outputs**

9. Add any remaining blocks or information. Right-click a block to copy and paste it. Notes are as follows.  
 Add a text box — **Drawing Tools > Text**  
 Add a FlexElement — **Elements > FlexElement**. An analog input is expected where a small arrow head shows in the box.



**Figure 143: FlexElement accepts analog inputs on left side where arrow heads display**

Add an Element — **Elements** tab. Available elements reflect the product, for example the Control Elements category.



**Figure 144: Elements reflect Control Elements**

10. Check for any blocks that have a red outline. These are invalid. Fix them before continuing, for example by configuring them.
11. Compile the logic diagram to check for errors by clicking the **Compile** button at the bottom left or by pressing the F7 key.

If prompted about a message about sorting, click **Yes** to apply the default (for this example), which can be automatic sorting based on an algorithm that applies fastest execution time.

With successful compiling, the file is saved and the FlexLogic equations populate automatically. Scroll up through the compile messages, with the red errors being the only messages that require fixing before proceeding.

The figure shows that we forgot to add the "Io" suffix to the names of virtual outputs 62 and 63, as indicated by Warning: Virtual output xx using default name. This warning is a minor warning.

The warning input using disabled feature means that input needs to be enabled. Double-click the block, click the **View Associated Screen** button, enable the setting, save, and recompile.

The output and messages are explained in the next section.

Some information displayed in the compile messages updates automatically, for example messages after a device is unplugged.




Figure 145: Compile and check the logic

12. View the FlexLogic equations by navigating in the Offline Window area to **FlexLogic > FlexLogic Equation Editor**. The window opens with the entries displayed in the next tab.

| FLEXLOGIC ENTRY   | TYPE                  | SYNTAX                |
|-------------------|-----------------------|-----------------------|
| View Graphic      | View                  | View                  |
| FlexLogic Entry 1 | Virtual Inputs On     | Virt Ip 61 On (VI61)  |
| FlexLogic Entry 2 | Assign Virtual Output | = Virt Op 61io (VO61) |
| FlexLogic Entry 3 | Virtual Inputs On     | Virt Ip 62 On (VI62)  |
| FlexLogic Entry 4 | Assign Virtual Output | = Virt Op 62io (VO62) |
| FlexLogic Entry 5 | Virtual Inputs On     | Virt Ip 63 On (VI63)  |
| FlexLogic Entry 6 | Assign Virtual Output | = Virt Op 63io (VO63) |

Figure 146: Logic displayed in FlexLogic Equation Editor

13. Save the work.
- The logic diagram has been created and the FlexLogic equations populated. The next steps are to upload the file to the device and to monitor the device.

5.5.2.4 COMPILED RESULTS AND WARNING MESSAGES

When a yellow caution symbol displays in the Offline Window area, it means that the settings file is not synchronized with the online device. Right-click the device in the Offline Window area, and select the Update SCL files option. SCL refers to the Substation Configuration Language. An Instantiated IED capability description (IID) file is an example of an SCL file and contains the actual settings on a UR device.




Figure 147: Settings files not synchronized between offline and online files

When the **Update SCL files** option is selected, the CID and IID files in the device folder are updated by the user configuration in the IEC 61850 panel and thereby become synchronized. The CID file and the IID file (depending on the preference 'Do not update IID file when updating SCL files') are updated. If the CID file is not already there, it is generated. The location of these files is



C:\ProgramData\GE Power Management\urpc, for example, in the **Offline** and **Online** folders.

Any FlexLogic equations entered in the Offline Window area are erased. The logic drawn in the Logic Designer window in Engineer in the Offline Window area remain. The warning icon disappears after updating. The following information is contained in the compile window.




Figure 148: Compiled results

- **Number of Lines Saved** — The number of compiled logic lines eliminated by using the optimization algorithm, as set in the **Optimize Compiled Output** option of the Preferences. In the example shown, no lines were saved because the optimizer is disabled.
- **FlexLogic Lines** — The number of lines that the compiled logic uses, for example seven of 512 available.
- **Virtual Output equations** — The number of FlexLogic equations used in the Logic Designer window.
- **Timers used** — The number of timers used in the Logic Designer window.
- **Memory Used** — The percent of memory used in the Logic Designer window.

Compilation errors

| Category | Block gate or gate affected | Message                                            | Description                                                                                  |
|----------|-----------------------------|----------------------------------------------------|----------------------------------------------------------------------------------------------|
| Error    | All                         | Number of lines (nnn) exceeds maximum limit of 512 | The compiled result exceeds the limit of 512. Reduce the number of equations to 512 or less. |
| Error    | Tag-In                      | Tag-in not configured (TAG_ID, SheetReference)     | A Tag-In is connected to a circuit but the Tag-In is not referencing an existing Tag-Out     |

| Category | Block gate or gate affected | Message                                               | Description                                                                                                                                                                                                                                |
|----------|-----------------------------|-------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Error    | 1 Shots                     | One Shot is over limit (SYMBOL_ID, SheetReference)    | The number of One-Shots contained within all of the VO blocks has exceeded the maximum allowed for the firmware revision. This value can either be 0 or 32.                                                                                |
| Error    | =VO                         | VO has no inputs (VO_ID, SheetReference)              | A Virtual Output block is located within the FlexLogic diagram and there is no block connected as input to it. Connect and identify the inputs.                                                                                            |
| Error    | Time                        | Timer used more than once (TIMER_ID, SheetReference)  | The same timer is used in more than one place in the editor. This means either the circuit that the Timer belongs to has been branched, or the Timer has been duplicated.                                                                  |
| Error    | Input                       | Unrecognized Parameter SYMBOL_ID,Name,SheetReference) | An Input symbol is configured to an item that is not recognized by the current order code and version. Possible cause: The order code and/or version of the settings file was converted causing the input parameter to become unavailable. |

### Compilation warnings

When using the *Reset OP* operand, a warning can appear indicating that this is a disabled feature. This means that the Reset Setting's FlexLogic operand is set to *OFF*. Resetting of the relay can be done by pressing the reset button on the front panel of the relay or by sending a Reset command through communications.

| Category        | Block gate or gate affected | Message                                             | Description                                                                                                                                                                                                                              |
|-----------------|-----------------------------|-----------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Minor warning   | Input                       | Input set to unused VO (SYMBOL_ID,Name,Sheet)       | An Input symbol is using an unassigned Virtual Output                                                                                                                                                                                    |
| Major warning   | Tag-out                     | Tag-out not connected (TAG_ID,Sheet)                | A Tag-Out symbol has no input                                                                                                                                                                                                            |
| Major warning   | All                         | Symbol not connected (SYMBOL_ID,Name,Sheet)         | A symbol's input and/or output is not connected and is not part of a VO block. Draw the input and/or output to the block.                                                                                                                |
| Minor warning   | =VO                         | Virtual Output n using default name (VO_ID,Sheet)   | The Assigned Virtual Output is using the default name. Change the name.                                                                                                                                                                  |
| Minor warning   | Input                       | Input using default name (SYMBOL_ID,Name,Sheet)     | An Input symbol is using a Contact Input, Contact Output, Digital Element, FlexElement, or Digital Counter set to the default name. Change the name so that it is unique.                                                                |
| Setting warning | Input                       | Input using disabled feature (SYMBOL_ID,Name,Sheet) | An Input symbol is using a disabled Virtual Input, Contact Input, Digital Element, FlexElement, Digital Counter, Control Pushbutton, Programmable Pushbutton, Contact Output, or Protection/Monitoring Element. Enable it and try again. |
| Major warning   | Input                       | Input set to OFF (SYMBOL_ID,Sheet)                  | An Input symbol is set to OFF                                                                                                                                                                                                            |
| Major warning   | Input                       | Input set to ON (SYMBOL_ID,Sheet)                   | An Input symbol is set to ON                                                                                                                                                                                                             |
| Setting warning | Input                       | Contact Output Operate is OFF (SYMBOL_ID, Contacts) | The symbol block is using the default setting of OFF                                                                                                                                                                                     |
| Setting warning | Input                       | Contact Output Seal-In is OFF (SYMBOL_ID, Contacts) | The symbol block is using the default setting of OFF                                                                                                                                                                                     |

### 5.5.2.5 RAPIDLY ADD LOGIC BLOCKS IN SEQUENCE


Blocks are added by clicking an element then clicking in the drawing area, or by dragging and dropping the element onto the canvas. Blocks can be added rapidly in sequence, for example when you have inputs 1 to 10, without having to select the element each time.

1. In Engineer, click **File > Preferences**. The window opens.
2. Click the **Editor** entry.
3. Enable the **Repeat Symbol** check box.
4. Click the **OK** button to save and exit from the window.
5. In the logic diagram, select an element, then click in the drawing area to add it, click again to add a second box, and so on.

### 5.5.2.6 CONNECT TWO LOGIC DIAGRAMS

When the logic is complex and requires two sheets, for example, these two sheets can be connected. By connecting them, the logic is continuous from one sheet to the next.

1. In the first sheet, click the **I/O Tokens** tab.
2. Scroll to the bottom, and click and drag the **Tag Out** element to the sheet where the next sheet is to connect.
3. Double-click the element and in the window that opens, give it a name, such as "To Sheet 2" or "To IO Sheet 2."



**Figure 149: Connecting sheet 1 to sheet 2**

4. In the second sheet, click and drag the **Tag In** element to the sheet where the first sheet is to connect.
5. Double-click the element and in the window that opens, select the first sheet from the drop-down list to connect the two sheets.
6. Save the work.

### 5.5.2.7 OPTIMIZE THE LOGIC

The number of available FlexLogic entries depends on firmware, for example 515 or 1024 lines. The software can automatically optimize a logic diagram to reduce space and free up entries.

1. In Engineer, enable the **Optimization** check box in the **Compile** tab. With this option enabled, the software automatically optimizes a logic diagram to reduce space and free up FlexLogic entries.
2. Run the compiler by clicking the **Compile** button. The number of saved lines displays in the **Optimization Summary**. Changes also display when the FlexLogic Equation Editor is accessed. The logic diagram does not change. In the example shown, no lines were saved to free up space.




Figure 150: Code optimization results

### 5.5.2.8 CHANGE LOGIC ORDER

The order in which the FlexLogic is populated in the FlexLogic Equation Editor window depends on settings.


First, when automatic sorting is not enabled, the sequence in which the blocks were drawn is followed.

Second, the order in which equations are executed can be manually changed, as outlined here.

Third, automatic sorting can be set in preferences, as outlined here. It is enabled by default and means that an algorithm is implemented to give best results and quickest performance. For example, the block with the fastest execution time is entered first in the FlexLogic. When two block functions have the same execution time the block drawn first displays first in the FlexLogic. For example, drawing input 61 to output 61, then input 62 to output 62 causes the input/output 61 to be entered into the FlexLogic first. Automatic sorting takes precedence over manual sort; if you enable this option, manual sorting is not implemented.

To manually change logic order:

1. In the compile area, click the **VO Order** tab.
2. If the window is blank, click the **Refresh** button.
3. Select an entry and click the up or down arrow. To cancel any manual changes, click the **Sort** or **Refresh** button.
4. Recompile. The change is not executed or saved if automatic sorting is enabled



| Name, NumDeps          | VOs Used |
|------------------------|----------|
| Virt Op 61io (VO61), 0 | None     |
| Virt Op 62io (VO62), 0 | None     |
| Virt Op 63io (VO63), 0 | None     |

Figure 151: Ordering FlexLogic entries

To set automatic sorting:

1. In Engineer, under **File > Preferences**, select the Compiler option. The **Automatically Sort VOs** option means that the block with the fastest execution time is entered first in the FlexLogic. When two block functions have the same execution time the block drawn first displays first in the FlexLogic. For example, drawing input 61 to output 61, then input 62 to output 62 causes the input/output 61 to be entered into the FlexLogic first.

5.5.2.9 SEARCH LOGIC

Items that can be searched in a logic diagram include gates, Input, Contact Input, Contact Output, Timer, Virtual Output, Tag In, Tag Out, and User-programmable LED. You can perform a search while designing or monitoring.

1. In the compiler area of Engineer, click the **Search** tab.
2. Use one of the following methods to set search criteria:
  - a. Select an element from the first drop-down list. Results display automatically.
  - b. Type in the second text string box, or select any of the 32 previous searches from the drop-down list. Click the **Search** button. Any results display.  
The search applies to all tabs, not just the active tab.
3. Double-click a search result to view the item.




Figure 152: Search function

You can also select an element from the drop-down list on the toolbar. It is then highlighted in the logic diagram

5.5.2.10 EXCLUDE SHEET FROM COMPILE

While designing the FlexLogic equations, you can remove entire sheets from the compile logic. This allows you to test various schemes by placing schemes on separate sheets and including either sheet at compile time.

1. In the Logic Designer window, right-click the tab and select the **Exclude from Compile** option so that the check mark displays. When sheets are excluded, a message displays with each compile that `excluded sheets will not be reflected in the RPN`. An excluded sheet is denoted with end brackets, similar to `< Sheet 1 >`.




Figure 153: Excluding a tab from compiling

### 5.5.3 SEND FILE TO AND FROM DEVICE

With the logic diagram created, compiled, and errors eliminated, the FlexLogic can be sent to a live device. And, conversely, a file from a live device can be added to the Offline Window area for additional work.

To send a file to a device:

1. In the Offline Window area of the software, right-click the device name and select the **Write Settings to Device** option. A prompt can appear that the URS file has been repaired; acknowledge the message.
2. When a window opens, select the device to which you want to send the file, then click the **Send** button and confirm. The order codes and IEC 61850 edition must match. The file is sent to the live device. Any errors can be viewed in the log file at the prompt.

To import a file from a device:

1. Close all open files in Engineer that relate to the device, else a message displays to that effect, for example to close the FlexLogic view associated with the file. When the file is not associated with a live device, a message displays to that effect; you need to identify the device to which you want to send the file. The order codes must match.
2. Right-click the device in the Online Window area and select the **Add Device to Offline Window** option. After you enter a name for the file, it is written to the Offline Window area.

### 5.5.4 MONITOR LOGIC

After creating the logic diagram, validating it, and uploading the FlexLogic to a device, the results from the device can be viewed.

The following checks are performed automatically when switching from design to monitoring, and prompts display when necessary:

- Verify that the order code of the linked relay matches the settings file
- Verify that the version of the linked relay matches the settings file
- Verify that the FlexLogic Equation Editor of the linked relay matches the settings file. Solution: Compile the FlexLogic logic diagram and send the settings file to the relay.
- Verify that the FlexLogic Timers of the linked relay match the settings file. Solution: Compile the FlexLogic logic diagram and send the settings file to the relay.
- If the settings file contains a serial number lock, then verify that the serial number of the linked relay matches the settings file

To view results:

1. In the Offline Window area of the software, expand the Engineer entry for the device.
2. Double-click the **Logic Designer** entry and Compile the logic.
3. Double-click the **Logic Monitor** entry, or click the M button in the toolbar at the top of the window.

With successful launch, the logic displays and a green indicator displays at the bottom of the tab.

When the file is not associated with a live device, a message displays to that effect; you need to identify the device to which you want to send the file. The order codes must match between the Offline Window and the Online Window.

When the device is offline, a message indicates problems communicating with the device.

When the devices are not synchronized, a message indicates the FlexLogic does not match the settings file. To send the offline file to the device, right-click the device name and select the Write Settings to Device option.

When the state of a symbol is OFF, the symbol is shown in the default color or no color.

When a symbol's state changes to ON, the symbol and connection line turns green.

The state of some symbols can either be unknown or the state transitions faster than the update interval. For these two cases, the state of the symbol is considered 'UNKNOWN' and the symbol is outlined in red.

The colors for the ON and Unknown state can be customized in the Preferences.

The figure shows that the software is communicating with devices (square green indicator) and that a minor error is present (green box outline). In this case, the battery is weak and needs to be replaced. This can be viewed as the Replace Battery message on the front panel of the device and in the EnerVista software under **Actual Values > Front Panel > Front Panel** or **Display/Keypad**.




Figure 154: Monitoring a device, with minor error caused by weak battery

### 5.5.5 VIEW FRONT PANEL AND PRINT LABELS

This window displays the LEDs that are on the front panel. You can create labels and print them for the device. You do not use the window to add text labels and upload them to the device. Custom labeling is also outlined earlier in this chapter; see the Front Panel Labeling section.

To view the front panel:

1. In the Offline Window area of the software, expand the **Engineer** entry for the device.
2. Double-click the **Front Panel Report** entry. The report displays. The Device Summary is read from the settings file and cannot be changed. The LEDs and pushbuttons display below the summary.
3. To save the report, click **File > Save As**, enter a file name, and select the front panel report (FPR), JPG, or PDF format.

To print labels:

1. In the **Front Panel Report** window, double-click an LED or pushbutton and enter text.
2. To print the labels, click the **Print** icon on the toolbar.
3. To save the report and labels, click **File > Save As**, enter a file name, and select the FPR, JPG, or PDF format.
4. Use the instructions in the second tab of the window to add the labels to the physical device.

## 5.5.6 GENERATE CONNECTIVITY REPORT

This report displays basic information about a device, such as order code, port numbers, inputs and outputs. You can use it to create a PDF file of basic information. The report is based on CID and/or IID files, and not the system or full SCD. All device details including Remote Inputs, Remote Outputs, and Analog Inputs/Outputs are indicated, including quantities used and available.

To display a device report:

1. In the Offline Window area of the software, expand the **Engineer** entry for the device.
2. Double-click the **Device Connectivity Report** entry. The report displays.
3. To save as a PDF file, click **File > Save As**.

## 5.5.7 PREFERENCES

Preferences determine functionality. As such, you are encouraged to review them. This section outlines some options available in the menus and preference panels.

Access them in the Logic Designer panel under the View menu and under **File > Preferences**. The Logic Designer and Logic Monitor preferences are outlined here, not all preferences for a device.

### 5.5.7.1 VIEW MENU

**View > Toolbar > Advanced Actions** — Active when in Logic Designer. Toggles a toolbar to nudge, rotate, flip, or change the order of an element.

**View > Show Unused Pins** — Enable to display unconnected pins. Disable to eliminate unconnected pins from the view, for example when printing:




Figure 155: Unused pins on and off

### 5.5.7.2 LOGIC DESIGNER

The path is **File > Preferences > Logic Designer**.

#### Workbook Setup

| Option                                 | Description                                                                                                                                                                                                                                                                                |
|----------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Size and Units</b>                  | Changes the size of diagram area displayed in Engineer. If you set the size to be smaller than an existing logic diagram, the content is cut off.                                                                                                                                          |
| <b>WorkBook &gt; Print Scale</b>       | The scale for logic diagram when printing. Scaling a large diagram to 200 percent, for example, results in the diagram being cut off.                                                                                                                                                      |
| <b>WorkBook &gt; Orphan Protection</b> | When enabled, the printing output prevents Virtual Output circuits from spanning more than a single page. The largest Virtual Output circuit is scaled to fit on a single page and all remaining Virtual Output circuits are scaled so that all circuits are printed using the same scale. |
| <b>WorkBook &gt; Show Title Block</b>  | When enabled, places an information box at the bottom right of the diagram when printing. Enter the information in the File Information panel.                                                                                                                                             |
| <b>WorkBook &gt; Show Sheet Name</b>   | When enabled, shows Sheet 1, Sheet 2, or any other name at the top of the logic diagram when printing.                                                                                                                                                                                     |



| Option                                       | Description                                                                                                                                                                                                    |
|----------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>WorkBook &gt; Start Sheet On New Page</b> | Places the sheet on the next page when printing.                                                                                                                                                               |
| <b>WorkBook &gt; Show Notes Selection</b>    | When other than None, prints the text from any information notes added to the document (under Drawing Tools tab > Note). The text is printed after the logic diagram.                                          |
| <b>File Information</b>                      | The text entered here displays at the bottom right of a diagram when printing, provided that the Show Title Block option is enabled. Note the option to change the logo from the GE logo to your company logo. |

## Display

The panel sets how the element boxes display. The figure shows how an AND gate displays when the UR default, IEC, or ISO symbol type is selected.




Figure 156: AND gate varies by standard selected

## Editor

| Option                                          | Description                                                                                                                                                                                                                                                                                                                |
|-------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Repeat Symbol</b>                            | Enable this feature to add element blocks rapidly in sequence, for example when you have inputs 1 to 10, without having to select the element each time. Select the element block from the toolbox, click the diagram, then continue to click to add additional blocks.                                                    |
| <b>Use first available VO / Timer</b>           | When enabled and you copy and paste a virtual output or timer element, the numbering continues in sequence. For example, you copy timer 5 and paste it as timer 6. When disabled and you copy and paste a virtual output or timer element, the same number is used. For example, you copy timer 5 and paste it as timer 5. |
| <b>Auto-Save Logic Designer every x minutes</b> | Logic diagrams with changes are saved automatically according to this interval. The range is 5 minutes (default) to 30 minutes. With auto-save, the file extension of the saved file is .auto. This file remains until you save the file manually.                                                                         |

## Auto Populate

These options work in the **Edit > Auto Populate Workbook** function

| Option                                     | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>VOs per Worksheet</b>                   | When an existing settings file is opened in the Logic Designer, the Logic Designer populates the canvas and attempts to evenly distribute the Virtual Output circuits across multiple sheets. A value of 100 in this setting places all FlexLogic equations on a single sheet until there are 100, then the next ones are placed on another sheet. A value of 1 places each Virtual Output circuit on a separate sheet.                                              |
| <b>Show / FlexLogic Merge / Show Unuse</b> | If Show Contact Outputs and Show LEDs are selected, for example, the function places Contact Output and User-programmable LED symbols for settings that are configured. If you disable the LED check boxes, then the LED tab/sheet does not display when you next open the Logic Designer window. The settings apply to all products, not just the active window when it is next opened. Close then reopen the Logic Designer window for the setting to take effect. |

**Compiler**

| Option                          | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Show Warnings</b>            | Options to filter the messages that display when logic compiles.                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Minor</b>                    | Enable to display minor errors. An example is using the default values of an element added to the diagram, such as the name of the element. An example is "Warning: Virtual output xx using default name," for which you simply click into the element to rename it.                                                                                                                                                                                                                                  |
| <b>Major</b>                    | Enable to display major errors. Examples are an input that does not have a corresponding output, using disabled features, and failing to connect a symbol. Fix these errors.                                                                                                                                                                                                                                                                                                                          |
| <b>Setting</b>                  | Enable to display error message related to settings, such as an improperly configured setting, such as using ON or OFF.                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Automatically Sort VOs</b>   | When enabled, the logic is compiled with an algorithm to give best results and quickest performance, for example the fastest logic first. The fastest logic displays in the FlexLogic Equation Editor output as the first entries in the table. Use sorting when virtual outputs have dependencies on other virtual outputs. This setting takes precedence over order set manually in the <b>VO Order</b> tab in the compiler. When disabled, the sequence in which the blocks were drawn is followed |
| <b>Optimize Compiled Output</b> | Not applicable. Use the check box outlined earlier in the Optimize the Logic section                                                                                                                                                                                                                                                                                                                                                                                                                  |

**5.5.7.3 LOGIC MONITOR****Display**

The software displays the color specified when an element is on. There is no color when the element is off. The software displays another color when the status cannot be determined and is unknown.

**Timing**

Timing Information can be displayed in the monitoring window. This timing information is only an approximate representation of how Engineer sees transitions. Use the device's Event Record to view accurate timing information.

The timing information can also be streamed to a comma-separated values (CSV) spreadsheet.

The timing information displayed and recorded can be filtered based on six categories. If a category is not selected, any timing information related to that category does not display and is not recorded to the CSV file.

| Option                                          | Description                                                                                                                                                                                                                                                                                                     |
|-------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Show Timing Information in Output Window</b> | Enable to display times in the monitoring window.<br>Because of the update rate of the Logic Monitoring, the timing information cannot be used as an accurate representation of the events that occur within the relay. Use instead the device's event record. Timing information can be delayed by 30 seconds. |
| <b>Save Timing Information to CSV File</b>      | Enable to write timing information in a spreadsheet. The timing information is recorded in a text file that uses commas to separate each of the fields. This file uses the extension CSV that is supported by any spreadsheet application.<br>Every change written to the CSV file requires a timestamp.        |

**Timestamp format**

```
yyyy/mm/dd hh:dd:ss, devicename, offline
```

```
yyyy/mm/dd hh:dd:ss, devicename, ONLINE
```

```
yyyy/mm/dd hh:dd:ss, VO1: Virt Out 1, 0
```

```
yyyy/mm/dd hh:dd:ss, VI4: Virt In 4, 1
```

```
yyyy/mm/dd hh:dd:ss, DI3: Direct In 3, 0
```

```
yyyy/mm/dd hh:dd:ss, RI2: Remote In 2, 1
yyyy/mm/dd hh:dd:ss, H5a: Contact In 1, 1
yyyy/mm/dd hh:dd:ss, H1: Contact Output 1, 0
```

**Note:**  
Data is only appended to the CSV file

**Note:**  
Options display for filtering, such as recording timing for Virtual Inputs and Outputs, but not Communications Status

#### 5.5.7.4 COMTRADE WAVEFORMS


Waveform files are viewable in the EnerVista software. The preferences are unrelated to Engineer and are outlined in the UR Family Communications Guide.

#### 5.5.8 TOOLBARS

These are toggled in the **View > Toolbar** menu.

The UR symbols are displayed for the toolbox icons. They change when the default setting is changed to IEC or ISO symbols. The symbols displayed in the toolbox also vary by firmware version, reflecting what is supported for each release.

##### FlexLogic Editor toolbar




**Figure 157: FlexLogic Editor toolbar**

From left to right:

- Create a new settings file
- Open an existing settings file in the URS, CID, or IID format
- Save the Logic Designer diagram
- Create a PDF document from Logic Designer diagram(s). Settings can be changed under File > Preferences > Workbook Setup.
- Display or hide the compile window area
- Select to change the sort order of the Virtual Output list to the right of the icon. Virtual Outputs can be sorted numerically in ascending and descending order based on numbers and names.
- Select a Virtual Output to locate and select it in the workbook. Each Virtual Output listed also contains the name of the sheet where the Virtual Output is located.
- Switch to Logic Designer mode
- Switch to Logic Monitor mode
- Turn on all communications to all Logic Designer diagrams that are in the monitoring mode. Default upon each launch of Engineer.
- Turn off all communications to all Logic Designer diagrams that are in the monitoring mode. This is a legacy function for serial communication to turn off communication to devices. Turning off communication applies to the current session only. When you re-launch the EnerVista software, communication is on by default.

### Token Toolbox




**Figure 158: Drawing Tools**

From left to right:

- Draw a line. Click and drag to draw.
- Draw multiple joined lines. Click and drag for each line. Double-click to finish.
- Draw multi-sided object. Click for each line. Double-click to finish.
- Draw four-sided object. Click and drag to draw.
- Draw multiple curves. Click for each line. Double-click to finish.
- Draw multiple, closed curves. Click for each line. Double-click to finish.
- Draw oval or circle. Click and drag to draw.
- Add text box with rectangle around it. Click to add. Double-click it to change text.
- Add figure. Select file in the window that opens, then click on diagram canvas to add figure.
- Add note icon and text. Click to add. Double-click to edit the title and text.

### I/O Tokens

These are parts used in FlexLogic equations. They are the inputs and outputs of the Virtual Output equations. The display can vary from that shown here.



**Figure 159: I/O tokens**

From left to right:

- Input symbol that can be configured to any FlexLogic operand value
- Remote inputs from other devices
- Input from another UR device. Teleprotection inputs/outputs and direct inputs/outputs are mutually exclusive and cannot be used simultaneously.
- Teleprotection inputs/outputs and direct inputs/outputs are mutually exclusive and cannot be used simultaneously.
- FlexAnalog symbol that can be used as the input to a FlexElement or use the FlexAnalog symbol to monitor an actual value when in logic Monitoring mode
- Contact Input Gate is similar to the Input symbol but is restricted to the operands associated with a Contact Input
- Contact Output Gate is similar to the Input symbol but is restricted to the operands associated with a Contact Output. The Operate and Seal-In settings can be configured graphically.
- The Non-Volatile Latch is similar to the Input symbol but is restricted to the operands associated with a Non-Volatile Latch. The Set and Reset settings can be configured graphically.
- The final output of an equation is a numbered register called a virtual output. Virtual outputs can be used as an input operand in any equation, including the equation that generates the output, as a seal-in or other type of feedback.
- Place and configure a Remote Output. The UR's order code and firmware version then determine the availability of the Remote Output.

- Place and configure a Direct Output. The UR's order code and firmware version then determine the availability of the Direct Output to another UR device.
- Place and configure a Teleprotection Output. The UR's order code and firmware version then determine the availability of the Teleprotection Output.
- Place a User Programmable LED in the Logic Designer diagram. Not applicable when using a graphical front panel.
- A Tag Out can be used in 1 of 2 ways. The first use of the Tag Out is to break up logic that needs to span several sheets. The second use of the Tag Out is to associate a frequently used block of code with the Tag Out and then repeatedly use the same block of code using a Tag In. When a Tag Out is referenced more than once, the Tag Out is replaced with a Virtual Output during the compile phase.
- Tag-In can be used to reference an existing Tag-Out. It joins another diagram to a previous diagram.

### Boolean Tokens

These symbols are used to create FlexLogic Equations. Use them as intermediate logic for the Virtual Output equations. The display can vary from that shown here.



**Figure 160: Boolean tokens**

From left to right:


- Place an OR gate in the Logic Designer diagram. Only one action needs to occur. Any function input on the left side satisfies the condition. The number of inputs is configurable from two to 16.
- Place an AND gate in the Logic Designer diagram. Multiple actions need to occur. All functions input on the left side are required to satisfy the condition. The number of inputs is configurable from two to 16.
- Place a NOR gate in the Logic Designer diagram. Gives the value of one when all input operands have a value of zero and otherwise gives a value of zero. It gives an output signal when there are no input signals. An inverter that reverses the logic state. The number of inputs is configurable from two to 16.
- Place a NAND gate in the Logic Designer diagram. Gives the value of zero when all input operands have a value of one and otherwise gives a value of one. It gives an output signal until all signals are present on its inputs. An inverter that reverses the logic state. The number of inputs is configurable from two to 16.
- Place a XOR gate in the Logic Designer diagram, which is two exclusive OR gates. Only one action needs to occur. If there are two inputs or there is no input, there is no output.
- Place a NOT gate in the Logic Designer diagram. Gives the value of one when the input operand has a value of zero and otherwise gives a value of zero. It gives an output signal when there is no input signal. An inverter that reverses the logic state.
- Place a latch in the Logic Designer diagram. A latch has two inputs and one output. One input is the Set input, and other input is the Reset input.
- Place a positive one shot symbol that responds to a positive going edge in the Logic Designer diagram. A "one shot" is a single input gate that generates a pulse in response to an edge on the input.
- Place a negative one shot symbol that responds to a negative going edge in the Logic Designer diagram
- Place a positive one shot and a negative one shot symbol in the Logic Designer diagram
- Place a timer in the Logic Designer diagram

### Elements



For the following elements, you should use EITHER Logic Designer OR the manual setting screen. Do not use both as this will cause inconsistencies with their settings

These blocks configure properties of the element or use element operands as input to FlexLogic equations.



**Figure 161: Elements**

From left to right:

- Place and configure a FlexElement. A FlexElement is a universal comparator used to monitor any analog actual value calculated by the relay or a net difference of any two analog actual values of the same type.
- Place and configure the Settings Group settings
- Place and configure a Selector Switch element. Firmware version determines feature availability. The Selector Switch element is intended to replace a mechanical selector switch. Typical applications include setting group
- control or control of multiple logic sub-circuits in user-programmable logic. The element provides for two control inputs.
- Place and configure a Digital Element. A Digital Element can monitor any FlexLogic operand
- and present a target message and/or enable events recording depending on the output operand state.
- Place and configure a Digital Counter element. A Digital Counter counts the number of state transitions
- from Logic 0 to Logic 1. The counter is used to count operations such as the pickups of an element.

### Basic Actions toolbar



**Figure 162: Basic Actions toolbar**

From left to right:

- Select components. Click one component and hold down the CTRL key to select others. Or click and drag an area that contains multiple components to select.
- Shows vertices points for the component selected (if the component support vertices manipulation)
- Shows the properties of the selected component
- Zoom in and center the screen to the spot selected
- Zoom in to a magnitude that fits your entire schema layout on your entire screen
- Zoom in on the components that you have selected
- Move the viewable area of your screen around the schema. To activate, select this tool and then place the hand icon over and part of your schema. Click and drag the hand in a direction to move around the schema.
- Align the selected components to the top of the reference component
- Align the selected components to the middle of the reference component
- Align the selected components to the bottom of the reference component
- Align the selected components to the left of the reference component
- Align the selected components to the centre of the reference component
- Align the selected components to the right of the reference component
- Evenly space the selected components across a horizontal axis, starting from the far left component and ending at the far right component
- Evenly space the selected components across a vertical axis, starting from the top component and ending at the bottom component

- Set the width of the selected components to the same width as the reference component
- Set the height of the selected components to the same height as the reference component
- Set the width and height of the selected components to the same width and height of the reference component

#### Advanced Actions toolbar



**Figure 163: Advanced Actions toolbar**

Only basic objects (lines, rectangles, ellipses) can be rotated and flipped.

Only objects from the Drawing Toolbar can be structured (grouped, ungrouped, forward, backward)


From left to right:

- Moves selected component one pixel upward
- Moves selected component one pixel downward
- Moves selected component one pixel left
- Moves selected component one pixel right
- Rotates selected component freely. Once selected, put your mouse cursor over the component and move the component clockwise or counter-clockwise depending on what you need.
- Rotates selected component 90 degrees counter-clockwise
- Rotates selected component 90 degrees clockwise
- Flips the selected component on the vertical axis
- Flips the selected component on the horizontal axis
- Combines all selected components into one combined entity.
- Ungroups components into separate components.
- Moves current components to the absolute front of all viewable layers
- Moves current components to the absolute back of all viewable layers
- Moves current components on layer higher than its original layer hierarchy
- Moves current components on layer lower than its original layer hierarchy

---

### 5.5.9 FLEXLOGIC OPERANDS

For flexibility, the arrangement of internal digital logic combines fixed and user-programmed parameters. Logic upon which individual features are designed is fixed, and all other logic, from contact input signals through elements or combinations of elements to contact outputs, is variable. The user has complete control of all variable logic through FlexLogic. In general, the system receives analog and digital inputs that it uses to produce analog and digital outputs. The figure shows major subsystems of a generic UR-series relay involved in this process.



**Figure 164: UR architecture overview**

The states of all digital signals used in the Product are represented by flags (or FlexLogic operands, which are described later in this section). A digital “1” is represented by a set flag. Any external contact change-of-state can be used to block an element from operating, as an input to a control feature in a FlexLogic equation, or to operate a contact output. The state of the contact input can be displayed locally or viewed remotely via the communications facilities provided. If a simple scheme where a contact input is used to block an element is wanted, this selection is made when programming the element. This capability also applies to the other features that set flags: elements, virtual inputs, remote inputs, schemes, and human operators.

If more complex logic than shown in the figure is required, it is implemented via FlexLogic. For example, to have the closed state of contact input H7a and the operated state of the phase undervoltage element block the operation of the phase time overcurrent element, the two control input states are programmed in a FlexLogic equation. This equation ANDs the two control inputs to produce a virtual output that is then selected when programming the phase time overcurrent to be used as a blocking input. Virtual outputs can only be created by FlexLogic equations.

Traditionally, protective relay logic has been relatively limited. Any unusual applications involving interlocks, blocking, or supervisory functions had to be hard-wired using contact inputs and outputs. FlexLogic minimizes the requirement for auxiliary components and wiring while making more complex schemes possible.

The logic that determines the interaction of inputs, elements, schemes, and outputs is field-programmable through the use of logic equations that are sequentially processed. The use of virtual inputs and outputs in addition to hardware is available internally and on the communication ports for other relays to use (distributed FlexLogic).

FlexLogic allows users to customize the relay through a series of equations that consist of operators and operands. The operands are the states of inputs, elements, schemes, and outputs. The operators are logic gates, timers, and latches (with set and reset inputs). A system of sequential operations allows any combination of operands to be assigned as inputs to specified operators to create an output. The final output of an equation is a numbered register



called a virtual output. Virtual outputs can be used as an input operand in any equation, including the equation that generates the output, as a seal-in or other type of feedback.

A FlexLogic equation consists of parameters that are either operands or operators. Operands have a logic state of 1 or 0. Operators provide a defined function, such as an AND gate or a Timer. Each equation defines the combinations of parameters to be used to set a Virtual Output flag. Evaluation of an equation results in either a 1 (=ON, or flag set) or 0 (=OFF, or flag not set). Each equation is evaluated at least four times every power system cycle.

Some types of operands are present in the relay in multiple instances, for example contact and remote inputs. These types of operands are grouped together (for presentation purposes only) on the front panel display. The table lists characteristics of the different types of operands.

| Operand type                              | State          | Example of format    | Characteristics [Input Is '1' (= ON) if...]                                                                                                                                                         |
|-------------------------------------------|----------------|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Contact Input                             | On             | Cont Ip On           | Voltage is applied presently to the input (external contact closed)                                                                                                                                 |
|                                           | Off            | Cont Ip Off          | Voltage is not applied presently to the input (external contact open)                                                                                                                               |
| Contact Output (type Form-A contact only) | Contact Closed | Cont Op 1 Closed     | Contact output is closed                                                                                                                                                                            |
|                                           | Current On     | Cont Op 1 Ion        | Current is flowing through the contact                                                                                                                                                              |
|                                           | Voltage On     | Cont Op 1 VOn        | Voltage exists across the contact                                                                                                                                                                   |
|                                           | Voltage Off    | Cont Op 1 VOff       | Voltage does not exist across the contact                                                                                                                                                           |
| Direct Input                              | On             | DIRECT INPUT 1 On    | The direct input is presently in the ON state                                                                                                                                                       |
| Element (Analog): (not C30)               | Pickup         | PHASE TOC1 PKP       | The tested parameter is presently above the pickup setting of an element that responds to rising values or below the pickup setting of an element that responds to falling values                   |
|                                           | Dropout        | PHASE TOC1 DPO       | This operand is the logical inverse of the above PKP operand                                                                                                                                        |
|                                           | Operate        | PHASE TOC1 OP        | The tested parameter has been above/below the pickup setting of the element for the programmed delay time, or has been at logic 1 and is now at logic 0 but the reset timer has not finished timing |
|                                           | Block          | PHASE TOC1 BLK       | The output of the comparator is set to the block function                                                                                                                                           |
| Element (Digital)                         | Pickup         | Dig Element 1 PKP    | The input operand is at logic 1                                                                                                                                                                     |
|                                           | Dropout        | Dig Element 1 DPO    | This operand is the logical inverse of the above PKP operand                                                                                                                                        |
|                                           | Operate        | Dig Element 1 OP     | The input operand has been at logic 1 for the programmed pickup delay time, or has been at logic 1 for this period and is now at logic 0 but the reset timer has not finished timing                |
| Element (Digital Counter): (not B90)      | Higher than    | Counter 1 HI         | The number of pulses counted is above the set number                                                                                                                                                |
|                                           | Equal to       | Counter 1 EQL        | The number of pulses counted is equal to the set number                                                                                                                                             |
|                                           | Lower than     | Counter 1 LO         | The number of pulses counted is below the set number                                                                                                                                                |
| Fixed                                     | On             | On                   | Logic 1                                                                                                                                                                                             |
|                                           | Off            | Off                  | Logic 0                                                                                                                                                                                             |
| RxGOOSE Boolean                           | On             | RxGOOSE Boolean 1 On | The RxGOOSE Boolean is presently in the ON state                                                                                                                                                    |
| Virtual Input                             | On             | Virt Ip 1 On         | The virtual input is presently in the ON state                                                                                                                                                      |
| Virtual Output                            | On             | Virt Op 1 On         | The virtual output is presently in the set state (that is, evaluation of the equation that produces this virtual output results in a "1")                                                           |

A full list of operands for the UR-series of relays is available in the appendix. You can also view them online in a relay by entering the IP address of the relay in a web browser and accessing the **Device Information Menu**.

**Note:**

Any FlexLogic operands that are visible online but not listed below, are intended for factory use.

You can rename the following operand types if desired.

- Breakers in the breaker control feature
- The ID (identification) of the contact inputs and outputs
- The ID of virtual inputs and outputs.

If you change the default name or ID of any of these operands, the assigned name will appear in the relay list of operands.

The characteristics of the logic gates are tabulated in the following table, and the operators available in FlexLogic are listed in the FlexLogic operators table.

| Gates | Number of inputs | Output is '1' (= ON) if... |
|-------|------------------|----------------------------|
| NOT   | 1                | input is '0'               |
| OR    | 2 to 16          | any input is '1'           |
| AND   | 2 to 16          | all inputs are '1'         |
| NOR   | 2 to 16          | all inputs are '0'         |
| NAND  | 2 to 16          | any input is '0'           |
| XOR   | 2                | only one input is '1'      |

| Type     | Syntax            | Description                                                                                      | Notes                                                                                                                                                                                                                                          |
|----------|-------------------|--------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Editor   | INSERT            | Insert a parameter in an equation list                                                           |                                                                                                                                                                                                                                                |
|          | DELETE            | Delete a parameter from an equation list                                                         |                                                                                                                                                                                                                                                |
| End      | END               | The first END encountered signifies the last entry in the list of processed FlexLogic parameters |                                                                                                                                                                                                                                                |
| One shot | POSITIVE ONE SHOT | One shot that responds to a positive going edge                                                  | A 'one shot' refers to a single input gate that generates a pulse in response to an edge on the input. The output from a 'one shot' is True (positive) for only one pass through the FlexLogic equation. There is a maximum of 64 'one shots'. |
|          | NEGATIVE ONE SHOT | One shot that responds to a negative going edge                                                  |                                                                                                                                                                                                                                                |
|          | DUAL ONE SHOT     | One shot that responds to both the positive and negative going edges.                            |                                                                                                                                                                                                                                                |

| Type                  | Syntax      | Description                                            | Notes                                                                                                            |
|-----------------------|-------------|--------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|
| Logic gate            | NOT         | Logical NOT                                            | Operates on the previous parameter                                                                               |
|                       | OR(n)       | n input OR gate                                        | Operates on the n previous parameters                                                                            |
|                       | AND(n)      | n input AND gate                                       | Operates on the n previous parameters                                                                            |
|                       | NOR(n)      | n input NOR gate                                       | Operates on the n previous parameters                                                                            |
|                       | NAND(n)     | n input NAND gate                                      | Operates on the n previous parameters                                                                            |
|                       | XOR(2)      | 2 input Exclusive OR gate                              | Operates on the 2 previous parameters                                                                            |
|                       | LATCH (S,R) | Latch (set, reset): reset-dominant                     | The parameter preceding LATCH(S,R) is the reset input. The parameter preceding the reset input is the set input. |
| Timer                 | TIMER n     | Timer set with FlexLogic timer n settings              | The timer is started by the preceding parameter. The output of the timer is TIMER n.                             |
| Assign virtual output | = Virt Op n | Assigns previous FlexLogic operand to virtual output n | The virtual output is set by the preceding parameter                                                             |

### 5.5.10 FLEXLOGIC RULES

When forming a FlexLogic equation, the sequence in the linear array of parameters must follow these general rules:

1. Operands must precede the operator that uses the operands as inputs.
2. Operators have only one output. The output of an operator must be used to create a virtual output if it is to be used as an input to two or more operators.
3. Assigning the output of an operator to a virtual output terminates the equation.
4. A timer operator (for example, TIMER 1) or virtual output assignment (for example, = Virt Op 1) can be used once only. If this rule is broken, a syntax error is declared.

### 5.5.11 FLEXLOGIC EVALUATION

Each equation is evaluated in the ascending order in which the parameters have been entered.

FlexLogic provides built-in latches that by definition have a memory action, remaining in the set state after the set input has been asserted. These built-in latches are reset dominant, meaning that if logical "1" is applied to both set and reset entries simultaneously, then the output of the latch is logical "0." However, they are volatile, meaning that they reset upon removal of control power.

When making changes to FlexLogic entries in the settings, all FlexLogic equations are re-compiled whenever any new FlexLogic entry value is entered, and as a result of the re-compile all latches are reset automatically.


To implement FlexLogic using a graphical user interface, see the FlexLogic Design and Monitoring using Engineer section in the previous chapter.

### 5.5.12 FLEXLOGIC EXAMPLE

This section provides an example of logic implementation for a typical application. The sequence of steps is important to minimize the work to develop the relay settings. Note that the example in the following figure demonstrates the procedure, not to solve a specific application situation.

Note that there is also a graphical interface with which to draw logic and populate FlexLogic equation entries.

In the example, we assume that logic has already been programmed to produce virtual outputs 1 and 2, and is only a part of the full set of equations used. When using FlexLogic, it is important to make a note of each virtual output used; a virtual output designation (1 to 256) can be assigned only once.



827025A2.CDR


**Figure 165: Logic example**

1. Inspect the example logic diagram to determine if the required logic can be implemented with the FlexLogic operators. If this is not possible, the logic must be altered until this condition is satisfied. Once done, count the inputs to each gate to verify that the number of inputs does not exceed the FlexLogic limits, which is unlikely but possible. If the number of inputs is too high, subdivide the inputs into multiple gates to produce an equivalent. For example, if 25 inputs to an AND gate are required, connect Inputs 1 through 16 to AND(16), 17 through 25 to AND(9), and the outputs from these two gates to AND(2).

Inspect each operator between the initial operands and final virtual outputs to determine if the output from the operator is used as an input to more than one following operator. If so, the operator output must be assigned as a virtual output.

For the example shown, the output of the AND gate is used as an input to both OR#1 and Timer 1, and must therefore be made a virtual output and assigned the next available number (that is, Virtual Output 3). The final output must also be assigned to a virtual output as virtual output 4, which is programmed in the contact output section to operate relay H1 (that is, contact output H1).


Therefore, the required logic can be implemented with two FlexLogic equations with outputs of virtual output 3 and virtual output 4, shown as follows.



827026A2.CDR

**Figure 166: Logic example with virtual outputs**


2. Prepare a logic diagram for the equation to produce virtual output 3, as this output is used as an operand in the virtual output 4 equation (create the equation for every output that is used as an operand first, so that when these operands are required they already have been evaluated and assigned to a specific virtual output). The logic for virtual output 3 is shown as follows with the final output assigned.



827027A2.CDR

**Figure 167: Logic for virtual output 3**


3. Prepare a logic diagram for virtual output 4, replacing the logic ahead of virtual output 3 with a symbol identified as virtual output 3, shown as follows.



827028A2.CDR

**Figure 168: Logic for virtual output 4**

4. Program the FlexLogic equation for virtual output 3 by translating the logic into available FlexLogic parameters. The equation is formed one parameter at a time until the required logic is complete. It is generally easier to start at the output end of the equation and work back towards the input, as shown in the following steps. It is also recommended to list operator inputs from bottom to top. For demonstration, the final outputs are arbitrarily identified as parameter 99, and each preceding parameter decremented by one in turn. Until accustomed to using FlexLogic, it is suggested that a worksheet with a series of cells marked with the arbitrary parameter numbers be prepared shown as follows.



**Figure 169: FlexLogic worksheet**

5. Following the procedure outlined, start with parameter 99, as follows:

99: The final output of the equation is virtual output 3, which is created by the operator "= Virt Op n". This parameter is therefore "= Virt Op 3".

98: The gate preceding the output is an AND, which in this case requires two inputs. The operator for this gate is a 2-input AND so the parameter is "AND(2)". Note that FlexLogic rules require that the number of inputs to most types of operators must be specified to identify the operands for the gate. As the 2-input AND operates on the two operands preceding it, these inputs must be specified, starting with the lower.

97: This lower input to the AND gate must be passed through an inverter (the NOT operator) so the next parameter is "NOT". The NOT operator acts upon the operand immediately preceding it, so specify the inverter input next.


96: The input to the NOT gate is to be contact input H1c. The ON state of a contact input can be programmed to be set when the contact is either open or closed. Assume for this example that the state is to be ON for a closed contact. The operand is therefore "Cont Ip H1c On".

95: The last step in the procedure is to specify the upper input to the AND gate, the operated state of digital element 2. This operand is "DIG ELEM 2 OP".

Writing the parameters in numerical order forms the equation for virtual output 3:

```
[95] DIG ELEM 2 OP
[96] Cont Ip H1c On
[97] NOT
[98] AND(2)
[99] = Virt Op 3
```

It is now possible to check that this selection of parameters produces the required logic by converting the set of parameters into a logic diagram. The result of this process is shown in the figure, which is compared to the logic for virtual output 3 diagram as a check.




**Figure 170: FlexLogic equation for virtual output 3**

6. Repeating the process described for virtual output 3, select the FlexLogic parameters for Virtual Output 4.
  - 99: The final output of the equation is virtual output 4, which is parameter “= Virt Op 4”.
  - 98: The operator preceding the output is timer 2, which is operand “TIMER 2”. Note that the settings required for the timer are established in the timer programming section.
  - 97: The operator preceding timer 2 is OR #2, a 3-input OR, which is parameter “OR(3)”.
  - 96: The lowest input to OR #2 is operand “Cont Ip H1c On”.
  - 95: The center input to OR #2 is operand “TIMER 1”.
  - 94: The input to timer 1 is operand “Virt Op 3 On”.
  - 93: The upper input to OR #2 is operand “LATCH (S,R)”.
  - 92: There are two inputs to a latch, and the input immediately preceding the latch reset is OR #1, a 4-input OR, which is parameter “OR(4)”.
  - 91: The lowest input to OR #1 is operand “Virt Op 3 On”.
  - 90: The input just above the lowest input to OR #1 is operand “XOR(2)”.
  - 89: The lower input to the XOR is operand “DIG ELEM 1 PKP”.
  - 88: The upper input to the XOR is operand “Virt Ip 1 On”.
  - 87: The input just below the upper input to OR #1 is operand “Virt Op 2 On”.
  - 86: The upper input to OR #1 is operand “Virt Op 1 On”.
  - 85: The last parameter is used to set the latch, and is operand “Virt Op 4 On”.

The equation for virtual output 4 is:

```
[85] Virt Op 4 On
[86] Virt Op 1 On
[87] Virt Op 2 On
[88] Virt Ip 1 On
[89] DIG ELEM 1 PKP
[90] XOR(2)
[91] Virt Op 3 On
[92] OR(4)
[93] LATCH (S,R)
[94] Virt Op 3 On
[95] TIMER 1
[96] Cont Ip H1c On
[97] OR(3)
[98] TIMER 2
[99] = Virt Op 4
```

Now check that the selection of parameters produce the required logic by converting the set of parameters into a logic diagram. The result is shown in the figure, which is compared to the logic for virtual output 4 diagram as a check



**Figure 171: FlexLogic equation for virtual output 4**

7. Now write the complete FlexLogic expression required to implement the logic, making an effort to assemble the equation in an order where Virtual Outputs that are used as inputs to operators are created before needed. In cases where a lot of processing is required to perform logic, this can be difficult to achieve, but in most cases does not cause problems as all logic is calculated at least four times per power frequency cycle. The possibility of a problem caused by sequential processing emphasizes the necessity to test the performance of FlexLogic before it is placed in service.

In the following equation, virtual output 3 is used as an input to both latch 1 and timer 1 as arranged in the following order:

```

DIG ELEM 2 OP
Cont Ip H1c On
NOT
AND(2)
= Virt Op 3
Virt Op 4 On
Virt Op 1 On
Virt Op 2 On
Virt Ip 1 On
DIG ELEM 1 PKP
XOR(2)
Virt Op 3 On
OR(4)
LATCH (S,R)
Virt Op 3 On
TIMER 1
Cont Ip H1c On
OR(3)
TIMER 2
= Virt Op 4
END

```



In this expression, the virtual output 4 input to the four-input OR is listed before it is created. This is typical of a form of feedback, in this case, used to create a seal-in effect with the latch, and is correct.

8. Always test the logic after it is loaded into the relay, in the same way as has been used in the past. Testing can be simplified by placing an "END" operator within the overall set of FlexLogic equations. The equations are evaluated up to the first "END" operator.

The "On" and "Off" operands can be placed in an equation to establish a known set of conditions for test purposes, and the "INSERT" and "DELETE" commands can be used to modify equations.

### 5.5.13 FLEXELEMENT BASE UNITS

| Unit                                                                                                                                             | Description                                                                                                                                                                                                                        |
|--------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 87L SIGNALS<br>(Local IA Mag, IB, and IC)<br>(Diff Curr IA Mag, IB, and IC)<br>(Terminal 1 IA Mag, IB, and IC)<br>(Terminal 2 IA Mag, IB and IC) | IBASE = maximum primary RMS value of the +IN and –IN inputs<br>(CT primary for source currents, and 87L source primary current for line differential currents)<br>(L30, L90)                                                       |
| 87L SIGNALS<br>(Op Square Curr IA, IB, and IC)<br>(Rest Square Curr IA, IB, and IC)                                                              | BASE = Squared CT secondary of the 87L source<br>(L30, L90)                                                                                                                                                                        |
| BREAKER ACC ARCING AMPS<br>(Brk X Acc Arc Amp A, B, and C)                                                                                       | BASE = 2000 kA <sup>2</sup> · cycle<br>(All but B90, C30, N60)                                                                                                                                                                     |
| BREAKER ARCING AMPS<br>(Brk X Arc Amp A, B, and C)                                                                                               | BASE = 1 kA <sup>2</sup> · cycle<br>(All but B90, C30, N60)                                                                                                                                                                        |
| BUS DIFFERENTIAL DIFFERENTIAL CURRENT<br>(Bus Diff Mag)                                                                                          | IBASE = maximum phase CT primary current of all configured bays (sources) for a given bus differential zone of the +IN and –IN inputs<br>(B30)                                                                                     |
| BUS DIFFERENTIAL RESTRAINING CURRENT<br>(Bus Rest Mag)                                                                                           | IBASE = maximum phase CT primary current of all configured bays (sources) for a given bus differential zone of the +IN and –IN inputs<br>(B30)                                                                                     |
| BUS GROUND DIFFERENTIAL DIFFERENTIAL CURRENT<br>(Bus Ground Diff Mag)                                                                            | IBASE = maximum ground CT primary current of all configured bays (sources) for a given bus differential zone of the +IN and –IN inputs for "Measured" option or maximum phase CT primary current for "Calculated" option.<br>(B30) |
| BUS GROUND DIFFERENTIAL RESTRAINING CURRENT (Bus Ground Rest Mag)                                                                                | IBASE = maximum ground CT primary current of all configured bays (sources) for a given bus differential zone of the +IN and –IN inputs for "Measured" option or maximum phase CT primary current for "Calculated" option.<br>(B30) |
| CURRENT UNBALANCE<br>(Amp Unbalance)                                                                                                             | BASE = 100%<br>(M60)                                                                                                                                                                                                               |
| DCmA                                                                                                                                             | BASE = maximum value of the DCMA INPUT MAX setting for the two transducers configured under the +IN and –IN inputs<br>(All UR products)                                                                                            |
| DELTA TIME                                                                                                                                       | BASE = 1 μs<br>(All UR products)                                                                                                                                                                                                   |
| FAULT LOCATION                                                                                                                                   | BASE = Line Length as specified in Fault Report<br>(C60, C95, D30, D60, F35, F60, L30, L60, L90)                                                                                                                                   |
| FIELD CURRENT                                                                                                                                    | IBASE = maximum value setting defined for the specific transducer input configured<br>(G60 only)                                                                                                                                   |
| FIELD GROUND CURRENT                                                                                                                             | IBASE = 5 mA<br>(G60 only)                                                                                                                                                                                                         |
| FIELD GROUND FAULT LOCATION                                                                                                                      | BASE = 100%<br>(G60 only)                                                                                                                                                                                                          |
| FIELD GROUND INJECTED VOLTAGE                                                                                                                    | VBASE = 15 V<br>(G60 only)                                                                                                                                                                                                         |

| Unit                                                                                  | Description                                                                                                                                                                                      |
|---------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FIELD GROUND RESISTANCE                                                               | RBASE = 250 K $\Omega$<br>(G60 only)                                                                                                                                                             |
| FIELD VOLTAGE                                                                         | VBASE = 500 V<br>(G60 only)                                                                                                                                                                      |
| FREQUENCY                                                                             | fBASE = 1 Hz<br>(All UR products)                                                                                                                                                                |
| FREQUENCY RATE OF CHANGE                                                              | df/dtBASE = 1 Hz/s<br>(D30, D60, F60, G30, G60, L30, L90, N60, T60)                                                                                                                              |
| MSOD FREQ_OSC                                                                         | 1 Hz<br>(D60, G30, G60, L90, N60, T60)                                                                                                                                                           |
| MSOD MAG_OSC                                                                          | 1 pu<br>(D60, G30, G60, L90, N60, T60)                                                                                                                                                           |
| MSOD PHASE_OSC                                                                        | 360 degrees<br>(D60, G30, G60, L90, N60, T60)                                                                                                                                                    |
| MSOD DAMPR_OSC                                                                        | 1%<br>(D60, G30, G60, L90, N60, T60)                                                                                                                                                             |
| PHASE ANGLE                                                                           | jBASE = 360 degrees (see the UR angle referencing convention)<br>(All UR products)                                                                                                               |
| POWER FACTOR                                                                          | PFBASE = 1.00<br>(All UR products)                                                                                                                                                               |
| RTDs                                                                                  | BASE = 100°C<br>(All UR products)                                                                                                                                                                |
| SENSITIVE DIR POWER<br>(Sns Dir Power)                                                | PBASE = maximum value of 3 x VBASE x IBASE for the +IN and –IN inputs of the sources configured for the sensitive power directional element(s).<br>(C60, C95, D60, F60, G30, G60, L90, N60, T60) |
| SOURCE CURRENT                                                                        | IBASE = maximum nominal primary RMS value of the +IN and –IN inputs<br>(All UR products)                                                                                                         |
| SOURCE ENERGY<br>(Positive and Negative Watthours,<br>Positive and Negative Varhours) | EBASE = 10000 MWh or MVAh, respectively<br>(B30, C60, C95, D60, F35, F60, G30, G60, L90, M60, N60, T60)                                                                                          |
| SOURCE POWER                                                                          | PBASE = maximum value of VBASE x IBASE for the +IN and –IN inputs<br>(All UR products)                                                                                                           |
| SOURCE THD & HARMONICS                                                                | BASE = 1%<br>C70, D60, F35, F60, G30, G60, L30, L90, N60, T60                                                                                                                                    |
| SOURCE VOLTAGE                                                                        | VBASE = maximum nominal primary RMS value of the +IN and –IN inputs<br>(All UR products)                                                                                                         |
| STATION BATTERY VOLTAGE<br>MEASUREMENT                                                | V <sub>DC_BASE</sub> = <b>STATION BATTERY NOM VOLTAGE</b> setting<br>(All UR products)                                                                                                           |
| STATOR DIFFERENTIAL CURRENT<br>(Stator Diff Iar, Ibr, and Icr)                        | IBASE = maximum primary RMS value of the +IN and –IN inputs<br>(CT primary for source currents, and bus reference primary current for bus differential currents)<br>(G60, M60)                   |
| STATOR GROUND 3RD HARMONIC<br>VOLTAGES<br>(Stator Gnd Vn/V0 3rd)                      | VBASE = Primary auxiliary voltage of the STATOR GROUND SOURCE<br>(G60, M60)                                                                                                                      |
| STATOR GROUND RESISTANCE                                                              | RBASE = 10 K $\Omega$<br>(G60)                                                                                                                                                                   |

| Unit                                                                                                                   | Description                                                                                                                                                                                         |
|------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| STATOR GROUND SUB-HARMONIC VOLTAGE                                                                                     | VBASE = nominal secondary voltage of auxiliary VT for the stator ground source (G60)                                                                                                                |
| STATOR GROUND SUB-HARMONIC CURRENT                                                                                     | IBASE = ground CT primary current of stator ground source (G60)                                                                                                                                     |
| STATOR RESTRAINING CURRENT<br>(Stator Diff Iad, Ibd, and Icd)                                                          | IBASE = maximum primary RMS value of the +IN and -IN inputs<br>(CT primary for source currents, and bus reference primary current for bus differential currents)<br>(G60, M60)                      |
| SYNCHROCHECK<br>(Max Delta Volts)                                                                                      | VBASE = maximum primary RMS value of all the sources related to the +IN and -IN inputs<br>(B30, C60, C95, D30, D60, F60, G30, G60, L30, L60, L90, N60, T60)                                         |
| THERMAL MODEL<br>(Model Capacity Used)<br>(Model Motor Unbalance)                                                      | BASE = 100%<br>(M60)                                                                                                                                                                                |
| THERMAL MODEL<br>(Model Lockout Time)                                                                                  | BASE = 10 minutes<br>(M60)                                                                                                                                                                          |
| THERMAL MODEL<br>(Thermal Model Load)<br>(Biased Motor Load)                                                           | BASE = 1.00 pu of FLA<br>(M60)                                                                                                                                                                      |
| THERMAL MODEL<br>(Trip Time on Overload)                                                                               | BASE = 10 seconds<br>(M60)                                                                                                                                                                          |
| THRU FLT x TOT ACC A<br>THRU FLT x TOT ACC B<br>THRU FLT x TOT ACC C<br>Transformer total thermal/mechanical damage    | BASE = 1.00 pu<br>(T35, T60)                                                                                                                                                                        |
| VOLTS PER HERTZ                                                                                                        | BASE = 1.00 pu<br>(G30, G60, L90, T60)                                                                                                                                                              |
| XFMR DIFFERENTIAL CURRENT<br>(Xfmr Iad, Ibd, and Icd Mag)                                                              | IBASE = maximum primary RMS value of the +IN and -IN inputs<br>(CT primary for source currents, and transformer reference primary current for transformer differential currents)<br>(G30, T35, T60) |
| XFMR VOLTAGE COMPENSATED DIFFERENTIAL CURRENT<br>(Intturn# Cmp Iad Mag, Intturn# Cmp Ibd Mag and Intturn# Cmp Icd Mag) | IBASE = maximum primary RMS value of the +IN and -IN inputs<br>(CT primary for source currents, and transformer reference primary current for transformer differential currents)<br>(T35, T60)      |
| XFMR RAW DIFFERENTIAL CURRENT<br>(Intturn# Raw Iad Mag, Intturn# Raw Ibd Mag and Intturn# Raw Icd Mag)                 | IBASE = maximum primary RMS value of the +IN and -IN inputs<br>(CT primary for source currents, and transformer reference primary current for transformer differential currents)<br>(T35, T60)      |
| INTERTURN FAULT DETECTION COEFFICIENTS<br>(Intturn# Coef Ka Mag, Intturn# Coef Kb Mag, Intturn# Coef Kc Mag)           | BASE=0.1<br>(T35, T60)                                                                                                                                                                              |
| XFMR DIFFERENTIAL HARMONIC CONTENT<br>(Xfmr Harm2 Iad, Ibd, and Icd Mag)<br>(Xfmr Harm5 Iad, Ibd, and Icd Mag)         | BASE = 10%<br>(G30, T35, T60)                                                                                                                                                                       |
| XFMR RESTRAINING CURRENT<br>(Xfmr Iar, Ibr, and Icr Mag)                                                               | IBASE = maximum primary RMS value of the +IN and -IN inputs<br>(CT primary for source currents, and transformer reference primary current for transformer differential currents)<br>(G30, T35, T60) |

| Unit  | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ZBASE | <p>ZBASE = <math>\text{PhaseVTSecondary} / \text{PhaseCTSecondary}</math>, where PhaseVTSecondary and PhaseCTSecondary are the secondary nominal voltage and the secondary nominal current of the distance source. In case multiple CT inputs are summed as one source current and mapped as the distance source, use the PhaseCTSecondary value from the CT with the highest primary nominal current.</p> <p>Distance source is specified in setting under SETTINGS &gt; GROUPED ELEMENTS &gt; SETTING GROUP 1(6) &gt; DISTANCE.</p> <p>PhaseVTSecondary and PhaseCTSecondary are specified in setting under SETTINGS → SYSTEM SETUP → AC INPUTS.</p> <p>(D30, D60, G60, L60, L90, T60)</p> |

## CHAPTER 6

# CYBERSECURITY

---

# 6.1      CHAPTER OVERVIEW

---

This chapter contains the following sections:

|                                            |     |
|--------------------------------------------|-----|
| Chapter Overview                           | 258 |
| Cybersecurity overview                     | 259 |
| Security setup                             | 260 |
| IEC62351-9 Encryption for R-GOOSE messages | 285 |
| RADIUS server configuration                | 312 |

## 6.2 CYBERSECURITY OVERVIEW

---

The UR family of products are digital devices designed to be installed and operated in utility substations & industrial plant environments and connected to secure private networks. UR relays should not be connected to the public internet.

We strongly recommend that you protect your digital devices using a *defense-in-depth* strategy. This will protect your products, your network, your systems and your interfaces against cybersecurity threats. This includes, but is not limited to:

- Locating your digital devices inside the control system network security perimeter
- Deploying and maintaining access controls
- Monitoring and Intrusion Detection
- Security awareness training of security policies
- Network segmentation
- Firewalls installation
- Strong and active password management
- Data encryption
- Antivirus protection

UR relays are available with an optional software option (CyberSentry), which provides additional cybersecurity mechanisms to help you protect against cybersecurity intrusion. We strongly recommend that you use this "CyberSentry" option.

For additional details and recommendations on how to protect your relays, please read this chapter and implement the principles outlined. From time to time, we may issue additional instructions and recommendations relating to the products and other cybersecurity threats or vulnerabilities.

As a customer of GE Vernova, it is YOUR sole responsibility to make sure that your UR relays are installed and operated in accordance with its cybersecurity capabilities, the security context, and the instructions and recommendations provided. Users assume all risks and liability associated with damages or losses incurred in connection with any and all cybersecurity incidences.

## 6.3 SECURITY SETUP

The following security features are available:


- **Password security** — Basic security present by default
- **EnerVista security** — Role-based access to various EnerVista software screens and configuration elements. The feature is present by default in the EnerVista software.
- **CyberSentry security** — Advanced security available using a software option. When purchased, the option is enabled automatically, and the default Password security and EnerVista security are disabled.

To maximize security, see the UR Family Secure Deployment Guide.

### 6.3.1 PASSWORD SECURITY

Password security is a basic security feature present by default. Two levels of password security are provided: command and setting. Use of a password for each level controls whether all users can enter commands and/or change settings. Two types of connection security are provided: password entry from local or remote connection. Local access is defined as access to settings or commands via the front panel interface. This includes both keypad entry and the through a front panel port. Remote access is defined as access to settings or commands via any rear communications port. This includes both Ethernet and RS485 connections. These two settings are on by default and apply to all users. When entering a settings or command password via EnerVista or any serial interface, the user must enter the corresponding connection password. If the connection is to the back of the relay, the remote password is used. If the connection is to a front panel port, the local password applies. (These two local and remote password settings are not shown in the figure.)

Password access events are logged in the Event Recorder.



**Figure 172: Password security**

#### Lost password

If all passwords are lost, reset the unit to default values. Follow the instructions outlined later for:

**COMMANDS > RELAY MAINTENANCE > SERVICE COMMAND**



*Note:*  
The entire relay is reset to default values, not just the passwords.

Then change the CyberSentry password as described in the Set Up CyberSentry and Change Default Password section at the end of the Installation chapter.

**Password requirements**

A user account requires an alpha-numeric password that meets the following requirements:

- Password is case-sensitive
- Password cannot contain the user account name or parts of the user account that exceed two consecutive characters
- Password must be 8 to 20 characters in length
- Password must contain characters from all of the following categories:
  - English uppercase characters (A through Z)
  - English lowercase characters (a through z)
  - Base 10 digits (0 through 9)
  - Non-alphabetic characters (for example, ~, !, @, #, \$, %, &)

**6.3.1.1 PASSWORD SECURITY SETTINGS**

Setting path: **SETTINGS > PRODUCT SETUP > SECURITY**

|                                    |   |                                        |                                                                                |
|------------------------------------|---|----------------------------------------|--------------------------------------------------------------------------------|
| <div>■ SECURITY</div> <div>■</div> | ⇔ | ACCESS LEVEL:<br>Restricted            | Range: Restricted, Command, Setting,<br>Factory Service (for factory use only) |
|                                    | ⇕ | ■ CHANGE LOCAL<br>■ PASSWORDS          |                                                                                |
|                                    | ⇔ | ■ CHANGE REMOTE<br>■ PASSWORDS         |                                                                                |
|                                    | ⇕ | ■ ACCESS<br>■ SUPERVISION              |                                                                                |
|                                    | ⇕ | ■ DUAL PERMISSION<br>■ SECURITY ACCESS |                                                                                |
|                                    | ↑ | PASSWORD ACCESS<br>EVENTS: Disabled    | Range: Disabled, Enabled                                                       |

The relay supports password entry from either a local or remote connection.

Local access is defined as access to settings or commands via the front panel. This includes both keypad entry and the RS232 port. Remote access is defined as access to settings or commands via any rear communications port. This includes both Ethernet and RS485 connections. Any change to the local or remote password enables this functionality.

*Note:*  
For a relay without CyberSentry, ANY user can activate the RESET button or Reset/Acknowledge an alarm in the Graphical Front Panel Annunciator without password entry.

The security menu has the following settings:

- **ACCESS LEVEL**
- **PASSWORD ACCESS EVENTS**

### ACCESS LEVEL

This setting is viewable on the front panel. The Setting and Command passwords can be changed in the EnerVista interface.

The "Restricted" option means that settings and commands can be accessed, but there is no access to factory configuration. Access automatically reverts to the Restricted level according to the ACCESS LEVEL TIMEOUTS values. The access level is set to Restricted when control power is cycled. The "Factory Service" level is for factory functions.

There are two user security access levels, setting and command, for which you can set a password for each. Use of a password for each level controls whether users can enter commands or change settings. Another option is to specify setting and/or command access for individual user accounts.

- Setting — Allows the user to make any changes to any of the setting values:
  - Change any setting
  - Test mode operation
- Command — Restricts the user from making any settings changes, but allows the user to perform the following operations:
  - Operate the breakers via front panel keypad (not all UR models)
  - Change the state of virtual inputs
  - Clear the event records
  - Clear the oscillography records
  - Clear fault reports
  - Change the date and time
  - Clear the breaker arcing current
  - Clear energy records
  - Clear the data logger
  - Clear the user-programmable pushbutton states

When entering a settings or command password via EnerVista or any serial interface, you must enter the corresponding connection password. If the connection is to the back of the relay, use the remote password. If the connection is to the RS232 port of the front panel, use the local password.

The local setting and command sessions are initiated by the user through the front panel display and are disabled either by the user or by timeout (via the setting and command level access timeout settings). The remote setting and command sessions are initiated through the EnerVista software and are disabled either by the user or by timeout.

The state of the session (local or remote, setting or command) determines the state of the following FlexLogic operands:

- ACCESS LOC SETG OFF — Asserted when local setting access is disabled
- ACCESS LOC SETG ON — Asserted when local setting access is enabled
- ACCESS LOC CMND OFF — Asserted when local command access is disabled
- ACCESS LOC CMND ON — Asserted when local command access is enabled
- ACCESS REM SETG OFF — Asserted when remote setting access is disabled
- ACCESS REM SETG ON — Asserted when remote setting access is enabled
- ACCESS REM CMND OFF — Asserted when remote command access is disabled
- ACCESS REM CMND ON — Asserted when remote command access is enabled

**Note:**  
*A command or setting write operation is required to update the state of the remote and local security operands listed.*

**Note:**  
*When a setting password or command password is set or updated, user access with a graphical front panel is removed. Simply log in again on the graphical front panel.*

**Note:**  
*When the setting password is set or updated, the graphical front panel Access Level displays as Command. This is because the graphical front panel is a Modbus client and it does not have automatic access to the password change.*

### PASSWORD ACCESS EVENTS

This setting allows recording of password access events in the event recorder.


The security menu has the following sub-menus:

- **CHANGE LOCAL PASSWORDS**
- **CHANGE REMOTE PASSWORDS**
- **ACCESS SUPERVISION**
- **DUAL PERMISSION SECURITY ACCESS**

These sub-menus are described in the subsequent sections.

#### 6.3.1.1.1 CHANGE LOCAL PASSWORDS SETTING

Setting path: **SETTINGS > PRODUCT SETUP > SECURITY > CHANGE LOCAL PASSWORDS**



There are two user security access levels, setting and command. Use of a password for each level controls whether users can enter commands or change settings. Proper password codes are required to enable each access level. When a CHANGE COMMAND PASSWORD or CHANGE SETTING PASSWORD setting is SET to “Yes” via the front panel interface, the following message sequence is shown:

1. ENTER NEW PASSWORD:
2. VERIFY NEW PASSWORD:
3. NEW PASSWORD HAS BEEN STORED.

To gain write access to a restricted setting, program the ACCESS LEVEL setting in the main security menu to *Setting* and then change the setting, or attempt to change the setting and follow the prompt to enter the programmed password. If the password is correctly entered, access is allowed. Access automatically reverts to the restricted level according to the access level timeout setting values and when power is cycled.

#### 6.3.1.1.2 CHANGE REMOTE PASSWORDS SETTING

Setting path: **SETTINGS > PRODUCT SETUP > SECURITY > CHANGE REMOTE PASSWORDS**

|                                                                |   |                                                                    |                |
|----------------------------------------------------------------|---|--------------------------------------------------------------------|----------------|
| <div> <div>■ CHANGE REMOTE</div> <div>■ PASSWORDS</div> </div> | ↔ | <div>CHANGE SETTING</div> <div>PASSWORD: No</div>                  | Range: No, Yes |
|                                                                | ↑ | <div> <div>■ CHANGE COMMAND</div> <div>■ PASSWORD: No</div> </div> | Range: No, Yes |

To set the command or setting password in EnerVista:

1. In the EnerVista software or from the front panel, navigate to **Settings > Product Setup > Security** menu item to open the remote password settings window.
2. Click the command or setting password **Change** button.
3. Enter the new password in the **New Password** field.
4. Re-enter the password in the **Confirm Password** field
5. Click **OK** to confirm. The password is checked to ensure that it meets requirements.

**Note:**

*If you establish a local (serial) connection to the relay, you cannot view remote passwords*

### 6.3.1.1.3 ACCESS SUPERVISION SETTING

Setting path: **SETTINGS > PRODUCT SETUP > SECURITY > ACCESS SUPERVISION**

|                                                           |   |                                                              |                                      |
|-----------------------------------------------------------|---|--------------------------------------------------------------|--------------------------------------|
| <div> <div>■ ACCESS</div> <div>■ SUPERVISION</div> </div> | ↔ | <div> <div>■ ACCESS LEVEL</div> <div>■ TIMEOUTS</div> </div> |                                      |
|                                                           | ⇅ | INVALID ATTEMPTS BEFORE LOCKOUT: 3                           | Range: 2 to 5 in steps of 1          |
|                                                           | ⇅ | PASSWORD LOCKOUT DURATION: 5 min                             | Range: 5 to 60 minutes in steps of 1 |
|                                                           | ⇅ | FACTORY SERVICE MODE: Disabled                               | Range: Enabled, Disabled             |
|                                                           | ↑ | LOCK FIRMWARE: Enabled                                       | Range: Enabled, Disabled             |

This menu displays when the ACCESS LEVEL setting is set to anything other than *Restricted* or *Command*.

The ACCESS SUPERVISION menu has the following settings:

- INVALID ATTEMPTS BEFORE LOCKOUT
- PASSWORD LOCKOUT DURATION
- FACTORY SERVICE MODE
- LOCK FIRMWARE

The following access settings are available.

#### INVALID ATTEMPTS BEFORE LOCKOUT

This setting specifies the number of times that an incorrect password can be entered within three minutes before lockout occurs. When lockout occurs, the LOCAL ACCESS DENIED or REMOTE ACCESS DENIED FlexLogic operands are turned to the *On* state. These operands *Off* state after the lockout has expired.

#### PASSWORD LOCKOUT DURATION

This setting specifies the time that the relay locks out password access after the number of invalid password entries specified by the INVALID ATTEMPTS BEFORE LOCKOUT setting.

The relay provides a means to raise an alarm upon failed password entry. If password verification fails while accessing a password-protected level of the relay (either settings or commands), the UNAUTHORIZED ACCESS FlexLogic operand is asserted. The operand can be programmed to raise an alarm via contact outputs or communications. This feature can be used to protect against both unauthorized and accidental access attempts.

The UNAUTHORIZED ACCESS operand is reset with the COMMANDS > CLEAR RECORDS > RESET UNAUTHORIZED ALARMS command. Therefore, to apply this feature with security, password-protect the Command level. The operand does not generate events or targets.

If events or targets are required, the UNAUTHORIZED ACCESS operand can be assigned to a digital element programmed with event logs or targets enabled.

### FACTORY SERVICE MODE

A factory service user is supported to perform additional operations intended only for them. This setting allows access by GE support staff to be turned on and off. A factory service user can log in only when this setting is configured as Enabled. It is disabled by default. When Enabled, the relay logs events and activates the TROUBLE LED.

GE recommends that Factory Service Mode be disabled when factory operations are not intended to be performed. The TROUBLE LED de-activates when a user disables Factory Service Mode.

Login is required for this user, and the password is unique for each relay.

A factory service user is logged out with any of the following circumstances:

- UR restarts
- FACTORY SERVICE MODE setting is disabled by Administrator or factory service user
- ACCESS LEVEL setting is changed from "Factory Service" via front panel or serial connection

### LOCK FIRMWARE

This setting determines whether the device accepts or blocks a firmware upgrade. When disabled, firmware can be updated. When enabled, the firmware cannot be updated. When Enabled/locked and a firmware upgrade is attempted using the software, the UNAUTH FW ATTEMPT FlexLogic operand does not assert. When locked and a firmware upgrade is attempted without using the software, the operand asserts. A user with an Access Level of "Settings" can modify this setting.

The ACCESS SUPERVISION menu also has an ACCESS LEVEL TIMEOUTS sub-menu containing the following settings

### COMMAND LEVEL ACCESS TIMEOUT

This setting specifies the length of inactivity (no local or remote access) required to return to restricted access from the Command password level.

*Note:*

*The access level is set to `Restricted` when control power is cycled*

### SETTING LEVEL ACCESS TIMEOUT

This setting specifies the length of inactivity (no local or remote access) required to return to restricted access from the Settings password level.

*Note:*

*The access level is set to `Restricted` when control power is cycled*

### 6.3.1.1.4 DUAL PERMISSION SECURITY ACCESS

Setting path: **SETTINGS > PRODUCT SETUP > SECURITY > DUAL PERMISSION SECURITY ACCESS**

|                                                                        |   |                                |                                       |
|------------------------------------------------------------------------|---|--------------------------------|---------------------------------------|
| <div> <div>■ DUAL PERMISSION</div> <div>■ SECURITY ACCESS</div> </div> | ⇔ | LOCAL SETTING AUTH:<br>On      | Range: selected FlexLogic operands    |
|                                                                        | ⇕ | REMOTE SETTING AUTH:<br>On     | Range: FlexLogic operand              |
|                                                                        | ↑ | ACCESS AUTH<br>TIMEOUT: 30 min | Range: 5 to 480 minutes in steps of 1 |

This menu displays when the ACCESS LEVEL setting is other than *Restricted* or *Command*. This feature provides a mechanism to prevent unauthorized or unintended upload of settings to a relay through the local or remote interface. The following settings are available through the local (front panel) interface only.

The DUAL PERMISSION SECURITY ACCESS menu has the following settings:

- LOCAL SETTING AUTH
- REMOTE SETTING AUTH
- ACCESS AUTH TIMEOUT

#### LOCAL SETTING AUTH

This setting is used for local (front panel or RS232 interface) setting access supervision. Valid values for the FlexLogic operands are either “On” (default) or any physical “Contact Input ~~ On” value. If this setting is “On,” then local setting access functions as normal; that is, a local setting password is required. If this setting is any contact input on FlexLogic operand, then the operand must be asserted (on) prior to providing the local setting password to gain setting access.

If setting access is not authorized for local operation (front panel or RS232 interface) and the user attempts to obtain setting access, then the UNAUTHORIZED ACCESS message displays on the front panel.

If this setting is Off, firmware upgrades are blocked. If this setting is On, firmware upgrades are allowed.

#### REMOTE SETTING AUTH

This setting is used for remote (Ethernet or RS485 interface) setting access supervision.

If this setting is “On” (the default setting), then remote setting access functions as normal; that is, a remote password is required. If this setting is “Off,” then remote setting access is blocked even if the correct remote setting password is provided. If this setting is any other FlexLogic operand, then the operand must be asserted (set as on) prior to providing the remote setting password to gain setting access.

If this setting is "Off," firmware upgrades are blocked. If this setting is "On," firmware upgrades are allowed.

#### ACCESS AUTH TIMEOUT

This setting represents the timeout delay for local setting access. This setting is applicable when the LOCAL SETTING AUTH setting is programmed to any operand except “On.” The state of the FlexLogic operand is monitored continuously for an off-to-on transition. When this occurs, local access is permitted and the timer programmed with the ACCESS AUTH TIMEOUT setting value is started. When this timer expires, local setting access is immediately denied. If access is permitted and an off-to-on transition of the FlexLogic operand is detected, the timeout is restarted. The status of this timer updates every five seconds.

The following settings are available through the remote (EnerVista UR Setup) interface only. Select the **Settings > Product Setup > Security** menu item to display the security settings window.

The **Remote Settings Authorized** setting is used for remote (Ethernet or RS485 interface) setting access supervision. If this setting is “On” (the default setting), then remote setting access functions as normal; that is, a

remote password is required. If this setting is “Off,” then remote setting access is blocked even if the correct remote setting password is provided. If this setting is any other FlexLogic operand, then the operand must be asserted (on) prior to providing the remote setting password to gain setting access.

The **Access Authorized Timeout** setting represents the timeout delay remote setting access. It applies when the Remote Settings Authorized setting is programmed to any operand except “On” or “Off.” The state of the FlexLogic operand is continuously monitored for an off-to-on transition. When this occurs, remote setting access is permitted, and the timer programmed with the Access Authorized Timeout setting value is started. When this timer expires, remote setting access is denied immediately. If access is permitted and an off-to-on transition of the FlexLogic operand is detected, the timeout is restarted. The status of this timer updates every five seconds.

---

### 6.3.2 ENERVISTA SECURITY

The EnerVista security management system is a role-based access control (RBAC) system that allows an administrator to manage the privileges of multiple users. This allows for access control of UR devices by multiple personnel within a substation and conforms to the principles of RBAC as defined in ANSI INCITS 359-2004. The EnerVista security management system is disabled by default to allow the administrator direct access to the EnerVista software after installation. It is recommended that security be enabled before placing the device in service.

Basic password or enhanced CyberSentry security applies, depending on purchase.

---

### 6.3.3 CYBERSENTRY SECURITY

CyberSentry is a software option, specified at the time of ordering. It provides advanced security features, which are not available in the standard product. When the option is purchased, the basic password security is disabled automatically. CyberSentry provides security through the following features:

- An Authentication, Authorization, Accounting (AAA) Remote Authentication Dial-In User Service (RADIUS) client that is managed centrally, enables user attribution, provides accounting of all user activities, and uses secure standards-based strong cryptography for authentication and credential protection. In other words, this option uses a RADIUS server for user authentication.
- A Role-Based Access Control (RBAC) system that provides a permission model that allows access to UR device operations and configurations based on specific roles and individual user accounts configured on the AAA server. That is, Administrator, Supervisor, Engineer, Operator, and Observer roles are used. There is no login required for the Observer role.
- Security event reporting through the Syslog protocol for supporting Security Information Event Management (SIEM) systems for centralized cybersecurity monitoring.
- Strong encryption of all access and configuration network messages between the EnerVista software and UR devices using the Secure Shell (SSH) protocol, the Advanced Encryption Standard (AES), and 128-bit keys in Galois Counter Mode (GCM) as specified in the U.S. National Security Agency Suite B extension for SSH and approved by the National Institute of Standards and Technology (NIST) FIPS-140-2 standards for cryptographic systems.
- Authentication and encryption of machine-to-machine (M2M) traffic, as described in IEC 62351-9. This option requires the CyberSentry level 2 order code.

The EnerVista software provides the means to configure and authenticate the relay access using either a server or the device. Access to functions depends on user role. The login screen of EnerVista has two options:

- Server authentication
- Device authentication.

When the server authentication is selected, the relay uses the RADIUS server and not its local authentication database to authenticate the user.

When the device authentication is selected, the relay uses its local authentication database and not the RADIUS server to authenticate the user. In this case, it uses built-in roles as login accounts and the associated passwords are stored on the relay. In this case, access is not user-attributable. In cases where user-attributable access is required, especially for auditable processes for compliance reasons, use server authentication (RADIUS) only.



No password or security information is displayed in plain text by the EnerVista software or the UR device, nor are they ever transmitted without cryptographic protection.

**Note:**

Only (TCP/UDP) ports and services that are needed for device configuration and for customer enabled features are open. All the other ports are closed. For example, Modbus is on by default, so its TCP port 502, is open. But if Modbus is disabled, port 502 is closed. This function has been tested and no unused ports have been found open.

When CyberSentry is enabled, Modbus communications over Ethernet is encrypted for all roles but for the Observer. The built-in Observer role has read-only access to data over Modbus over Ethernet without authentication. Encrypted Modbus communication over Ethernet is not always tolerated by SCADA systems. The UR has a bypass access feature for such situations, which allows unencrypted Modbus over Ethernet. The Bypass Access setting is available on the **SETTINGS > PRODUCT SETUP > SECURITY > SUPERVISORY** screen. Note that other protocols (DNP, 101, 103, 104, EGD) are not encrypted, and they are good communications options for SCADA systems when CyberSentry is enabled.


When using the rear RS485 port and CyberSentry, registers can be read with a maximum buffer of 64 bytes. Settings may not be written, so use another port or configure the **SERIAL INACTIVITY TIMEOUT** setting to a high value, such as eight minutes, to give the relay enough time to finish the task.

### 6.3.3.1 CYBERSENTRY USER ROLES

CyberSentry user roles (Administrator, Supervisor, Engineer, Operator, Observer) limit the levels of access to various UR functions. This means that the EnerVista software allows for access to functionality based on the user's logged in role.

**Example:** Administrative functions can be segmented from common operator functions, or engineering type access, all of which are defined by separate roles so that access of UR devices by multiple personnel within a substation is allowed.

One role of one type is allowed to be logged in at a time. For example, one Operator can be logged in but not a second Operator at the same time. This prevents subsets of settings from being changed at the same time.



**Figure 173: Cybersentry user roles**

The following table lists user roles and permissions.

|                   |               | Administrator   | Engineer                                        | Operator     | Supervisor         | Observer     |
|-------------------|---------------|-----------------|-------------------------------------------------|--------------|--------------------|--------------|
| Summary           |               | Complete access | Complete access except for CyberSentry Security | Command menu | Authorizes writing | Default role |
| Device Definition |               | R               | R                                               | R            | R                  | R            |
| Settings          |               |                 |                                                 |              |                    |              |
| -----             | Product Setup |                 |                                                 |              |                    |              |



|          |                            |                                | Administrator   | Engineer | Operator | Supervisor      | Observer |
|----------|----------------------------|--------------------------------|-----------------|----------|----------|-----------------|----------|
|          | -----                      | Security (CyberSentry)         | RW              | R        | R        | R               | R        |
|          | -----                      | Supervisory                    | See table notes | R        | R        | See table notes | R        |
|          | -----                      | Display Properties             | RW              | RW       | R        | R               | R        |
|          | -----                      | Clear Relay Records (settings) | RW              | RW       | R        | R               | R        |
|          | -----                      | Communications                 | RW              | RW       | R        | R               | R        |
|          | -----                      | Modbus User Map                | RW              | RW       | R        | R               | R        |
|          | -----                      | Real Time Clock                | RW              | RW       | R        | R               | R        |
|          | -----                      | Oscillography                  | RW              | RW       | R        | R               | R        |
|          | -----                      | Data Logger                    | RW              | RW       | R        | R               | R        |
|          | -----                      | Demand                         | RW              | RW       | R        | R               | R        |
|          | -----                      | User-Programmable LEDs         | RW              | RW       | R        | R               | R        |
|          | -----                      | User-Programmable Self Tests   | RW              | RW       | R        | R               | R        |
|          | -----                      | Control Pushbuttons            | RW              | RW       | R        | R               | R        |
|          | -----                      | User-Programmable Pushbuttons  | RW              | RW       | R        | R               | R        |
|          | -----                      | Flex state Parameters          | RW              | RW       | R        | R               | R        |
|          | -----                      | User-Definable Displays        | RW              | RW       | R        | R               | R        |
|          | -----                      | Direct I/O                     | RW              | RW       | R        | R               | R        |
|          | -----                      | Teleprotection                 | RW              | RW       | R        | R               | R        |
|          | -----                      | Installation                   | RW              | RW       | R        | R               | R        |
| -----    | System Setup               |                                | RW              | RW       | R        | R               | R        |
| -----    | FlexLogic                  |                                | RW              | RW       | R        | R               | R        |
| -----    | Grouped Elements           |                                | RW              | RW       | R        | R               | R        |
| -----    | Control Elements           |                                | RW              | RW       | R        | R               | R        |
| -----    | Inputs / Outputs           |                                | RW              | RW       | R        | R               | R        |
|          | -----                      | Contact Inputs                 | RW              | RW       | R        | R               | R        |
|          | -----                      | Contact Input threshold        | RW              | RW       | R        | R               | R        |
|          | -----                      | Virtual Inputs                 | RW              | RW       | R        | R               | R        |
|          | -----                      | Contact Outputs                | RW              | RW       | R        | R               | R        |
|          | -----                      | Virtual Outputs                | RW              | RW       | R        | R               | R        |
|          | -----                      | Resetting                      | RW              | RW       | R        | R               | R        |
|          | -----                      | Direct Inputs                  | RW              | RW       | R        | R               | R        |
|          | -----                      | Direct Outputs                 | RW              | RW       | R        | R               | R        |
|          | -----                      | Teleprotection                 | RW              | RW       | R        | R               | R        |
|          | -----                      | Direct Analogs                 | RW              | RW       | R        | R               | R        |
|          | -----                      | Direct Integers                | RW              | RW       | R        | R               | R        |
| -----    | Transducer I/O             |                                | RW              | RW       | R        | R               | R        |
| -----    | Testing                    |                                | RW              | RW       | R        | R               | R        |
| -----    | Front Panel Label Designer |                                | NA              | NA       | NA       | NA              | NA       |
| -----    | Protection Summary         |                                | NA              | NA       | NA       | NA              | NA       |
| Commands |                            |                                | RW              | RW       | RW       | R               | R        |

|               |                    |  | Administrator | Engineer | Operator | Supervisor | Observer |
|---------------|--------------------|--|---------------|----------|----------|------------|----------|
| -----         | Virtual Inputs     |  | RW            | RW       | RW       | R          | R        |
| -----         | Clear Records      |  | RW            | RW       | RW       | R          | R        |
| -----         | Set Date and Time  |  | RW            | RW       | RW       | R          | R        |
| User Displays |                    |  | R             | R        | R        | R          | R        |
| Targets       |                    |  | R             | R        | R        | R          | R        |
| Actual Values |                    |  | R             | R        | R        | R          | R        |
| -----         | Front Panel        |  | R             | R        | R        | R          | R        |
| -----         | Status             |  | R             | R        | R        | R          | R        |
| -----         | Metering           |  | R             | R        | R        | R          | R        |
| -----         | Transducer I/O     |  | R             | R        | R        | R          | R        |
| -----         | Records            |  | R             | R        | R        | R          | R        |
| -----         | Product Info       |  | R             | R        | R        | R          | R        |
| Maintenance   |                    |  | RW            | RW       | R        | R          | R        |
| -----         | Modbus Analyzer    |  | NA            | NA       | NA       | NA         | NA       |
| -----         | Change front panel |  | RW            | RW       | RW       | R          | R        |
| -----         | Update firmware    |  | Yes           | No       | No       | No         | No       |

**Table Notes:**

- RW = read and write access
- R = read access
- Supervisor = RW (default), Administrator = R (default), Administrator = RW (only if Supervisor role is disabled)
- NA = the permission is not enforced by CyberSentry security

**6.3.3.2 CYBERSENTRY SETTINGS THROUGH ENERVISTA**

CyberSentry security settings are configured under **Settings > Product Setup > Security**.

Security // \_myDesk: 33: Settings: Product Se...


Save Restore Default Reset

| SETTING                               | PARAMETER  |
|---------------------------------------|------------|
| Primary RADIUS IP Address             | 0. 0. 0. 0 |
| Primary Authentication Port           | 1812       |
| Primary Accounting Port               | 1813       |
| Vendor ID                             | 2910       |
| RADIUS Authentication Method          | PAP        |
| RADIUS Authentication (Shared) Secret | Change     |
| Local Supervisor Password             | Change     |
| Local Administrator Password          | Change     |
| Local Engineer Password               | Change     |
| Local Operator Password               | Change     |
| Session Lockout                       | 3          |
| Session Lockout Period                | 3 min      |
| Syslog Function                       | Disabled   |
| Syslog Server IP Address              | 0. 0. 0. 0 |
| Syslog Server Port Number             | 514        |

33 Settings: Product Setup

**Figure 174: Security panel when CyberSentry installed**

For the **Device > Settings > Product Setup > Supervisory** option, the panel looks like the following.



**Figure 175: Supervisory panel**

For the Security panel, the following settings are available:

#### Radius server settings

| Setting name                          | Description                                                                                                                                                                          | Minimum                                                       | Maximum                                             | Default                          | Units | Minimum permission |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|-----------------------------------------------------|----------------------------------|-------|--------------------|
| Primary RADIUS IP Address             | IP address of the main RADIUS server. Default value indicates no Primary RADIUS server is configured, and hence RADIUS is disabled. Restart the relay for any change to take effect. | 0.0.0.0                                                       | 223.255.255.254                                     | 0.0.0.0                          | -     | Administrator      |
| Primary Authentication Port           | RADIUS authentication port                                                                                                                                                           | 1                                                             | 65535                                               | 1812                             | -     | Administrator      |
| Primary Accounting Port               | RADIUS accounting port                                                                                                                                                               | 1                                                             | 65535                                               | 1813                             | -     | Administrator      |
| Vendor ID                             | An identifier that specifies RADIUS vendor-specific attributes used with the protocol                                                                                                |                                                               |                                                     | Value that represents GE Vernova |       | Administrator      |
| RADIUS Authentication Method          | Authentication method used by RADIUS server                                                                                                                                          | EAP-TTLS                                                      | PAP                                                 | EAP-TTLS                         | -     | Administrator      |
| RADIUS Authentication (Shared) Secret | Shared secret used in authentication. It displays as asterisks. This setting must meet the CyberSentry password requirements.                                                        | See the Password Requirements section earlier in this chapter | See the following password section for requirements | N/A                              | -     | Administrator      |

| Setting name                                  | Description                                                         | Minimum                               | Maximum        | Default | Units | Minimum permission |
|-----------------------------------------------|---------------------------------------------------------------------|---------------------------------------|----------------|---------|-------|--------------------|
| Confirm RADIUS Authentication (Shared) Secret | Confirmation of the shared secret. The entry displays as asterisks. | See the Password Requirements section | 245 characters | N/A     | -     | Administrator      |

### General security settings

| Setting name           | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Minimum                                                       | Maximum                                             | Default     | Units | Minimum permission                                                                   |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|-----------------------------------------------------|-------------|-------|--------------------------------------------------------------------------------------|
| Session Lockout        | Number of failed authentications before the device blocks subsequent authentication attempts for the lockout period                                                                                                                                                                                                                                                                                                                                                                                                                          | 0 (lockout disabled)                                          | 99                                                  | 3           | -     | Administrator                                                                        |
| Session Lockout Period | The period in minutes that a user is prevented from logging in after being locked out                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 0 (no period)                                                 | 9999                                                | 3           | min   | Administrator                                                                        |
| Device Authentication  | When enabled, local Device authentication with roles is allowed. When disabled, the UR only authenticates to the AAA server (RADIUS). NOTE: Administrator and Supervisor (if still enabled) remain active even after Device authentication is disabled. The only permission for local Administrator is to re-enable Device authentication when Device authentication is disabled. To re-enable Device authentication, the Supervisor unlocks the device for setting changes, and then the Administrator can re-enable Device authentication. | Disabled                                                      | Enabled                                             | Enabled     | -     | Administrator                                                                        |
| Factory Service Mode   | When enabled, the device can go into factory service mode. To enable, Supervisor authentication is necessary.                                                                                                                                                                                                                                                                                                                                                                                                                                | Disabled                                                      | Enabled                                             | Disabled    | -     | Supervisor (Administrator when Supervisor is disabled)                               |
| Lock Settings          | When disabled, the device allows modification of settings. To enable, Supervisor authentication is necessary.                                                                                                                                                                                                                                                                                                                                                                                                                                | Disabled                                                      | Enabled                                             | Disabled    | -     | Supervisor (Administrator when Supervisor is disabled)                               |
| Lock Firmware          | When enabled, the device denies firmware upload. To change setting, Supervisor authentication is necessary.                                                                                                                                                                                                                                                                                                                                                                                                                                  | Disabled                                                      | Enabled                                             | Disabled    | -     | Supervisor (Administrator when Supervisor is disabled)                               |
| Restore to Defaults    | Sets the device to factory defaults                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | No                                                            | Yes                                                 | No          | -     | Administrator                                                                        |
| Supervisor Role        | When enabled, the Supervisor role is active. To enable, Administrator authentication is necessary. When disabled, the Supervisor role is inactive. To disable, Supervisor authentication is necessary.                                                                                                                                                                                                                                                                                                                                       | Disabled                                                      | Enabled                                             | Enabled     | -     | Administrator to enable and Supervisor to disable                                    |
| RADIUS user names      | Ensures that RADIUS user names are not the same as local/device role names                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | See RADIUS server documents                                   | See RADIUS server documents                         |             | -     | Administrator                                                                        |
| Password               | Local/device roles except for Observer are password-protected. All RADIUS users are password-protected.                                                                                                                                                                                                                                                                                                                                                                                                                                      | See the Password Requirements section earlier in this chapter | See the following password section for requirements | Change Me1# | Text  | The specified role and Administrator, except for Supervisor, where it is only itself |

### Security alarm settings

| Setting name           | Description / Details                                                                                                                                                                                                                                            | Min      | Max     | Default | Units | Minimum permissions                                           |
|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------|---------|-------|---------------------------------------------------------------|
| Failed Authentications | A threshold number indicating when an alarm is set off to indicate too many failed authentication attempts                                                                                                                                                       | Disabled | Enabled | Enabled | -     | Administrator                                                 |
| Firmware Lock          | A value indicating if the device can receive a firmware upgrade. If Enabled and a firmware upgrade attempt is made, the device alarm activates. If Disabled, the device alarm does not activate. On each firmware upgrade this setting goes back to the default. | Disabled | Enabled | Enabled | -     | Administrator                                                 |
| Settings Lock          | A value indicating if the device can accept any settings changes. If Enabled and a settings change attempt is made, the device alarm activates. If Disabled, the device alarm does not activate.                                                                 | Disabled | Enabled | Enabled | -     | Supervisor<br>(Administrator if Supervisor has been disabled) |

#### 6.3.3.3 CYBERSENTRY AUTHENTICATION

The following types of authentication are supported by CyberSentry to access the UR device:

- Device Authentication (local UR device authenticates)
- Server Authentication (RADIUS server authenticates)

##### User authentication

The EnerVista software allows access to functionality that is determined by the user role, which comes either from the local UR device or the RADIUS server.

The EnerVista software has a device authentication option on the login screen for accessing the UR device. When the "Device" button is selected, the UR uses its local authentication database and not the RADIUS server to authenticate the user. In this case, it uses its built-in roles (Administrator, Engineer, Supervisor, Observer, Operator, or Administrator and Supervisor when Device Authentication is disabled) as login names and the associated passwords are stored on the UR device. As such, when using the local accounts, access is not user-attributable.

In cases where user-attributable access is required especially to facilitate auditable processes for compliance reasons, use RADIUS authentication.

When the "Server" Authentication Type option is selected, the UR uses the RADIUS server and not its local authentication database to authenticate the user.

No password or security information is displayed in plain text by the EnerVista software or UR device, nor is such information ever transmitted without cryptographic protection.

##### Server authentication

The UR has been designed to direct automatically the authentication requests based on user names. In this respect, local account names on the UR are considered as reserved and not used on a RADIUS server.

The UR detects automatically whether an authentication request is to be handled remotely or locally. As there are five local accounts possible on the UR, if the user ID credential does not match one of the five local accounts, the UR forwards automatically the request to a RADIUS server when one is provided.

If a RADIUS server is provided, but is unreachable over the network, server authentication requests are denied. In this situation, use local UR accounts to gain access to the UR system.

##### SSH Server Authentication:

From 8.60 onwards the URPC supports Server authentication functionality. In SSH communication, the EnerVista UR setup software is the client and the UR relay is the SSH server.

### 6.3.3.4 CYBERSENTRY SETTINGS THROUGH THE FRONT PANEL

Setting path: **SETTINGS > PRODUCT SETUP > SECURITY**

|                                    |   |                               |                                                                                            |
|------------------------------------|---|-------------------------------|--------------------------------------------------------------------------------------------|
| <div>■ SECURITY</div> <div>■</div> | ⇔ | LOGIN:<br>None                | Range: Administrator, Supervisor, Engineer, Operator, Factory (for factory use only), None |
|                                    | ⇕ | ■ CHANGE DEVICE<br>■ PASSWORD |                                                                                            |
|                                    | ⇕ | ■ SESSION<br>■ SETTINGS       |                                                                                            |
|                                    | ⇕ | ■ RESTORE DEFAULTS<br>■       |                                                                                            |
|                                    | ⇕ | ■ SYSLOG<br>■ SETTINGS        |                                                                                            |
|                                    | ↑ | ■ SUPERVISORY<br>■            |                                                                                            |

#### LOGIN setting

This setting is applicable for Device authentication only. This setting allows a user to log in with a specific role, as outlined here. For the Supervisor role, enable the “Supervisor Role” setting. Log out by right-clicking the device in EnerVista and selecting the **Disconnect** option.

Whenever a new role is logged in, the user is prompted to enter a password. Passwords must obey the requirements specified earlier in the chapter in the Password Requirements section. The UR device supports five roles. Roles have their corresponding passwords, except the Observer role, which does not require a password. There are no time-outs for the Administrator, Engineer, Operator, and Supervisor when logged in using the front panel; log out manually or use the **Command > Security** commands in the software.

The roles are defined as follows:

- Administrator — Complete read/write access to all settings and commands. This role does not allow concurrent access. This role has an operand to indicate when it is logged on.
- Supervisor — This is only an approving role. This role’s authentication commits setting changes submitted by Administrator or Engineer. The Supervisor role authenticates to unlock the UR relay for setting changes and not approve changes after the fact. Only a Supervisor can set the Settings Lock and Firmware Lock in the Security settings. This role also has the ability to forcefully log off any other role and clear the security event log. This role can also be disabled, but only through a Supervisor authentication. When this role is disabled its permissions are assigned to the Administrator role.
- Engineer — Complete read/write access to all settings and commands except configuring Security settings and firmware upgrades. This role does not allow concurrent access.
- Operator — The Operator has read/write access to all settings under the Commands menu/section. This role does not exist offline.
- Observer — This role has read-only access for all settings. This role allows concurrent viewing access but it has no download access to any files on the device. Observer is the default role if no authentication has been done. This role displays as *None* on the front panel. When local authentication is used, no password is required for this role. When RADIUS server authentication is used, a password is required.
- Factory — For GE Vernova service personnel only

**Note:**

*The Local Access Denied message on the front panel can mean that you need to log in to the UR in order to complete the action.*

The SECURITY menu option has the following sub-menus:

- CHANGE DEVICE PASSWORD
- SESSION SETTINGS
- RESTORE DEFAULTS
- SYSLOG SETTINGS
- SUPERVISORY

These sub-menus are described in the following sections.

### 6.3.3.4.1 CHANGE DEVICE PASSWORD

Setting path: *SETTINGS > PRODUCT SETUP > SECURITY > CHANGE DEVICE PASSWORD*

|                                           |   |                   |                                   |
|-------------------------------------------|---|-------------------|-----------------------------------|
| <div>■ CHANGE DEVICE<br/>■ PASSWORD</div> | ↔ | NEW PASSWORD:     | Range: 20 alphanumeric characters |
|                                           | ↑ | CONFIRM PASSWORD: | Range: 20 alphanumeric characters |

The menu displays on the front panel upon successful login of the Administrator role. Passwords are stored in salted hash format.

In Device authentication mode, the Observer role does not have a password associated with it. In Server authentication mode the Observer role requires a password.

If you are locked out of the software, reset the device to factory defaults as outlined later for *COMMANDS < RELAY MAINTENANCE < SERVICE COMMAND*. When using CyberSentry, the default password is *ChangeMe1#*.

Once the passwords are set, the Administrator with Supervisor approval can change the role-associated password.

### 6.3.3.4.2 SESSION SETTINGS

Setting path: *SETTINGS > PRODUCT SETUP > SECURITY > SESSION SETTINGS*

|                                     |   |                         |                                   |
|-------------------------------------|---|-------------------------|-----------------------------------|
| <div>■ SESSION<br/>■ SETTINGS</div> | ↔ | SESSION LOCKOUT:        | Range: 20 alphanumeric characters |
|                                     | ↑ | SESSION LOCKOUT PERIOD: | Range: 20 alphanumeric characters |

#### SESSION LOCKOUT setting

This setting specifies the number of failed authentications before the device blocks subsequent authentication attempts for the lockout period. A value of zero means lockout is disabled.

#### SESSION LOCKOUT setting

This setting specifies the period of time in minutes of a lockout period. A value of 0 means that there is no lockout period.

### 6.3.3.4.3 RESTORE DEFAULTS

Setting path: *SETTINGS > PRODUCT SETUP > SECURITY > RESTORE DEFAULTS*



■ SESSION  
■ SETTINGS



LOAD FACTORY  
DEFAULTS: NoRange: Yes, No

### LOAD FACTORY DEFAULTS setting

This setting is used to reset all the settings, communication, and security passwords. An Administrator role is used to change this setting and a Supervisor role (if not disabled) approves it.

#### 6.3.3.4.4 SYSLOG SETTINGS

Setting path: *SETTINGS > PRODUCT SETUP > SECURITY > SYSLOG SETTINGS*

■ SYSLOG  
■ SETTINGS



SYSLOG FUNCTION:

Disable:

Range: Enable, Disable



SYSLOG IP ADDRESS:

0.0.0.0:

Range: 0.0.0.0 to 223.255.255.255



SYSLOG PORT NUMBER:

514

Range: 1 to 65535

### SYSLOG FUNCTION setting

This setting allows the Syslog functionality to be enabled or disabled in the relay.

### SYSLOG IP ADDRESS setting

The IP address of the target Syslog server to which all security events are transmitted.

### SYSLOG PORT NUMBER setting

The UDP port number of the target Syslog server to which all security events are transmitted.

| Date       | Time     | Priority     | Hostname       | Message                                                                                                                                                                                   |
|------------|----------|--------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 11-30-2022 | 15:32:51 | Auth.Info    | 192.168.100.33 | 1 2022-11-30T13:02:55.502 UR7 --- auth[9339830]: Info: Event_Log 56, Nov 30 2022 15:32:46.878719, 840, 2, 1, 5, 0.0.0.0, 0, 1, 00FF0C75F50B, 6DC653T3E... 56, Nov 30 2022 15:32:55.341216 |
| 11-30-2022 | 15:32:50 | Auth.Info    | 192.168.100.33 | 1 2022-11-30T13:02:54.492 UR7 --- auth[935bfb0]: Info: Security_Log 92, Nov 30 2022 15:32:53.993304, Administrator, 10.130.42.191, 1, 15, 5                                               |
| 11-30-2022 | 15:32:42 | Auth.Notice  | 192.168.100.33 | 1 2022-11-30T13:02:47.342 UR7 --- auth[07d708]: Notice: Security_Log 91, Nov 30 2022 15:32:46.878719, Administrator, 10.130.42.191, 1, 6, 5                                               |
| 11-30-2022 | 15:32:42 | Auth.Info    | 192.168.100.33 | 1 2022-11-30T13:02:47.092 UR7 --- auth[07d708]: Info: Nov 30 2022 15:32:46.878719, Disabled, Local and Remote, Bypass Access, 0x332C                                                      |
| 11-30-2022 | 15:32:42 | Auth.Warning | 192.168.100.33 | 1 2022-11-30T13:02:47.092 UR7 --- auth[07d708]: Warning: Security_Log 90, Nov 30 2022 15:32:46.641219, Administrator, 10.130.42.191, 1, 25, 5                                             |
| 11-30-2022 | 15:31:46 | Auth.Info    | 192.168.100.33 | 1 2022-11-30T13:01:51.132 UR7 --- auth[935bfb0]: Info: Security_Log 89, Nov 30 2022 15:31:50.641221, Administrator, 10.130.42.191, 1, 14, 5                                               |

Figure 176: Example of the Syslog data

#### 6.3.3.4.5 SUPERVISORY

Setting path: *SETTINGS > PRODUCT SETUP > SECURITY > SUPERVISORY*

■ SUPERVISORY  
■



DEVICE

AUTHENTICATION: Yes

Range: Yes, No



BYPASS ACCESS:  
Disabled

Range: Local, Remote, Local and Remote, Disabled, Pushbuttons

|   |                                          |                          |
|---|------------------------------------------|--------------------------|
| ⇅ | RESET KEY ACCESS:<br>Disabled            | Range: Enabled, Disabled |
| ⇅ | FACTORY SERVICE<br>MODE: Disabled        | Range: Enabled, Disabled |
| ⇅ | ■ SELF TESTS<br>■                        |                          |
| ⇅ | SUPERVISOR ROLE:<br>Disabled             | Range: Enabled, Disabled |
| ⇅ | SERIAL INACTIVITY<br>TIMEOUT: 1 min      | Range: 1 to 9999 minutes |
| ⇅ | FRONT PANEL INACTIVITY<br>TIMEOUT: 5 min | Range: 2 to 60 minutes   |
| ⇅ | SSH INACTIVITY<br>TIMEOUT: 5 min         | Range: 1 to 60 minutes   |
| ⇅ | BANNER FUNCTION<br>ENABLED               | Range: Enabled, Disabled |
| ⇅ | LOCK SETTINGS:<br>Disabled               | Range: Enabled, Disabled |
| ↑ | LOCK FIRMWARE:<br>Enabled                | Range: Enabled, Disabled |

The Supervisory menu settings are available for Supervisor role only, or if the Supervisor role is disabled then for the Administrator role only. The following settings are available:

- DEVICE AUTHENTICATION
- BYPASS ACCESS
- RESET KEY ACCESS
- FACTORY SERVICE MODE
- SUPERVISOR ROLE
- SERIAL INACTIVITY TIMEOUT
- FRONT PANEL INACTIVITY TIMEOUT
- SSH INACTIVITY TIMEOUT
- BANNER FUNCTION
- LOCK SETTINGS
- LOCK FIRMWARE

### DEVICE AUTHENTICATION setting

This setting is enabled by default, meaning "Yes" is selected. When enabled, Device authentication with roles is enabled. When this setting is disabled, the UR only authenticates to the AAA server (RADIUS). However, the Administrator and Supervisor (when enabled) remain active even after device authentication is disabled and their only permission is to re-enable Device authentication. To re-enable Device authentication, the Supervisor unlocks the device for settings changes, then the Administrator re-enables device authentication.

### BYPASS ACCESS setting

The bypass security feature provides an easier access, with no authentication and encryption for those special situations when this is considered safe. Only the Supervisor, or the Administrator when the Supervisor role is disabled, can enable this feature.

| Mode          |                                                                          |                                                             |
|---------------|--------------------------------------------------------------------------|-------------------------------------------------------------|
| Normal        | Authentication — Role Based Access Control (RBAC) and passwords in clear | Authentication — RBAC and passwords encrypted SSH tunneling |
| Bypass access | No passwords for allowed RBAC levels                                     | No passwords for allowed RBAC levels<br>No SSH tunneling    |

The bypass options are as follows:

- Local — Bypasses authentication for push buttons, keypad, and RS232
- Remote — Bypasses authentication for RS485 and Ethernet
- Local and Remote — Bypasses authentication for push buttons, keypad, RS232, RS485, and Ethernet
- Pushbuttons — Bypasses authentication for front panel push buttons, including in the software. On the graphical front panel, the authentication for side pushbuttons to control breakers and disconnects also is bypassed.

With BYPASS ACCESS set to other than "Disabled," the software displays a message that LOCK SETTINGS is ignored.

### RESET KEY ACCESS setting

This setting Indicates whether user authentication is required for executing the RESET button on the front panel or the front panel in the software. When Disabled, user authentication is required at the Administrator or Engineer level. When Enabled, any user can execute the RESET command without authentication. A Supervisor, or the Administrator if the Supervisor role is disabled, can enable this feature.

### FACTORY SERVICE MODE setting

This setting allows access by GE support staff to be turned on and off. When Enabled, the device can go into factory service mode. A Supervisor role is necessary to enable the setting, and otherwise an Administrator role when the Supervisor role is disabled. The default value is Disabled. An event is generated when disabling and enabling, and the TROUBLE LED activates when enabled. The factory service user enters a password that is unique for each device. When a factory service user is logged in on the front panel, a remote user cannot access the device at the same time. A factory service user is logged out with any of the following circumstances:

- UR restarts
- Factory Service Mode setting is disabled by Administrator or factory service user
- When a non-factory service user logs in via front panel or serial connection

### SUPERVISOR ROLE setting

When Enabled, the Supervisor role is active. To Disable this setting a Supervisor authentication is necessary. If disabled, the Supervisor role is not allowed to log in. In this case, the Administrator can change the settings under the Supervisory menu. If enabled, Supervisor authentication is required to change the settings in the Supervisory menu. If the Supervisor disables their role after authentication, the Supervisor session remains valid until they switch to another role using MMI or until they end the current Supervisor session if using communications. This role is disabled by default.

### SERIAL INACTIVITY TIMEOUT setting

The role logged via a serial port is auto logged off after the Serial Inactivity timer times out. A separate timer is maintained for RS232 and RS485 connections. Set this value to a high number, such as eight minutes, when using the rear RS485 terminals for settings write.

GE recommends setting this value to at least 3 minutes for the following scenario: while connected to a CyberSentry device, with serial or USB cable connected to the front panel, and performing "Add Device to Offline Window" or an online/ offline comparison. With less than the recommended 3 minutes, the serial activity timeout interrupts the connection and the security role login window appears. Upon login, the process resumes.

### FRONT PANEL INACTIVITY TIMEOUT

The user logged in via the front panel is automatically logged off after the Front Panel Inactivity timer expires. This applies to both the Enhanced Front Panel (EFP) and the Graphical Front Panel (GFP). Inactivity is defined as lack of any key presses.

### SSH INACTIVITY TIMEOUT

The user logged in over SSH is automatically logged off after the SSH Inactivity timer expires. This applies to SSH connection over Ethernet. Inactivity is defined as lack of communication sent by a client, including Enervista Setup, to the relay.

### BANNER FUNCTION

This setting allows you to enable a banner function. You can edit the text in a separate field.

### LOCK SETTINGS setting

Specifies whether the device accepts settings changes, with a default of Disabled to allow changes. The Supervisor role Disables this setting for the relay to start accepting setting changes or command changes. After all the setting changes are applied or commands executed, the Supervisor then Enables the setting to lock setting changes. When set to "Enabled," all other settings in the Supervisory window cannot be edited. Any setting changes on other Modbus screens and IEC 61850 screens cannot be saved to the relay. When the BYPASS ACCESS setting is set to a local or remote option, it overrides LOCK SETTINGS and allows changes.


### LOCK FIRMWARE setting

Specifies whether the device accepts a firmware upgrade, with a default of Enabled to deny upgrade. The Supervisor role Disables this setting to allow upgrades. After the upgrade, the Supervisor then Enables the setting to prevent upgrades. When the BYPASS ACCESS setting is set to a local or remote option, it overrides LOCK FIRMWARE and allows changes.

The SUPERVISORY menu has the sub-menu SELF TESTS.

### SELF TESTS sub-menu

Setting path: *SETTINGS > PRODUCT SETUP > SECURITY > SUPERVISORY > SELF TESTS*



### FAILED AUTHENTICATE > FAILED AUTHENTICATE setting

If this setting is Enabled then the number of failed authentications is compared with the Session Lockout threshold. When the Session Lockout threshold is exceeded, this minor alarm indication comes up.

### FIRMWARE LOCK setting

If this setting is Enabled, then any firmware upgrade operation attempt when the LOCK FIRMWARE setting is enabled brings up this self test alarm.

### SETTINGS LOCK setting

If this setting is Enabled then an unauthorized write attempt to a setting for a given role activates this self test.

#### 6.3.3.4.6 CYBERSENTRY SETUP

When first using CyberSentry security, use the following procedure for setup.

1. Log into the relay as Administrator by using the VALUE keys on the front panel to enter the default password "ChangeMe1#". Note that the LOCK SETTINGS setting needs to be disabled (default) in the SETTINGS > PRODUCT SETUP > SECURITY > SUPERVISORY menu.
2. Enable the Supervisor role if you have a need for it.
3. Make any required changes in configuration, such as setting a valid IP address for communication over Ethernet.
4. Log out of the Administrator account by choosing None.
5. Next, Device or Server authentication can be chosen on the login screen, but the choice is available only in EnerVista. Use Device authentication to log in using the five pre-configured roles (Administrator, Supervisor, Engineer, Operator, Observer). When using a serial connection, only Device authentication is supported. When Server authentication is required, characteristics for communication with a RADIUS server must be configured. This is possible only in the EnerVista software. The RADIUS server itself also must be configured. The appendix called RADIUS Server at the end of this instruction manual gives an example of how to set up a simple RADIUS server. Once both the RADIUS server and the parameters for connecting the UR to the server have been configured, you can choose Server authentication on the login screen of EnerVista.

#### Notes

The use of CyberSentry for devices communicating through an Ethernet-to-RS485 gateway is not supported. Because these gateways do not support the secure protocols necessary to communicate with such devices, the connection cannot be established. Use the device as a non-CyberSentry device.

Users logged in through the front panel are not timed out and cannot be forcefully logged out by a supervisor. Roles logged in through the front panel that do not allow multiple instances (Administrator, Supervisor, Engineer, Operator) must switch to None (equivalent to a logout) when they are done in order to log out.

For all user roles except Observer, only one instance can be logged in at a time, for both login by front panel and software.

To configure Server authentication:

1. In the EnerVista software, choose Device authentication and log in as Administrator.
2. Configure the following RADIUS server parameters: IP address, authentication port, shared secret, and vendor ID.
3. On the RADIUS server, configure the user accounts. Do not use the five pre-defined roles as user names (Administrator, Supervisor, Engineer, Operator, Observer) in the RADIUS server. If you do, the UR relay automatically provides the authentication from the device.
4. In the EnerVista software, choose Server authentication and log in using the user name and password configured on the RADIUS server for Server authentication login.
5. After making any required changes, log out.

**Note:**

*When changing settings offline, ensure that only settings permitted by the role that performs the settings download are changed because only those changes are applied.*

Pushbuttons (both user-control buttons and user-programmable buttons) located on the front panel can be pressed by an Administrator or Engineer role. This also applies to the RESET button, which resets targets, where targets are errors displayed on the front panel or the Targets panel of the EnerVista software. The RESET button has special behavior in that it allows these two roles to press it even when they are logged in through the RS232 port and not through the front panel.

To reset the security event log and self-test operands:

1. Log in as Supervisor (if the role is enabled) or Administrator (if the Supervisor role is disabled)
2. Execute a clear security command under **Commands > Security > Clear Security**.

#### 6.3.3.4.7 SECURITY EVENTS

The security events produced when the CyberSentry option is purchased are sent as system log (syslog) messages to a syslog server, if one is configured. The format is as follows.

|  | Security log | Event number | Date & Timestamp | Username | IP address | Role | Category | Log type | Activity value | Event result |
|--|--------------|--------------|------------------|----------|------------|------|----------|----------|----------------|--------------|
|--|--------------|--------------|------------------|----------|------------|------|----------|----------|----------------|--------------|

Event Number — Event identification number (index)

Date & Timestamp — UTC date and time

Username — 255 chars maximum, but in the security log it is truncated to 20 characters

IP address — Device IP address

Role — 16 bit unsigned, of type format F617

| Enumeration | Role          |
|-------------|---------------|
| 0           | None          |
| 1           | Administrator |
| 2           | Supervisor    |
| 3           | Engineer      |
| 4           | Operator      |
| 5           | Factory       |

Category — Based on IEC62443-4-2 CR2.8

| Category                    |
|-----------------------------|
| a) Access Control           |
| b) Request Error            |
| c) Control System event     |
| d) Backup and Restore event |
| e) Configuration Changes    |
| f) Audit Log event          |

LogType — Fixed string: "IEC62351-14"

Activity Value — 16 bit unsigned

| Activity Value/<br>Event ID | Event Result          | Category                 |
|-----------------------------|-----------------------|--------------------------|
| 1                           | Authentication Failed | a) Access Control        |
| 2                           | User Lockout          | a) Access Control        |
| 3                           | FW Upgrade            | e) Configuration Changes |
| 4                           | FW Lock               | a) Access Control        |
| 5                           | Settings Lock         | a) Access Control        |

| Activity Value/<br>Event ID | Event Result                                                                                                                                               | Category                 |
|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|
| 6                           | Settings Change. Because this can fill the entire event log, it is supported by the already existing Settings_Change.log file. This event is not required. | e) Configuration Changes |
| 7                           | Clear Oscillography command                                                                                                                                | c) Control System event  |
| 8                           | Clear Data Logger command (not applicable to all UR products)                                                                                              | c) Control System event  |
| 9                           | Clear Demand Records command (not applicable to all UR products)                                                                                           | c) Control System event  |
| 10                          | Clear Energy command (not applicable to all UR products)                                                                                                   | c) Control System event  |
| 11                          | Clear Unauthorized Access command                                                                                                                          | a) Access Control        |
| 12                          | Clear Teleprotection Counters command (not applicable to all UR products)                                                                                  | c) Control System event  |
| 13                          | Clear All Relay Records command                                                                                                                            | c) Control System event  |
| 14                          | Role Log in                                                                                                                                                | a) Access Control        |
| 15                          | Role Log out                                                                                                                                               | a) Access Control        |
| 16                          | WRITE_SETTING_FILE                                                                                                                                         | e) Configuration Changes |
| 17                          | Factory Mode enabled                                                                                                                                       | f) Audit Log event       |
| 18                          | Factory Mode disabled                                                                                                                                      | f) Audit Log event       |
| 19                          | FW file validation successful                                                                                                                              | f) Audit Log event       |
| 20                          | FW file validation failed                                                                                                                                  | b) Request Error         |
| 21                          | Supervisor password changed                                                                                                                                | e) Configuration Changes |
| 22                          | Administrator password changed                                                                                                                             | e) Configuration Changes |
| 23                          | Engineer password changed                                                                                                                                  | e) Configuration Changes |
| 24                          | Operator password changed                                                                                                                                  | e) Configuration Changes |
| 25                          | Bypass mode activated                                                                                                                                      | a) Access Control        |
| 26                          | Bypass mode deactivated                                                                                                                                    | a) Access Control        |
| 30                          | CERT_V_FORMAT                                                                                                                                              | f) Audit Log events      |
| 31                          | CERT_PK_SIG_ALG                                                                                                                                            | f) Audit Log events      |
| 32                          | CERT_V_PK_EXPIRED                                                                                                                                          | f) Audit Log events      |
| 33                          | CERT_V_PK_EARLY                                                                                                                                            | f) Audit Log events      |

If System Integrity Recovery events are logged during a restart of the unit due to an incorrect shutdown sequence, upgrade the firmware to version 7.31 or later to correct this issue.

In addition to supporting syslog, a relay with CyberSentry also saves the security events in two local security files, these being `SECURITY_EVENTS.CSV` and `SETTING_CHANGES.LOG`. Details on these files and how to retrieve them are available in the EnerVista software under **Maintenance > Retrieve File**. Depending on the level of criticality/severity, a syslog server or a reporting tool gathering information from a syslog server can produce reports, charts, and so on. All severity levels are per RFC 5424.

### CyberSentry system events recorded

| Event                           | Severity    | Description                                                                                                              |
|---------------------------------|-------------|--------------------------------------------------------------------------------------------------------------------------|
| FAILED_AUTH, ORIGIN, TIMESTAMP  | Notice (5)  | A failed authentication with origin information (username and IP:MAC address), a time stamp in UTC time when it occurred |
| AUTH_LOCKOUT, ORIGIN, TIMESTAMP | Warning (4) | An authentication lockout has occurred because of too many failed authentication attempts                                |

| Event                            | Severity        | Description                                                                |
|----------------------------------|-----------------|----------------------------------------------------------------------------|
| FIRMWARE_UPGD, ORIGIN, TIMESTAMP | Information (6) | Indicates that a change of firmware has occurred                           |
| FIRMWARE_LOCK, ORIGIN, TIMESTAMP | Warning (4)     | An attempt was made to change firmware while the firmware lock was enabled |
| SETTING_CHG, ORIGIN, TIMESTAMP   | Notice (5)      | Indicates setting change(s)                                                |
| SETTING_LOCK, ORIGIN, TIMESTAMP  | Warning (4)     | An attempt was made to change settings while the settings lock was enabled |
| LOGIN, ORIGIN, TIMESTAMP         | Information (6) | Indicates when a certain role logged in                                    |
| LOGOUT, ORIGIN, TIMESTAMP        | Information (6) | Indicates when a certain role logged out or timed out                      |
| CLEAR_OSCILLOGRAPHY              | Notice (5)      | Clear oscillography command was issued                                     |
| CLEAR_DATA_LOGGER                | Notice (5)      | Clear data logger command was issued                                       |
| CLEAR_DEMAND_RECS                | Notice (5)      | Clear demand records command was issued                                    |
| CLEAR_ENERGY                     | Notice (5)      | Clear energy command was issued                                            |
| RESET_UNAUTH_ACCESS              | Notice (5)      | Reset Unauthorized access command was issued                               |
| CLEAR_TELEPROTECTION_CNT         | Notice (5)      | Clear teleprotection counters command was issued                           |
| CLEAR_ALL_RECS                   | Notice (5)      | Clear all records command was issued                                       |
| WRITE_SETTING_FILE               | Notice (5)      | Write settings file to the relay                                           |
| BYPASS_ACTIVATE                  | Warning (4)     | Bypass was activated (serial, keypad or both)                              |
| BYPASS_DEACTIVATE                | Warning (4)     | Bypass was deactivated                                                     |
| FACTORY_MODE_ENABLED             | Warning (4)     | Factory Service Mode activated                                             |
| FACTORY_MODE_DISABLED            | Warning (4)     | Factory Service Mode deactivated                                           |
| FW_FILE_VALIDATION_SUCCESSFUL    | Information (6) | Firmware file signature validation successful                              |
| FW_FILE_VALIDATION_FAILED        | Warning (4)     | Firmware file signature validation failed                                  |
| SUPERVISOR_PSWD_CHANGED          | Notice (5)      | Supervisor user account's password changed                                 |
| ADMIN_PSWD_CHANGED               | Notice (5)      | Administrator user account's password changed                              |
| ENGINEER_PSWD_CHANGED            | Notice (5)      | Engineer user account's password changed                                   |
| OPERATOR_PSWD_CHANGED            | Notice (5)      | Operator user account's password changed                                   |



## 6.4 IEC62351-9 ENCRYPTION FOR R-GOOSE MESSAGES

From version 8.70, all UR relays are equipped with Authentication and encryption of machine-to-machine (M2M) traffic, as described in IEC 62351-9. To get this feature you will need to order CyberSentry Level 2, which contains all of the functionality in CyberSentry Level 1 plus IEC 61850 R-GOOSE security.

### 6.4.1 SECURITY REFERENCES AND ACRONYMS

| Abbreviation | Meaning                                                                                                                                |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------|
| CA           | Certificate Authority                                                                                                                  |
| GCKS         | Group Controller/Key Server                                                                                                            |
| GDOI         | Group Domain of Interpretation, RFC 6407<br>Group Domain of Interpretation Protocol Support for IEC 62351 Security Services, RFC 8052. |
| IKE          | Internet Key Exchange, RFC 2409                                                                                                        |
| ISAKMP       | Internet Security Association and Key Management Protocol, RFC 2408                                                                    |
| KDA          | Key Delivery Assurance                                                                                                                 |
| KDC          | Key Distribution Center                                                                                                                |
| KEK          | Key Encryption Key. The key used to secure Push messages                                                                               |
| OCSP         | Online Certificate Status Protocol, RFC 6960                                                                                           |
| PKI          | Public Key Infrastructure                                                                                                              |
| RA           | Registration Authority                                                                                                                 |
| RSA          | Rivest-Shamir-Adleman. A public-key cryptosystem                                                                                       |
| SA           | Security Association                                                                                                                   |
| SCEP         | Simple Certificate Enrollment Protocol, RFC 8894                                                                                       |
| TEK          | Traffic Encryption Key. The key used to secure R-GOOSE messages                                                                        |

| Term                      | Meaning                                                                                |
|---------------------------|----------------------------------------------------------------------------------------|
| Diffie-Hellman            | A mathematical method of securely generating a symmetric key over a public channel     |
| IEC 61850, Edition 2.1    | Communication networks and systems for power utility automation                        |
| IEC 62351-6               | Security for IEC 61850                                                                 |
| IEC 62351-9, Edition 2    | Cyber security key management for power system equipment                               |
| IEC 62351-14              | Cyber security event logging                                                           |
| PCIttek Garibaldi         | A KDC supporting IEC 62351 security for IEC 61850 data streams                         |
| Syslog Protocol, RFC 5424 | Windows Server NDES – Windows Server Network Device Enrollment Service (SCEP and OCSP) |
| X.509                     | Standard for digital certificates                                                      |

### 6.4.2 SECURITY KEY MANAGEMENT

The rules governing the process of managing and distributing keys for machine-to-machine secure data communication utilize the following:

- Group Domain of Interpretation (GDOI) RFC 6407
- Internet Security Association and Key Management Protocol (ISAKMP) RFC 2408
- Internet Key Exchange (IKE) RFC 2409.

These reference documents are used to implement IEC 61850 security extensions as described in IEC 62351-9 and IEC 62351-6.

Key management is provided by a Group Controller Key Server (GCKS), more commonly referred to as a Key Distribution Center (KDC) server. This is responsible for producing the symmetric security keys and coordinating with all publishers and subscribers for key distribution and Key Delivery Assurance (KDA). The publishing and subscribing devices, such as URs, are known as Group Members, and can be configured to publish and subscribe to multiple R-GOOSE data streams. Each R-GOOSE group consists of one publisher member and one or more subscriber members. Depending on the configuration, each device could be a member of multiple groups.

A KDC server is usually deployed as software on a standalone computer. It manages the distribution of security keys for all publishers and subscribers. Each device communicates with the KDC to obtain keys, which are used to secure IEC 61850 R-GOOSE data streams via encryption and digital signatures. To increase system reliability, KDCs may be deployed in a redundant configuration. The UR supports communication with either a single or two redundant KDCs.

The KDC server must meet the following requirements:

- It must be capable of identifying the KDC clients on a per data stream basis within the IEC 61850 domain. The stream type supported by the UR is:
  - UDP R-GOOSE as defined in IEC 61850-8-1.
- It must be capable of identifying data streams using:
  - Destination IP addresses.
  - IEC 61850 DataSet references.
- It must support clients requesting keys via *GROUPKEY-PULL* exchanges, as described in IEC 62351-9.
- It must allow a Public Key Infrastructure (PKI) to be used for identity establishment and authentication of clients (such as URs) requesting keys.
- Additionally, it may be able to publish keys to a configured group via *GROUPKEY-PUSH* messages.

The KDC provides unique, common, time limited security keys as part of a Security Association (SA) for each communication group. The publisher and subscribers in that group will use the key from the currently active SA. Each configured group will use a different unique security key. The keys are distributed only to the members of a specific group. They are not shared between groups. If a device is configured to support multiple groups, it will request keys from the KDC for each group of which it is a member. The process of distributing keys is repeated continually to ensure that there is always an active, unexpired SA and associated key available for each group.

Both the KDC and R-GOOSE publishers and subscribers are required to use X.509 digital certificates to provide authentication. This establishes and verifies a chain of trust between the KDC and group members. Certificate enrolment is accomplished using Simple Certificate Enrolment Protocol (SCEP), RFC 8894. Certificate revocation checks are accomplished using Online Certificate Status Protocol (OCSP), RFC 6960. This is also described in IEC 62351-9.

*Note:*

*All security content for machine-to-machine communication has been migrated from IEC 61850-90-5 (now obsolete) into the IEC 61850 Edition 2.1 and IEC 62351 series of standards.*

---

## 6.4.3 KEY DISTRIBUTION PROCESS

The *GDOI GROUPKEY-PULL* (Pull) exchange is used to establish an authenticated association between the KDC and a Group Member and to distribute keys via SAs. Pull exchanges are initiated by client devices.

Subsequent keys may be distributed using either Pull or *GDOI GROUPKEY-PUSH* (Push) messages. Push messages are initiated by the KDC server. The policy of using either Pull or Push messages is determined by the KDC. If a Group Member does not receive a Push message with a new SA in a timely manner, it will initiate a Pull exchange.

### 6.4.3.1 GDOI GROUPKEY-PULL SECURITY PHASES

GDOI defines two phases of communication for the Pull exchange. The complete Pull exchange is a Phase 2 ISAKMP protocol, which is protected by a Phase 1 IKE protocol. Phase 1 provides peer authentication,

confidentiality and message integrity. This allows for the secure (encrypted and signed) transfer of Security Association data, including a security key, during Phase 2.

The KDC and all group members must use X.509 digital certificate credentials for authentication, as required by IEC 62351-9. Key distribution is not possible without certificates. The UR and KDC both contain default sample certificates that can be used for testing. These should be replaced with certificates issued by a SCEP server before deployment.

### Phase 1: Authentication and secure channel establishment

Phase 1 is concerned with the establishment of a secure, authenticated channel for communication between the KDC server and group member client (UR). The Diffie-Hellman key exchange method is used to establish the secure channel.

Mutual authentication between the KDC and the group member occurs using certificate data. When the UR receives the KDC certificate data, it will also, if configured, periodically initiate an OCSP transaction to verify that the KDC certificate has not been revoked.

Phase 1 starts with the exchange of clear text data and finishes with the exchange of encrypted data using the newly established secure channel.

### Phase 2: Determining the policies in use for the group and retrieving the keys

The KDC is configured to know about every group and group member. R-GOOSE groups are uniquely identified by the combination of the destination IP address and the GOOSE dataset reference. In addition, the KDC is configured to know the group member source IP addresses.

During Phase 2 the group member identifies the group for which it is requesting keys. If the configurations are correct, the KDC server responds with the SA data for one or more SAs. This includes the security key, key lifetime, encryption and signature algorithm identifiers, and SA identifiers. If the client supports the algorithms, the exchange completes successfully.

All data exchanged during Phase 2 is encrypted.

#### 6.4.3.2 REKEYING

After an initial authentication and key delivery through a Pull exchange, subsequent keys can be delivered using Push messages (initiated by the KDC) or by new Pull exchanges (initiated by group members). Group members will initiate Pull exchanges to ensure that there is a valid security association and key available before the previous SA has expired.

The SA lifetime is controlled by the KDC policy configuration.

#### 6.4.3.3 SECURITY ASSOCIATIONS

The KDC delivers more than just a security key to group members. The SA data includes the following:

- TEK (Traffic Encryption Key): Used for R-GOOSE encryption and signatures.
- KEK (Key Encryption Key): Used for Push message security.
- SPI (Security Parameter Index): An identifier for the key.
- Authentication Algorithm Identifier: A code that specifies the Authentication Algorithm to be used for the R-GOOSE stream.
- Encryption Algorithm Identifier: A code that specifies the Encryption Algorithm to be used for the R-GOOSE stream.
- Remaining Lifetime: The life of the SA in seconds.
- SA Activation Time Delay (ATD): The time in seconds before the SA will become active.
- KDA (Key Delivery Assurance): A policy that allows the group publisher to use a new key only after a configured percentage of subscribers has indicated successful delivery of the new key.

Except for KDA, the above values are all determined completely by policy settings in the KDC. The use of KDA must be configured in both the KDC and group members. KDA configurations must match.

Generally, the KDC will send two SAs to each group member. One will be the currently active SA, and the other will have an Activation Time Delay. The time delay will be selected by the KDC such that when the currently active SA is nearing its end of life, the delayed SA will become active. This allows the group members to have uninterrupted transitions between keys. The UR refers to the states of SAs as Activated, Pending, or Expired.

#### 6.4.3.4 UR SUPPORTED ENCRYPTION AND SIGNATURE (HASH) ALGORITHMS

##### Encryption

- AES-CBC-128
- AES-CBC-256
- AES-GCM-128
- AES-GCM-256

##### Signature

- HMAC-SHA256-128
- HMAC-SHA256-256
- AES-GMAC-128
- AES-GMAC-256

#### 6.4.3.5 HIGH LEVEL SEQUENCE OF EVENTS FOR GDOI PULL EXCHANGE




Figure 177: High level sequence for GDOI Pull Exchange

#### 6.4.4 CERTIFICATE MANAGEMENT

##### 6.4.4.1 SIMPLE CERTIFICATE ENROLLMENT PROTOCOL

Simple Certificate Enrollment Protocol (SCEP) is a protocol used for the purpose of issuing and managing X.509 certificates.

The protocol supports the following operations:

- Certificate Authority (CA) public key distribution
- Certificate enrollment and issue
- Certificate renewal
- Certificate query
- CRL query

SCEP defines two types of entities:

- SCEP Server – may be a CA, sub-CA, or RA.
  - A CA is the entity that signs client certificates. It may also act as the SCEP server. In a more complex infrastructure, there may be multiple levels of CAs.
  - A Registration Authority (RA) is a SCEP server that performs validation and authorization of the SCEP request coming from the client, before forwarding it to the CA. The RA, if present, serves as an intermediary between the client and the CA.
- SCEP client – This is the device in need of an X.509 certificate. The client submits the request for a certificate and installs it upon reception from the SCEP server. Clients include both GDOI group members (URs) and the KDC.

SCEP greatly simplifies the process of loading and managing X.509 digital certificates on a device.

The SCEP process allows a user to configure a few parameters on the client device and then instruct the device to interact with the SCEP server in order to retrieve its certificate.

SCEP recommends the use of a challenge password to provide authentication for the certificate request, and a fingerprint to validate the certificate. The values of the password and fingerprint should be obtained manually from the SCEP server. The client will use these values to request and verify the certificates.

The UR implements SCEP client functionality. This includes enrollment and renewal (manual or automatic) requests. The enrollment process includes obtaining a certificate chain to the CA, performing an OCSP certificate revocation check, and obtaining a client certificate to be used for GDOI authentication. The certificate lifetime is determined by the SCEP server and is encoded as part of the certificate.

Note that RFC 8894, which describes SCEP, has an RFC Category of “Informational”. The other RFCs mentioned here all have a Category of “Standards Track”. SCEP was not created as a standard, and therefore there are a number of variations between servers in the implementation details of the protocol. The UR supports SCEP servers that implement SCEP as per the recommendations in RFC 8864. The UR also supports Windows Server NDES SCEP.

### 6.4.4.2 ONLINE CERTIFICATE STATUS PROTOCOL


Online Certificate Status Protocol (OCSP) RFC 6960 is a protocol utilized for obtaining the revocation status of an X.509 certificate. OCSP client requests can be sent periodically to ensure that a certificate has not been revoked. OCSP servers, often called OCSP responders, provide the revocation status information.

OCSP was created as an alternative to the use of Certificate Revocation Lists (CRL), which are lists of permanently and temporarily revoked certificates published by certificate authorities. OCSP overcomes the main limitation of CRL, which was that clients were required to manage these lists. Using OCSP, a client can send a request for the status of only the certificate it is interested in and only when it intends to use that certificate, which makes it more efficient.

If configured, the UR will use OCSP to check the revocation status of the KDC certificate periodically during Pull exchanges. In the case of OCSP servers with long response times, the UR will issue OCSP requests independent of Pull exchanges. In addition, the UR will use OCSP to check the revocation status of the issuer of its own client certificate during the enrolment process.

As per IEC 62351-9 Edition 2, if a KDC certificate revocation check request fails due to an unresponsive OCSP server, the UR will send the appropriate Syslog security event message and continue to initiate Pull exchanges. This prevents denial-of-service attacks caused by making OCSP responders (servers) unavailable. If the OCSP check indicates that the certificate is either revoked or unrecognized, Pull exchanges will not be continued, unless the UR “Allow Failed Validation” feature is enabled.

#### 6.4.4.3 CERTIFICATE SECURITY



### Figure 178: High Level Sequence of Events for GDOI Pull Exchange

The UR supports RSA security for certificates. The RSA key pair is generated using the UR built-in key generator. RSA is a cryptosystem in which the encryption key is public, and it differs from the decryption key, which is kept private (secret). The key generator uses a random number generator to produce two prime numbers and, through several computations, determines the public and private keys associated with them. The key size will be as per the UR configuration. The private key is kept on the UR, while the public key will be used by SCEP.

The SCEP server will provide a chain of certificates, such as RA certificate, sub-CA certificate, and root CA certificate. All certificates are signed by the next highest certificate in the chain. For example, the RA certificate is signed by the sub-CA certificate, the sub-CA certificate is signed by the root CA certificate. The Root CA certificate is self-signed but is verified using the fingerprint value. This is known as a chain of trust. In a simple PKI, the chain may be just the CA and the client.

### 6.4.5 CONFIGURATION

M2M Security settings can only be configured using the Enervista UR Setup application. Administrator permissions are needed for all settings.

The description of each setting follows after the table below.

| Setting Name              | Min                                                                                                                                                                                                            | Max             | Default     |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|-------------|
| <b>SCEP Configuration</b> |                                                                                                                                                                                                                |                 |             |
| SCEP Server IP            | 0.0.0.0                                                                                                                                                                                                        | 223.255.255.254 | 0.0.0.0     |
| SCEP Server Port          | 1                                                                                                                                                                                                              | 65535           | 80          |
| SCEP Server Path          | Edit field displaying ASCII characters. Maximum 128 characters.                                                                                                                                                |                 |             |
| SCEP Password             | Edit field will display only "*****".<br>This is a "PrintableString" subset of ASCII characters (alphanumeric plus special characters with the exception of "@" and "&"). Minimum 8 and maximum 64 characters. |                 |             |
| SCEP Signature Algorithm  | MD5, SHA-1, SHA-256, SHA-384, SHA-512                                                                                                                                                                          |                 | SHA-256     |
| SCEP Encryption Algorithm | DES-EDE-CBC, AES-CBC-128, AES-CBC-192, AES-CBC-256                                                                                                                                                             |                 | DES-EDE-CBC |

| Setting Name                                 | Min                                                                    | Max             | Default         |
|----------------------------------------------|------------------------------------------------------------------------|-----------------|-----------------|
| SCEP Poll Retries                            | 0                                                                      | 120             | 10              |
| SCEP Poll Interval                           | 1                                                                      | 10              | 5 seconds       |
| SCEP Automatic Renewal                       | Disabled                                                               | Enabled         | Disabled        |
| SCEP Compatibility                           | RFC 8894                                                               | Windows Server  | RFC 8894        |
| CA Certificate                               |                                                                        |                 |                 |
| Fingerprint Algorithm                        | MD5, SHA-1, SHA-256, SHA-384, SHA-512                                  |                 | MD5             |
| CA Certificate Fingerprint                   | Edit field displaying alphanumeric characters. Maximum 64 characters.  |                 |                 |
| Certificate Distinguished Name Configuration |                                                                        |                 |                 |
| Certificate Common Name                      | Edit field displaying ASCII characters. Maximum 64 characters.         |                 |                 |
| Certificate Email                            | Edit field displaying ASCII characters. Maximum 64 characters.         |                 |                 |
| Certificate Organization                     | Edit field displaying ASCII characters. Maximum 64 characters.         |                 |                 |
| Certificate OrgUnit                          | Edit field displaying ASCII characters. Maximum 64 characters.         |                 |                 |
| Certificate Locality                         | Edit field displaying ASCII characters. Maximum 64 characters.         |                 |                 |
| Certificate State                            | Edit field displaying ASCII characters Maximum 64 characters.          |                 |                 |
| Certificate Country                          | Edit field displaying a 2-character country code.                      |                 |                 |
| Certificate Certificate RSA Key Length       | 2048, 3072                                                             |                 | 2048 bits       |
| Basic OCSP Configuration                     |                                                                        |                 |                 |
| OCSP Server IP                               | 0.0.0.0                                                                | 223.255.255.254 | 0.0.0.0         |
| OCSP Use Port From Certificate               | No                                                                     | Yes             | No              |
| OCSP Server Port                             | 1                                                                      | 65535           | 80              |
| Allow Failed Validation                      | No                                                                     | Yes             | No              |
| Advanced OCSP Configuration                  |                                                                        |                 |                 |
| OCSP Poll Retries                            | 0                                                                      | 120             | 10              |
| OCSP Poll Interval                           | 1                                                                      | 10              | 5 seconds       |
| OCSP Use Path From Certificate               | No                                                                     | Yes             | No              |
| OCSP Path                                    | Edit field displaying alphanumeric characters. Maximum 128 characters. |                 |                 |
| OCSP CertId Algorithm                        | MD5, SHA-1, SHA-256, SHA-384, SHA-512                                  |                 | SHA-1           |
| Basic GDOI Configuration                     |                                                                        |                 |                 |
| KDC Server IP 1                              | 0.0.0.0                                                                | 223.255.255.254 | 0.0.0.0         |
| KDC Server IP 2                              | 0.0.0.0                                                                | 223.255.255.254 | 0.0.0.0         |
| Key Usage Policy                             | No Expired Keys, Allow Expired Keys, Use KDA Method                    |                 | No Expired Keys |
| Advanced GDOI Configuration                  |                                                                        |                 |                 |
| KDC Retry Interval                           | 10 sec                                                                 | 300 sec         | 30 sec          |
| KDC Diffie-Hellman Group Size                | Range: MODP-2048, MODP-3072, MODP-4096, MODP-6144, MODP-8192           |                 | MODP-4096       |
| Use Test Key                                 | Yes, No                                                                |                 | No              |

## SCEP Configuration

### SCEP Server IP

IP address of the SCEP Server. 0.0.0.0 or 127.0.0.1 indicates that no SCEP Server is configured, in which case SCEP is disabled.

### SCEP Server Port

The TCP port number used by the SCEP server.



### ***SCEP Server Path***

The path to the program that parses the SCEP requests on the SCEP server.

### ***SCEP Password***

A Challenge Password obtained manually from the SCEP server. The UR sends it in the certificate request and the SCEP server uses it to authenticate the request.

Less frequently used settings for the SCEP server are available when the “Advanced” button is pressed. These are described below.

### ***SCEP Signature Algorithm***

The signature algorithm used in SCEP transactions.

### ***SCEP Encryption Algorithm***

The encryption algorithm used in SCEP transactions.

### ***SCEP Poll Retries***

The maximum number of retries used by the UR when the SCEP server is not available, times out, or indicates that the request is pending.

### ***SCEP Poll Interval***

The time between retries.

### ***SCEP Automatic Renewal***

Enable/Disable automatic renewal of UR client certificate.

### ***SCEP Compatibility***

This allows the UR to obtain certificates from either RFC 8894 compliant SCEP servers, or from Windows Server NDES. Windows Server NDES uses a slightly different certificate renewal methodology than what is recommended in RFC 8894. If this setting is set to “RFC 8894” and the UR requests a certificate renewal from Windows Server NDES, a “badRequest” error response will be returned.

### ***Fingerprint Algorithm***

The hash algorithm used to calculate the fingerprint.

### ***CA Certificate Fingerprint***

The fingerprint (hash digest) of the CA certificate obtained manually from the SCEP server. It is used to validate the CA root certificate received by the UR during the certificate request.

## **Certificate Distinguished Name Configuration**

A certificate Distinguished Name (DN) is a set of attributes that uniquely identify the client certificate. These attributes are the common name, email address, organization, organization unit, locality, state and country. The following settings are used to configure these attribute fields.

### ***Certificate Common Name***

A unique identifier in this field can be used to ensure that the certificate DN is unique. This setting has a unique value by default, but it can be changed as required. The default value is a Globally Unique Identifier (GUID) with the format shown below. This is the string representation of the 16-byte Unique Identifier encoded as a 32-byte hex string.



| PEN [3] | RES [2] | PRN [4] | SN [7] |
|---------|---------|---------|--------|
|---------|---------|---------|--------|

- PEN = Private Enterprise Number – a 3-byte number created and maintained by IANA in a public registry.
- RES = A 2-byte reserved field, set to 0x0000.
- PRN = A 4-byte Product Number.
- SN = A 7-byte Serial Number.

If this value has been changed, it can be restored to the default by resetting the UR to its factory default values.

***Certificate Email***

Email address associated with the UR to be enrolled.

***Certificate Organization***

Organization where the UR to be enrolled belongs.

***Certificate OrgUnit***

Organization Unit where the UR to be enrolled belongs.

***Certificate Locality***

Locality where the UR to be enrolled resides.

***Certificate State***

State where the UR to be enrolled resides.

***Certificate Country***

Country where the UR to be enrolled resides. ISO 3166 2-character country code.

***Certificate RSA Key Length***

Number of bits used for certificate RSA keys.

**OCSP Configuration*****OCSP Server IP***

IP address of the OCSP Server. 0.0.0.0 or 127.0.0.1 indicates that no OCSP Server is configured, in which case OCSP is disabled.

***OCSP Use Port From Certificate***

Use OCSP port number from the certificate Authority Information Access field. If set to No, the OCSP Server Port Number setting value will be used.

***OCSP Server Port***

The TCP port number used by the OCSP server.

***Allow Failed Validation***

When set to “Yes” the UR will continue to accept keys provided by the KDC server even if the OCSP server indicates that the KDC certificate has been revoked or is unknown.

**OCSP Advanced Configuration*****OCSP Poll Retries***

The maximum number of retries used by the UR when the OCSP server is not available or times out.

### **OCSP Poll Interval**

The time between retries.

### **OCSP Use Path From Certificate**

Use OCSP Path from the certificate Authority Information Access field. If set to No, the OCSP Path setting value will be used.

### **OCSP Path**

The path to the program that parses the OCSP requests on the OCSP server.

### **OCSP CertId Algorithm**

The algorithm used by the UR for the hash calculation of the CertId data.

OCSP requests include information from the issuing certificate of the certificate that is being checked. This information is called the “CertId”. The requester performs a hash calculation on this data and includes it in the request. An algorithm identifier is also included so that the OCSP responder can verify the hash value. SHA-1 is commonly used as the hash algorithm, but some OCSP servers may require more modern hash algorithms. The algorithm used by the UR is selected by this setting.

## **GDOI Configuration**

### **KDC Server IP 1**

The IP address of the first of two redundant KDC servers.

### **KDC Server IP 2**

The IP address of the second of two redundant KDC servers. If there is no redundant KDC server, this can be set to 0.0.0.0 or 127.0.0.1.

### **Key Usage Policy**

This setting determines how the security keys distributed by the KDC server are used with regards to their lifetimes. There are three options.

*No Expired Keys:* When this option is selected, neither publishers nor subscribers will use expired keys. If the KDC has failed or become isolated from the network, secure R-GOOSE communication will stop. This policy should be chosen when the security of data takes precedence over the reliability of R-GOOSE communication.

*Allow Expired Keys:* When this option is selected, both publishers and subscribers will continue to use the latest keys that they have available even after the keys have expired. This will allow secure R-GOOSE communication to continue, with expired keys, if the KDC fails or becomes isolated from the network.

*Use KDA Method:* The Key Delivery Assurance (KDA) method allows for continued secure R-GOOSE communication, with an up-to-date key, when enough subscribers in a group have acknowledged delivery of new keys. R-GOOSE publishers are informed by the KDC when a configured percentage of subscribers have new keys. At this point the group publisher is allowed to start using the new key in the normal manner before the current key expires. If an insufficient percentage of subscribers have acknowledged delivery of new keys, secure R-GOOSE communication will continue with the existing key, even after it has expired. Note that this is all on a per group basis. The KDA percentage for each group is determined and sent to each group publisher separately. The percentage required to allow the publisher to use a new key is a KDC policy configuration.

This method should be chosen when the reliability of the R-GOOSE communication takes precedence over cyber security concerns.

If the UR Key Usage Policy is set to *Use KDA Method*, all groups on the UR will use KDA. This setting is not available on a per group basis. The KDC policy must then be set so that all groups of which the UR is a member

are configured to use KDA. It is critical that there is not a mismatch between the UR and the KDC in these configurations!

### Advanced GDOI Configuration

Less frequently used settings for the KDC server are available when the **Advanced** button is pressed.

#### ***KDC Retry Interval***

The interval between consecutive Pull exchange retries. Used for scheduling Pull exchanges. If the KDC policy is configured to use Push messages for any group on the UR, this setting should be set to its maximum value of 300 seconds (five minutes). This will allow the KDC enough time to send Push messages before the UR will initiate Pull exchanges. If no groups are configured for Push, the default value of 30 seconds can be used.

#### ***Diffie-Hellman Group Size***

The Diffie-Hellman group size value to be used during a Pull exchange.

#### ***Use Test Key***

Enable the UR Test Key feature.

For testing the transmission of encrypted and signed R-GOOSE traffic over a network, the UR can be configured to use a fixed test key. This common key is hardcoded in every UR and has an unlimited lifetime. When this setting is set to "Yes", the test key will be used instead of keys obtained from the KDC using Pull exchanges or Push messages. No certificates are needed, and no connectivity to KDC or OCSP servers is required. This setting applies to all R-GOOSE groups on the UR, both publishers and subscribers. The UR should not be deployed with this feature enabled.

---

## 6.4.6 COMMANDS

### ***Retrieve Certificates***

This command triggers the following sequence:

1. The UR generates a new RSA public/private key pair to be used with the UR client certificate. The key length is as per the UR setting "Certificate RSA Key Length".
2. The UR sends a SCEP request for the CA certificates chain (e.g. root CA, subordinate CA, RA).
3. The UR sends an OCSP request to verify the revocation state.
4. The UR sends a SCEP request for the new UR client certificate.

This sequence may take many seconds or minutes depending on the operation of the SCEP and OCSP servers. The SCEP server in particular may make the UR wait in polling mode while it finishes other operations or obtains the certificates from a higher-level server. The SCEP and OCSP Poll and Retry settings can be adjusted to create appropriate response characteristics. Timeout errors can be prevented by increasing the values of these settings.

The following errors may be returned:

`SCEP Server Unavailable`: The SCEP server is not online or cannot be reached.

`SCEP HTTP Error`: The SCEP server returned an HTTP error.

`SCEP Response failInfo = badAlg`: The SCEP server returned 0 (badAlg). Unrecognized or unsupported algorithm.

`SCEP Response failInfo = badMessageCheck`: The SCEP server returned 1 (badMessageCheck). Signature verification failed.

`SCEP Response failInfo = badRequest`: The SCEP server returned 2 (badRequest). Transaction not permitted or supported.

`SCEP Response failInfo = badTime`: The SCEP server returned 3 (badTime). The request time was not sufficiently close to the SCEP server time.

`SCEP Response failInfo = badCertId`: The SCEP server returned 4 (badCertId). No certificate could be identified matching the provided criteria.

`SCEP Request Incorrect DN`: The UR could not process the requested Distinguished Name. Check the UR Distinguished Name settings for errors.

`SCEP Failure Pending`: The SCEP Server did not complete the request within the maximum Poll Retries and Poll Interval settings.

`SCEP Fingerprint Error`: The UR fingerprint value calculation did not match the CA Certificate Fingerprint setting value. The Fingerprint Algorithm setting value may be incorrect.

`SCEP Decryption Error`: The response from the SCEP server could not be decrypted. Check the SCEP Encryption Algorithm setting, and the algorithm(s) supported by the SCEP server.

`OCSP Server Unavailable`: The OCSP server is not online or cannot be reached.

`OCSP Revoked Certificate`: The OCSP server indicated that the issuing certificate has been revoked. The UR has not requested a client certificate.

`OCSP Unknown Certificate`: The OCSP server indicated that it did not recognize the issuer of the certificate.

`OCSP malformedRequest`: The OCSP server indicated that the request did not conform to the OCSP syntax.

`OCSP internalError`: The OCSP server returns indicated that it reached an inconsistent internal state.

`OCSP tryLater`: The OCSP server indicated that the service exists but is temporarily unable to respond.

`OCSP sigRequired`: The OCSP server returns this in cases where the server requires that the client sign the request in order to construct a response.

`OCSP unauthorized`: The OCSP server returns this in cases where the client is not authorized to make this query to this server, or the server is not capable of responding authoritatively.

### ***Display Certificate***

This command triggers UR Setup to obtain the UR client certificate and open a screen to display the content of the certificate, if a valid certificate is available.

### ***Get SCEP Server Capabilities***

This command triggers the UR to send the SCEP Get Capabilities request to the SCEP server. The server will respond with a list of its capabilities. This includes supported features and algorithms. Upon reception of the response from the SCEP server, the UR will make this information available in a text file. This can be obtained from the UR using UR Setup by opening **Maintenance > Retrieve File** then selecting SCEP\_GetCACaps.txt and Read File as shown below.




Figure 179: SCEP\_GetCACaps.txt file

The file contents should be similar to the following example retrieved from Windows Server NDES:

```
POSTPKIOperation
Renewal
SHA-512
SHA-256
SHA-1
DES3
```

### Renew Certificate

This command triggers the UR to send a SCEP renewal request to the SCEP server. Possible error codes are the same as those shown for the **Retrieve Certificates** command, with the addition of:


Command Not Accepted: It is not possible for the SCEP server to renew a certificate that it did not issue. Ensure that the UR sample certificates are not in use.

## 6.4.7 ADVANCED CONFIGURATION AND TROUBLESHOOTING

### 6.4.7.1 USING UR SAMPLE CERTIFICATES

The UR comes from the factory with sample CA and client X.509 certificates installed. The sample certificates can be used for testing with the KDC, which also comes with sample certificates. Before deployment, the UR should be configured to obtain certificates supplied by a SCEP server. When certificates are issued by a SCEP server, the sample certificates will be deleted. To restore the sample certificates, the UR must have all of its settings reset to factory values.

In order to work with the UR, the KDC requires a copy of the CA certificate from the UR. This can be obtained from the UR using UR Setup by opening **Maintenance > Retrieve File** then selecting `ca.pem` and **Read File** as shown below.




842940A1

Figure 180: Retrieve file "ca.pem"

### 6.4.7.2 SCEP SERVER CHALLENGE PASSWORD AND FINGERPRINT (THUMBPRINT) EXAMPLE

The challenge password and fingerprint (also referred to as thumbprint) should be obtained from the SCEP server. In the case of Windows Server NDES, these values are available on a web page as shown below. These values can be copied from this page and used in the UR **SCEP Password** and **SCEP CA Fingerprint** settings. Note that when copying the fingerprint value from the Windows Server screen shown below, there are spaces every eight characters that should be removed before saving the value in UR Setup.



842941A1

Figure 181: Network Device Enrolment Service

Windows normally uses the MD5 algorithm to produce the above thumbprint. The value of the UR setting **Fingerprint Algorithm** must match the algorithm used by Windows.

### 6.4.7.3 USE OF PULL EXCHANGES VS. PUSH MESSAGES

The UR can obtain SAs from the KDC using either Pull exchanges or Push messages. Push messages are relatively simple since they involve the KDC pushing SAs to the UR using an already agreed upon, secure KEK

value. If requested, the UR will respond with a Push acknowledgement message. No re-authentication or additional secure channel establishment is required. In comparison, Pull exchanges involve a number of data exchanges to authenticate and re-establish the secure channel between the UR and KDC. Additionally, a revocation check of the KDC certificate using OCSP is initiated periodically by the UR in between the two phases of the Pull exchange.

The configuration to use either Push or Pull is set in the KDC for each Publication Group, in the IED Management page, by the **Key Generation Policy -> Key Exchange Mechanism** setting.

Note that even when using Push messages, there will be an initial Pull exchange so the UR can obtain SAs and KEK values from the KDC. Also, the UR expects to receive a Push message well before the SAs expire, and if it does not, it will initiate a new Pull exchange. If the KDC policy is configured to use Push messages for any group on the UR, the KDC Retry Interval setting should be set to its maximum value of 300 seconds (five minutes). This will allow the KDC enough time to send Push messages before the UR will initiate Pull exchanges. If no groups are configured for Push, the default value of 30 seconds can be used.

6.4.7.4 USE OF DIFFERENT CERTIFICATE ISSUERS BETWEEN URS AND THE KDC

OCSP requests are required to contain information from the issuer certificate of the certificate that is being checked for revocation. If the UR is configured to use an OCSP server, it will issue an OCSP request to check the KDC certificate whenever a GDOI Pull exchange is initiated. The UR thus requires information from the issuer of the KDC certificate. In a PKI where both the UR and KDC client certificates have the same issuer, the UR can use the issuer information from its own client certificate. This is the recommended PKI deployment.

If the PKI is more complex and the KDC and UR client certificates have different issuers, the UR will have no access to the issuer information from the KDC certificate. In this case the UR cannot use OCSP to check the revocation status of the KDC certificate.

6.4.7.5 KDC SECURITY POLICY MISMATCH WITH UR R-GOOSE SECURITY SETTING

IEC 61850 and IEC 62351 have created the possibility for a configuration mismatch between group members (URs and other devices) and the KDC. IEC 61850 specifies the Substation Configuration Language (SCL) element **securityEnable**. Possible values are *None*, *Signature*, and *SignatureAndEncryption*, as shown in the UR Setup screen below.





Figure 182: UR TxGOOSE Security Configuration

If a UR R-GOOSE publisher is configured for *SignatureAndEncryption*, it is necessary to configure the KDC policy for this publisher to have both *Key Confidentiality Mechanism* and *Hash Algorithm* values. as shown in the KDC screen excerpt below.



### 6.4.7.6 KDC KEY GENERATION POLICY




**Figure 183: KDC Key Generation Policy Encryption and Signature Algorithms**

If the UR publishers and subscribers are configured for *SignatureAndEncryption* and the KDC has configured that group with a Key Confidentiality Mechanism of *None*, then the UR will not be provided with an encryption algorithm value and will thus not be able to encrypt and publish R-GOOSE messages as per its configuration. This situation must be corrected so the UR and KDC configurations match, otherwise R-GOOSE publication will not occur.

The UR can be configured for non-secure R-GOOSE communication. In this case, if the UR R-GOOSE publisher and subscriber security is configured as *None*, the UR will not initiate GDOI Pull exchanges with the KDC. The R-GOOSE messages will be published with no security, and the values configured in the KDC policy screen will not be used.

### 6.4.7.7 UR UNICAST R-GOOSE

The UR supports a non-standard variation of R-GOOSE for use in networks without IP multicast capabilities. The destination IP address (DST IP) can be configured with a unicast address, instead of the standard multicast address. This unicast R-GOOSE capability is outside the scope of both IEC 61850 and IEC 62351. Unicast R-GOOSE cannot be used with IEC 62351 security.



**Figure 184: R-GOOSE Security**

### 6.4.7.8 UR CLOCK ACCURACY

High levels of UR clock accuracy are not required for IEC 62351 R-GOOSE security. However, there should be a time synchronization protocol such as SNTP, IRIG-B, or PTP utilized to provide a time value to the UR clock. If the UR clock has a large variance from the PKI and KDC time base, there could be problems with SCEP and OCSP transactions, and certificate usage. It is important to ensure that the UR clock is reasonably accurate, even during



bench testing. UR Setup can be used to provide single time synchronization commands from **Commands -> Set Date And Time**.

#### 6.4.7.9 NETWORK MAXIMUM TRANSMISSION UNIT (MTU)

During the GDOI Pull exchange, data from the X.509 certificates of the KDC and group member is exchanged. This data is contained in UDP datagrams. These particular datagrams are often larger than can be carried in one IP packet or one Ethernet frame (approximately 2000 bytes is common). In this situation, the UR will transmit and receive fragmented IP packets. The UR does not contain a setting for network MTU, so it will transmit frames of the maximum Ethernet length. This should be considered when configuring network equipment such as routers and firewalls.

### 6.4.8 STATUS

The UR provides a web page to show the status of certificates and the SCEP, OCSP, and KDC servers.

#### 6.4.8.1 M2M SECURITY STATUS CERTIFICATES

N60 Network Relay  
Revision 8.60

Relay Name: Relay-1  
IP Address: 10.14.21.39

M2M Security Status - Certificates  
[Click Here For The Main Menu](#)

| Certificate Status           |                                 |
|------------------------------|---------------------------------|
| Key Pair Creation Date       | Feb 19 2025 18:00:46            |
| Certificate Key Length       | 2048                            |
| SCEP Request Status          | Failure                         |
| Certificate Status           | Valid                           |
| Certificate Expiration Date  | Feb 19 20:05:01 2027 GMT        |
| Test Key in Use              | No                              |
| SCEP Server Status           | Offline                         |
| OCSP Server Status           | Online, at Feb 20 2025 12:17:31 |
| KDC Server Status            | Online, at Feb 20 2025 12:17:31 |
| Using UR Sample Certificates | No                              |

| Certificate Authority Information Access       |               |
|------------------------------------------------|---------------|
| Authority Information Access - UR Certificate  | Available     |
| AIA OCSP Port                                  | 80            |
| AIA OCSP Path                                  | /ocsp         |
| Authority Information Access - KDC Certificate | Not Available |
| AIA OCSP Port                                  | None          |
| AIA OCSP Path                                  | None          |

842945A1

**Figure 185: M2M security status certificates**

The SCEP Request Status possible values are *Not Sent*, *Failure*, *Pending*, and *Success*.

The Certificate Status possible values are *No Certificate*, *Valid*, *Expired*, and *Revoked*.

Certificate Authority Information Access (AIA) is optional data that may be on a certificate. If available, it contains the OCSP port number and path of the OCSP server.

The server status information is available on the UR front panel.

ACTUAL VALUES > ACTUAL VALUES STATUS > SECURITY STATUS > SERVER STATUS:

|                 |   |                                     |                       |
|-----------------|---|-------------------------------------|-----------------------|
| ■ SERVER STATUS | ↔ | SCEP:Online<br>2025/02/11 09:35:49  | Range: Online/Offline |
| ■               | ↕ | KDC:Online<br>2025/02/11 09:35:49   | Range: Online/Offline |
|                 | ↑ | OCSP: Online<br>2025/02/11 09:35:49 | Range: Online/Offline |

The UR provides a web page that shows the values and status of all of the Security Associations used by the UR. This includes configurations where the UR is a subscriber group member, and where it is a publisher group member.

| Group 12 - Subscriber (Signature & Encryption)                                   |         |           |                  |                |     |            |      |     |
|----------------------------------------------------------------------------------|---------|-----------|------------------|----------------|-----|------------|------|-----|
| IP: [224.0.2.9], DataSet: [SUBMaster/LLN0.TT3DataSet05]                          |         |           |                  |                |     |            |      |     |
| SA                                                                               | Current | State     | Time to Activate | Time to Expire | KDA | SPI        | Life | ATD |
| 1                                                                                | >>>>    | ACTIVATED | --               | 280            | 0   | 0x3dd8437f | 589  | 0   |
| 2                                                                                |         | PENDING   | 221              | --             | 0   | 0x9cca5953 | 600  | 530 |
| 3                                                                                |         | EXPIRED   | --               | --             | 0   | 0x8d167387 | 0    | 0   |
| Pull timer not Running.                                                          |         |           |                  |                |     |            |      |     |
| Encryption Algorithm: AES-CBC-256      Authentication Algorithm: HMAC-SHA256-256 |         |           |                  |                |     |            |      |     |

842946A1

Figure 186: Excerpt from M2M Security Status - IEC 62351

The UR can store up to three SAs simultaneously. Only one SA is active at any given time. All SAs have equal priority, and the SA currently being used is based on the state of the SA and the SA being used by the publisher.

In the above example, the SA 1 state is *Activated*, and the associated key is currently being used to secure the R-GOOSE stream. It expires in 280 seconds. The SA 2 state is *Pending* and will become *Activated* in 221 seconds. In this example there will be an overlap time of 280-221 = 59 seconds to allow the publisher and other subscribers to transition to the new key. SA 3 has previously become *Expired*.

This UR web page also shows the Encryption and Authentication algorithms that are being used to secure the R-GOOSE stream. These policy values are configured on the KDC and sent to the UR.

|                                 | NEXT                | CURRENT       |
|---------------------------------|---------------------|---------------|
| KEY CONFIDENTIALITY MECHANISM:  | AES-CBC-256         | AES-CBC-256   |
| HASH ALGORITHM:                 | HMAC-SHA2-256       | HMAC-SHA2-256 |
| INTERVAL FOR GENERATION (MIN.): | 5                   | 5             |
| GDOI CERTIFICATE VALIDATION:    | CERTIFICATEVALIDITY |               |
| KEY EXCHANGE MECHANISM:         | GROUP-PULL          |               |
| KDA PCT MEMBERS PUSH:           | 90                  |               |

Use KDA  
 FALSE ☐ TRUE

Save

Force ReKey

842947A1

Figure 187: KDC Key Generation Policy screen

### 6.4.8.2 SYSLOG SECURITY EVENTS

IEC 62351-9 defines many Syslog security events. The UR supports the generation of the events that are relevant to its functionality. The format of the event messages is compliant to RFC 5424 and follows the information structure rules in IEC 62351-14.

The following Syslog security events specified in IEC 62351-9 are supported by the UR:

#### Certificate Enrollment Events

IEC 62351-9:1.3 Enrollment with SCEP successfully performed

IEC 62351-9:1.4 Enrollment with SCEP aborted due to failure

#### Certificate Verification Events

IEC 62351-9:2.2 Public Certificate signature verification failed

IEC 62351-9:2.3 Version of X.509 certificate not matching expected version

IEC 62351-9:2.4 Issuer does not match known and trusted issuer.

IEC 62351-9:2.5 Signature algorithm not supported

IEC 62351-9:2.6 Public-key certificate validity: expired

IEC 62351-9:2.7 Public-key certificate validity: not valid, yet

IEC 62351-9:2.8 Subject not included in public-key certificate  
IEC 62351-9:2.9 Algorithm in public-key certificate not supported  
IEC 62351-9:2.10 Path validation error as trust anchor is not supported  
IEC 62351-9:2.11 Certification path validation error  
IEC 62351-9:2.12 Critical extension unknown  
IEC 62351-9:2.14 Authority key identifier not included in public-key certificate  
IEC 62351-9:2.15 Subject key identifier not included in public-key certificate  
IEC 62351-9:2.17 BC not included in CA certificate  
IEC 62351-9:2.18 Violation of path length constraints in CA certificate  
IEC 62351-9:2.21 Key usage not included for signing certificates.  
IEC 62351-9:2.25 Extended Key Usage not included for OCSP signing in OCSP responder certificate  
IEC 62351-9:2.27 OCSP responder information not contained in public-key certificate

#### **Certificate Revocation Status Events**

IEC 62351-9:4.1 Certificate has been revoked  
IEC 62351-9:4.5 OCSP responder not accessible  
IEC 62351-9:4.6 OCSP responder connection timeout  
IEC 62351-9:4.7 Certificate not known to OCSP responder  
IEC 62351-9:4.8 OCSP response expired  
IEC 62351-9:4.9 OCSP response message signature verification failed

#### **GDOI Security Events**

IEC 62351-9:5.1 GDOI Cryptographic algorithms not supported  
IEC 62351-9:5.4 GDOI-PULL Phase 2 decryption issue  
IEC 62351-9:5.6 GROUPKEY-PULL unable to agree to PHASE 1 keys  
IEC 62351-9:5.8 KDA failure

### **6.4.8.3 UR SELF-TESTS AND FLEXLOGIC OPERANDS**

Each Self-test has an associated Flexlogic operand.

#### **SCEP SERVER UNAVAIL**

Description: A certificate was requested, but the SCEP server is not reachable.

Type: minor

Latched: No

Message: `Server HTTP Error, Server Timeout Error, or Verify connectivity.`

What to do: Verify SCEP Server IP Address setting, network settings, and connectivity.

#### **SCEP WRONG PATH**

Description: SCEP path is wrong.

Type: minor

Latched: No

Message: `Correct the path.`

What to do: Verify the SCEP Server Path setting.

### SCEP FAILURE

Description: SCEP server error.

Type: minor

Latched: No

Message: `Pending, Bad Algorithm, Bad Message Check, Bad Request, Bad Time, Bad Certificate ID, Reused Private Key, CA Error, Wrong DN.`

What to do: Check SCEP server error logs.

### CERT NEAR EXPIRY

Description: The X.509 certificate is close to expiration.

Type: minor

Latched: No

Message: `Renew certificate.`

What to do: Use the UR Setup **Renew Certificate** command.

### CERT UNAVAILABLE

Description: Certificate was not issued, or it expired.

Type: minor

Latched: No

Message: `Retrieve certs, or Renew certificate.`

What to do: Use the UR Setup **Retrieve Certificates** command.

### KDC SERVER UNAVAIL

Description: The KDC server is not reachable (neither the main server nor the backup one).

Type: minor

Latched: No

Message: `Verify connectivity.`

What to do: Verify KDC Server IP Address settings, network settings, and connectivity.

### KDC AUTH FAILED

Description: The KDC response contains errors, no KDC certificate is provided or the KDC certificate is invalid.

Type: minor

Latched: No

Message: `Not Authenticated.`

What to do: Verify UR and KDC certificates, and KDC certificate configuration.

### KDC SA UNSUPPORTED

Description: UR does not support the algorithms specified by the KDC server.

Type: minor

Latched: No

Message: `Unsupported SA.`

What to do: Check KDC Key Generation Policy configuration.

### KDC INVALID KEY

Description: The key download contains errors.

Type: minor

Latched: No

Message: `KDC Key Error.`

What to do: Verify network connectivity between URs and KDC. Check KDC Key Generation Policy configuration.

### OCSP SERVER UNAVAIL

Description: The OCSP server is not reachable.

Type: minor

Latched: No

Message: `Server Timeout Error.`

What to do: Verify OCSP IP Address setting, network settings, and connectivity.

### OCSP RA CERT FAIL

Description: The RA server certificate has been revoked or the status is unknown.

Type: minor

Latched: No

Message: `Revoked RA Cert, or Unknown RA Cert.`

What to do: Verify UR certificate chain revocation status. Use UR Setup **Retrieve Certificates** command to obtain new certificates.

### OCSP KDC CERT FAIL

Description: The KDC server certificate has been revoked.

Type: minor

Latched: No

Message: `Revoked KDC Cert, or Unknown RA Cert.`

What to do: Verify revocation status of the KDC certificate. The UR Allowed Failed Validation feature can be used to allow the UR to continue to receive keys from a KDC with a revoked certificate.

### RGOOSE SECURITY

Description: R-GOOSE packet failed authentication / decryption.

Type: minor

Latched: No

Message: `RGOOSE Security Fail.`

What to do: Verify network connectivity between URs and KDC. A UR may not be able to obtain keys and has become out of sync with the other group members.

### KDA FAILED

Description: Key Delivery Assurance failed for at least one group.

Type: minor

Latched: No

Message: `KDA Failure`.

What to do: Verify network connectivity between URs and KDC. At least one UR has not been able to obtain keys and has become out of sync with the other group members. Check to ensure that the KDA configuration is the same on all URs in a group, and in the KDC Key Generation Policy configuration for the group.

### KDC SECURITY WRONG

Description: UR R-GOOSE security configuration does not match KDC Key Generation Policy.

Type: minor

Latched: No

Message: `KDC / securityEnable`.

What to do: Check to ensure that R-GOOSE ***securityEnable*** setting values (i.e. *None*, *Signature*, or ***SignatureAndEncryption***) match the configuration in the KDC Key Generation Policy for all groups.

### M2M EXCEPTION

Description: Internal UR alarm.

Type: minor

Latched: Yes

Message: `Contact factory (01), Contact factory (02), or Contact factory (03)`.

where:

- 01 indicates "Memory allocation failed"
- 02 indicates "File access errors".
- 03 indicates "Function argument check failed".

What to do: Contact the factory for technical support.

---

## 6.4.9 SECURE R-GOOSE CONFIGURATION PROCEDURE

The UR must be configured correctly in order for secure R-GOOSE to function successfully. The following sequence of steps describes the configuration procedure. This assumes that the PCIttek Garibaldi KDC is used to provide the security keys.

The procedure below starts with a simple non-encrypted R-GOOSE configuration and adds additional security layers, GDOI, SCEP and OCSP. It includes the following steps:

1. Non-secure R-GOOSE configuration.
2. Using the built-in UR test key for encrypting and decrypting R-GOOSE messages.
3. Using the built-in sample certificates to prepare the UR to obtain security keys from the KDC.
4. Using a SCEP server to obtain secure certificates.
5. Using an OCSP server to check the KDC server certificate.
6. Configuring the GDOI settings in the UR.
7. Configuring the KDC server settings.

### 6.4.9.1 NON-SECURE R-GOOSE CONFIGURATION

A UR can be configured to both publish multiple R-GOOSE message streams and subscribe to multiple R-GOOSE message streams. The R-GOOSE message streams can be non-secure or secure. A non-secure configuration is easier to deploy since R-GOOSE messages are not encrypted or signed, and a KDC is not required. It is recommended to start with a non-secure configuration and achieve successful communication before enabling security. A simple configuration with one UR configured as an R-GOOSE stream publisher, and one UR as an R-GOOSE subscriber can be used.

Using EnerVista UR Setup software:

- Select Settings -> IEC 61850 -> DataSets to create a dataset for publishing in one UR.
- Select Settings -> IEC 61850 -> GOOSE -> TxGOOSE to configure the publisher stream.
- Select Settings -> IEC 61850 -> GOOSE -> RxGOOSE to configure the subscriber in the other UR. Import the CID file from publisher UR to select the subscribed data.
- Set the "SECURITY" setting for each publisher and subscriber stream to "None" to test non-secure R-GOOSE communication.
- Save the settings to the URs.
- Select Actual Values -> Status -> RxGOOSE Status to view the subscription status in the subscriber UR. Ensure that the configured R-GOOSE stream is online and working as expected.

With a suitable network configuration, the R-GOOSE messages can be viewed using a network traffic capture program such as Wireshark.

### 6.4.9.2 TEST KEY

Once non-secure R-GOOSE communication is working, the Test Key feature can be used to cause the URs to use a fixed security key for all R-GOOSE publisher and subscriber groups.

Using EnerVista UR Setup software:

Select Settings -> Product Setup -> Security M2M -> Use Test Key and then change the value to "Yes". Do this for both the publisher and subscriber URs.

The R-GOOSE messages on the network will now contain data encrypted with the test key.

The Use Test Key settings in both URs must be set back to "No" before continuing.

### 6.4.9.3 CERTIFICATES

To use real keys provided by the KDC server, instead of the built-in test key, the UR must use X.509 digital security certificates. Each UR contains sample certificates that can be used for testing secure R-GOOSE. The UR can also be configured to retrieve certificates from a SCEP server, which is necessary before actual deployment. Optionally the UR can be configured to check certificates using an OCSP server. Windows Server NDES provides SCEP and OCSP server services.

#### 6.4.9.3.1 USING SAMPLE CERTIFICATES

From the factory, each UR contains a sample client certificate file and a sample CA certificate file. These two files are the same in all URs. In order to establish a chain of trust between the URs and the Garibaldi KDC, the UR CA certificate file, ca.pem, must be loaded into Garibaldi. The UR CA sample certificate can be obtained from any one of the URs by following the procedure in "USING UR SAMPLE CERTIFICATES". The ca.pem file must then be loaded into the Garibaldi KDC.

After this process is completed, the URs will be able to authenticate with Garibaldi and obtain security keys using network GDOI "Pull" requests. SCEP and OCSP are not required. However, in a fully secure system, certificates must be obtained by the UR from a SCEP server. When the UR successfully receives certificates from a SCEP server, it deletes the sample certificates.



### 6.4.9.3.2 USING SCEP

For an actual deployment, the URs should be configured to obtain certificates from a SCEP server that is part of an existing PKI. There are many SCEP related settings that must be set correctly before the UR "Retrieve Certificates" command can be issued. Detailed descriptions of these settings are in "SCEP Configuration".

The following is a sample UR configuration that works with Windows Server NDES:

The screenshot shows a configuration window titled "Security M2M // R-GOOSE Security: UR1-37: Settings: Product Setup". It features buttons for "Save", "Restore", "Default", and "Reset", along with a "VIEW ALL mode" link. The settings are organized into three sections: "SCEP Configuration", "Advanced", and "Certificate Information".

| SETTING                        | PARAMETER                  |
|--------------------------------|----------------------------|
| <b>SCEP Configuration</b>      |                            |
| SCEP Server IP                 | 10. 14. 12. 21             |
| SCEP Server Port               | 80                         |
| SCEP Server Path               | /certsrv/mscep/mscep.dll   |
| SCEP Password                  |                            |
| <b>Advanced</b>                |                            |
| SCEP Signature Algorithm       | SHA-256                    |
| SCEP Encryption Algorithm      | DES-EDE-CBC                |
| SCEP Poll Retries              | 10                         |
| SCEP Poll Interval             | 10 sec                     |
| SCEP Automatic Renewal         | Disabled                   |
| SCEP Compatibility             | Windows Server             |
| Fingerprint Algorithm          | MD5                        |
| CA Certificate Fingerprint     |                            |
| <b>Certificate Information</b> |                            |
| Certificate Common Name        | 000B5E000055525F3737393927 |
| Certificate Email              | drew.baigent@ge.com        |
| Certificate Organization       | UR1-RA                     |
| Certificate OrgUnit            | Multilin                   |
| Certificate Locality           | Markham                    |
| Certificate State              | Ontario                    |
| Certificate Country            | CA                         |
| Certificate RSA Key Length     | 3072                       |

**Figure 188: SCEP Server Configuration**


The SCEP Password and CA Certificate Fingerprint settings must be obtained from the SCEP server. An example of this is given in "SCEP SERVER CHALLENGE PASSWORD AND FINGERPRINT (THUMBPRINT) EXAMPLE". Note that it is possible to obtain only one set of certificates with each challenge password issued by the SCEP server. That is, each password can be used to successfully obtain a certificate only once.

Once the above settings are saved, use the "Retrieve Certificates" command button to make the UR request certificates from the SCEP server. Repeat this for the other UR, using a new challenge password.

### 6.4.9.3.3 USING OCSP

OCSP is used to check the online status of certificates. It is optional. To disable OCSP, the OCSP Server IP setting should be set to "0.0.0.0". OCSP is used by the UR to check the status of the Garibaldi KDC certificate during the authentication phase of each security key Pull request.

The following is a sample UR configuration that works with Windows Server NDES:



**Figure 189: OSCP Server Configuration**

Detailed descriptions of these settings are given in "OCSP Configuration".

#### 6.4.9.4 UR GDOI CONFIGURATION

The KDC Server IP 1 setting must be set to the IP address of the computer running the Garibaldi KDC.

#### 6.4.9.5 KDC CONFIGURATION

The KDC must be installed and configured following the Garibaldi KDC Installation and User Guides.

As described above, the UR CA certificate file must be loaded into the Garibaldi KDC.

The CID file for at least the UR R-GOOSE publisher must be loaded into the Garibaldi KDC. The CID file for the UR R-GOOSE subscriber can optionally be loaded so that the KDC configuration contains a complete list of the configured devices.

#### 6.4.9.6 STATUS OF SECURITY KEYS IN THE URS

The status of the Security Associations between the URs and the KDC can be seen on a webpage available on each UR. There should always be at least one "ACTIVATED" Security Association which contains the security key currently in use by the publisher and subscriber URs.

M2M Security Status - IEC 62351-9

[Click Here For The Main Menu](#)

| KDC Transaction Information        |                      |
|------------------------------------|----------------------|
| Pull Request Sent                  | 1408                 |
| Push Received                      | 0                    |
| Current Active KDC                 | KDC 1                |
| OCSP Status of KDC Certificate     | Valid                |
| Last OCSP Check of KDC Certificate | Oct 23 2025 07:44:34 |

| Publisher Group 1 (Signature & Encryption)                    |         |           |                                           |                |     |            |      |      |
|---------------------------------------------------------------|---------|-----------|-------------------------------------------|----------------|-----|------------|------|------|
| IP: [232.147.120.1], DataSet: [Rly147Master/LLN0.TT6DataSet1] |         |           |                                           |                |     |            |      |      |
| SA                                                            | Current | State     | Time to Activate                          | Time to Expire | KDA | SPI        | Life | ATD  |
| 1                                                             | >>>>    | ACTIVATED | --                                        | 1127           | 0   | 0xa0c1423d | 1661 | 0    |
| 2                                                             |         | PENDING   | 1057                                      | --             | 0   | 0x2a264d8f | 1800 | 1521 |
| 3                                                             |         | INVALID   | --                                        | --             | 0   | 0x00000000 | 0    | 0    |
| Pull request not scheduled.                                   |         |           |                                           |                |     |            |      |      |
| Encryption Algorithm: AES-CBC-256                             |         |           | Authentication Algorithm: HMAC-SHA256-256 |                |     |            |      |      |

Figure 190: M2M Security Status - IEC 62351-9

Detailed descriptions of these settings are given in “OCSP Configuration”.

## 6.5 RADIUS SERVER CONFIGURATION

The following procedure is an example of how to set up a simple RADIUS server. You install the RADIUS server software on a separate computer. In this example, we use FreeRADIUS third-party software.

1. Download and install FreeRADIUS from [www.freeradius.org](http://www.freeradius.org) as the RADIUS server. This is a Windows 32-bit installation that is known to work. If you try another third-party tool and it does not work, use the FreeRADIUS software.
2. Open the `radiusd.conf` file in the `<Path_to_Radius>\etc\raddb` folder
3. Locate the `bind_address` field and enter your RADIUS server IP address.  
Text editor software that supports direct editing and saving of UNIX text encodings and line breaks, such as EditPad Lite, is needed for this editing.
4. In the `users.conf` file in the `<Path_to_Radius>\etc\raddb` folder, add the following text to configure a user **Tester** with an Administrator role.

```
Tester                                User-Password == "TesterPw1#"
                                     GE-UR-Role = Administrator
```

5. In the `clients.conf` file in the `<Path_to_Radius>\etc\raddb` folder, add the following text to define the UR as a RADIUS client, where in this example the client IP address is 10.14.61.132, the shared secret specified here is also configured on the UR device for successful authentication, and the shortname is a short, optional alias that can be used in place of the IP address.

```
client 10.14.61.132 {
secret = Testing!123
shortname = url-test
}
```

Alternatively, you may specify one secret for a network of clients, where in the example below the clients are all within the 10.14.61.0/24 subnet and the shared secret specified here is also configured on all the UR devices in the subnet for successful authentication.

```
client 10.14.61.0/24 {
secret = Testing!123
shortname = net1-test
}
```

6. In the `<Path_to_Radius>\etc\raddb` folder, create a file called `dictionary.ge` and add the following content.

```
# #####
```

```
# GE VSAs
```

```
#####
```

```
VENDOR                                GE                                2910
```

```
# Management
authorization
```

```
BEGIN-VENDOR                                GE
```

```
# Role ID
```

```
ATTRIBUTE                                GE-UR-Role                                1                                integer
```

```
# GE-UR-ROLE values
VALUE GE-UR-Role      Administrator      1
VALUE GE-UR-Role      Supervisor         2
VALUE GE-UR-Role      Engineer           3
VALUE GE-UR-Role      Operator            4
VALUE GE-UR-Role      Observer            5
```

```
END-VENDOR                                GE
```

```
#####
```

7. In the dictionary file in the <Path\_to\_Radius>\etc\raddb folder, add the following line.  

```
$INCLUDE dictionary.ge
```

For example, the file can look like the following:

```
$INCLUDE ../share/freeradius/dictionary
$INCLUDE dictionary.ge
```
8. For the first start, run the RADIUS server in debug mode to ensure that there are no compiling errors.  
<Path\_to\_Radius>/start\_radiusd\_debug.bat
9. Set up the RADIUS parameters on the UR as follows.
  - a. If logging in, select **Device** for the **Authentication Type**, and use `Administrator` for the **User Name**. The default password is `ChangeMe1#`.
  - b. Access **Settings > Product Setup > Security**.
  - c. Configure the IP address (10.14.61.122 in this example) and ports (default values in this example) for the RADIUS server. Leave the GE vendor ID field at the default of 2910.
  - d. Update the RADIUS shared secret (`Testing!123` in this example) as specified in the `clients.conf` file. Restart the relay for the IP address and port changes to take effect.
10. Verify the operation by logging in to the UR software as follows.
  - a. In the login window, select **Server** as the **Authentication Type**
  - b. Enter the user name (for example user name `Tester` with password `TesterPw1#`).
  - c. Check that the RADIUS server log file shows the access with an `Access-Accept` entry.

## CHAPTER 7

# PROCESS BUS MODULE

---

# 7.1      **CHAPTER OVERVIEW**

---

This chapter contains the following sections:

|                                             |     |
|---------------------------------------------|-----|
| Chapter Overview                            | 315 |
| Overview                                    | 316 |
| Parallel Redundancy Protocol (PRP)          | 317 |
| High-availability seamless redundancy (HSR) | 319 |
| Process Bus Settings                        | 321 |
| SV Stream Configuration                     | 327 |
| Remote resources configuration              | 344 |

---

## 7.2 OVERVIEW

---

**Note:**

*This feature requires a Process Bus Module (order code 85, 86, or 87).*

**Note:**

*Process Bus GOOSE requires IEC 61850 and IEEE 1588 software options*

The UR provides a digital process bus by use of a Process Bus Module. A digital process bus enables digital transmission of data between the switchyard and relays in a control house using communication cables instead of hard-wired connections.

The Process Bus Module supports the IEC 61850-9-2LE and IEC 61869 protocols, switched networks, and two redundancy protocols (Parallel Redundancy Protocol and High-Availability Seamless Redundancy). The module is used to transfer data streams in protection and control networks, including dataset samples referred to as sampled values (SVs), with the stability of redundancy.

A Process Bus Module with order code 85, 86, or 87 is distinct from the HardFiber Process Bus Module with order code 81. This section does not apply to the HardFiber module.

Configuration includes that for redundancy and synchronization of time-clock sources because data transfer occurs among multiple devices.

**Note:**

*For any device that is connected to a copper SFP of the Process Bus Module, set its port speed to Auto Negotiate. The copper SFP supports 100 Mbps and 1 Gbps speeds in auto-negotiate mode. If the device connecting to the Process Bus Module has a fixed port speed, does not support auto-negotiation, or its auto-negotiate is disabled, then the link speed of the copper SFP is fixed at 1 Gbps and it communicates only with a device that supports 1 Gbps.*




## 7.3 PARALLEL REDUNDANCY PROTOCOL (PRP)

PRP enables seamless switchover and zero recovery time during a single network failure in substation automation networks. It ensures that critical data, such as GOOSE and sampled value (SV) data, are transmitted without delay in case of local area network (LAN) defects. In other words, with PRP functionality, the Process Bus Module can be connected to redundant LANs and work with zero recovery time.

PRP is supported to the IEC 62439-3:2012 standard, Clause 4.

The figure shows that PRP achieves redundancy by using a combination of frame and LAN duplication. Identical frames, here labeled frames A and B, are sent on two independent networks that connect source and destination. The frames carry GOOSE or supervisory data. Under normal circumstances, both frames reach the destination and one of them is sent up the stack to the destination application, while the other frame is discarded. If an error occurs in one of the networks and traffic is prevented from flowing on that path, connectivity is provided by the other network to ensure continuous communication. When designing this network care was taken to ensure that there is no single point of failure in the two LANs, such as a common power supply, as such scenarios can bring down simultaneously both LANs.



859778A1.ppt

**Figure 191: PRP redundant network example**

PRP implements redundancy in the nodes rather than in the network by using specialized nodes called Doubly Attached Nodes Running PRP (DANP) for handling the duplicated frames. The figure shows an example. Each DANP node has two ports that are connected to the two independent LANs with similar (but not necessarily identical) topology. A source DANP sends identical frames over both LANs and a destination DANP receives both frames from the two LANs within a certain time period, consumes the first frame, and discards the duplicate frame.

Each UR device in this example implements PRP on ports 1a and 1b of the Process Bus Module. Both URs require a Process Bus Module. Ports 1a and 1b act as DANP in the PRP network. With two ports required, Process Bus Modules with order code 85, 86, or 87 can be used. While this example shows a UR as receiving the frames, the receiver can be a merging unit or UR.

A device with only one port, such as a printer or computer, is called a Singly Attached Node (SAN). It is a node with non-redundant network adapters. A SAN can communicate with other SANs and DANPs on the same LAN. When a SAN is attached to a redundant LAN by a Redundancy Box (RedBox) device, the SAN can communicate with all DANPs and SANs in both LANs. In other words, if redundancy for a SAN is required, the SAN is connected to both LANs through a RedBox.

A merging unit (MU), such as the GE MU320, is an interface between analog and digital worlds. With an MU, the analog signals from the CTs and VTs in the yard are converted to digital signals and transmitted via the sampled value (SV) network communication protocol.


The bridges shown are network switches that connect devices participating in the PRP network and otherwise do not have an active role in PRP.

## 7.4 HIGH-AVAILABILITY SEAMLESS REDUNDANCY (HSR)

Similar to PRP, High-Availability Seamless Redundancy (HSR) enables seamless switchover and zero recovery time during a single network failure in substation automation networks. It ensures that critical data, such as GOOSE and SV data, are transmitted without delay in case of LAN defects.

HSR is supported to IEC 62439-3, Clause 5. SV data can be received from merging units meeting IEC 61869-9.

HSR is used in network topology with rings and rings of rings. All nodes in the ring are doubly attached. The figure shows an example. The Doubly Attached Node with HSR (DANH) is a node that has two ports interconnected by full-duplex links and participates in the HSR ring. The source node receives a frame from its upper layer, inserts an HSR tag to identify duplicates, and sends it over its two ports in different directions, shown by the red and blue arrows. In a normal, fault-free state, the identical frames reach the destination DANH within a certain interval, the destination DANH removes the HSR tag, sends the first frame up the stack to the destination application and discards the second frame. If an error occurs in one of the network nodes and traffic cannot flow on that path, connectivity is provided through the other direction and ensures continuous communication.



859776A1.ppt

**Figure 192: HSR single-ring configuration example**

A Singly Attached Node, or SAN, such as a computer or printer, is a node with non-redundant network adapters. It uses a redundancy box (RedBox) to connect to the ring.

A merging unit (MU), such as the GE MU320, is an interface between analog and digital worlds. With an MU, the analog signals from the CTs and VTs in the yard are converted to digital signals and transmitted via the sampled value (SV) network communication protocol.


A UR with the Process Bus Module implements either single or dual HSR capability. It supports hierarchical ring topologies, such as connected rings, mesh topology, and an HSR ring in a PRP network.

In single HSR configuration, ports 1a and 1b of the Process Bus Module act as DANH, and any other ports on the Process Bus Module are disabled. Point-to-point configuration is not available. For single HSR, Process Bus Module 85, 86, or 87 can be used.

In dual HSR configuration, the UR to connect to two independent HSR rings. Ports 1a and 1b form one DANH node, and ports 3a and 3b form the second DANH node. Any other ports on the module are disabled. Traffic from HSR-1 ring is not forwarded to the HSR-2 ring and vice versa. The UR does not facilitate any message communication between the two independent HSR rings. In dual HSR, with four ports required, a Process Bus Module with order code 86 or 87 can be used.

While the UR does not provide RedBox functionality, an HSR ring can be connected to a PRP network using two RedBoxes, one for each redundant LAN of the PRP network. The RedBoxes are configured to handle PRP frames on the interlinks and HSR frames on the HSR ring. As per the IEC 62439-3:2016 standard, up to seven PRP networks can be connected to the same HSR ring.

While the UR does not provide QuadBox functionality, a QuadBox can be added to interconnect two HSR rings, which is beneficial when traffic on a single ring exceeds the ring's capability.



859777A1.ppt

**Figure 193: Dual HSR, double-ring configuration example**

## 7.5 PROCESS BUS SETTINGS

Setting path: **SETTINGS > PROCESS BUS MODULE > GENERAL**

|                                                |   |                                                   |                                                                                                     |
|------------------------------------------------|---|---------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| <div> <div>■ GENERAL</div> <div>■</div> </div> | ⇔ | NETWORK CONFIG:<br>INDEPENDENT                    | Range: INDEPENDENT, PRP, HSR, Dual HSR                                                              |
|                                                | ⇕ | PRP SUPV MCST ADDR:<br>01154E000100               | Range: 01 15 4E 00 01 00 to 01 15 4E 00 01 FF                                                       |
|                                                | ⇕ | HSR-1 SUPV MCST ADDR:<br>01154E000100             | Range: 01 15 4E 00 01 00 to 01 15 4E 00 01 FF                                                       |
|                                                | ⇕ | HSR-2 SUPV MCST ADDR:<br>01154E000101             | Range: 01 15 4E 00 01 00 to 01 15 4E 00 01 FF                                                       |
|                                                | ⇕ | PORT 1a FUNCTION:<br>Enabled                      | Range: Disabled, Enabled                                                                            |
|                                                | ⇕ | ⇩                                                 |                                                                                                     |
|                                                | ⇕ | PORT 4b FUNCTION:<br>Enabled                      | Range: Disabled, Enabled                                                                            |
|                                                | ⇕ | SV TRBL PRT BLOCK:<br>Global                      | Range: Global, Partial                                                                              |
|                                                | ⇕ | SV TRBL CONT OP BLK:<br>Off                       | Range: FlexLogic operand                                                                            |
|                                                | ⇕ | SV DELAY ALARM:<br>6.0 ms                         | Range: 1.0 ms to 10.0 ms in steps of 0.1 ms                                                         |
|                                                | ⇕ | QUALITY CHECK:<br>Reject Questionable             | Range: Reject Questionable, Accept Questionable                                                     |
|                                                | ⇕ | ANTI-ALIASING FILTER:<br>Disabled                 | Range: Disabled, Enabled                                                                            |
|                                                | ⇕ | SMPSYNCH CHECK:<br>Global                         | Range: Global, Local, Local-87L, Any                                                                |
|                                                | ⇕ | Fallback GmID:<br>00 00 00 00 00 00 00 00         | Range: 8 Octet string                                                                               |
|                                                | ⇕ | TARGET: Click to view or<br>edit selected Targets | Range: List of available Targets. Access in EnerVista.                                              |
|                                                | ⇕ | EVENTS: Click to view or<br>edit selected Events  | Range: List of available FlexLogic operand types<br>from SV Stream Processing. Access in EnerVista. |

### NETWORK CONFIG

This setting specifies the network configuration and redundancy for the Process Bus Module. If set to *INDEPENDENT*, all ports on the Process Bus Module are enabled, and the Process Bus Module can be connected directly to merging units (MUs) or to a switch without redundancy. To enable and disable individual ports on the Process Bus Module in a point-to-point (PPP) network, use the **PORT x FUNCTION** settings. If set to *PRP* or *HSR*, ports 1a and 1b are enabled. The **PORT 1a FUNCTION** and **PORT 1b FUNCTION** settings change, depending on usage. If set to *Dual HSR*, ports 1a and 1b are enabled for one HSR ring. When using a Process Bus Module, ports 3a and 3b are enabled for another HSR ring.

### PRP SUPV MCST ADDR

This setting changes the multicast address used by the Parallel Redundancy Protocol (PRP) supervision frames. Configure all DANP devices in the PRP network with the same multicast address for the network supervision to operate properly. You can edit this setting when the **NETWORK CONFIG** setting is set to *PRP*.

### HSR-1 SUPV MCST ADDR

This setting changes the multicast address used by High-Availability Seamless Redundancy ring one (HSR-1 ports 1a and 1b) supervision frames, for single HSR configuration. Configure all DANH devices in the HSR network with the same multicast address for the network supervision to operate properly. This setting is editable when the **NETWORK CONFIG** setting is set to *HSR* or *Dual HSR*.

### HSR-2 SUPV MCST ADDR

This setting changes the multicast address used by the HSR-2 (ports 3a and 3b) supervision frames for the second DANH in a Dual HSR configuration. Configure all DANH devices in the HSR network with the same multicast address for the network supervision to operate properly. You can edit this setting when the **NETWORK CONFIG** setting is set to *Dual HSR*.

### PORT 1a to 4b FUNCTION

These settings manually enable and disable Process Bus Module Ethernet ports. Typically, Process Bus Module ports are order-code dependent, and the *INDEPENDENT* network configuration enables all the ports by default. These settings allow individual ports to be enabled and disabled individually. To connect only a few of the ports, other ports can be disabled to avoid a *PBEthPort-# Offline* self-test error. The fields active depend on order code and **NETWORK CONFIG** setting. For order code 85, ports 1a, 1b, 3a, and 3b are available to be turned on or off. For order codes 86 and 87, all eight ports can be available to be turned on or off.

When a port is disabled, all transmitting and receiving traffic on the port is blocked. Relay restart is not required when changing these port function fields.

### SV TRBL PRT BLOCK

In case of loss of any subscribed SV streams or due to bad quality of any subscribed SV frames, the relay's protection functions need to be blocked to avoid undesired operation. This setting specifies the type of blocking applied. When set to *Global*, all the protection functions that utilize the sampled values are blocked. Communications, data logging, and oscillography remain functional. Availability of switchgear control is determined by the SV TRBL CONT OP BLK operand. When set to *Partial*, only those protection functions are blocked that utilize the sampled values from the affected SV stream. All other protection functions remain operational.

### SV TRBL CONT OP BLK

This setting selects a FlexLogic operand that determines whether the contact outputs are blocked or not. When the state of the operand is low, the contact outputs are not blocked when there is a loss of any SV stream or received SV frames have bad quality. You can enable switchgear control through contact outputs during SV stream trouble. When the operand is high, the contact outputs are blocked when there is a loss of any SV stream or received SV frames have bad quality and the switchgear control is not available through contact outputs during SV stream trouble.

### SV DELAY ALARM

The sampled value (SV) frames may arrive with a delay from the MUs, which can be due to the MU performance or different network path delays. This setting specifies the maximum delay expected between the time a sample is taken at the MU and the time of arrival of that SV message. Sampling time is estimated based on the UR Process Bus Module clock and the sampling rate. If the calculated frame delay is more than this setting value, the RxSV# Delay Alm On FlexLogic operand asserts. The setting value needs to be calibrated and set at the commissioning time for the given network topology. An alarm in runtime indicates the network performance is degrading over the time. In short, this setting specifies how long the relay waits to declare that a sample is delayed. Protection is not blocked by this setting.

## QUALITY CHECK

Flags are used to assess the quality of sampled value data to ensure protection. This setting specifies how the sampled values are processed by the relay when the associated **q.validity** is set to *Questionable*. Quality is checked per AC bank, not per SV stream. When set to *Reject Questionable*, the questionable data is considered invalid and the frame is rejected. Only Good quality data is accepted. Set it to *Accept Questionable* only if it is absolutely known that questionable quality from a MU is not compromising the quality of the data for various applications. When set to *Accept Questionable*, both the *Good* and *Questionable* quality data are accepted.

## ANTI-ALIASING FILTER

This setting activates or deactivates the anti-aliasing filter that conditions the sampled values from the Process Bus network. If the Merging Unit providing sampled values is applies an anti-aliasing filter, this setting must be disabled. Otherwise, this setting can be enabled to apply filtering of the received sampled values. When enabled, the device applies a low-pass-filter, which attenuates all the harmonics above the 15th order.

## SMPSYNCH CHECK

This setting is a time synchronization check. It specifies the time synchronization source of an SV stream expected by the Process Bus Module.

When set to *Global*, only the SV streams with **SmpSynch** indicating a *Global (2)* value are accepted. A stream with a **SmpSynch** value other than *Global (2)* is rejected.

When set to *Local*, all SV streams with **SmpSynch** indicating a *Local (1)* or *Global (2)* area clock are accepted.

When set to *Any*, any **SmpSynch** value in the range of 0 to 254 is acceptable. Streams outside the range are rejected.

When all the subscribed MU streams support IEC61850 Ed 2.1, an additional acceptance criterion as outlined in the description of setting Fallback GmID, has been added from UR version 8.5 and onwards

## Fallback GmID

In the RxSV streams supporting IEC61850 Ed 2.1, the *SynchSrcID* attribute is used as acceptance criteria for the RxSV streams, which are used by the Protection elements. In the absence of Global Clock, this setting indicates the GmID of the local clock to which all subscribed MUs have to be synchronized for RxSV streams to be accepted. The effect of the **Fallback GmID** is explained as below:

When **SMPSYNCH CHECK** is set to *Global*, only the RxSV streams with SmpSynch attribute indicating a *Global (2)* value are accepted. SynchSrcID(GmID) Check is not done as all the streams accepted are Globally synchronized.




Figure 194: SympSynchCheck with GmID Flowchart

#### Effect of SMPSYNCH CHECK setting and attribute

| MU Smpsynchron Attribute | UR Setting: SMPSYNCH CHECK      |                                                 |                                       |
|--------------------------|---------------------------------|-------------------------------------------------|---------------------------------------|
|                          | Global                          | Local                                           | Any                                   |
| Global                   | Protection elements operational | Protection elements operational                 | Protection elements operational       |
| Local                    | Protection elements blocked     | Protection elements operational if GmID=GmIDRef | Protection elements operational       |
| Any                      | Protection elements blocked     | Protection elements blocked                     | Other protection elements operational |



TARGET

With this setting, you can select the target messages of the affected SV stream(s) to be displayed on the front panel. The target resets itself once the issue with the SV stream is resolved. Note that a selected target message applies to all the configured SV streams. For example, if target message **RxSV DELAY ALM ON** is selected, then a target displays when any of the configured SV streams has an active SV Delay Alarm. When disabled, no target message displays on the front panel.




Figure 195: FlexLogic operand target selection

EVENTS

With this setting, you can select the flexlogic operands, which will generate the events of the affected SV stream(s), to be recorded in the event recorder. Note that a selected event from the menu applies to all the configured SV streams. When disabled, no event is recorded in the event recorder.




Figure 196: FlexLogic operand event selection

**Note:**  
Choose carefully the events to be recorded in the event recorder. If an SV stream is noisy, there is risk of event recorder overflow. Apart from testing, select a minimal number of events following relay commissioning

**Important!**

**Note:**  
The assertion of the **Delayed Processing On** operand can be observed only in the event recorder because the oscillography is not running when the SV samples are delayed enough to trigger the assertion of this operand.

## 7.6 SV STREAM CONFIGURATION

The UR platform can subscribe up to eight sampled value (SV) streams. Up to six banks and up to six sources can be used for protection. Reception of a sampled value (RxSV) can be enabled in the IEC 61850-9-2LE or IEC 61869-9/13 format.

These settings are available in the EnerVista software and can also be configured in the software using a CID file.

The path is **Settings > Process Bus Module > SV Stream Config**. If a message displays that the data cannot be opened, it can mean that access timed out. In this case, try again.

Figure 197: Example of sampled values configuration

The configuration window is explained as follows:

- The four areas of the window (Common Setting, RxSV Streams, Advanced Config, AC Banks, and Sources) collapse and expand by clicking their buttons
- A column collapses and expands by clicking its heading
- The **Show Enabled** button toggles active/configured content
- The **Show Custom Layout** button toggles changes made to formatting, such as column width. Such changes can be made with or without the button active, and they are retained when the panel is closed.
- There are up to eight RxSV, eight AC Bank, and six Source columns. A B30 can have up to 24 RxSV, 30 AC Bank (24 CT and six VT), and 30 Source columns.
- With IEC 61869-9, the Advanced Config fields populate and are read-only when importing a file
- Rules are enforced and the configuration cannot be saved until the rules are followed. For example, Neutral Origin 1 and Neutral Origin 2 cannot be mapped to the same SV stream. See the troubleshooting section that follows.
- The window is configured based on the separate areas and not based on columns. For example, stream RxSV1 is configured in the SV Messages area of the window, not the first column in the entire window. Or for example, Source1 in the first column can be configured to use AC Bank B2 in the second column.
- The following example shows that Source1 at the bottom of the window is set to map to AC Bank B2, which is mapped to the first stream (RxSV1) and its available VT1 phase voltage and VT2 neutral voltage.

| SV MESSAGES  |            |      |
|--------------|------------|------|
| VT Channels  | 8          | 4    |
| ASDUs        | 1          | 1    |
| Variant Code | F4800S14U8 |      |
| CT1-A        | None       | AC1  |
| CT1-B        | None       | AC2  |
| CT1-C        | None       | AC3  |
| CT1-N        | None       | AC4  |
| CT2-A        | None       | None |
| CT2-B        | None       | None |
| CT2-C        | None       | None |
| CT2-N        | None       | None |
| VT1-A        | AC1        | AC5  |
| VT1-B        | AC2        | AC6  |
| VT1-C        | AC3        | AC7  |
| VT1-N        | AC4        | AC8  |
| VT2-A        | AC5        | None |
| VT2-B        | AC6        | None |
| VT2-C        | AC7        | None |
| VT2-N        | AC8        | None |

| AC BANKS            |          |               |
|---------------------|----------|---------------|
| AC BANKS            | B1       | B2            |
| Phase Origin 1      | None     | RxSV1-VT1/PHS |
| Phase Origin 2      | None     | None          |
| Neutral Origin 1    | None     | RxSV1-VT2/NTR |
| Neutral Origin 2    | None     | None          |
| Crosschecking       | None     | None          |
| Phase CT Primary    | 1 A      | 1 A           |
| Phase CT Secondary  | 1 A      | 1 A           |
| Phase CT Polarity   | Standard | Standard      |
| Ground CT Primary   | 1 A      | 1 A           |
| Ground CT Secondary | 1 A      | 1 A           |
| Ground CT Polarity  | Standard | Standard      |
| Phase VT Ratio      | 1.00 :1  | 1.00 :1       |
| Phase VT Secondary  | 66.4 V   | 66.4 V        |
| Phase VT Connection | Wye      | Wye           |
| AUX VT Ratio        | 1.00 :1  | 1.00 :1       |
| AUX VT Secondary    | 66.4 V   | 66.4 V        |
| AUX VT Connection   | Vag      | Vag           |

| SIGNAL SOURCES |         |         |
|----------------|---------|---------|
| PLATFORM       | SOURCE1 | SOURCE2 |
| Name           | SRC 1   | SRC 2   |
| Phase CT       | None    | None    |
| Ground CT      | None    | None    |
| Phase VT       | B2      | None    |
| Aux VT         | None    | None    |

Figure 198: Understanding SV configuration

- The UR allows switching AC banks (essentially streams) from the main measuring MU to the alternate measuring MU. Once an operand assigned to the **SWITCH ALT CT/VT** setting is logical 1, the input data to this source is switched from the banks assigned to **PHASE CT/GROUND CT** to the banks assigned to **ALT PHASE CT/ALT GROUND CT** settings for current transformers. This is similar for voltage transformers.
- Banks assigned to the same function for the main and alternate input data have to have the same CT and VT nominals and connections, otherwise a warning is generated and switching functionality is prohibited. For example, banks assigned to the PHASE CT and ALT PHASE CT have to have same primary and secondary CT values.
- During switching from the main CT/VT input data to alternate input data and vice versa, all relay functions are blocked for two power cycles and metering data does not update
- See the Source Switching section under **SETTINGS > SYSTEM SETUP > SIGNAL SOURCES** in this manual for application examples of AC bank switching

An example of the configuration process is as follows:

1. Configure SV streams by importing an MU CID file. This populates the SV Messages area of the window.
2. Configure the Sources fields.
3. Map the AC Bank fields to the RxSV Stream fields.
4. Troubleshoot using the messages displayed during configuration and/or upon save so that the rules are followed. Saving frequently during configuration helps to deal with issues early.
5. Restart the relay for the changes to take effect.

The table outlines mapping examples using CT channels. VT channels are similar.

| Scenario                                                                                           | AC Bank configuration                                                                                                                    | Advanced Config configuration                                            |
|----------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------|
| No CT signal in the SV stream                                                                      | ---                                                                                                                                      | ---                                                                      |
| One neutral                                                                                        | Neutral Origin 1 = RxSV1-CT1/NTR                                                                                                         | CT1-N maps to AC1                                                        |
| Two neutrals                                                                                       | Neutral Origin 1 = RxSV1-CT1/NTR<br>Neutral Origin 2 = RxSV2-CT2/NTR                                                                     | CT1-N maps to AC1<br>CT2-N maps to AC2                                   |
| Three phases                                                                                       | Phase Origin 1 = RxSV1-CT1/PHS                                                                                                           | CT1-A, B, C map to AC1, 2, 3                                             |
| Three phases followed by one neutral                                                               | Phase Origin 1 = RxSV1-CT1/PHS<br>Neutral Origin 1 = RxSV1-CT1/NTR                                                                       | CT1-A, B, C, N map to AC1, 2, 3, 4                                       |
| One neutral followed by three phases                                                               | Neutral Origin 1 = RxSV1-CT1/NTR<br>Phase Origin 1 = RxSV1-CT2/PHS                                                                       | CT1-N maps to AC1<br>CT2-A, B, C map to AC2, 3, 4                        |
| One neutral followed by three phases, then followed by one neutral                                 | Neutral Origin 1 = RxSV1-CT1/NTR<br>Phase Origin 1 = RxSV1-CT2/PHS<br>Neutral Origin 2 = RxSV2-CT2/NTR                                   | CT1-N maps to AC1<br>CT2-A, B, C, N map to AC2, 3, 4, 5                  |
| Three phases followed by one neutral, then another neutral                                         | Phase Origin 1 = RxSV1-CT1/PHS<br>Neutral Origin 1 = RxSV1-CT1/NTR<br>Neutral Origin 2 = RxSV2-CT2/NTR                                   | CT1-A, B, C, N map to AC1, 2, 3, 4<br>CT2-N maps to AC5                  |
| Two three-phases                                                                                   | Phase Origin 1 = RxSV1-CT1/PHS<br>Phase Origin 2 = RxSV2-CT2/PHS                                                                         | CT1-A, B, C map to AC1, 2, 3<br>CT2-A, B, C map to AC4, 5, 6             |
| Three phases followed by one neutral, then another three phases                                    | Phase Origin 1 = RxSV1-CT1/PHS<br>Neutral Origin 1 = RxSV1-CT1/NTR<br>Phase Origin 2 = RxSV2-CT2/PHS                                     | CT1-A, B, C, N map to AC1, 2, 3, 4<br>CT2-A, B, C map to AC5, 6, 7       |
| Three phases followed by another three phases, then one neutral                                    | Phase Origin 1 = RxSV1-CT1/PHS<br>Phase Origin 2 = RxSV2-CT2/PHS<br>Neutral Origin 2 = RxSV2-CT2/NTR                                     | CT1-A, B, C map to AC1, 2, 3<br>CT2-A, B, C, N map to AC4, 5, 6, 7       |
| Three phases, one neutral, then another three phases and one neutral.<br>See the following figure. | Phase Origin 1 = RxSV1-CT1/PHS<br>Neutral Origin 1 = RxSV1-CT1/NTR<br>Phase Origin 2 = RxSV2-CT2/PHS<br>Neutral Origin 2 = RxSV2-CT2/NTR | CT1-A, B, C, N map to AC1, 2, 3, 4<br>CT2-A, B, C, N map to AC5, 6, 7, 8 |

| SV MESSAGES             |                   |                   |
|-------------------------|-------------------|-------------------|
| Common Setting          |                   |                   |
| RxSV Format             | IEC 61869-9 ed1.0 |                   |
| RxSV Streams            |                   |                   |
|                         | RxSV1             | RxSV2             |
| SV Stream               | Enabled           | Enabled           |
| svID                    |                   |                   |
| Dst MAC                 | 01-0C-CD-04-00-00 | 01-0C-CD-04-00-00 |
| ConfRev                 | 0                 | 0                 |
| Force MU Out Of Service | OFF               | OFF               |
| Stream Status           | -NA-              | -NA-              |
| Advanced Config         |                   |                   |
| MU SCL Import           | Import            | Import            |
| SvCBRef                 |                   |                   |
| CT Channels             | 4                 | 8                 |
| VT Channels             | 4                 | 4                 |
| ASDUs                   | 1                 | 1                 |
| Variant Code            | F4800S1I4U4       | F4800S1I8U4       |
| CT1-A                   | AC1               | AC1               |
| CT1-B                   | AC2               | AC2               |
| CT1-C                   | AC3               | AC3               |
| CT1-N                   | AC4               | AC4               |
| CT2-A                   | None              | AC5               |
| CT2-B                   | None              | AC6               |
| CT2-C                   | None              | AC7               |
| CT2-N                   | None              | AC8               |
| VT1-A                   | AC5               | AC9               |
| VT1-B                   | AC6               | AC10              |
| VT1-C                   | AC7               | AC11              |
| VT1-N                   | AC8               | AC12              |
| VT2-A                   | None              | None              |
| VT2-B                   | None              | None              |
| VT2-C                   | None              | None              |
| < >                     |                   |                   |
| AC BANKS                |                   |                   |
| AC BANKS                |                   |                   |
|                         | B1                | B2                |
| Phase Origin 1          | RxSV1-CT1/PHS     | None              |
| Phase Origin 2          | RxSV2-CT1/PHS     | None              |
| Neutral Origin 1        | RxSV1-CT1/NTR     | None              |
| Neutral Origin 2        | RxSV2-CT2/NTR     | None              |
|                         |                   |                   |
| Crosschecking           | None              | None              |

Figure 199: Example three phases, one neutral, then three phases and one neutral

## 7.6.1 SV STREAM LOGIC




Figure 200: SV stream logic diagram

SV streams are accepted based on the following settings that need to match the MU:

- SmpSynch Check — Time synchronization check as outlined earlier in the General section
- Quality Check — Outlined earlier
- svID — Multicast Sampled Value Identification of a stream
- Dst MAC — Destination Media Access Control address in the header of the SV message
- ConfRev — When the configuration revision is non-zero, the UR accepts the frame when it matches its configured value

The relay decodes an SV stream when the DstMAC attribute of the injected SV stream matches any of the configured SV stream subscriptions.

Each qualified SV stream (that is, with matching svID, Dst MAC, and ConfRev) that is mapped to any of the AC Banks is checked for the SV delay, matching Sim bit, time synchronization source, and quality checks. When four samples in 1/8th of power cycle duration fail any of these checks, a corresponding FlexLogic operand is asserted, with a drop-out timer of one protection pass. The drop-out timer is retriggered each time that the check fails.

The RxSV# Lost FlexLogic operand is set when consecutive 160 samples (two cycles) are lost following the assertion of **SV DELAY ALARM**. The time accuracy for the assertion of this operand can be up to two protection passes.

The RxSV# Off FlexLogic operand is set when the "Miss Sample Algorithm" fails (for example, due to temporary loss of stream or stream rejected due to any condition check failure) or the stream is lost, with a drop-out time of 17 protection passes. Every "Miss Sample Algorithm" fail condition for that RxSV# stream retriggers the drop-out timer for the RxSV# Off operand.

---

## 7.6.2 MESSAGE TROUBLESHOOTING

Examples for messages displayed are as follows:

- The SvID attribute of RxSV1 is empty — Type a name for the stream in the svID field
- The number of channels being selected for CT2-N...exceed the total allowable 7 CT channels — Set the CT2-N field to None, or increase the CT Channels field to 8
- The number of channels being selected for CT inputs...exceeds the total allowable 4 CT channels — The CT Channels field is set at 4 and there are entries in the CT2-A/B/C/N fields. Set the latter fields to None or increase the number of channels.
- The selected 'RxSV3' stream is disabled. Configure stream before assigning to AC Bank Phase Origin — Enable the RxSV3 stream in its SV Stream field
- The AC Bank 2 assigned to Source 1 is not configured — B2 is set in a Source1 field at the bottom of the window. In the AC BANKS area of the window, go to the B2 column, and set one of the fields.
- The AC Bank 2 is a Voltage channel and is assigned to Phase CT of Source 1 — In the Source area of the window, change the B2 assignment from Phase CT to VT
- The AC Bank x assigned...is not configured... — Configure the AC Banks section in the software window before setting the field
- The CT channels set of the selected 'RxSV1-CT1' are not configured — In the Advanced Config section, set the CT fields

---

## 7.6.3 SV QUALITY PROCESSING

- Any degradation in the measurement or sampled value data of the merging unit inhibits the protection functions of the IED. IEC 61850 assigns quality attributes to each sampled value channel, to identify the data validity. The UR Process Bus Module interface uses the quality flags of subscribed analog channels to enable or inhibit the protection functions
- Quality is checked per channel in an ASDU/frame. For example, if A-phase current has invalid quality, but other current channels have good quality, the frames with good quality are still accepted and values are displayed in the metering. However, if any channel in the AC Bank has invalid quality, protection functions using this AC bank are blocked until all four channels have good quality.
- For protection functions to work correctly, q.validity needs to be good. Samples with invalid quality can result in unacceptable behavior from the protection functions. An SV analog quantity with q.validity = invalid is ignored.
- When "Quality Check" is set to 'Accept questionable' data, the data with q.validity = questionable is valid. When "Quality Check" is set to 'Reject questionable' data, the data with q.validity = questionable is ignored.
- When the relay is in-service, or test function is Disabled, the data with q.test set to TRUE is processed as invalid
- When the relay test function is forced or isolated, the data with q.test set to TRUE and q.test set to FALSE is valid.
- If any channel value within a sampled value stream is rejected due to a quality check, the device sets a FlexLogic operand "RxSV# QualChk Fail" for the duration of the quality check failure.



## SV Quality Processing table

| Publisher      | Quality Check Setting | MMXU.DO.mag | MMXU.DO.q |
|----------------|-----------------------|-------------|-----------|
| Offline        |                       | 0           | Invalid   |
| q=Invalid      |                       | 0           | Invalid   |
| q=Questionable | Reject Questionable   | 0           | Invalid   |
| q=Questionable | Accept Questionable   | Mag         | Good      |
| q=good,test    |                       | 0           | Invalid   |

| Combination of input qualities | Desired output quality | Desired output status |
|--------------------------------|------------------------|-----------------------|
| IF all {good}                  | good                   | as calculated         |
| ELSE IF all {invalid}          | invalid                | 0                     |
| ELSE IF one {good} and mag{}   | good                   | as calculated         |

If the AC Src# is not configured with required inputs to calculate a metering value, the validity of the metering value needs to be marked as Invalid. For example, if Ground CT is not configured for a given AC Src#, all metering values derived from the Ground CT input are not calculated and must be assigned Invalid validity.

In case of IED Major Error or Relay Settings is 'Not Programmed' Metering Values are Invalid.

#### 7.6.4 SV SIMULATION PROCESSING

When received SV frames have Sim Bit TRUE, the frame is ignored unless the value of @Master/LPHD1.Sim.stVal is true (@Master/LPHD1.Sim.stVal is true when **Settings > Simulation > Subscribe to Simulated Values > Simulation Mode** is enabled).

When @Master/LPHD1.Sim.stVal is TRUE...

- Once subscribed SV messages with simulation bit TRUE are accepted, subscribed SV messages with simulation bit FALSE are ignored and the received SV messages with the simulation bit TRUE are used in place of the actual SV messages until @Master/LPHD1.Sim.stVal is set to FALSE
- When a SV frame is received with simulation bit TRUE, the FlexLogic operand for the corresponding stream is set as RxSV# SimBit On. After the latest change in simulation bit as recorded by the "Latest Sim Bit Change" time stamp, the relay takes 4 to 8 msec to process and assert the RxSV# SimBit On FlexLogic operand.
- If SV messages with simulation bit TRUE are not received, the RxSV# continues to use the actual SV frames
- When the value of @Master/LPHD1.Sim.stVal changes from TRUE to FALSE
  - Subscribed SV messages with simulation bit TRUE are ignored immediately after this change
  - Only subscribed SV messages with simulation bit FALSE are accepted

#### 7.6.5 SV STREAM SETTINGS

The following settings are available.

##### RxSV Format

*Range: IEC 61850-9-2LE r2-1, IEC 61869-9 ed1.0*

*Default: IEC 61850-9-2LE r2-1*

This setting selects the SV frame format, or protocol.

When set to *IEC 61850-9-2LE r2-1*, the relay assumes that the received SV frame references datasets that comply with IEC 61850-9-2LE, Table 6: Dataset (PhsMeas1). The IED must be configured with a system frequency of 50 or 60 Hz for correct operation.

When set to *IEC 61869-9 ed1.0*, the relay assumes that the dataset rules comply with IEC 61869-9 ed1.0 and that the number of Application-layer Service Data Units (ASDUs) are user-configurable.

**Note:**

When a file using a single SV stream (either IEC 61850-9-2LE r2-1 or IEC 61869-9 ed1.0) is converted from firmware version 8.2x and below to firmware versions 8.3x and above, the conversion will complete with no errors and the RxSV Format setting will have the same value as the original file. If there is a mix of SV streams in the original file, then the user will be notified of this error and all configured SV streams will be set to the SV Stream default; "Disabled". The RxSV Format setting will also default to "IEC 61850-9-2LE r2-1"

## SV Stream

- Range: Disabled, Enabled
- Default: Disabled

This setting enables an SV stream. When disabled, all other **RxSV** settings are not editable and set to default.

## svID

- Range: 1 up to 129 Visible String characters
- Default: empty string

svID refers to the name of the sampled value packet. The svID field of incoming SV messages must exactly match this value for the message to be accepted as a valid RxSV# message. The svID field of the sampled value frame must be unique within the system/substation.

## Dst MAC

- Range: any valid multicast MAC (12-digit hexadecimal number)
- Default: 01-0C-CD-04-00-00

Only received SV messages having a destination Media Access Control (MAC) address equal to this value are accepted as valid RxSV# messages. Each address must be unique. The destination MAC increases the overall performance of multicast message reception by filtering only the configured messages for processing. For a received SV message, the Dst MAC is validated if it matches with any of the configured RxSV# Dst MAC. If validation is successful, the message is forwarded for further checks. There is no explicit check for the configured Dst MAC versus the SvID for a received SV message.

## ConfRev


- Range: 0 to 2147483647 in steps of 1
- Default: 0

ConfRev refers to configuration revision, which is a count of configuration changes in the SV control block. If the value entered here is non-zero, the ConfRev field of incoming SV messages must match this value for the message to be accepted as a valid RxSV# message. If the setting is zero, RxSV# does not check the value received in the ConfRev field.

## Force MU Out of Service

- Range: FlexLogic operand
- Default: Off

This setting is intended specifically for forcing a faulty Merging Unit (MU) out of service in applications where a circuit can be energized from more than one side, such as breaker and a half application, and the redundancy at MU level is not available. For such application current from both sides are summed up using UR source mechanism and if one MU fails, it will block all protection functions from using this source.



842839A1.cdr

**Figure 201: Forcing MU1 out of service for a Breaker-and-a-half configuration**

For example, in the above figure it is possible to open Breaker1 and still keep the system energized through Breaker 2. The setting **FORCE MU OUT OF SERVICE** allows MU1 to be taken out of service while keeping the protection and control elements operational by using the RxSV stream from MU2 only. If redundancy is available at MU level, then the protection can be kept operational without using setting **FORCE MU OUT OF SERVICE**, through the Cross-checking functionality. Please refer to the description of settings **CROSS-CHECKING**, **PHASE ORIGIN 1**, **2** and **NEUTRAL ORIGIN 1**, **2** for more details.

To put an MU out of service, the corresponding breaker has to be opened before asserting the FlexLogic selected in the setting **FORCE MU OUT OF SERVICE** to the *ON* state. The MU can now be disconnected for troubleshooting purposes. The current channels from the affected MU will be treated as online with sampled current values forced to ZEROs. The protection using respective source remains operational based on the current values sent by the other MU which is located on the closed breaker side.

Note that:

- Keeping RxSV online (with current substituted as ZEROs) is applicable to current channels only. The status of voltage channels will become Offline, and the protection elements will get blocked according to the setting **SV TRBL PRT BLOCK**.
- The FlexLogic operands on the SV Config logic show the actual state of the affected the RxSV stream (i.e., RxSV# Off/On), irrespective of setting **FORCE MU OUT OF SERVICE** being Off or On.

You must ensure that the primary circuit to which the affected MU is connected remains de-energized for the entire duration of forcing MU out of service, otherwise the protection elements will mal-operate. The circuit should be de-energized before changing the setting **FORCE MU OUT OF SERVICE** to *On*. The circuit should be energized only after the setting **FORCE MU OUT OF SERVICE** is set to *Off*.

SV stream processing FlexLogic operands must not be used to automate **FORCE MU OUT OF SERVICE**. We strongly recommend that **FORCE MU OUT OF SERVICE** is manually controlled (for example, through a pushbutton, contact input, virtual input, or GOOSE).

The setting **FORCE MU OUT OF SERVICE** is intended for applications where a breaker can be opened, and the corresponding MU can be taken out of service while the circuit is energized through another breaker such as in breaker-and-a-half application. For any other application, the use of this setting should be carefully evaluated.

We do not recommend using the setting **FORCE MU OUT OF SERVICE** together with the cross-checking function.

## Stream Status

This is an LED status indicator for the reception of an SV stream (RxSV#). A green LED reflects the RxSV# On FlexLogic operand, meaning that the SV stream is online. A red LED reflects the RxSV# Off FlexLogic operand, meaning that the SV stream is offline. When the EnerVista UR Setup software is not online or the stream is disabled, the LED is grayed-out with Not Available, or “-NA-” status.


## Advanced Configuration

Click the button to display or hide the fields.

These are settings to import an MU CID file and/or support IEC 61869-9 based SV streams, as per Table 902 on Standard sample rates. IEC 61869-9 allows flexibility on numbers of current and voltage channels. It can be in one of these sequences: A, B, C, N or A, AB, B, BC, C, CA, N. The UR supports up to eight CT channels and up to eight VT channels and one or two ASDUs for protection applications. The following settings are active when the SV Stream field is set to IEC 61869-9, and they also depend on the MU Variant Code.

## MU SCL Import

Use this feature to configure SV streams by importing an MU CID file. The setting file comparison with IEC 61869-9-2LE configuration is not available. The IEC 61850 Merge feature with IEC 61869-9-2LE is not available. Upon clicking the Import button and selecting a .cid file, a window appears from which to select the stream to import.



**Figure 202: Selecting a stream to import from a merging unit CID file**

Rules for accepting a CID file include:

- The same remote channel cannot be mapped to more than one AC bank channel
- An AC bank channel cannot be mapped to more than one remote channel
- For each AC bank, there are three phase inputs from the same SV control block and all three inputs are configured
- Phase 1 and Phase 2 inputs are not from the same SV control block
- Phase 1 and Phase 2 aux inputs are not from the same SV control block
- A configured Phase consumes three analog channels and Aux consumes one analog channel, with a maximum of 24 channels

## SvCBRef

- *Range: 0 up to 129 alphanumeric, underscore, slash, and period characters, beginning with an alpha character*
- *Default: empty string*

This field is read-only. When imported, the MU SCL file populates this field. The value is an ObjectReference to the publishing control block in the format:

- <LDName>/LLN0.<SvCBName>

where <LDName> is the function-related name, if any, of the logical device containing the publishing control block, otherwise the product-related name of that logical device, and <SvCBName> is the name of the publishing control block.

When RxSV# is configured manually, the field is empty.

### CT Channels

- Range: 0 to 8
- Default: 4

This setting specifies the number of CT channels available in the subscribed RxSV# message from the publisher MU. The CT-1 fields reflect the number selected here. The number of current quantities matches the number specified by the Variant Code of the MU.

Typically, a CT channel includes four current channels (three phase-ground currents and one ground/neutral/earth current). A current channel is the combination of the current sample value attribute (AmpSv.instMag.i) and the subsequent quality attribute (AmpSv.q).

If CT Channels is 4, CT1-A/B/C/N are supported for the stream.

If CT Channels is 8, CT2-A/B/C/N also are supported for the stream.

If CT Channels is 0, no CT channels display for AC input selection.

This setting is read-only and fixed at 4 when an **SV Stream** is set to IEC 61850-9-2LE.

If a message displays that *the number of channels being selected for CT inputs...exceeds the total allowable 4 CT channels*, this means that the CT Channels field is set at 4 and there are entries in the CT2-A/B/C/N fields. Set the latter fields to None or increase the number of channels.

### VT Channels

- Range: 0 to 8
- Default: 4

This setting specifies the number of VT channels in the subscribed RxSV# message from the publisher MU.

Typically, VT channels include four voltage channels (three phase-ground voltages and auxiliary voltage). This setting specifies the number of voltage channels in the subscribed RxSV# message. The voltage channel is the combination of voltage sample value attribute (VolSv.instMag.i) and the corresponding quality attribute (VolSv.q). The VT-1 fields reflect the number selected here. The number of voltage quantities matches the number specified by the Variant Code of the dataset.

If VT Channels is 4, VT1-A/B/C/N are supported for the stream.

If VT Channels is 8, VT2-A/B/C/ also are supported for the stream.

If VT Channels is 0, no VT channels display for AC input selection.

This setting is read-only and fixed at 4 when an **SV Stream** is set to IEC 61850-9-2LE.

If a message displays that *"the number of channels being selected for CT inputs...exceeds the total allowable 2 VT"*, this means that the VT Channels field is set at 2 and there are more than two entries in the VT1-A/B/C/N fields. The number of configured VT1 fields needs to match the VT Channels field.

### ASDUs

- Range: 1, 2
- Default: 1

This setting specifies the number of Application-layer Service Data Units (ASDUs) concatenated in one Application Protocol Data Unit (APDU) in the subscribed RxSV# message. When concatenating several ASDUs into one frame, the ASDU with the oldest samples is the first one in the frame. This setting is read-only and set at the default when an SV Stream is set to IEC 61850-9-2LE.

Recycle power to the relay when changing this setting.

### Variant Code

The EnerVista software auto-populates the Variant Code for the RxSV# message based on the settings Sample Rate, the number of ASDUs, the number of CT Channels, and the number of VT Channels configured.

For example, F4800S2I8U0 describes sampled values with 4800 samples per second, two ASDU (samples) per message, 8 currents, and no voltages.

As another example, F4800S1I8U4 means sampled values with 4800 samples per second, 1 ASDU per message, 8 CT channels, and 4 VT channels.

This field is read-only as per IEC 61869-9: 2016, Clause-6.903.2.

The number of samples (sample rate) in the variant code is set based on the **SETTINGS > SYSTEM SETUP > POWER SYSTEM > NOMINAL FREQUENCY** setting. This value displays *4000 Hz* for 50 Hz nominal frequency. This value displays *4800 Hz* for 60 Hz nominal frequency or any other nominal frequency except 50 Hz. IEC 61869-9 suggests the 4800 Hz sample rate for general measuring and protective applications, regardless of the power system frequency.

### CT1-A/B/C

- *Range: None, AC1 to AC16*
- *Default: AC1/AC2/AC3*

This setting specifies the sequence of Analog Channel (per phase) that is mapped to the CT-1 of the corresponding stream. An origin to CT Phase input defines the physical measurement input to the CT bank by mapping specific AC inputs from that merging unit (or SV message).

The fields are active when the **SV Stream** field is set to IEC 61869-9. The CT1 phases are available if the number of **CT Channels** is 4 or below. CT2 is added if **CT Channels** is 5 or higher.

The fields are set to the defaults and are read-only when the **SV Stream** field is set to IEC 61850-9-2LE.

### CT1- N

- *Range: None, AC1 to AC16*
- *Default: AC4*

This setting specifies the Analog Channel that is mapped to the CT ground/neutral input. An origin to CT1-N input defines the physical measurement input to the CT bank by mapping specific AC inputs from that MU (or SV message). If the MU does not publish any CT1-N inputs, configure the setting as None.

In the EnerVista software, the CT Aux input setting only populates the current channels of that RxSV#.

This CT Aux input setting is active when the **SV Stream** field is set to IEC 61869-9.

This CT Aux input setting is set to AC4 and is read-only when the **SV Stream** is set to IEC 61850-9-2LE.

### VT1-A/B/C

- *Range: None, AC1 to AC16*
- *Default: AC5/AC6/AC7*

This setting specifies the Analog Channel (per phase) that is mapped to the VT1- phase inputs. An origin to VT Phase input defines the physical measurement input to the VT bank by mapping specific AC inputs from that MU (or SV message). If the MU does not publish any VT channels, configure the setting as None.

The VT1 phase fields are active when the **SV Stream** field is set to IEC 61869-9. The VT1 phases are available if the number of **VT Channels** is 4 or below. VT2 is added if **VT Channels** is 5 or higher.

The fields are set to the defaults and are read-only when the **SV Stream** field is set to IEC 61850-9-2LE.

### VT1-N

- *Range: None, AC1 to AC16*
- *Default: AC8*

This setting specifies the Analog Channel that is mapped to the VT Aux/neutral input. An origin to VT input defines the physical measurement input to the VT bank by mapping specific AC inputs from that MU (or SV message). If the MU does not publish any VT1-N inputs, configure the setting as None.

In the EnerVista software, the VT Aux input setting only populates the voltage channels of that RxSV#.

The VT1-N input setting is active when the **SV Stream** field is set to IEC 61869-9.

The VT1-N input setting is set to the default and is read-only when the SV Stream field is set to IEC 61850-9-2LE.

### AC BANKS

The UR platform supports up to six AC Banks. They can be CT or VT banks (similar to **SETTINGS > SYSTEM SETUP > AC INPUTS > CURRENT/VOLTAGE BANK**). That is, each AC Bank can be configured either as current or voltage (not both). If configured as current, inapplicable voltage settings (such as VT ratio, VT secondary) are inactive. Similarly, if a bank is configured as voltage, current settings (such as CT primary, CT secondary) are inactive. In addition, bank level redundancy (that is, Origin-1 and Origin-2) is supported using crosschecking of each channel signal received from two different SV streams that are connected to the same electrical point on the primary power system. A maximum 24 channels can be configured to the AC Banks.

Click the button to display or hide the fields.

The following settings are available for each AC bank.

Each Phase Origin setting consumes three phase channels Ia/Va, Ib/Vb, or Ic/Vc, and a Neutral Origin setting consumes one ground or Aux Channel In/Vn, which means that

- An AC Bank with Phase Origin1 and Neutral Origin1 settings configured consumes four channels
- An AC Bank with both Phase Origin 1 and Phase Origin 2 and both Neutral Origin 1 and Neutral Origin 2 settings configured consumes eight channels

A maximum of 24 channels can be configured to the AC Banks.

For changes in this section, restart the relay, for example using **Maintenance > Reboot Relay Command**.

### Phase Origin 1, 2

- *Range: None, RxSV1-CT1/PHS, RxSV1-VT1/PHS to RxSV8-CT1/PHS, RxSV8-VT1/PHS*
- *Default: None*

An origin to an AC bank defines the physical measurement input to the bank by mapping specific AC inputs from a specific MU to the bank.

The UR Process Bus Module provides for the reliability of AC values for protection, metering, and oscillography by allowing duplicate origins of AC data. An origin is considered unavailable when set to None. If origin 1 is available, the relay uses the values from origin 1 for protection, metering, and oscillography. Otherwise if origin 2 is available, the relay uses the values from origin 2. If both origins are unavailable, then the bank AC values are forced to zero to prevent ambiguity of measurement.

With crosschecking, the relay can use different origins. See the **Crosschecking** setting for information regarding automatic protection blocking possibilities on loss of one or both origins.

The two-phase origins in an AC bank must be of the same type and connected to the same electrical point in the primary power system. The two origins must be two currents with the same CT settings, or two voltages with the same VT settings. The current/voltage type of the phase and auxiliary origins must also match on each AC bank. It



is intended that the origin AC inputs measure the same primary quantity with the same ratio. The same ratio and connection settings are applied to both origins.

### Neutral Origin 1, 2

- *Range: None, RxSV1-CT1/NTR, RxSV1-VT1/ NTR to RxSV8-CT1/NTR, RxSV8-VT1/ NTR*
- *Default: None*

These settings specify the field units that are the origins of the auxiliary input IN or VN. Duplicate auxiliary origins are supported in the same way as phase origins.

The two auxiliary origins in an AC bank must be of the same type. The two origins must be two currents with the same CT secondary setting, or two voltages. The current/voltage type of the phase and auxiliary origins also must match on each AC bank. It is intended that the origin AC inputs measure the same primary quantity with the same ratio. The same ratio and connection settings are applied to both origins.

### Crosschecking

- *Range: None, Depend Origin-1 Pref, Depend Origin-2 Pref*
- *Default: None*

The crosschecking feature allows application-level redundancy by checking between two independent SV streams from the same electrical connection of the instrument transformers. In addition to the network redundancy provided by PRP/HSR, the UR Process Bus Module allows the relay to communicate with redundant merging units.

When set to None, crosschecking is disabled. Use this on a non-protection-critical AC bank, such as one used for a synchrocheck voltage. GE strongly recommends setting it to None when redundancy is not supported at the merging unit level; otherwise the "ACBank# Orig1(2) In Use" operand status is inaccurate.

Origin preference is supported in case of discrepancy in dependability mode. This allows testing (secondary injection) or replacement of an MU that is configured to non-preferred origin without affecting protection functions since these functions are using a preferred origin stream when online. As such, dependability with Origin-1 preference allows continued use of Origin-1 in case of discrepancy between both online origin stream sampled values. Similarly, dependability with Origin-2 preference allows continued use of Origin-2 in case of discrepancy between both online origin stream sampled values.

The table shows how the Crosschecking setting, the availability of AC bank origins, and discrepancy checks determine whether protection is blocked. Blocked here means only protection elements. It does not inhibit metering, actual values, oscillography, or other functions.

When set to Depend Origin-1 Pref, protection is blocked if there is no good signal from both the Origin-1 and Origin-2 sources. When both the merging unit sources are good, the preference is given always for Origin-1. When the preferred MU sources fails, the alternate MU source is used for protection and measurement.

When set to Depend Origin-2 Pref, protection is blocked if there is no good signal from both the Origin-1 and Origin-2 sources. When both the merging unit sources are good, the preference is given always for Origin-2. When the preferred MU sources fails, the alternate MU source is used for protection and measurement.

**Note:**

*While switching from a preferred to non-preferred channel, the protection functions are delayed for two cycles. While switching back to a preferred channel, the protection functions are delayed for one cycle.*

### Crosschecking and protection behavior

| Crosschecking setting | Origin-1 RxSV stream status | Origin-2 RxSV stream status | Discrepancy check | Protection operation |
|-----------------------|-----------------------------|-----------------------------|-------------------|----------------------|
| None                  | Not relevant                | Not relevant                | No check          | Normal               |



|                      |            |            |                 |                              |
|----------------------|------------|------------|-----------------|------------------------------|
| Depend Origin-1 Pref | Not mapped | Not mapped | No check        | Normal                       |
|                      | Online     | Online     | OK / discrepant | Normal using Origin-1 stream |
|                      | Online     | Offline    | No check        | Normal using Origin-1 stream |
|                      | Offline    | Online     | No check        | Normal using Origin-2 stream |
|                      | Offline    | Offline    | No check        | Blocked                      |
| Depend Origin-2 Pref | Not mapped | Not mapped | No check        | Normal                       |
|                      | Online     | Online     | OK / discrepant | Normal using Origin-2 stream |
|                      | Online     | Offline    | No check        | Normal using Origin-1 stream |
|                      | Offline    | Online     | No check        | Normal using Origin-2 stream |
|                      | Offline    | Offline    | No check        | Blocked                      |

Origin1 becomes offline and switches to Origin2 for the following reasons:

- When more than three of five frame samples received are invalid or a frame with sequence number is received after three consecutive missed frames for any channel of origin. The reason for invalid frames can be any of the following reasons:
  - If one or more AmpSv.q or VolSv.q attribute(s) are invalid from the assigned SV frame channels to the AC bank origin
  - When “Quality Check” is set to ‘Reject questionable’ data, the data with q.validity = questionable is processed as invalid
  - When the relay is in-service or the test function is Disabled, the SV data with q.test set to TRUE is processed invalid
  - When received SV frames with Sim Bit TRUE, the frame is invalid unless the value of @Master/LPHD1.Sim.stVal is true (that is Settings > Simulation > GOOSE/SV > Accept Sim GOOSE&SV or Settings > Simulation > Subscribe to Simulated Values > Simulation Mode is set to Enabled)
  - If the value of @Master/LPHD1.Sim.stVal is TRUE, once a subscribed SV messages with simulation bit TRUE are received, subscribed SV messages with simulation bit FALSE are invalid until @Master/LPHD1.Sim.stVal is set to FALSE
  - SV streams with “SmpSync” value out of the following specified ranges are rejected:
    - i. When the “SmpSynch Check” is set to “Global” (2), SV streams with “SmpSynch” value set to Global (2) are accepted
    - ii. When the “SmpSynch Check” is set to “Local” (1), SV streams with “SmpSynch” value set to Global (2) or Local (1) are accepted
    - iii. When the “SmpSynch Check” is set to “Any” (0 to 254), SV streams with “SmpSynch” value set in the range of 0 to 254 are accepted. For 7.80 version, the accepted range is 0 to 127.
- SV frames are delayed/not received for more than 1.9 power system cycles

The selected Origin quality will be the quality of the AC Bank.

If both Origins have invalid quality, then the AC Bank data is marked as invalid and does not participate in protection.

### Phase/Ground CT Primary

- Range: 1 to 65000 A insteps of 1
- Default: 1

Enter the rated CT primary current value in Amperes. For 1000:5 and 1000:1 CTs, enter 1000.

### Phase/Ground CT Secondary

- Range: 1A, 5A
- Default: 1A

Enter the rated CT secondary current value in Amperes. For correct operation, the CT secondary rating must match the setting (that must also correspond to the specific CT connections used).

### Phase CT Polarity

- *Range: Standard, Inverted-3ph, Inverted Ph-A, Inverted Ph-B, Inverted Ph-C*
- *Default: Standard*

If CTs are wired with the correct polarity in all phases, i.e. CT polarity reversal is not required, "Standard" should be selected. If CT polarity is incorrect in just one phase, then select "Inverted Ph-A (B or C)"; choosing the affected phase. If CT polarities of all three phases are incorrect, select "Inverted-3Ph" to correct the CT polarities for all three phases. It should be noted that the oscillography record will capture the CTs current signal as applied to the relay terminal irrespective of this setting. This ensures correct relay behavior when recorded oscillography is played back to the relay.

### Ground CT Polarity

Range: Standard, Inverted

Default: Standard

If the ground CT is wired with the correct polarity, select "Standard" for this setting. If the Ground CT polarity is incorrect, then select "Inverted" to correct it. It should be noted that the oscillography record will capture ground CT current signal as applied to the relay terminal irrespective of this setting. This ensures the correct relay behavior when recorded oscillography is played back to the relay.

It is important that the settings **PHASE CT POLARITY** and **GROUND CT POLARITY** are set to the correct values before putting the relay into operation. Selecting the wrong value or changing this setting whilst relay is in operation would result in undesirable operation of the protection and control functions.

If you intend to use the crosschecking functionality (redundancy at MU level), then this setting should be used carefully to ensure that CT Polarity is the same on both MUs on each phase/neutral channel.

### SIGNAL SOURCES

Click the button to display or hide the fields. The first six Sources are the platform sources and can accept both current banks and voltage banks and are associated with AC bank 1 to 6. The first six sources allow current summation for phase and auxiliary CTs.

Recycle power to the relay when changing a source.

#### Name

- *Range: up to 20 alphanumeric characters*
- *Default: SRC 1*

This setting specifies an alphanumeric name for the source.

#### Phase CT

- *Range: None, B1, B2, B3, B4, B5, B6, B1+B2, ... B1+B2+B3+B4+B5+B6 or B7...B28*
- *Default: None*

This setting selects the phase CTs of an AC bank or the sum of the phase CTs of multiple AC banks to be the phase current of the source. That is, it select the AC Banks section above in the window.

If you see the message "the AC Bank x assigned...is not configured..," it means that you need to configure the AC Banks section in the software window before setting this field. The AC Bank selected can match the Origins fields and Sources, such as a Phase CT set at B1 with Phase Origin 1 RxSV1-CT1/PHS and source SRC1. Another example is to use Phase CT set at B2 with Phase Origin 1 RxSV2-CT1/PHS and source SRC2.

**Ground CT**

- *Range: None, B1, B2, B3, B4, B5, B6, B1+B2, ... B1+B2+B3+B4+B5+B6 or B7...B28*
- *Default: None*

This setting selects the ground CTs of an AC bank or the sum of the ground CTs of multiple AC banks to be the ground current of the source. That is, it selects the AC Banks section above in the window.

**Phase VT**

- *Range: None, B1, B2, B3, B4, B5, B6*
- *Default: None*

This setting selects the phase VTs of an AC bank to be the phase voltages of the source.

**Alt Phase CT**

- *Range: None, B1, B2, B3, B4, B5, B6, B1+B2, ... B1+B2+B3+B4+B5+B6 or B7...B28*
- *Default: None*

This setting is for switching between main and alternate sources. It selects the alternate phase CTs of an AC bank or the sum of the phase CTs of multiple AC banks to be the phase current of the source.

**Alt Ground CT**

- *Range: None, B1, B2, B3, B4, B5, B6, B1+B2, ... B1+B2+B3+B4+B5+B6 or B7...B28*
- *Default: None*

This setting is for switching between main and alternate sources. It selects the ground CTs of an AC bank or the sum of the ground CTs of multiple AC banks to be the ground current of the source.

**Switch Alt CT**

- *Range: FlexLogic operand*
- *Default: Off*

This setting is for switching the alternate source on or off.

**Alt Phase VT**

- *Range: None, B1, B2, B3, B4, B5, B6*
- *Default: None*

This setting is for switching between main and alternate sources. It selects the phase VTs of an AC bank to be the phase voltages of the source.

**Alt Aux VT**

- *Range: None, B1, B2, B3, B4, B5, B6*
- *Default: None*

This setting is for switching between main and alternate sources. It selects the auxiliary VT input of an AC bank to be the auxiliary voltage of the source.


**Switch Alt VT**

- *Range: FlexLogic operand*
- *Default: Off*

This setting is for switching the alternate source on or off.

## 7.7 REMOTE RESOURCES CONFIGURATION

When the relay is ordered with a process card module as a part of HardFiber system, an additional **Remote Resources** menu tree is available in the EnerVista software to allow configuration of the HardFiber system.



**Figure 203: Remote Resources configuration menu**

The remote resources settings configure a Product with a Process Bus Module to work with HardFiber Bricks. Remote resources configuration is only available through the EnerVista software, and is not available through the Product front panel. A Brick provides eight AC measurements, along with contact inputs, DC analog inputs, and contact outputs, to be the remote interface to field equipment such as circuit breakers and transformers. The Product with a Process Bus Module has access to all of the capabilities of up to eight Bricks. Remote resources settings configure the point-to-point connection between specific fiber optic ports on the Product process card and specific Brick. The relay is then configured to measure specific currents, voltages and contact inputs from those Bricks, and to control specific outputs.

The configuration process for remote resources is straightforward and consists of the following steps.

- Configure the field units. This establishes the point-to-point connection between a specific port on the relay Process Bus Module, and a specific digital core on a specific Brick. This is a necessary first step in configuring a process bus relay.
- Configure the AC banks. This sets the primary and secondary quantities and connections for currents and voltages. AC bank configuration also provides a provision for redundant measurements for currents and voltages, a powerful reliability improvement possible with process bus.
- Configure signal sources. This functionality of the Product has not changed other than the requirement to use currents and voltages established by AC bank configuration under the remote resources menu.
- Configure field contact inputs, field contact outputs, RTDs, and transducers as required for the application's functionality. These inputs and outputs are the physical interface to circuit breakers, transformers, and other equipment. They replace the traditional contact inputs and outputs located at the relay to virtually eliminate copper wiring.
- Configure shared inputs and outputs as required for the application's functionality. Shared inputs and outputs are distinct binary channels that provide high-speed protection quality signaling between relays through a Brick.

For additional information on how to configure a relay with a Process Bus Module, see the HardFiber Process Bus System Instruction Manual.

## CHAPTER 8

# SETTINGS

---

## 8.1 CHAPTER OVERVIEW

---

This chapter contains the following sections:

|                           |     |
|---------------------------|-----|
| Chapter Overview          | 346 |
| Overview                  | 347 |
| Settings menu             | 351 |
| Product setup             | 355 |
| System setup              | 422 |
| FlexLogic settings        | 491 |
| Grouped elements          | 501 |
| Control elements          | 584 |
| Monitoring elements       | 619 |
| Inputs/outputs            | 627 |
| Transducer inputs/outputs | 643 |
| Testing                   | 650 |
| Simulation                | 656 |
| Process Bus Settings      | 660 |
| SV stream settings        | 666 |

## 8.2 OVERVIEW

This chapter describes the relay's settings shown on the front panel display.

You can view settings remotely in a web browser by

1. Entering the IP address of the relay
2. Accessing the **Device Information Menu** option
3. Selecting the **Front-Panel Display Report** option.

When a restart is required for a setting change to take effect, use the **Maintenance > Reboot Relay** command in the software.

Settings file conversion from previous firmware versions is supported. This is described in the Maintenance chapter.

*Note:*

*The relay is not taken out of service when saving settings, but it is taken out of service when a settings file is written to it.*

### 8.2.1 INTRODUCTION TO ELEMENTS

The term *element* is used to describe a feature that is based around a comparator. The comparator is provided with an input (or set of inputs), which is tested against a programmed setting (or group of settings) to determine if the input is within the defined range. A logic output is set according to the result. The logic output is sometimes referred to as a *flag*. A single comparator can make multiple tests and provide multiple outputs. For example, the *time overcurrent* comparator sets a pickup flag when the current input is above the setting and sets an operate flag when the input current has been at a level above the pickup setting for the time specified by the time-current curve settings. All analog comparators use analog actual values as the input.

Elements are arranged into two classes, grouped and control. Each element classed as a grouped element is provided with six alternate sets of settings, in setting groups numbered 1 through 6. The performance of a grouped element is defined by the setting group that is active at a given time. The performance of a control element is independent of the selected active setting group.

The main characteristics of an element are shown on a logic diagram. This includes the inputs, settings, fixed logic, and the output operands generated.

Some settings are common to many elements, outlined as follows:

- **FUNCTION** setting — This setting programs the element to operate when selected as *Enabled*. The factory default is *Disabled*. Once *Enabled*, any element associated with the function becomes active and all options become available.
- **NAME** setting — This setting is used to uniquely identify the element.
- **SOURCE** setting — This setting is used to select the AC source to be monitored. See the Introduction to AC Sources section later.
- **PICKUP** setting — For simple elements, this setting is used to program the level of the measured parameter above or below which the pickup state is established. In more complex elements, a set of settings can be provided to define the range of the measured parameters that cause the element to pick up.
- **PICKUP DELAY** setting — This setting sets a time-delay-on-pickup, or on-delay, for the duration between the pickup and operate output states.
- **RESET DELAY** setting — This setting is used to set a time-delay-on-dropout, or off-delay, for the duration between the operate output state and the return to logic 0 after the input transits outside the defined pickup range.
- **BLOCK** setting — The default output operand state of all comparators is a logic 0 or '*flag not set*'. The comparator remains in this default state until a logic 1 is asserted at the RUN input, allowing the test to be performed. If the RUN input changes to logic 0 at any time, the comparator returns to the default state. The

RUN input is used to supervise the comparator. The BLOCK input is used as one of the inputs to RUN control.

- **TARGET** setting — This setting is used to define the operation of an element target message. When set to *Disabled*, no target message or illumination of a front panel LED indicator is issued upon operation of the element. When set to *Self-Reset*, the target message and LED indication follow the operate state of the element and self-resets once the operate element condition clears. When set to *Latched*, the target message and LED indication remains visible after the element output returns to logic 0 until a **RESET** command is received by the relay.
- **EVENTS** setting — This setting is used to control whether the pickup, dropout, or operate states are recorded by the event recorder. When set to *Disabled*, element pickup, dropout, or operate are not recorded as events. When set to *Enabled*, events are created for:
  - <Element> PKP (pickup)
  - <Element> DPO (dropout)
  - <Element> OP (operate)

The DPO event is created when the measure and decide comparator output transits from the pickup state (logic 1) to the dropout state (logic 0). This can happen when the element is in the operate state if the reset delay time is not zero.

Not every operand of a given element in a UR relay generates events, only the major output operands. Elements, asserting output per phase, log operating phase output only, without asserting the common three-phase operand event.

## 8.2.2 BASE QUANTITIES

Some settings are specified in per-unit (pu) calculated quantities, where  $pu\ quantity = (actual\ quantity) / (base\ quantity)$

Where the current source is from a single current transformer (CT), the base quantity is the *nominal* secondary or primary current of the CT. Use the secondary current base to convert pu settings to/from a secondary current value, and use the primary current base to convert pu settings to/from a primary current value.

Where the current source is the sum of two or more CTs with different nominal primary currents, the primary base quantity is the largest nominal primary current.

For example, if  $CT1 = 300 / 5\ A$  and  $CT2 = 100 / 1\ A$ , then the base quantity is 300 A primary, 5 A secondary per CT. The CT2 current is scaled to the CT1 base quantity. If 5A is injected into the CT1 secondary and 1A is injected into the 1A CT2 secondary windings, with both currents in-phase, the sum of CT1 and CT2 is measured as

$$[5A + 1A * (100/1) / (300/5)] * 300/5 = 400.00A\ primary\ or\ 400.00A / 300A = 1.333pu$$

Where the current source is the sum of two or more CTs with same nominal primary current but different secondary current, the first bank in the summation defines the secondary current base (for example in the F1+M1 sum, the F1 secondary nominal value defines the base).

For voltage elements in delta-connected VTs, the primary base quantity is the nominal phase-to-phase primary voltage of the protected system provided that the following two conditions are satisfied:

- The VT ratio setting is set to the nominal ratio of the VTs
- The secondary voltage setting is set to the phase-to-phase voltage seen by the relay

For example, on a system with a 13.8 kV nominal primary voltage, the base quantity is 13800 V. With 14400:120 V delta-connected VTs, the secondary base quantity and secondary voltage setting is:

$$(13800/14400) \times 120 = 115V$$

For wye-connected VTs, the primary and secondary base quantities are the phase-to-ground primary voltage of the protected system, provided that the VT ratio setting is set to the nominal ratio of the VTs and the secondary voltage setting PHASE VT x SECONDARY is set to the phase-to-ground voltage seen by the relay when the voltage of the protected system is nominal. For the same system with a 13.8 kV nominal primary voltage and same VTs as above, the secondary voltage setting (here a phase-to-ground value) is:



$$(13800/14400) \times (120/\sqrt{3}) = 66.4V$$

### 8.2.3 INTRODUCTION TO AC SOURCES

A mechanism called a Source creates a group of CT and VT input channels to be used by one or more protection and control elements. Sources, in the context of UR series relays, refer to the logical grouping of current and voltage signals such that one source contains all the signals required to measure the load or fault in a particular power system. A given source can contain some, or all, of the following signals:

- Three-phase currents
- Single-phase ground current
- Three-phase voltages
- An auxiliary voltage from a single VT for checking for synchronism.

For example, a line protection system having distance protection, phase and ground overcurrent protection supervised by a directional element, and breaker failure protection, can use a single source (SRC 1) shown in the table below. For some functions, two sources are needed. For example, for the synchrocheck function, voltage across the breaker needs to be measured, therefore both SRC1 with a phase voltage and source SRC 2 with an auxiliary voltage are needed.

Two AC sources are provided for each DSP module in UR relays. In relays with two DSP modules, four AC sources are provided. In relays with three DSP modules, six AC sources are provided.

| Parameter | Source 1 | Source 2 |
|-----------|----------|----------|
| Name      | SRC 1    | SRC 2    |
| Phase CT  | F1       | None     |
| Ground CT | F1       | None     |
| Phase VT  | F5       | None     |
| Aux VT    | None     | F5       |

Another important feature of the UR source is the ability to sum currents internally. In conventional analog or electronic relays, the sum of the currents is obtained from an external electrical connection of all CTs, through which any portion of the current for the element being protected can flow. In this case, auxiliary interposing CTs are needed to perform ratio matching, if the ratios of the primary CTs to be summed are not identical. In the UR series of relays, all the current signals are input to the UR device individually, where grouping, ratio correction, and summation are calculated internally with the help of configuration settings.

A major advantage of using internal summation is that the individual currents are still available to the protection device along with a summed current. For example, in a breaker-and-a-half configuration, CT current summed from both breakers is used for the line distance and overcurrent protection, while still being available as individual currents, for breaker failure protection for both breakers.

The internal grouping of current and voltage signals forms an AC source. This source can be given a specific name through the settings and becomes available to protection and metering elements. Individual names can be given to each source to help identify them for later use.

Once the sources have been configured, you have them available as selections for the choice of input signal for the protection elements and as metered quantities.

### 8.2.4 CT/VT CONFIGURATION

Current transformer (CT) and voltage transformer (VT) input channels are contained in CT/VT modules. The type of input channel can be phase/neutral/other voltage, phase/ground current, or sensitive ground current. The CT/VT modules calculate total waveform RMS levels, fundamental frequency phasors, symmetrical components, and harmonics for voltage or current, as allowed by the hardware in each channel. These modules can calculate other parameters as directed by the CPU module.

A CT/VT module contains up to eight input channels, numbered 1 through 8. The channel numbering corresponds to the module terminal numbering 1 through 8 and is arranged as follows. Channels 1, 2, 3, and 4 are always provided as a group, hereafter called a “bank,” and all four are either current or voltage, as are channels 5, 6, 7, and 8. Channels 1, 2, 3 and 5, 6, 7 are arranged as phase A, B, and C respectively. Channels 4 and 8 are either another current or voltage.

Banks are ordered sequentially from the block of lower-numbered channels to the block of higher-numbered channels, and from the CT/VT module with the lowest slot position letter to the module with the highest slot position letter, as follows.

| Increasing slot position > |                |                |
|----------------------------|----------------|----------------|
| CT/VT module 1             | CT/VT module 2 | CT/VT module 3 |
| <bank 1>                   | <bank 3>       | <bank 5>       |
| <bank 2>                   | <bank 4>       | <bank 6>       |

The UR platform allows for a maximum of six sets of three-phase voltages and six sets of three-phase currents. The result of these restrictions leads to the maximum number of CT/VT modules in a chassis to three. The maximum number of sources is six. A summary of CT/VT module configurations is as follows.

| Item                                            | Maximum number |
|-------------------------------------------------|----------------|
| CT/VT Module                                    | 2              |
| CT Bank (3 phase channels, 1 ground channel)    | 2              |
| VT Bank (3 phase channels, 1 auxiliary channel) | 2              |


Upon relay startup, configuration settings for every bank of current or voltage input channels are generated automatically from the order code. Within each bank, a channel identification label is assigned automatically to each bank of channels in a given product. The bank naming convention is based on the physical location of the channels. Bank identification consists of the letter designation of the slot in which the CT/VT module is mounted as the first character, followed by numbers indicating the channel, either 1 or 5.


For three-phase channel sets, the number of the lowest numbered channel identifies the set. For example, F1 represents the three-phase channel set of F1/F2/F3, where F is the slot letter and 1 is the first channel of the three channels.

Upon startup, the CPU configures the settings required to characterize the current and voltage inputs. It displays them in the appropriate section in the sequence of the banks as follows for a maximum configuration: F1, F5, L1, L5, S1, and S5.

### 8.3 SETTINGS MENU

In this manual, the settings are described with the help of pictorial representations as shown below. The boxes with borders represent the LCD display on the relay and the text within the boxes show what is displayed on the LCD screen. The horizontal positions depict how you move between the settings using the horizontal cursor keys and the vertical positions depict how you move between the settings using the vertical cursor keys. The small black boxes on the left within each cell show that there are sub-menus. The cells with four black boxes on the left show that it is as the highest menu level while the cells with two black boxes show that it is a sub-menu, which parents further settings.





|                                      |   |                                           |
|--------------------------------------|---|-------------------------------------------|
|                                      | ⇅ | ■ UNDERFREQUENCY<br>■                     |
|                                      | ⇅ | ■ OVERFREQUENCY<br>■                      |
|                                      | ⇅ | ■ FREQUENCY RATE<br>■ OF CHANGE           |
|                                      | ⇅ | ■ FREQUENCY OOB<br>■ ACCUMULATION         |
|                                      | ⇅ | ■ SYNCHROCHECK<br>■                       |
|                                      | ⇅ | ■ DIGITAL ELEMENTS<br>■                   |
|                                      | ⇅ | ■ DIGITAL COUNTERS<br>■                   |
|                                      | ⇅ | ■ MONITORING ELEMENTS<br>■                |
| ↑                                    | ↑ | ■ MULTI-RANGE SIGNAL<br>■ OSCILL DETECTOR |
| ■ ■ SETTINGS<br>■ ■ INPUTS / OUTPUTS | ↔ | ■ CONTACT INPUTS<br>■                     |
| ↓                                    | ⇅ | ■ VIRTUAL INPUTS<br>■                     |
|                                      | ⇅ | ■ CONTACT OUTPUTS<br>■                    |
|                                      | ⇅ | ■ VIRTUAL OUTPUTS<br>■                    |
|                                      | ⇅ | ■ DIRECT INPUTS<br>■                      |
|                                      | ⇅ | ■ DIRECT OUTPUTS<br>■                     |
| ↑                                    | ↑ | ■ TELEPROTECTION<br>■                     |
| ■ ■ SETTINGS<br>■ ■ TRANSDUCER I/O   | ↔ | ■ DCMA INPUTS<br>■                        |
| ↓                                    | ⇅ | ■ RTD INPUTS<br>■                         |
| ↑                                    | ↑ | ■ DCMA OUTPUTS<br>■                       |
| ■ ■ SETTINGS<br>■ ■ TESTING          | ↔ | ■ IED MODE CONFIG<br>■                    |
| ↓                                    | ⇅ | ■ FORCE CONTACT<br>■ INPUTS               |
|                                      | ⇅ | ■ FORCE CONTACT<br>■ OUTPUTS              |
| ■ ■ SETTINGS<br>■ ■ SIMULATION       | ↑ | ■ SUBSCRIBE TO<br>■ SIMULATED VALUES      |
|                                      | ↔ | ■ PUBLISH<br>■ SIMULATED VALUES           |



# 8.4 PRODUCT SETUP

The PRODUCT SETUP menus is where you set up the basic configuration of the relay.

## 8.4.1 SECURITY

The UR relay provides a large array of security features and options. These are fully described in the Cybersecurity chapter and will not be repeated here.

## 8.4.2 DISPLAY PROPERTIES

Setting path: **SETTINGS > PRODUCT SETUP > DISPLAY PROPERTIES**

|                                                           |   |                                    |                                                                                                 |
|-----------------------------------------------------------|---|------------------------------------|-------------------------------------------------------------------------------------------------|
| <div> <div>■ DISPLAY</div> <div>■ PROPERTIES</div> </div> | ⇔ | LANGUAGE:<br>English               | Range: Language depending on order code) Visible when language other than English is purchased. |
|                                                           | ⇕ | FLASH MESSAGE<br>TIME: 1.0 s       | Range: 0.5 to 10.0 s in steps of 0.1                                                            |
|                                                           | ⇕ | DEFAULT MESSAGE<br>TIMEOUT: 300 s  | Range: 10 to 900 s in steps of 1                                                                |
|                                                           | ⇕ | DEFAULT MESSAGE<br>INTENSITY: 25 % | Range: 25%, 50%, 75%, 100%<br>Visible when a VFD is installed                                   |
|                                                           | ⇕ | SCREEN SAVER<br>FEATURE: Disabled  | Range: Disabled, Enabled<br>Visible when an LCD is installed                                    |
|                                                           | ⇕ | SCREEN SAVER WAIT<br>TIME: 30 min  | Range: 1 to 65535 min. in steps of 1<br>Visible when an LCD is installed                        |
|                                                           | ⇕ | CURRENT CUT-OFF<br>LEVEL: 0.020 pu | Range: 0.002 to 0.020 pu in steps of 0.001                                                      |
|                                                           | ↑ | VOLTAGE CUT-OFF<br>LEVEL: 1.0 V    | Range: 0.1 to 2.0 V secondary in steps of 0.1                                                   |

The **DISPLAY PROPERTIES** sub-menu has the following settings.

### LANGUAGE

This setting selects the language used to display settings, actual values, and targets. This setting displays when a language other than English was purchased, and the range depends on the order code of the relay. For Japanese, the settings display in Japanese on the graphical front panel, while the keys printed on the panel are in English.

For Japanese and Chinese, up to 10 characters can be input in a field on the graphical front panel, not the usual 20. If you have a graphical front panel, you can change the language regardless of the language purchased. If you select a language with which you are unfamiliar and want to switch back to English for example, the menu order remains the same.

If you change the language after entering user-configured names, such as relay names, the strings are not translated. For example, a relay name is entered in English, the language is changed to Japanese, and the relay name remains in English. For this reason it is important to set the language before changing the settings.

You can also select the language in EnerVista under **Maintenance > Change Front Panel**. The language of the EnerVista software can be changed under **View > Language**. Only languages supported by the operating system can be displayed. For example, for Polish or Japanese, the software needs to be installed on a Polish or Japanese operating system.

*Note:*

*Restart the relay after changing the LANGUAGE setting*

### FLASH MESSAGE TIME

Flash messages are status, warning, error, and information messages displayed in response to certain key presses during settings programming. These messages override any normal messages. Use this setting to change the duration of flash messages on the display.

### DEFAULT MESSAGE TIMEOUT

If the keypad is inactive for a period of time, the relay automatically reverts to a default message. The inactivity time is modified using this setting to ensure that messages remain on the screen long enough during programming or reading of actual values. This setting is not supported on the graphical front panel.

### DEFAULT MESSAGE INTENSITY

The brightness can be attenuated during default message display. During keypad interrogation, the display always operates at full brightness. This setting is not supported on the graphical front panel.

### SCREEN SAVER FEATURE and SCREEN SAVER WAIT TIME

These settings control the back-lighting for relays with an LCD. When **SCREEN SAVER FEATURE** is enabled, the LCD back-lighting turns off after the **DEFAULT MESSAGE TIMEOUT** followed by the **SCREEN SAVER WAIT TIME**, provided that no keys have been pressed and no target messages are active. When a key press occurs or a target becomes active, the LCD back-lighting turns on. These settings are not supported on the graphical front panel.

### CURRENT CUT-OFF LEVEL

This setting modifies the current cut-off threshold. Very low currents (1 to 2% of the rated value) are very susceptible to noise. Some customers prefer very low currents to display as zero, while others prefer the current to display even when the value reflects noise rather than the actual signal. The relay applies a cut-off value to the magnitudes and angles of the measured currents. If the magnitude is below the cut-off level, it is substituted with zero. This applies to phase and ground current phasors as well as true RMS values and symmetrical components. The cut-off operation applies to quantities used for metering, protection, and control, as well as those used by communications protocols. Note that the cut-off level for the sensitive ground input is 10 times lower than the **CURRENT CUT-OFF LEVEL** setting value. Raw current samples available via oscillography are not subject to cut-off. This setting does not affect the 87L metering cutoff, which is constantly at 0.02 pu.

### VOLTAGE CUT-OFF LEVEL

This setting modifies the voltage cut-off threshold. Very low secondary voltage measurements (at the fractional volt level) can be affected by noise. Some customers prefer these low voltages to be displayed as zero, while others prefer the voltage to be displayed even when the value reflects noise rather than the actual signal. The relay applies a cut-off value to the magnitudes and angles of the measured voltages. If the magnitude is below the cut-off level, it is substituted with zero. This operation applies to phase and auxiliary voltages, and symmetrical components. The cut-off operation applies to quantities used for metering, protection, and control, as well as those used by communications protocols. Raw samples of the voltages available via oscillography are not subject to cut-off.

### Considerations:

*Note:*

*The Current and Voltage Cut-off levels not only affect the display values, they also affect the actual values used by the protection and the control elements. Thus, the settings CURRENT CUT-OFF LEVEL and VOLTAGE CUT-OFF LEVEL should not be changed while relay is in service*



The **CURRENT CUT-OFF LEVEL** and the **VOLTAGE CUT-OFF LEVEL** are used to determine the metered power cut-off levels. The power cut-off level is calculated using the following equations.

For Delta connections:

$$\text{3-phase power cut-off} = (\sqrt{3} \times \text{CURRENT CUT-OFF LEVEL} \times \text{VOLTAGE CUT-OFF LEVEL} \times \text{VT primary} \times \text{CT primary}) / \text{VT secondary}$$

For Wye connections:

$$\text{3-phase power cut-off} = (3 \times \text{CURRENT CUT-OFF LEVEL} \times \text{VOLTAGE CUT-OFF LEVEL} \times \text{VT primary} \times \text{CT primary}) / \text{VT secondary}$$

$$\text{Per-phase power cut-off} = (\text{CURRENT CUT-OFF LEVEL} \times \text{VOLTAGE CUT-OFF LEVEL} \times \text{VT primary} \times \text{CT primary}) / \text{VT secondary}$$

where

$$\text{VT primary} = \text{VT secondary} \times \text{VT ratio} \text{ and } \text{CT primary} = \text{CT secondary} \times \text{CT ratio}.$$

For example, given the following settings:

- **CURRENT CUT-OFF LEVEL:** 0.02 pu
- **VOLTAGE CUT-OFF LEVEL:** 1.0 V
- **PHASE CT PRIMARY:** 100 A
- **PHASE VT SECONDARY:** 66.4 V
- **PHASE VT RATIO:** 208.00 : 1
- **PHASE VT CONNECTION:** Delta

We have:

$$\text{CT primary} = 100 \text{ A}$$

$$\text{VT primary} = \text{PHASE VT SECONDARY} \times \text{PHASE VT RATIO} = 66.4 \text{ V} \times 208 = 13811.2 \text{ V}$$

The power cut-off is therefore:

$$\text{Power cut-off} = (\text{CURRENT CUT-OFF LEVEL} \times \text{VOLTAGE CUT-OFF LEVEL} \times \text{CT primary} \times \text{VT primary}) / \text{VT secondary, therefore}$$

$$\text{Power cut-off} = (\sqrt{3} \times 0.02 \text{ pu} \times 1.0 \text{ V} \times 100 \text{ A} \times 13811.2 \text{ V}) / 66.4 \text{ V} = 720.5 \text{ watts}$$

Any calculated power value below this cut-off does not display. As well, the three-phase energy data do not accumulate if the total power from all three phases does not exceed the power cut-off.

*Note:*

Lower the **VOLTAGE CUT-OFF LEVEL** and **CURRENT CUT-OFF LEVEL** with care as the relay accepts lower signals as valid measurements. Unless dictated otherwise by a specific application, we recommend default settings of 0.02 pu for **CURRENT CUT-OFF LEVEL** and 1.0 V for **VOLTAGE CUT-OFF LEVEL**.

### 8.4.3 CLEAR RELAY RECORDS

Setting path: **SETTINGS > PRODUCT SETUP > CLEAR RELAY RECORDS**

|                                               |   |                                                |                          |
|-----------------------------------------------|---|------------------------------------------------|--------------------------|
| <div>■ CLEAR</div> <div>■ RELAY RECORDS</div> | ⇔ | <div>CLEAR USER REPORTS:</div> <div>Off</div>  | Range: FlexLogic operand |
|                                               | ⇕ | <div>CLEAR EVENT RECORDS:</div> <div>Off</div> | Range: FlexLogic operand |
|                                               | ⇕ | <div>CLEAR OSCILLOGRAPHY:</div> <div>Off</div> | Range: FlexLogic operand |

|   |                             |                                                                           |
|---|-----------------------------|---------------------------------------------------------------------------|
| ⇅ | CLEAR DATA LOGGER:<br>Off   | Range: FlexLogic operand                                                  |
| ⇅ | CLEAR ENERGY:<br>Off        | Range: FlexLogic operand                                                  |
| ⇅ | RESET UNAUTH ACCESS:<br>Off | Range: FlexLogic operand                                                  |
| ↑ | CLEAR DIR I/O STATS:<br>Off | Range: FlexLogic operand<br>Visible only for units with Direct I/O module |

## RESET UNAUTH ACCESS

This setting Resets the access restriction counter. Selected records can be cleared from user-programmable conditions with FlexLogic operands. Assigning user-programmable pushbuttons to clear specific records is a typical application for these commands. Since the relay responds to rising edges of the configured FlexLogic operands, they must be asserted for at least 50 ms to take effect.

Clearing records with user-programmable operands is not protected by the command password. However, user-programmable pushbuttons are protected by the command password. Thus, if they are used to clear records, the user-programmable pushbuttons can provide extra security if required.

For example, to assign user-programmable pushbutton 1 to clear demand records, apply the following settings:

1. Assign the clear demand function to pushbutton 1 by making the following change in the **SETTINGS > PRODUCT SETUP > CLEAR RELAY RECORDS** menu.  
CLEAR DEMAND: PUSHBUTTON 1 ON
2. Set the properties for user-programmable pushbutton 1 by making the following changes in the **SETTINGS > PRODUCT > SETUP > US -PROGRAMMABLE PUSHBUTTONS > USER PUSHBUTTON 1** menu:  
PUSHBUTTON 1 FUNCTION: *Self-reset*  
PUSHBTN 1 DROP-OUT TIME: *0.20 s*

## 8.4.4 COMMUNICATIONS

The UR relay provides a large array of communication features and options. All theory and general information relating to communications can be found in the Communications Guide. This setting contains information about the front panel and Enervista settings only.

All IEC61850 information including the settings has been moved into the Communications Guide.

### 8.4.4.1 COMMUNICATIONS SETTINGS MENU

Setting path: **SETTINGS > PRODUCT SETUP > COMMUNICATIONS**

*Note:*  
Not all settings are used for all models

|                       |   |                         |
|-----------------------|---|-------------------------|
| ■ COMMUNICATIONS<br>■ | ⇅ | ■ SERIAL PORTS<br>■     |
|                       | ⇅ | ■ NETWORK<br>■          |
|                       | ⇅ | ■ IPV4 ROUTE TABLE<br>■ |

|   |                                 |
|---|---------------------------------|
| ⇅ | ■ MODBUS PROTOCOL<br>■          |
| ⇅ | ■ PROTOCOL<br>■                 |
| ⇅ | ■ DNP PROTOCOL<br>■             |
| ⇅ | ■ DNP / IEC104<br>■ POINT LISTS |
| ⇅ | ■ IEC 61850 PROTOCOL<br>■       |
| ⇅ | ■ LEGACY FIXED GOOSE<br>■       |
| ⇅ | ■ WEB SERVER<br>■ HTTP PROTOCOL |
| ⇅ | ■ TFTP PROTOCOL<br>■            |
| ⇅ | ■ IEC 60870-5-104<br>■ PROTOCOL |
| ⇅ | ■ EGD PROTOCOL<br>■             |
| ⇅ | ■ IEC103<br>■ PROTOCOL          |
| ↑ | ■ USB 2.0 PORT<br>■             |

The sub-menus are described in the following sections.

### 8.4.4.2 SERIAL PORTS

This section does not describe the principles of serial communication. It only describes the required settings. For further details on serial communication, refer to the Installation and Maintenance chapters of this manual and the separate Communications Guide.

Setting path: **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > SERIAL PORTS**

|                     |   |                                       |                                                                                               |
|---------------------|---|---------------------------------------|-----------------------------------------------------------------------------------------------|
| ■ SERIAL PORTS<br>■ | ⇅ | RS485 COM2 PORT<br>FUNCTION: Enabled  | Range: Disabled, Enabled                                                                      |
|                     | ⇅ | RS485 COM2 BAUD RATE:<br>19200        | Range: 300, 1200, 2400, 4800, 9600, 14400, 19200,<br>28800, 33600, 38400, 57600, 115200 bit/s |
|                     | ⇅ | RS485 COM2 PARITY:<br>Even            | Range: None, Odd, Even                                                                        |
|                     | ⇅ | RS485 COM2 RESPONSE<br>MIN TIME: 0 ms | Range: 0 to 1000 ms in steps of 10                                                            |
|                     | ⇅ | RS232 PORT FUNCTION:<br>Enabled       | Range: Disabled, Enabled                                                                      |
|                     | ↑ | RS232 BAUD RATE:<br>115200 ms         | Range: 19200, 115200                                                                          |

RS485 PORT FUNCTION

This setting enables and disables the RS485 COM2 serial port on the rear panel. When the port function is disabled, SCADA (Modbus or IEC103 communications) and other comms on the rear RS485 port are not permitted.

RS485 COM2 BAUD RATE

This setting sets the COM2 Baud rate. It is important that this parameter agrees with the setting used on the computer or other equipment that is connected to the port. If IEC 60870-103 is chosen as the protocol, valid baud rates are 9600 and 19200 bps.

RS485 COM2 PARITY

This setting sets the COM2 parity. It is important that this parameter agrees with the setting used on the computer or other equipment that is connected to the port. If IEC 60870-103 is chosen as the protocol, valid parity is Even.

RS485 COM2 RESPONSE MIN TIME

This setting specifies the minimum time before the rear RS485 port transmits after receiving data from a host. This feature allows operation with hosts that hold the RS485 transmitter active for some time after each transmission.

RS232 PORT FUNCTION

This setting enables and disables the RS232 serial port on the front panel. When the port function is enabled, a standard RS232 serial cable allows a computer running the EnerVista UR Setup software to retrieve, display, and write settings either individually or collectively, to display status and actual values, to initiate controls, and to retrieve and display event records, oscillography records, data logger records, and disturbance records. This setting is applicable to both enhanced and basic front panels.

RS485 COM2 BAUD RATE

This setting sets the COM2 Baud rate. It is important that this parameter agrees with the setting used on the computer or other equipment that is connected to the port. If IEC 60870-103 is chosen as the protocol, valid baud rates are 9600 and 19200 bps.

8.4.4.3 NETWORK

This section does not describe the principles of Ethernet networking topology. It only describes the required settings. For further details on Ethernet networking, refer to the Installation and Maintenance chapters of this manual and the separate Communications Guide.

Setting path: **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > NETWORK**

|                                          |   |                                   |                                                                       |
|------------------------------------------|---|-----------------------------------|-----------------------------------------------------------------------|
| <div>■ NETWORK PORT 1</div> <div>■</div> | ↔ | PRT1 IP ADDRESS:<br>127.0.0.1     | Range: standard IPV4 address format                                   |
|                                          | ⇅ | PRT1 SUBNET IP MASK:<br>255.0.0.0 | Range: standard IPV4 address format                                   |
|                                          | ↑ | PRT1 FUNCTION:<br>Enabled         | Range: Enabled, Disabled                                              |
| <div>■ NETWORK PORT 2</div> <div>■</div> | ↔ | PRT2 IP ADDRESS:<br>127.0.0.1     | Range: standard IPV4 address format                                   |
|                                          | ⇅ | PRT2 SUBNET IP MASK:<br>255.0.0.0 | Range: standard IPV4 address format                                   |
|                                          | ⇅ | PRT2 REDUNDANCY:<br>None          | Range: None, Failover, PRP<br>Range if no PRP license: None, Failover |

|                                                       |   |                                   |                                               |
|-------------------------------------------------------|---|-----------------------------------|-----------------------------------------------|
| <div> <div>■ NETWORK PORT 3</div> <div>■</div> </div> | ⇅ | PRP MCST ADDR:<br>01154E000100    | Range: 01-15-4E-00-01-00 to 01-15-4E-00-01-FF |
|                                                       | ↑ | PRT2 FUNCTION:<br>Enabled         | Range: Enabled, Disabled                      |
|                                                       | ⇅ | PRT3 IP ADDRESS:<br>127.0.0.1     | Range: standard IPV4 address format           |
|                                                       | ⇅ | PRT3 SUBNET IP MASK:<br>255.0.0.0 | Range: standard IPV4 address format           |
|                                                       | ↑ | PRT3 FUNCTION:<br>Enabled         | Range: Enabled, Disabled                      |

The **NETWORK** menu is used to set the Ethernet network parameters. When using more than one Ethernet port, configure each to belong to a different network or subnet using the IP addresses and mask. Configure the network IP and subnet settings before configuring the routing settings.

**Note:**

To obtain a list of all port numbers used, for example for audit purposes, contact GE technical support with substantiating information, such as the serial number and order code of your device.

The IP addresses are used with the DNP, Modbus/TCP, IEC 61580, IEC 60870-5-104, TFTP, HTTP, and PRP protocols.

You must use the front panel to change these settings. You can only use EnerVista software to enable or disable the ports. In the Offline Window area, all settings can be changed except port 2 redundancy (depending on firmware version).

When using GOOSE, in failover or PRP mode, port 3 configuration in the CID file is ignored. The Port 3 ConnectedAP elements has no meaning, as ports 2 and 3 use the port 2 MAC address, IP address, and mask.

### PRT1 (2 or 3) IP ADDRESS

This setting sets the port's IPv4 address in standard IPV4 format. This setting is valid on port 3 if **PRT2 REDUNDANCY** is set to *None*.

### PRT1 (2 or 3) SUBNET MASK

This setting sets the port's IPv4 subnet mask in standard IPV4 format. This setting is valid on port 3 if **PRT2 REDUNDANCY** is set to *None*.

### PRT1 (2 or 3) FUNCTION

This setting enable/disables network communication on the respective port. When the port function is disabled, the network traffic on this port is disabled. The **PRT2 REDUNDANCY** setting has no effect on this functionality. The change takes effect after restarting the relay.

**Note:**

If you disable a port, which is used to communicate between the relay and the software, you will break all communication between the two. If you do this, you must re-enable the port and check the IP and gateway addresses. You must also set the relay to *Programmed*.

## PRT2 REDUNDANCY

This setting determines whether ports 2 and 3 will operate in redundant or independent mode. If your product includes PRP, the available options will include *PRP* in addition to *None* and *Failover*. In non-redundant mode, ports 2 and 3 operate independently with their own MAC, IP, and mask addresses. If **REDUNDANCY** is set to Failover, the operation of ports 2 and 3 is as follows:

- Ports 2 and 3 use the port 2 MAC address, IP address, and mask
- The configuration fields for IP address and mask on port 3 are hidden
- Port 3 is in standby mode and does not actively communicate on the Ethernet network but monitors its link to the Multilink switch. If port 2 detects a problem with the link, communications is switched to Port 3. Port 3 is, in effect, acting as a redundant or backup link to the network for port 2. Once port 2 detects that the link between itself and the switch is good and that communication is healthy for five minutes, then switching back to port 2 is performed. The delay in switching back ensures that rebooted switching devices connected to the relay, which signal their ports as active prior to being completely functional, have time to completely initialize themselves and become active. Once port 2 is active again, port 3 returns to standby mode.

If **REDUNDANCY** is set to PRP, the operation of ports 2 and 3 is as follows:

- Ports 2 and 3 use the port 2 MAC address, IP address, and mask
- The configuration fields for IP address and mask on port 3 are overwritten with those from port 2. This is visible on the front panel but not displayed in the EnerVista software.
- **PRT 2 MCST ADDRESS** field is visible
- The port 2 PTP function still uses only port 2 and the port 3 PTP function still uses only port 3. The relay still synchronizes to whichever port has the best master. When ports 2 and 3 see the same master, as is typically the case for PRP networks, the port with the better connectivity is used.

Behavior for GOOSE messages is as follows:

- If **REDUNDANCY** is set to *Failover* or *PRP*, in order to transmit a GOOSE message on port 2, the CID file must be configured to have the corresponding GSE element in both ConnectedAPs S2 and S3. In the EnerVista software, the **TxGOOSE CPU PORT ASSIGNMENT** needs to be *Ports-1,2,3* to transmit GOOSE on both ports 1 and 2, or *Ports-2,3* to have GOOSE only on port 2, with failover/PRP.
- If **REDUNDANCY** is set to *PRP*, the port 2 configured GOOSE message is simultaneously transmitted on ports 2 and 3.
- If **REDUNDANCY** is set to *Failover* and the port 2 link fails, then only the port 2 configured GOOSE message is transmitted on port 3.

**Note:**

*The two ports must be connected to completely independent LANs with no single point of failure, such as common power supplies that feed switches on both LANs.*

**Note:**

*When **REDUNDANCY** is set to *PRP* or *Failover* and the network path with resolved default gateway is broken, then the ARP table needs approximately five seconds to rebuild. The layer 2 protocols (GOOSE and PTP) are not affected. However, the TCP/IP or UDP protocols (MMS connections, DNP3.0, and so on) may require reconnection if their active connection does not ride through re-transmission frames.*

For any changes to this setting to take effect, restart the unit.


## PRT2 PRP MCST ADDR

This setting allows you to change the multicast address used by the PRP supervision frames. This setting is available if **REDUNDANCY** is set to *PRP*. All devices in the same PRP network must have the same multicast address. Choose an address that does not conflict with another multicast protocol.


### 8.4.4.4 IPV4 ROUTE TABLE

Setting path: **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > IPv4 ROUTE TABLE 1**


You can configure up to 6 static routes and one default route. The following description shows just the first of the six static routes.



In the **DEFAULT IPv4 ROUTE** menu, you specify the gateway address using the GATEWAY ADDRESS setting.




In the **IPv4 NETWORK** menu, you set the individual static routes by specifying the destination address and the subnet mask as follows:



**Note:**  
Configure the network IP and subnet settings before configuring the routing settings

### 8.4.4.5 MODBUS PROTOCOL

Setting path: **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > MODBUS PROTOCOL**



The serial communication ports utilize the Modbus protocol, unless the port is configured for DNP or IEC 60870-5-103 operation. This allows the EnerVista UR Setup software to be used on the port. UR devices operate as Modbus slave devices only. For more information on the protocol, including the memory map table, see the UR Family Communications Guide.

### MODBUS SLAVE ADDRESS

When using the Modbus protocol on the RS232 port, the relay responds regardless of the **MODBUS SLAVE ADDRESS** programmed. For the RS485 port, each device on the serial bus must have a unique slave address from 1 to 254. Address 0 and addresses from 248 and up are reserved by the Modbus protocol specification, and so we do not recommend their use here. Address 0 is the broadcast address to which all Modbus slave devices listen. Addresses do not have to be sequential, but no two devices can have the same address or conflicts resulting in errors will occur. Generally, starting at 1, set each device added to the link to use the next higher address. When

using Modbus TCP/IP, the client must use the programmed **MODBUS SLAVE ADDRESS** value in the Unit Identifier field.

### MODBUS TCP PORT NUMBER

You can also use Modbus over TCP/IP on any of the Ethernet ports. The listening TCP port 502 is reserved for Modbus communications, and only in exceptional cases when **MODBUS TCP PORT NUMBER** is set to any other port. A **MODBUS TCP PORT NUMBER** of 0 disables Modbus over TCP/IP, meaning closes the Modbus TCP port. When the port number is changed to 0, the change takes effect when the relay is restarted. When it is set to 0, use the front panel or serial port to communicate with the relay.

**Note:**

*Do not set more than one protocol to the same TCP/UDP port number, as this results in unreliable operation of those protocols.*

#### 8.4.4.6 PROTOCOLS & AUTHORITY

Setting path: **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > PROTOCOL & AUTHORITY**

|                                                                 |   |                                    |                                                  |
|-----------------------------------------------------------------|---|------------------------------------|--------------------------------------------------|
| <div> <div>■ PROTOCOL &amp;</div> <div>■ AUTHORITY</div> </div> | ⇔ | PROTOCOL:<br>DNP 3.0               | Range: DNP 3.0, IEC 60870-5-104, IEC 60870-5-103 |
|                                                                 | ⇕ | IEC61850 Edition<br>Edition 2      | Range: Edition 1, Edition 2                      |
|                                                                 | ⇕ | SFTP PROTOCL:<br>Enabled           | Range: Disabled, Enabled                         |
|                                                                 | ⇕ | MMS PORT FUNCTION:<br>Enabled      | Range: Disabled, Enabled                         |
|                                                                 | ⇕ | CID FILE WRITE VIA MMS:<br>Enabled | Range: Disabled, Enabled                         |
|                                                                 | ⇕ | SETTING WRITE VIA MMS:<br>Disabled | Range: Disabled, Enabled                         |
| Control authority                                               |   |                                    |                                                  |
|                                                                 | ⇕ | MULTILEVEL CONTROL:<br>Enabled     | Range: Disabled, Enabled                         |
|                                                                 | ↑ | IED LOCAL STATUS:<br>Off           | Range: FlexLogic operand                         |

### PROTOCOL

This setting selects the SCADA protocol on which the unit communicates, either DNP3.0, IEC 60870-104 or IEC 60870-103, with DNP being the default. Options depend on order code. For any change to take effect, restart the unit.

The following table shows the protocols that are operational on the RS232, RS485, and Ethernet ports. It shows all possible combinations of the protocol and DNP channel port settings.

| Protocol | DNP CHANNEL 1(2)<br>PORT                 | RS232  | RS485  | Ethernet               |
|----------|------------------------------------------|--------|--------|------------------------|
| DNP      | Channel 1: Eth TCP<br>Channel 2: Eth TCP | Modbus | Modbus | DNP, Modbus, IEC 61850 |
| DNP      | Channel 1: Eth TCP<br>Channel 2: none    | Modbus | Modbus | DNP, Modbus, IEC 61850 |



| Protocol | DNP CHANNEL 1(2)<br>PORT                  | RS232  | RS485                  | Ethernet                   |
|----------|-------------------------------------------|--------|------------------------|----------------------------|
| DNP      | Channel 1: none<br>Channel 2: Eth TCP     | Modbus | Modbus                 | DNP, Modbus, IEC 61850     |
| DNP      | Channel 1: Eth UDP<br>Channel 2: none     | Modbus | Modbus                 | DNP, Modbus, IEC 61850     |
| DNP      | Channel 1: Eth TCP<br>Channel 2: RS485    | Modbus | DNP                    | DNP, Modbus, IEC 61850     |
| DNP      | Channel 1: Eth TCP<br>Channel 2: RS232    | DNP    | Modbus                 | DNP, Modbus, IEC 61850     |
| DNP      | Channel 1: Eth UDP<br>Channel 2: RS485    | Modbus | DNP                    | DNP, Modbus, IEC 61850     |
| DNP      | Channel 1: Eth UDP<br>Channel 2: RS232    | DNP    | Modbus                 | DNP, Modbus, IEC 61850     |
| DNP      | Channel 1: RS485<br>Channel 2: Eth TCP    | Modbus | DNP                    | DNP, Modbus, IEC 61850     |
| DNP      | Channel 1: RS232<br>Channel 2: Eth TCPDNP | Modbus | DNP, Modbus, IEC 61850 | DNP, Modbus, IEC 61850     |
| DNP      | Channel 1: RS485<br>Channel 2: RS232      | DNP    | DNP                    | Modbus, IEC 61850          |
| DNP      | Channel 1: RS232<br>Channel 2: RS485      | DNP    | DNP                    | Modbus, IEC 61850          |
| DNP      | Channel 1: RS485<br>Channel 2: none       | Modbus | DNP                    | Modbus, IEC 61850          |
| IEC 104  |                                           | Modbus | Modbus                 | IEC 104, Modbus, IEC 61850 |
| IEC 103  |                                           | Modbus | IEC 103                | Modbus, IEC 61850          |

## SFTP

This setting enables or disables file transfers to/from the relay by Secure Shell (SSH) and Secure File Transfer Protocol (SFTP). This setting displays when using IEC 61850 without CyberSentry.

## MMS PORT FUNCTION

This setting enables or disables MMS port 102. This setting does not, affect GOOSE operation.

## CID FILE WRITE FROM MMS

This setting enables or disables CID file writes from the MMS client.

## SETTING WRITE VIA MMS

When set to Enabled, **Setting write** from MMS client is enabled, otherwise **Setting write** from MMS client is not allowed.

Note that upon this setting change, the latest setting will be reflected only in IID not the CID.

## MULTILEVEL CONTROL

When enabled, control authority from multiple levels (Bay, Station and Remote) are allowed simultaneously based on Local/Remote status and status authority status. Otherwise only one level has the authority to control, based on Local/Remote status and status authority status.

Note:

**MULTILEVEL CONTROL** setting is only available for order codes with the IEC 61850 software option. It is only applicable to Breaker and Disconnect switch control related logical nodes (XCBR/XSWI and CSWI), which instantiates Loc and LocSta data objects. For all other controllable data objects in other logical nodes (like virtual inputs in GGIO2) **MULTILEVEL CONTROL** setting is not applicable.

## IED LOCAL STATUS

This selects an operand, that indicates the relay is in Local or Remote mode. When the operand value is set, the relay is in Local mode and any commands from remote protocols (IEC 61850) are rejected.

Note:

**IED LOCAL STATUS** setting is only available for order codes with the IEC 61850 software option. It is applicable for all IEC 61850 commands including Breaker and Disconnect switch controls, and the commands are allowed only when the FlexOperand assigned to IED LOCAL STATUS setting is at logic "0". When the FlexOperand assigned to IED Local Status is at logic "1", all the control actions from IEC 61850 client are blocked.

### 8.4.4.7 DNP PROTOCOL

Setting path: **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > DNP PROTOCOL**

|                                        |   |                                                        |                                                                                        |
|----------------------------------------|---|--------------------------------------------------------|----------------------------------------------------------------------------------------|
| <div>■ DNP PROTOCOL</div> <div>■</div> | ⇔ | <div>■ DNP CHANNELS</div> <div>■ DNP 3.0</div>         |                                                                                        |
|                                        | ⇕ | DNP ADDRESS:<br>1                                      | Range: 0 to 65535 in steps of 1                                                        |
|                                        | ⇕ | <div>■ DNP NETWORK</div> <div>■ CLIENT ADDRESSES</div> |                                                                                        |
|                                        | ⇕ | DNP TCP/UDP PORT<br>NUMBER(20000): 20000               | Range: 0 to 65535 in steps of 1                                                        |
|                                        | ⇕ | DNP UNSOL RESPONSE<br>FUNCTION: Disabled               | Range: Disabled, Enabled                                                               |
|                                        | ⇕ | DNP UNSOL RESPONSE<br>TIMEOUT: 5 s                     | Range: 0 to 60 s in steps of 1                                                         |
|                                        | ⇕ | DNP UNSOL RESPONSE<br>MAX RETRIES: 10                  | Range: 1 to 255 in steps of 1                                                          |
|                                        | ⇕ | DNP UNSOL RESPONSE<br>DEST ADDRESS: 1                  | Range: 0 to 65519 in steps of 1                                                        |
|                                        | ⇕ | DNP CURRENT SCALE<br>FACTOR: 1                         | Range: 0.001, 0.01, 0.1, 1, 10, 100, 1000, 10000, 100000, 1000000, 10000000, 100000000 |
|                                        | ⇕ | DNP VOLTAGE SCALE<br>FACTOR: 1                         | Range: 0.001, 0.01, 0.1, 1, 10, 100, 1000, 10000, 100000, 1000000, 10000000, 100000000 |
|                                        | ⇕ | DNP POWER SCALE<br>FACTOR: 1                           | Range: 0.001, 0.01, 0.1, 1, 10, 100, 1000, 10000, 100000, 1000000, 10000000, 100000000 |
|                                        | ⇕ | DNP ENERGY SCALE<br>FACTOR: 1                          | Range: 0.001, 0.01, 0.1, 1, 10, 100, 1000, 10000, 100000, 1000000, 10000000, 100000000 |
|                                        | ⇕ | DNP PF SCALE<br>FACTOR: 1                              | Range: 0.001, 0.01, 0.1, 1, 10, 100, 1000, 10000, 100000, 1000000, 10000000, 100000000 |
|                                        | ⇕ | DNP OTHER SCALE<br>FACTOR: 1                           | Range: 0.001, 0.01, 0.1, 1, 10, 100, 1000, 10000, 100000, 1000000, 10000000, 100000000 |

|   |                                           |                                      |
|---|-------------------------------------------|--------------------------------------|
| ⇅ | DNP CURRENT DEFAULT<br>DEADBAND: 30000    | Range: 0 to 100000000 in steps of 1  |
| ⇅ | DNP VOLTAGE DEFAULT<br>DEADBAND: 30000    | Range: 0 to 100000000 in steps of 1  |
| ⇅ | DNP POWER DEFAULT<br>DEADBAND: 30000      | Range: 0 to 100000000 in steps of 1  |
| ⇅ | DNP ENERGY DEFAULT<br>DEADBAND: 30000     | Range: 0 to 100000000 in steps of 1  |
| ⇅ | DNP PF DEFAULT<br>DEADBAND: 30000         | Range: 0 to 100000000 in steps of 1  |
| ⇅ | DNP OTHER DEFAULT<br>DEADBAND: 30000      | Range: 0 to 100000000 in steps of 1  |
| ⇅ | DNP TIME SYNC IIN<br>PERIOD: 1440 min     | Range: 1 to 10080 min. in steps of 1 |
| ⇅ | DNP MESSAGE FRAGMENT<br>SIZE: 240         | Range: 30 to 2048 in steps of 1      |
| ⇅ | DNP OBJECT 1<br>DEFAULT VARIATION: 2      | Range: 1, 2                          |
| ⇅ | DNP OBJECT 2<br>DEFAULT VARIATION: 2      | Range: 1, 2, 3                       |
| ⇅ | DNP OBJECT 20<br>DEFAULT VARIATION: 1     | Range: 1, 2, 5, 6                    |
| ⇅ | DNP OBJECT 21<br>DEFAULT VARIATION: 1     | Range: 1, 2, 9, 10                   |
| ⇅ | DNP OBJECT 22<br>DEFAULT VARIATION: 1     | Range: 1, 2, 5, 6                    |
| ⇅ | DNP OBJECT 23<br>DEFAULT VARIATION: 1     | Range: 1, 2, 5, 6                    |
| ⇅ | DNP OBJECT 30<br>DEFAULT VARIATION: 1     | Range: 1, 2, 3, 4, 5                 |
| ⇅ | DNP OBJECT 32<br>DEFAULT VARIATION: 1     | Range: 1, 2, 3, 4, 5, 7              |
| ⇅ | DNP NUMBER OF PAIRED<br>CONTROL POINTS: 0 | Range: 0 to 32 in steps of 1         |
| ⇅ | DNP TCP CONNECTION<br>TIMEOUT: 120 s      | Range: 10 to 7200 s in steps of 1    |
| ↑ | DNP EVENT TIME BASE:<br>LOCAL             | Range: UTC, LOCAL                    |

### DNP TCP/UDP PORT NUMBER

This setting is for normal DNP operation. To close the port, set the port number to 0.

### DNP UNSOL RESPONSE FUNCTION

This is set to *Disabled* for RS485 applications since there is no collision avoidance mechanism.

### DNP UNSOL RESPONSE TIMEOUT

This sets the time the relay waits for a DNP master to confirm an unsolicited response.

### The DNP UNSOL RESPONSE MAX RETRIES

This setting determines the number of times the relay retransmits an unsolicited response without receiving confirmation from the master; a value of *255* allows infinite re-tries.

### DNP UNSOL RESPONSE DEST ADDRESS

This is the DNP address to which all unsolicited responses are sent. The IP address to which solicited responses are sent is determined by the relay from the current TCP connection or the most recent UDP message. The DNP scale factor settings are numbers used to scale analog input point values. These settings group the analog input data into the following types: current, voltage, power, energy, power factor, and other. Each setting represents the scale factor for all analog input points of that type. For example, if the **DNP VOLTAGE SCALE FACTOR** setting is set to *1000*, all DNP analog input points that are voltages are returned with values 1000 times smaller (for example, a value of 72000 V on the relay is returned as 72). These settings are useful when analog input values must be adjusted to fit within certain ranges in DNP masters. Note that a scale factor of 0.1 is equivalent to a multiplier of 10 (that is, the value is 10 times larger).

### DNP DEFAULT DEADBAND

These settings determine when to trigger unsolicited responses containing analog input data. These settings group the analog input data into the following types: current, voltage, power, energy, power factor, and other. Each setting represents the default deadband value for all analog input points of that type. For example, to trigger unsolicited responses from the relay when any current values change by 15 A, the **DNP CURRENT DEFAULT DEADBAND** setting is set to *15*. Note that these settings are the deadband default values. DNP object 34 points can be used to change deadband values, from the default, for each individual DNP analog input point.

### DNP TIME SYNC IIN PERIOD

This setting determines how often the Need Time Internal Indication (IIN) bit is set by the relay. Changing this time allows the DNP master to send time synchronization commands more or less often, as required.

### DNP MESSAGE FRAGMENT SIZE

This setting determines the size, in bytes, at which message fragmentation occurs. Large fragment sizes allow for more efficient throughput; smaller fragment sizes cause more application layer confirmations to be necessary, which provides more robust data transfer over noisy communication channels.

*Note:*

Check the **DNP Points Lists** relay web page to view the analog inputs and/or binary inputs points lists. This page can be viewed with a web browser by entering the IP address of the Ethernet port employed to access the Main Menu, then by clicking the **Device Information Menu** item, then the **DNP Points Lists** item.

### DNP OBJECT 1 DEFAULT VARIATION to DNP OBJECT 32 DEFAULT VARIATION

These settings select the DNP default variation number for object types 1, 2, 20, 21, 22, 23, 30, and 32. The default variation refers to the variation response when variation 0 is requested and/or in class 0, 1, 2, or 3 scans.

The DNP binary outputs typically map one-to-one to IED data points. That is, each DNP binary output controls a single physical or virtual control point in an IED. DNP binary outputs are mapped to virtual inputs. However, some legacy DNP implementations use a mapping of one DNP binary output to two physical or virtual control points to support the concept of trip/close (for circuit breakers) or raise/lower (for tap changers) using a single control point. That is, the DNP master can operate a single point for both trip and close, or raise and lower, operations. The relay can be configured to support paired control points, with each paired control point operating two virtual inputs.

### DNP NUMBER OF PAIRED CONTROL POINTS

This setting allows configuration of 0 to 64 binary output paired controls. The control points pairing starts from the highest number of binary outputs available i.e. 128. Points not configured as paired operate on a one-to-one basis.

So if you select a value of 2 for this setting, the pairing starts from the highest number; 128. Control points 128-127 and 126-125 operate in pairs and the rest (1-124) are operated individually.

### DNP TCP CONNECTION TIMEOUT

This setting specifies a time delay for the detection of dead network TCP connections. If there is no data traffic on a DNP TCP connection for greater than the time specified by this setting, the connection is aborted. This frees up the connection to be re-used by a client.

See the UR Family Communications Guide for more information on DNP.

*Note:*  
For any change to DNP settings, restart the relay.

### DNP CHANNELS sub-menu

|                                        |   |                             |                                                                                            |
|----------------------------------------|---|-----------------------------|--------------------------------------------------------------------------------------------|
| <div>■ DNP Channels</div> <div>■</div> | ⇔ | DNP CHANNEL 1 PORT:<br>NONE | Range: NONE, COM1 - RS485, COM2 - RS485, FRONT PANEL - RS232, NETWORK - TCP, NETWORK - UDP |
|                                        | ↑ | DNP CHANNEL 2 PORT:<br>NONE | Range: NONE, COM1 - RS485, COM2 - RS485, FRONT PANEL - RS232, NETWORK - TCP                |

The **DNP CHANNEL 1 PORT** and **DNP CHANNEL 2 PORT** settings select the communications port assigned to the DNP protocol for each channel. Once DNP is assigned to a serial port, DNP is the only protocol running on that port; Modbus or IEC 60870-5-103 are disabled. If DNP is assigned to RS485, the protocol must be set to DNP on the serial port configuration as well, for the change to take effect. When the **DNP CHANNEL <n> PORT** setting is set to *Network - TCP*, the DNP protocol can be used over TCP/IP on the Ethernet ports. When this value is set to *Network - UDP*, the DNP protocol can be used over UDP/IP on channel 1 only. The *Front Panel - RS232* value does not apply to the graphical front panel; when selected the DNP client cannot establish a connection on a USB port.

*Note:*  
Do not set more than one protocol to the same TCP/UDP port number, as this results in unreliable operation of those protocols.

The **DNP ADDRESS** setting is the DNP slave address. This number identifies the relay on a DNP communications link. Assign a unique address to each DNP slave.

The relay can specify a maximum of five clients for its DNP connections. These are IP addresses for the controllers to which the relay can connect. The settings are defined in the following sub-menu.

### DNP NETWORK CLIENT ADDRESS sub-menu

|                                        |   |                              |                            |
|----------------------------------------|---|------------------------------|----------------------------|
| <div>■ DNP Channels</div> <div>■</div> | ⇔ | CLIENT ADDRESS 1:<br>0.0.0.0 | Range: standard IP address |
|                                        | ↑ | CLIENT ADDRESS 2:<br>0.0.0.0 | Range: standard IP address |
|                                        |   | CLIENT ADDRESS 3:<br>0.0.0.0 | Range: standard IP address |
|                                        |   | CLIENT ADDRESS 4:<br>0.0.0.0 | Range: standard IP address |
|                                        |   | CLIENT ADDRESS 5:<br>0.0.0.0 | Range: standard IP address |

#### 8.4.4.8 DNP / IEC 60870-5-104 POINT LISTS

You can configure up to 256 binary and up to 256 analog input points for the DNP protocol, or the MSP and MME points for IEC 60870-5-104 protocol. The value for each point is user-programmable and can be configured by assigning FlexLogic operands for binary inputs / MSP points or FlexAnalog parameters for analog inputs / MME points. The menu is as follows:

Setting path: **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > DNP / IEC104 POINT LISTS**

|                                 |   |                                  |
|---------------------------------|---|----------------------------------|
| ■ DNP / IEC104<br>■ POINT LISTS | ⇔ | ■ BINARY INPUT / MSP<br>■ POINTS |
|                                 | ⇕ | ■ ANALOG INPUT / MME<br>■ POINTS |

You can configure to 256 binary input points for the DNP or IEC 60870-5-104 protocols. The points are configured by assigning an appropriate FlexLogic operand. See the FlexLogic section for the range of assignable operands.

The menu for the binary input points (DNP) or MSP points (IEC 60870-5-104) follows.

|                                  |   |                   |                          |
|----------------------------------|---|-------------------|--------------------------|
| ■ BINARY INPUT / MSP<br>■ POINTS | ⇔ | POINT: <n><br>Off | Range: FlexLogic operand |
|----------------------------------|---|-------------------|--------------------------|

where n is 0 to 255.

You can configure up to 256 analog input points for the DNP or IEC 60870-5-104 protocols. The analog point list is configured by assigning an appropriate FlexAnalog parameter to each point. See the FlexAnalog Parameters section for the range of assignable parameters.

The menu for the analog input points (DNP) or MME points (IEC 60870-5-104) follows.

|                                  |   |                   |                                 |
|----------------------------------|---|-------------------|---------------------------------|
| ■ ANALOG INPUT / MME<br>■ POINTS | ⇔ | POINT: <n><br>Off | Range: any FlexAnalog parameter |
|----------------------------------|---|-------------------|---------------------------------|

where n is 0 to 255.

**Note:**  
Changes to the DNP / IEC 60870-5-104 point lists take effect when the relay is restarted

**Note:**  
The DNP / IEC 60870-5-104 point lists always begin with point 0 and end at the first **OFF** value. Since DNP / IEC 60870-5-104 point lists must be in one continuous block, any points assigned after the first **OFF** point are ignored.


#### 8.4.4.9 WEB SERVER HTTP PROTOCOL

Setting path: **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > WEB SERVER HTTP PROTOCOL**

|                                 |   |                                 |                                 |
|---------------------------------|---|---------------------------------|---------------------------------|
| ■ WEB SERVER<br>■ HTTP PROTOCOL | ⇔ | HTTP TCP PORT<br>NUMBER(80): 80 | Range: 0 to 65535 in steps of 1 |
|---------------------------------|---|---------------------------------|---------------------------------|

The relay contains an embedded web server and can display pages in a web browser. The web pages are organized as a series of menus that can be accessed starting at the Main Menu. Web pages are read-only and are available showing IEC 60870-5-104 points lists, Modbus registers, event records, fault reports, and so on. First connect the relay and a computer to an Ethernet network, then enter the IP address of the relay Ethernet port in a web browser. To close the port, set the port number to 0.

Any change takes effect when the relay is restarted.



| Event Number | Time and Date               | Event Cause        |
|--------------|-----------------------------|--------------------|
| 214          | Nov 04 2014 14:02:56.062087 | PROTOTYPE FIRMWARE |
| 213          | Nov 04 2014 14:02:56.062087 | POWER ON           |
| 212          | Nov 03 2014 14:00:20.364906 | POWER OFF          |
| 211          | Nov 03 2014 13:55:15.061866 | PROTOTYPE FIRMWARE |
| 210          | Nov 03 2014 13:55:15.061866 | POWER ON           |
| 209          | Nov 03 2014 13:10:59.733179 | POWER OFF          |
| 208          | Nov 03 2014 13:06:11.062104 | PROTOTYPE FIRMWARE |
| 207          | Nov 03 2014 13:06:11.062104 | POWER ON           |
| 206          | Oct 31 2014 10:07:25.078203 | POWER OFF          |
| 205          | Oct 31 2014 10:00:44.062027 | PROTOTYPE FIRMWARE |

Figure 204: Example of UR web page showing event records

**Note:**

Do not set more than one protocol to the same TCP/UDP port number, as this results in unreliable operation of those protocols

#### 8.4.4.10 TFTP PROTOCOL

Setting path: **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > TFTP PROTOCOL**

|                                                                               |   |                                   |                                 |
|-------------------------------------------------------------------------------|---|-----------------------------------|---------------------------------|
| <input checked="" type="checkbox"/> TFTP PROTOCOL<br><input type="checkbox"/> | ↔ | TFTP MAIN UDP PORT NUMBER(69): 69 | Range: 0 to 65535 in steps of 1 |
|                                                                               | ⇕ | TFTP DATA UDP PORT 1 NUMBER: 0    | Range: 0 to 65535 in steps of 1 |
|                                                                               | ↑ | TFTP DATA UDP PORT 2 NUMBER: 0    | Range: 0 to 65535 in steps of 1 |

The Trivial File Transfer Protocol (TFTP) can be used to transfer files from the relay over a network. The relay operates as a TFTP server. TFTP client software is available from various sources, including Microsoft Windows NT. The `dir.txt` file obtained from the relay contains a list and description of all available files, for example event records and oscillography.

The `put` function is not available for security reasons. You can enter a `get` command but not a `put` command.

#### TFTP MAIN UDP PORT NUMBER

To close the port, set the port number to 0. Any change takes effect when the relay is restarted.

**Note:**

Do not set more than one protocol to the same TCP/UDP port number, as this results in unreliable operation of those protocols.

### 8.4.4.11 IEC 60870-5-104 PROTOCOL

Setting path: **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > IEC 60870-5-104 PROTOCOL**

|                                                                 |   |                                                                     |                                     |
|-----------------------------------------------------------------|---|---------------------------------------------------------------------|-------------------------------------|
| <div> <div>■ IEC 60870-5-104</div> <div>■ PROTOCOL</div> </div> | ↔ | IEC TCP PORT<br>NUMBER(2404): 2404                                  | Range: 0 to 65535 in steps of 1     |
|                                                                 | ⇅ | <div> <div>■ IEC NETWORK</div> <div>■ CLIENT ADDRESSES</div> </div> |                                     |
|                                                                 | ⇅ | IEC COMMON ADDRESS<br>OF ASDU: 0                                    | 0 to 65535 in steps of 1            |
|                                                                 | ⇅ | IEC CYCLIC DATA<br>PERIOD: 60 s                                     | Range: 1 to 65535 in steps of 1     |
|                                                                 | ⇅ | IEC CURRENT DEFAULT<br>THRESHOLD: 30000                             | Range: 0 to 100000000 in steps of 1 |
|                                                                 | ⇅ | IEC VOLTAGE DEFAULT<br>THRESHOLD: 30000                             | Range: 0 to 100000000 in steps of 1 |
|                                                                 | ⇅ | IEC POWER DEFAULT<br>THRESHOLD: 30000                               | Range: 0 to 100000000 in steps of 1 |
|                                                                 | ⇅ | IEC ENERGY DEFAULT<br>THRESHOLD: 30000                              | Range: 0 to 100000000 in steps of 1 |
|                                                                 | ⇅ | IEC PF DEFAULT<br>THRESHOLD: 1.00                                   | Range: 0.00 to 1.00                 |
|                                                                 | ⇅ | IEC OTHER DEFAULT<br>THRESHOLD: 30000                               | Range: 0 to 100000000 in steps of 1 |
|                                                                 | ⇅ | IEC REDUNDANCY<br>ENABLED: No                                       | Range: No, Yes                      |
|                                                                 | ↑ | IEC EVENT TIME BASE:<br>LOCAL                                       | Range: Local, UTC                   |

The relay supports the IEC 60870-5-104 protocol. IEC 60870-5-104 is a transmission protocol for network access, specifically for communication between a control station and substation over a TCP/IP network. The relay can be used as an IEC 60870-5-104 slave device connected to a maximum of two masters (usually either an RTU or a SCADA master station). Since the relay maintains two sets of IEC 60870-5-104 data change buffers, ideally no more than two masters actively communicate with the relay at one time.

#### IEC TCP PORT NUMBER

This setting sets the TCP port number. To close the port, set the port number to 0. Any change takes effect when the relay is restarted.

#### IEC COMMON ADDRESS OF ASDU

This setting sets the ASDU address number. The change takes effect when the relay is restarted.

#### IEC CYCLIC DATA PERIOD

This setting sets the time of each cycle. The change takes effect when the relay is restarted.

#### The DEFAULT threshold settings

The default threshold settings are used to determine when to trigger spontaneous responses containing M\_ME\_NC\_1 analog data. These settings group the analog data into types: current, voltage, power, energy, and other. Each setting represents the default threshold value for all M\_ME\_NC\_1 analog points of that type. For example, to trigger spontaneous responses from the relay when any current values change by 15 A, the **IEC**



**CURRENT DEFAULT THRESHOLD** setting is set to 15. Note that these settings are the default values of the deadbands. P\_ME\_NC\_1 (parameter of measured value, short floating point value) points can be used to change threshold values, from the default, for each individual M\_ME\_NC\_1 analog point. Whenever power is removed and re-applied, the default thresholds are in effect.

### IEC REDUNDANCY

This setting decides whether multiple client connections are accepted or not. If redundancy is set to *Yes*, two simultaneous connections can be active at any given time.

### IEC Event timebase

This setting sets which time source to use, Local or UTC.

*Note:*  
Do not set more than one protocol to the same TCP/UDP port number, as this results in unreliable operation of those protocols.

### IEC NETWORK CLIENT ADDRESS sub-menu

■ IEC NETWORK

■ CLIENT ADDRESSES

⇔

CLIENT ADDRESS <n>:

0.0.0.0

Range: standard IPV4 address format

where n = 1 to 5

### 8.4.4.12 IEC 60870-5-103 PROTOCOL

The relay is provided with optional IEC 60870-5-103 communications capability, specified as a software option at the time of ordering.

Setting path: **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > IEC 60870-5-103 PROTOCOL**

■ IEC103

■ PROTOCOL

⇔

IEC103 COMMON

ADDRESS OF ASDU: 0

Range: 0 to 254 in steps of 1

⇕

IEC103 SYNC TIMEOUT:

1

Range: 1 to 1440 min in steps of 1

⇕

■ IEC103 INPUTS

■ BINARY

⇕

■ IEC103 INPUTS

■ MEASURANDS

⇕

■ IEC103 COMMANDS

■

IEC 60870-5-103 is a companion standard to the IEC 60870-5 suite of standards for transmission protocols. It defines messages and procedures for interoperability between protection equipment and devices of a control system in a substation for communicating on a serial line.

The IEC 60870-5-103 is an unbalanced (master-slave) protocol for coded-bit serial communication, exchanging information with a control system. In the context of this protocol, the protection equipment is the slave and the control system is the master. The communication is based on a point-to-point principle. The master must be able to interpret the IEC 60870-5-103 communication messages.

The UR implementation of IEC 60870-5-103 consists of the following functions:

- Report binary inputs
- Report analog values (measurands)
- Commands
- Time synchronization

The RS485 port supports IEC 60870-5-103.

The UR Family Communications Guide contains more information on the protocol.

**IEC103 COMMON ADDRESS OF ASDU**


This setting uniquely defines this relay on the serial line. The ID is an integer between 0 and 254. This ID does not need to be in sequential order for all stations that communicate with a controller, but we recommend it. Note that RS485 allows a maximum of 32 slave stations on a communication line, so the entire range of 254 addresses is never exhausted.

**IEC103 SYNC TIMEOUT**

This setting defines the time that the relay waits for a synchronization message. The relay synchronizes its clock using all available sources, with the source synchronizing more frequently overwriting the time of the other sources. Since the synchronization message received from the IEC 60870-5-103 master is less frequent than IRIG-B, PTP, or SNTP, its time is overwritten by these three sources, if any of them is active. If the synchronization timeout occurs and none of IRIG-B, PTP, or SNTP is active, the relay sets the invalid bit in the time stamp of a time-tagged message.

The settings for the remaining sub-menus are outlined as follows.

**IEC 103 INPUTS BINARY sub-menus**



The binary input points are mapped using elements from a list of possible FlexLogic operands. A maximum of 96 binary inputs (points) can be mapped this way.

The IEC 60870-5-103 point list always starts with point 0 and ends at the first *Off* value. Since the IEC 60870-5-103 point list must be in a continuous block, any points assigned after the first *Off* point are ignored.

For each defined point, set appropriate values for the Function Type (FUN) and Information Number (INF), which form the Information Object Identifier field of the ASDU, as defined in IEC 60870-5-103.

The binary input points are sent as Class 1 data. They are sent either as a response to a general interrogation received from the controller or reported spontaneously. Spontaneous transmission occurs as a response to cyclic Class 2 requests. If the relay wants to transmit Class 1 data at that time, it demands access for Class 1 data transmission (ACD=1 in the control field of the response).

For any change to take effect, restart the relay.

IEC 103 INPUTS MEASURANDS sub-menus

■ IEC103 INPUTS

■ MEASURANDS



■ ASDU <n>

■

where n = 1 to 4

In the following, only ASDU 1 is shown.

■ ASDU 1:

■



|                   |               |
|-------------------|---------------|
| ASDU 1 TYP:       | 9             |
| ASDU <n> FUN:     | 0             |
| ASDU 1 INF:       | 0             |
| ASDU 1 SCAN TOUT: | 0             |
| ASDU 1 ANALOG <n> | Off           |
| ASDU 1 ANALOG <n> | FACTOR: 1.000 |
| ASDU 1 ANALOG <n> | OFFSET: 0     |

Range: 3 or 9

Range: 0 to 255 in steps of 1

Range: 0 to 255 in steps of 1

where n = 1 to 9

The configuration menu allows a maximum of four ASDUs containing measurands. Measurands are sent as a response to Class 2 requests, which are cyclic requests coming from the master.

TYPE IDENTIFICATION (TYP)

The configuration field TYP indicates how many measurands are present in the corresponding ASDU. Each ASDU can take either 4 or 9 measurands maximum, depending on the type identification. For any change to take effect, restart the relay.

FUNCTION TYPE (FUN) and INFORMATION NUMBER (INF)

These two fields form the Information Object Identifier of the ASDU as defined in IEC 60870-103. For any change to take effect, restart the relay.

SCAN TIMEOUT (SCAN TOUT)

This is the cyclic period used by the relay to decide when a measurand ASDU is included in a response. The measurand is sent as response to a Class 2 request when the corresponding timeout expires. The default value 0 means 500 ms.

ANALOG #

This field contains the actual measurand to be sent in the response to the master. The measurands can be mapped using elements from a list of FlexAnalog operands. The measurands sent are voltage, current, power, power factor, frequency and fault location (in km or miles). If any other FlexAnalog is chosen, the relay sends 0 instead of its value. Note that the power is transmitted in kW, not W. Measurands are transmitted as ASDU 3 or ASDU 9 (type identification value set to measurands I, respectively measurands II).

Each IEC 60870-5-103 measurands list ends at the first *Off* value. Any measurand assigned after the first *Off* value is ignored.

At least one measurand per ASDU must be configured in order to configure the following ASDU. For example, the user can configure only one measurand for each ASDU, but the user is not allowed to skip ASDU 2 and configure measurands in ASDU 3.

For any change to take effect, restart the relay.

### ANALOG # FACTOR and OFFSET

For each measurand included in the ASDU, a factor and offset also can be configured. The factor and offset allow for scaling to be performed on measurands. The final measurement sent to the IEC 60870-103 master is then  $ax + b$ , where  $x$  is the measurand,  $a$  is the multiplying factor and  $b$  is the offset. The master has to perform the reversed operation in order to retrieve the actual value if such scaling is done. By default  $a = 1$  and  $b = 0$ , so no scaling is done if these values are left at their defaults. Examples of when scaling is appropriate are as follows:

- If the measured value contains decimals and it is important to preserve the resolution.  
Since the format for transmitting the measurand does not permit decimals, a factor  $a > 1$  can be applied before transmission. For example, a frequency of 59.9Hz can be transmitted as  $F_t = 10 * F = 10 * 59.9 = 599$ . In this case  $a = 10$ ,  $b = 0$ . The master receives a value of 599 and has to divide by 10 to retrieve the real value of 59.9.
- If the measured value is larger than what fits in the format defined in IEC 103.  
The format defined in the standard allows for signed integers up to 4095. By offsetting, unsigned integers up to  $4096 + 4095 = 8191$  are supported. Scaling using factors  $< 1$  may be required in such cases. The calculation is outlined in the IEC 60870-5-103 chapter of the UR Family Communications Guide. Two examples follow, where you decide factors  $a$  and  $b$ .

#### Example 1

Nominal power  $P_n = 100 \text{ MW} = 100000 \text{ KW}$  (power is transmitted in KW)

Since  $P$  can be both positive and negative:

$$\text{Transmitted power } P_t = (4095/(P_n * 2.4)) * P = (4095/(100000 * 2.4)) * P = 0.017 * P$$

$$a = 0.017$$

$$b = 0$$

$$P_t = 0.017 * P$$

For a max power  $100000 \text{ KW} * 2.4 = 240000 \text{ KW}$ , we transmit

$$P_t = 0.017 * 240000 = 4080$$

A value above 240 MW is indicated by overflow.

#### Example 2

Nominal voltage  $V_n = 500000 \text{ V}$

Since RMS voltage  $V$  can be only positive:

$$\text{Transmitted voltage } V_t = (8191/(V_n * 2.4)) * V - 4096 = (8191/(500000 * 2.4)) * V - 4096 = 0.0068 * V - 4096$$

$$a = 0.0068$$

Since the step is in increments of 0.001, we round it at:

$$a = 0.006$$


$$b = -4096$$

$$V_t = 0.006 * V - 4096$$

For max voltage  $500000 \text{ V} * 2.4 = 1200000 \text{ V}$ , we transmit


$$V_t = 0.006 * 1200000 - 4096 = 7200 - 4096 = 3104$$

### IEC 103 COMMANDS sub-menus



where n = 0 to 31

In the following, only **COMMAND 0** is shown.



Commands are received as General Command (Type Identification 20). You can configure the action to perform when an ASDU command comes.

A list of available mappings is provided on the relay. This includes 128 virtual inputs (see the following table). The *ON* and *OFF* for the same ASDU command can be mapped to different virtual inputs.

Each command is identified by the unique combination made by the function type (FUN) and information number (INF). If the master sends an ASDU command that does not have the FUN and INF of any configured command, the relay rejects it.


### IEC 103 COMMANDS mapping table

| Description       | Value |
|-------------------|-------|
| Off               | 0     |
| Virtual Input 1   | 1     |
| Virtual Input 2   | 2     |
| ...               | ...   |
| Virtual Input 128 | 128   |

For any change to take effect, restart the relay.

#### 8.4.4.13 USB PORT

Setting path: **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > USB 2.0**



*Note:*  
This setting applies to the USB port on the graphical front panel

This setting enables/disables the USB port on the graphical front panel. When the port function is enabled, a standard USB serial cable allows a computer running the EnerVista UR Setup software to retrieve, display, and write settings either individually or collectively, to display status and actual values, to initiate controls, and to retrieve and display event records, oscillography records, data logger records, and disturbance records. Installation of the EnerVista software automatically installs the drivers required to use this USB port.

DNP is not available using the USB port on the graphical front panel.

### 8.4.5 MODBUS USER MAP

Setting path: **SETTINGS > PRODUCT SETUP > MODBUS USER MAP**

|                        |   |                       |                                                 |
|------------------------|---|-----------------------|-------------------------------------------------|
| ■ MODBUS USER MAP<br>■ | ⇔ | ADDR 1: 0<br>VALUE: 0 | n = 1 to 256<br>Range: 0 to 65535 in steps of 1 |
|------------------------|---|-----------------------|-------------------------------------------------|

The Modbus user map provides read-only access for up to 256 registers. The memory map can be read from the front panel, the UR Family Communications Guide, or in a web browser. For the web browser, enter the IP address of the Product and click a Modbus Memory Map option.

On the front panel, the address to read a specific Modbus register depends on whether the requested value is a setting or an actual value.

Up to firmware version 7.8x, the settings and actual values are in the same Modbus table. To obtain a memory map value, enter its address on the front panel.

Starting in firmware version 7.90, the settings have their own Modbus memory table and the actual values are in their own table. To obtain a memory map value, use the following sequence:

1. Obtain the hexadecimal Modbus address of the data item. It must have four digits, such as 024A.
2. Prefix the address by 3 for settings or by 4 for actual values.
3. Convert the resulting hexadecimal number to decimal.
4. Enter the resulting number in the first column of the Modbus user map. The corresponding value (if programmed) displays in second column (VALUE). A value of "0" in subsequent register lines automatically returns values of Modbus registers having the address of the previous line incremented by 1. These subsequent addresses are all in the same Modbus table (settings or actual values) as the address that was entered. An address value of "0" in the initial register means "none" and values of "0" display for all registers. Different address values can be entered as required in any of the register positions.

Here are two examples of how to add a setting or actual value to the front panel Modbus user map.

To add the setting **Phase TOC 1 Pickup** to the Modbus user map:

1. Find the address of the setting **Phase TOC 1 Pickup**, which is 334Eh (334E in hexadecimal format).
2. Prefix this address by 3 to obtain 3334Eh.
3. Convert this value to decimal to obtain 209742 and enter it on the front panel.

To add the actual value **SRC 1 Frequency** to the Modbus user map:

1. Find the address of the actual value **SRC 1 Frequency**, which is 1D80h.
2. Prefix this address by 4 to obtain 41D80h.
3. Convert this value to decimal to obtain 269696 and enter it on the front panel.

### 8.4.6 REAL-TIME CLOCK

Setting path: **SETTINGS > PRODUCT SETUP > REAL TIME CLOCK**

|                        |   |                                       |                                                                                       |
|------------------------|---|---------------------------------------|---------------------------------------------------------------------------------------|
| ■ REAL TIME<br>■ CLOCK | ⇔ | SYNCHRONIZING SOURCE:<br>None         | Range: None, PP/IRIG-B/PTP/Other, IRIG-B/PP/PTP/Other, PP/PTP/IRIG-B/Other, PBM Clock |
|                        | ⇕ | REAL TIME CLOCK EVENTS:<br>Disabled   | Range: Enabled, Disabled                                                              |
|                        | ⇕ | IRIG-B SIGNAL TYPE:<br>None           | Range: None, DC Shift, Amplitude Modulated                                            |
|                        | ⇕ | ■ PRECISION TIME<br>■ PROTOCOL (1588) |                                                                                       |

|   |                      |
|---|----------------------|
| ⇅ | ■ SNTP PROTOCOL<br>■ |
| ⇅ | ■ LOCAL TIME<br>■    |
| ↑ | ■ PBM PTP<br>■       |

The relay contains a real time clock (RTC) to create time stamps for communications protocols as well as for historical data, such as event records and oscillography. When the relay restarts, the RTC initializes from an onboard clock (backed up by supercapacitor for TL and TH models, or battery for SL and SH models). The RTC has an accuracy of approximately  $\pm 1$  minute per month ( $\sim 23$  ppm). Once the RTC is synchronized with the Precision Time Protocol (PTP), IRIG-B, or SNTP, its accuracy approaches that of the synchronizing time delivered to the relay. While the RTC is not synchronized via PTP or IRIG-B, or the relay determines that it has an offset possibly greater than  $10 \mu\text{s}$  from the international time standard, the **CLOCK UNSYNCHRONIZED** FlexLogic operand is activated. When channel asymmetry function is used, the relay's real time clock must be synchronized to an external time source using PTP or IRIG-B, typically from a global positioning system (GPS) receiver.

## SYNCHRONIZING SOURCE

This setting is shown when the relay includes the IEEE 1588 software option. The setting configures the priority sequence of the time synchronization source, to determine which of the available external time sources to use for time synchronization. A setting value of *None* causes the RTC and the synchrophasor clock to free-run, and the clock can be changed from the front panel or from communications protocols. A setting value of *PP/IRIG-B/PTP/Other*, *IRIG-B/PP/PTP/Other*, or *PP/PTP/IRIG-B/Other* causes the relay to track the first source named that is enabled and operational, or free-run if none of these are available. Here, *PP* means a time source that is strictly compliant with PP, *PTP* means a time source that is not strictly compliant with PP, and *Other* means any less precise source (SNTP, IEC 103, IEC 104, Modbus, or DNP). When a time source fails or recovers, the relay automatically transfers synchronization as required by this setting.

Selecting *PBM Clock* causes the relay to use the time source from any non-HardFiber Process Bus Module clock. If the Process Bus Module **PTP FUNCTION** setting is enabled and PTP grandmaster is available in the process bus network, the Process Bus Module clock is synchronized to the PTP grandmaster. If this is not the case, the Process Bus Module clock free-runs. A relay can use a synchronizing source either from the real-time clock (main CPU) or a Process Bus Module.

Note that a relay does not need to be time synchronized to accept the sampled values. All the elements (protection, control, monitoring, logic, and so on) in the UR (except Line Current Differential element) remain fully functional without requiring any external synchronizing source for the UR, as long as all the sampled values subscribed by the relay are synchronized according to the **Settings > Process Bus Module > General > SmpSynch Check** setting and pass the other acceptance criteria as defined in **Settings > Process Bus Module > SV Stream Config > Logic**.

**Note:**

Some UR applications like oscillography, event recorder, and datalogger use the real-time clock for time-stamping.

If clock synchronization is lost, the Line Current Differential function is blocked. All other elements remain functional.

When the relay does not have the IEEE 1588 software option and this setting does not display, it uses IRIG-B when enabled and operational. If IRIG-B is not available the it uses SNTP (if configured). If SNTP is not available it free-runs, unless the clock is changed from the front panel or from communications protocols.

For the Other protocols, whenever a time synchronization message is received through any of the active protocols, the clock updates. However, given that IEC 60870-5-103, IEC 60870-5-104, Modbus, and DNP are low-accuracy time synchronization methods, avoid their use for synchronization when better accuracy time protocols, such as IRIG-B and PTP, are available. If IRIG-B or PTP is used to update the relay clock, the other protocols (such as SNTP) are prevented from being used to update, even if active.

See the **COMMANDS > SET DATE AND TIME** menu section of this manual to manually set the RTC.

**Note:**  
*When 1 ms accuracy is required for events, oscillography, time stamping, synchrophasors, and 87L asymmetry with respect to the master clock, the PTP clock needs to be connected to the CPU of a relay. The 1 ms accuracy cannot be maintained if the CPU is synchronized through the Process Bus Module due to a delay up to 2 ms in transmitting a time stamp from the Process Bus Module to a CPU.*

**REAL TIME CLOCK EVENTS**

This setting allows changes to the date and/or time to be captured in the event record. The event records the RTC time before the adjustment. A Date/Time Changed event is generated when:

- The real time clock changed from *SNTP/PTP/IRIG-B* and the time difference is more than one second
- The real time clock changed from the front panel or via Modbus register. The relay always generates this event regardless of the time difference.
- The Daylight Saving Time (DST) setting gets enabled and the current relay time is already in the DST zone
- The real time clock enters or leaves DST

**IRIG-B SIGNAL TYPE**

To enable IRIG-B synchronization, the input **IRIG-B SIGNAL TYPE** must be set to *DC Shift* or *Amplitude Modulated*. Make this setting *None* to disable IRIG-B synchronization. When IRIG-B is enabled and active, clock synchronization by communication protocols DNP, IEC 60870-5-103 or IEC 60870-5-104 is blocked. Clock synchronization from the front panel and over Modbus is always enabled.

Clocks can be synchronized locally among several relays using the computer time. When using a time source, such as IRIG-B, the time is overwritten eventually by the time source. To synchronize clocks among UR devices:

1. In the EnerVista software, expand the main menu in the Online Window area and select the **Synchronize Devices** entry. The software prompts to acknowledge any offline devices.
2. Click the **Synchronize Devices** button at the top of the window, and confirm the action at the prompt. The devices adopt the time of the computer being used.

To configure and enable PTP and/or SNTP, or to set local time parameters (for example time zone, daylight savings), use the sub-menus described in the following sections.

The relay supports the adjustment of real-time clock for the leap second (addition or removal of a leap second) per applicable standards, when the UR is synchronized using PTP or IRIG-B. The Flexlogic operand LEAP SECOND DETECTED gets asserted for 1 second when leap second adjustment is made and event is recorded in the events log. The following functions are affected by the leap second time adjustment:

- Real-time clock
- Synchrophasors publishing and Comtrade recording
- Regular transient recorder Comtrade and data logger Comtrade.
- Event Logger

**8.4.6.1 PRECISION TIME PROTOCOL (1588)**

Setting path: **SETTINGS > PRODUCT SETUP > REAL TIME CLOCK > PRECISION TIME PROTOCOL (1588)**

|                   |   |                       |                          |
|-------------------|---|-----------------------|--------------------------|
| ■ PRECISION TIME  | ⇔ | STRICT POWER PROFILE: | Range: Enabled, Disabled |
| ■ PROTOCOL (1588) |   | Disabled              |                          |
|                   | ⇕ | PTP DOMAIN NUMBER:    | Range: 0 to 255          |
|                   |   | 0                     |                          |
|                   | ⇕ | PTP VLAN PRIORITY:    | Range: 0 to 7            |
|                   |   | 4                     |                          |



|   |                     |                  |
|---|---------------------|------------------|
| ⇅ | PTP VLAN ID:<br>0   | Range: 0 to 4095 |
| ↑ | ■ PTP PORT <n><br>■ |                  |

where n = 1 to 3

The following sub-menu for **PTP PORT <n>** is shown below:

### Sub-menu PTP PORT 1

|   |                                         |                                        |
|---|-----------------------------------------|----------------------------------------|
| ⇅ | ■ PTP PORT 1<br>■                       |                                        |
|   | PORT 1 PTP FUNCTION:<br>Disabled        | Range: Enabled, Disabled               |
|   | PORT 1 PATH DELAY ADDER:<br>0 ns        | Range: 0 to 60000 ns in steps of 1     |
| ↑ | PORT 1 PATH DELAY<br>ASYMMETRY:<br>0 ns | Range: -1000 to +1000 ns in steps of 1 |

The relay provides optional Precision Time Protocol (PTP) capability. This feature is specified as the IEEE 1588 software option at the time of ordering.

The relay supports the Precision Time Protocol (PTP) specified in IEEE Std 1588 2008 using the Power Profile (PP) specified in IEEE Std C37.238 2017. This enables the relay to synchronize to the international time standard over an Ethernet network that implements PP.

The relay can be configured to operate on some PTP networks that are not strictly PP compliant. Time accuracy can be less than specified for a PP network. Tolerated deviations from strict PP include:

- Missing declaration of PP compliance in the messages
- Connection to a network device that does not support the PTP peer delay mechanism
- Jitter substantially greater than 1 µs in received event messages
- Certain non-compliant announce and sync message update rates

The relay implements PTP according to IEEE Std 1588 2008 and the equivalent IEC 61588:2009(E), sometimes referred to as version 2 PTP. It does not support version 1 of the standard.

PTP is a protocol that allows multiple clocks in a network to synchronize with one another. It permits synchronization accuracies better than 1 ns, but this requires that each and every component in the network can achieve very high levels of accuracy and a very high baud rate, faster than normally used for relay communications. When operating over a generic Ethernet network, time errors can amount to 1 ms or more. PP is a profile of PTP which specifies a limited subset of PTP suitable for use in power system protection, control, automation, and data communication applications, and thereby facilitates interoperability between different vendor's clocks and switches. PP specifies a worst-case delivered time error of less than 1 µs over a 16-hop network.

In a PTP system and in a PP system, the clocks automatically organize themselves into a master-slave synchronization hierarchy with the best clock available making itself the 'grandmaster' at the top of the hierarchy. All other clocks make themselves slaves and track the grandmaster. Typically the grandmaster clock receives its time from GPS satellites or some other link to the international time standard. If the grandmaster fails, the next best clock available in the domain assumes the grandmaster role. When a clock on start-up discovers that it is better than the present grandmaster, it adopts the grandmaster role and the previous grandmaster reverts to slave. The qualification mechanism accepts a potential master clock as a new grandmaster, when in a four-second interval it has received three announce messages from it, all better than the present grandmaster clock and better than any other announce in this interval.

Time messages issued by the grandmaster are delayed as they pass through the network both due to the finite speed of the signal in the interconnecting fiber or wire, and due to processing delays in the Ethernet switches. Each clock and switch implementing PP measures the propagation delay to each of its PP neighbors, and compensates

for these delays in the time received. Each network device implementing PP measures the processing delay it introduces in each time message and compensates for this delay in the time it transmits. As a result, the time delivered to end-devices such as the relay, are virtually identical to the grandmaster time. If one of the network devices in the hierarchy does not fully implement PP, the associated propagation delay and/or latency may not be compensated for, and the time received at the end-device can be in error by more than 100  $\mu$ s.

The following settings are available for configuring the relay for PTP. The PTP menu displays only when the option is purchased.

### STRICT POWER PROFILE

Power profile (IEEE Std C37.238 2017) requires that the relay only selects a clock as a grandmaster, which is compliant with PP. This means the delivered time has a worst-case error of  $\pm 1 \mu$ s, and the peer delay mechanism is implemented. With the strict power profile setting enabled, the relay only selects as master the clocks displaying the IEEE\_C37\_238 identification codes. It uses a port only when the peer delay mechanism is operational. With the strict power profile setting disabled, the relay uses clocks without the power profile identification when no power profile clocks are present, and uses ports, even if the peer delay mechanism is non-operational. This setting applies to all of the relay's PTP-capable ports.

### PTP DOMAIN NUMBER

Set this setting to the domain number of the grandmaster-capable clock(s). A network can support multiple time distribution domains, each distinguished with a unique domain number. More commonly, there is a single domain using the default domain number zero. This setting applies to all of the relay's PTP-capable ports.

### PTP VLAN PRIORITY

This setting selects the value of the priority field in the 802.1Q VLAN tag in request messages issued by the relay's peer delay mechanism. In compliance with PP, the default VLAN priority is 4, but we recommend you set it to 7 in accordance with PTP. Depending on the characteristics of the device to which the relay is linked directly, VLAN Priority may have no effect. This setting applies to all of the relay's PTP-capable ports.

### PTP VLAN ID

This setting selects the value of the ID field in the 802.1Q VLAN tag in request messages issued by the relay's peer delay mechanism. It is provided in compliance with PP. As these messages have a destination address that indicates they are not to be bridged, their VLAN ID serves no function, and so can be left at its default value. Depending on the characteristics of the device to which the relay is linked, VLAN ID may have no effect. This setting applies to all of the relay's PTP-capable ports.

The settings in the sub-menu **PTP PORT <n>** are now described

### PTP PORT <n> FUNCTION

This setting enables or disables the PTP function on the port.

### PTP PORT <n> PATH DELAY ADDER

This setting sets the time compensation for the path delay. The time delivered by PTP is advanced by the set time value prior to the time being used to synchronize the relay's real time clock. This is to compensate for time delivery delays not compensated for in the network. In a fully compliant PP network, the peer delay and the processing delay mechanisms compensate for all the delays between the grandmaster and the relay. In such networks, make this setting zero. In networks containing one or more switches and/or clocks that do not implement both of these mechanisms, not all delays are compensated, so the time of message arrival at the relay is later than the time indicated in the message. This setting can be used to approximately compensate for this delay. However, as the relay is not aware of network switching that dynamically changes the amount of uncompensated delay, there is no setting that always and completely corrects for uncompensated delay. A setting can be chosen that reduces the worst-case error to half of the range between minimum and maximum uncompensated delay, if these values are known.

### PTP PORT <n> PATH DELAY ASSYMMETRY

This setting corresponds to *delayAsymmetry* in PTP, which is used by the peer delay mechanism to compensate for any difference in the propagation delay between the two directions of a link. Except in unusual cases, the two fibers are of essentially identical length and composition, so make this setting zero. In unusual cases where the length of the link is different in different directions, set this setting to the number of nanoseconds the Ethernet propagation delay to the relay is longer than the mean of path propagation delays to and from the relay. For instance, if it is known say from the physical length of the fibers and the propagation speed in the fibers that the delay from the relay to the Ethernet switch it is connected to is 9000 ns and that the delay from the switch to the relay is 11000 ns, then the mean delay is 10000 ns, and the path delay asymmetry is 11000 - 10000 = +1000 ns.

### 8.4.6.2 SNTP PROTOCOL

Setting path: **SETTINGS > PRODUCT SETUP > REAL TIME CLOCK > SNTP PROTOCOL**

|                                         |   |                                                |                                   |
|-----------------------------------------|---|------------------------------------------------|-----------------------------------|
| <div>■ SNTP PROTOCOL</div> <div>■</div> | ↔ | <div>SNTP FUNCTION:<br/>Disabled</div>         | Range: Enabled, Disabled          |
|                                         | ⇅ | <div>SNTP SERVER1 IP<br/>ADDR: 127.0.0.1</div> | Range: standard IP address format |
|                                         | ⇅ | <div>SNTP SERVER2 IP<br/>ADDR: 127.0.0.1</div> | Range: standard IP address format |
|                                         | ⇅ | <div>SNTP SERVER1 UDP<br/>PORT: 123</div>      | Range: 0 to 65535 in steps of 1   |
|                                         | ⇅ | <div>SNTP SERVER2 UDP<br/>PORT: 123</div>      | Range: 0 to 65535 in steps of 1   |

The relay supports the Simple Network Time Protocol specified in RFC-2030. With SNTP, the relay can obtain clock time over an Ethernet network. The relay acts as an SNTP client to receive time values from redundant SNTP/NTP servers, usually a dedicated product using a GPS receiver to provide an accurate time. One or two SNTP servers can be used; use of both servers for redundancy is recommended but not required.

To use SNTP, enable the function and set the IP addresses of **SNTP SERVER1 IP ADDR** and **SNTP SERVER2 IP ADDR**. The relay attempts to obtain time values from server 1. If server 1 is not available the relay tries server 2.

Since many time values are obtained and averaged, it generally takes three to four minutes until the relay clock is closely synchronized with the SNTP/NTP server. It can take up to 20 minutes for the relay to signal an SNTP self-test error if the server is offline, depending on the number and SNTP server modes. Broadcast mode timeout is 10 minutes and unicast timeout is 80 seconds (corresponds to three unicast request retries).

#### SNTP FUNCTION

Enables or disables the SNTP feature on the relay.

#### SNTP SERVER1 IP ADDR

This sets the SNTP Server 1 IP address. If SERVER1 SNTP server is set to 127.0.0.1, the relay considers the SERVER1 SNTP server to be not configured. To use SERVER1 SNTP in broadcast mode, set the SNTP SERVER1 IP ADDR setting to "0.0.0.0" The relay SNTP client then listens to SNTP messages sent to the broadcast address for the subnet. The relay waits up to 18 minutes (>1024 seconds) without receiving an SNTP broadcast message before switching to the alternate channel.

#### SNTP SERVER2 IP ADDR

This sets the SNTP Server 2 IP address. The relay uses this address to contact an SNTP/NTP server if SERVER1 channel fails or is not reachable. The operation of SNTP server is the same as described for SNTP 1 server.

### SNTP SERVER1 UDP PORT

This setting is 123 for normal SNTP operation. If SERVER1 SNTP is not required, close the port by changing this setting to zero.

### SNTP SERVER2 UDP PORT

This setting is 123 for normal SNTP operation. If SERVER2 SNTP is not required, close the port by changing this setting to zero.

*Note:*

*Do not set more than one protocol to the same TCP/UDP port number, as this results in unreliable operation of those protocols.*

*Note:*

*If **SERVER1 IP ADDR** and **UDP PORT** settings match the **SERVER2 IP ADDR** and **UDP PORT** settings, the relay considers only the **SERVER1 SNTP** server as being configured and generates an SNTP Failure error message. The failure message also displays when both servers are unavailable.*

#### 8.4.6.3 LOCAL TIME

Setting path: **SETTINGS > PRODUCT SETUP > REAL TIME CLOCK > LOCAL TIME**

|                                                   |   |                                       |                                                  |
|---------------------------------------------------|---|---------------------------------------|--------------------------------------------------|
| <div> <div>■ LOCAL TIME</div> <div>■</div> </div> | ⇔ | LOCAL TIME OFFSET FROM UTC:<br>0.0 hr | Range: –24.0 to 24.0 hr in steps of 0.5          |
|                                                   | ⇕ | DAYLIGHT SAVINGS TIME:<br>Disabled    | Range: Disabled, Enabled                         |
|                                                   | ⇕ | DST START MONTH:<br>January           | Range: January to December (all months)          |
|                                                   | ⇕ | DST START DAY:<br>Sunday              | Range: Sunday to Saturday (all days of the week) |
|                                                   | ⇕ | DST START DAY INSTANCE:<br>First      | Range: First, Second, Third, Fourth, Last        |
|                                                   | ⇕ | DST START HOUR:<br>2:00               | Range: 0:00 to 23:00 in steps of one hour        |
|                                                   | ⇕ | DST STOP MONTH:<br>January            | Range: January to December (all months)          |
|                                                   | ⇕ | DST STOP DAY:<br>Sunday               | Range: Sunday to Saturday (all days of the week) |
|                                                   | ⇕ | DST STOP DAY INSTANCE:<br>First       | Range: First, Second, Third, Fourth, Last        |
|                                                   | ↑ | DST STOP HOUR:<br>2:00                | Range: 0:00 to 23:00 in steps of one hour        |

The relay maintains two times: local time and Universal Coordinated Time (UTC). Local time can be provided by IRIG-B signals. UTC time is provided by SNTP servers.

The real-time clock (RTC) and time stamps reported in historical records and communication protocols may be incorrect if the Local Time settings are not properly configured.

See the IRIG-B section in the Installation chapter for guidance on these settings when using an IRIG-B source that sets the IRIG-B control bits according to IEEE Std 1344-1995.

LOCAL TIME OFFSET FROM UTC

This setting is used to specify the local time zone offset from UTC (Greenwich Mean Time) in hours. Time zones in the eastern hemisphere have positive values; time zones in the western hemisphere have negative values. A value of zero causes the relay to use UTC for local time. This setting has two uses. When the system RTC is synchronized with a communications protocol providing only local time or it is free-running, the offset setting is used to calculate UTC from the local time these provide. When the RTC is synchronized with a communications protocol providing only UTC (such as PTP or SNTP), the time offset setting is used to determine local time from the UTC provided. PTP ALTERNATE\_TIME\_OFFSET\_INDICATOR TLVs are not used to calculate local time.

DAYLIGHT SAVINGS TIME

This setting enables or disables daylight saving time.

DST settings

You use these settings to allow the relay to follow the DST rules of the local time zone. Note that when IRIG-B time synchronization is active, the local time in the IRIG-B signal contains any daylight savings time offset and so the DST settings are ignored.

Note that the following items do not include the DST:

- Time of Day Timer Start Time
- Time of Day Timer Stop Time
- Event Recorder Last Cleared Date
- Source x Demand VAR Maximum Date
- Source x Demand WATT Maximum Date
- Source x Demand VA Maximum Date
- Source x Demand Ia Maximum Date
- Source x Demand Ib Maximum Date
- Source x Demand Ic Maximum Date
- PMU x Last Cleared Date
- PMU One-Shot Time
- Data Logger Newest Time
- Data Logger Oldest Time
- Oscillography Last Cleared Date
- Last Settings Change Date
- User Programmable Fault Report Cleared Date
- Digital Counter x Frozen Time Stamp
- HIZ RMS Capture x Time
- HIZ Capture x Time.

8.4.6.4 PBM PTP

Setting path: *SETTINGS > PRODUCT SETUP > REAL TIME CLOCK > PBM PTP*

|                                   |   |                                      |                                            |
|-----------------------------------|---|--------------------------------------|--------------------------------------------|
| <div>■ PBM PTP</div> <div>■</div> | ⇔ | PTP FUNCTION:<br>Disabled            | Range: Disabled, Master-Slave, Slave-only  |
|                                   | ⇕ | PTP PROFILE:<br>Power Utility Profil | Range: Power Utility Profil, Power Profile |
|                                   | ⇕ | PTP DOMAIN NUMBER:<br>93             | Range: 0 to 255                            |

|   |                          |                  |
|---|--------------------------|------------------|
| ⇅ | PTP VLAN PRIORITY:<br>4  | Range: 0 to 7    |
| ⇅ | PTP VLAN ID:<br>0        | Range: 0 to 4094 |
| ⇅ | PTP MASTER PRIO1:<br>128 | Range: 0 to 255  |
| ⇅ | PTP MASTER PRIO2:<br>128 | Range: 0 to 255  |
| ⇅ | ■ Port <n>a<br>■         |                  |
| ↑ | ■ Port <n>a<br>■         |                  |

where n = 1 to 4.

A different time source is set for the Process Bus Module. The Process Bus Module supports the Precision Time Protocol (PTP) as PTP master and slave functionality. The PTP state of each port is determined by the PTP settings and grandmaster clock availability on the local network. Time synchronization supports IEEE 1588 PTPv2.

### PBM PTP configuration

The relay supports IEEE 1588 PTPv2 as PTP Slave or PTP Master on its Process Bus Module ports. It can be supplied with an external RTC clock from the main CPU ports (station bus ports), the Process Bus Module ports, or both. It utilizes one of the two clocks depending upon the configuration of the synchronization source and PTP function as follows:

To use an external PTP Grand Master clock from the Process Bus Module port (UR acts as PTP Slave only), configure the following settings:

- **SETTINGS > PRODUCT SETUP > REAL TIME CLOCK > SYNCHRONIZING SOURCE** = *PBM clock*
- **SETTINGS > PRODUCT SETUP > REAL TIME CLOCK > PBM PTP > PTP FUNCTION** = *Slave-only*

With this configuration, the relay RTC will use the clock from the Process Bus Module port. For ensuring full functionality of the line current differential element including channel asymmetry compensation, this combination of settings is not recommended. If channel asymmetry is enabled with this combination of settings, the line current differential element is permanently blocked as indicated by the operand 87L DIFF BLOCKED. For the full and proper functionality of the line current differential element, the PTP clock available at Station bus/CPU port should be used as described later in this section.

If the **SETTINGS > PRODUCT SETUP > REAL TIME CLOCK > SYNCHRONIZING SOURCE** setting is *PBM clock* and the **SETTINGS > PRODUCT SETUP > REAL TIME CLOCK > PBM PTP > PTP FUNCTION** setting is disabled, the RTC clock free-runs.

To use an external PTP Grand Master clock from the Process Bus Module port (UR in PTP Slave mode) or to enable the relay as PTP Master on its Process Bus Module ports, configure the following settings:

- **SETTINGS > PRODUCT SETUP > REAL TIME CLOCK > SYNCHRONIZING SOURCE** = *PBM clock*
- **SETTINGS > PRODUCT SETUP > REAL TIME CLOCK > PBM PTP > PTP FUNCTION** = *Master-Slave*

With this configuration, the relay RTC uses the clock from the Process Bus Module port.

To use an external clock through a main CPU port (PTP Slave, IRIG-B, other source) and to enable the relay as PTP Master on its Process Bus Module ports, configure the following settings:

- **SETTINGS > PRODUCT SETUP > REAL TIME CLOCK > SYNCHRONIZING SOURCE** = *PP/IRIG-B/PTP/Other*, or *IRIG-B/PP/PTP/Other*, or *PP/PTP/IRIG-B/Other*
- **SETTINGS > PRODUCT SETUP > REAL TIME CLOCK > PBM PTP > PTP FUNCTION** = *Master-Slave*, or *Slave*, or *Disabled*

With this configuration, the relay RTC uses the clock from the main CPU port.

**Note:**

*Some UR applications like oscillography, event recorder, and datalogger use the real-time clock for time-stamping.*

In all of these scenarios, when the Grand Master clock is not available through a CPU port and/or Process Bus Module, all the elements except the Line Current Differential element, remain functional without requiring any external synchronizing source for the relay, as long as all the sampled values subscribed by the relay are synchronized according to the setting defined in **SETTINGS > PROCESS BUS MODULE > GENERAL > SMPSYNCH CHECK** and pass the other acceptance criteria.

The settings are as follows:

### PTP FUNCTION

This setting sets the source for time synchronization for the Process Bus Module. When disabled, PTP is disabled on all ports of the Process Bus Module. When set to *Master-Slave*, the Process Bus Module acts as a PTP slave when a grandmaster clock is available in the communication path. If no better clock than its own clock is available in the communication path, the module switches to master mode and provides the grandmaster functionality by sending Announce frames and other supporting PTP Master frames.

When set to *Slave-only*, the Process Bus Module acts as a PTP slave ordinary clock if a grandmaster clock is available in the network. If no grandmaster clock is available in the communication path, the module continues to wait for the Announce messages.

When PTP is enabled but no grand master is available on any of the Process Bus Module ports, *PB PTP Failure* events are generated.

To view the synchronizing source, see the setting **ACTUAL VALUES > PB MODULE > TIME SYNC > SYNC SOURCE**.

### PTP PROFILE

This specifies the profile to be used for PTP Master communication. The Power Utility Profile option relates to IEC 61850-9-3, while the Power Profile option relates to IEEE C37.238 2017. When the Process Bus Module PTP is in the slave state, this setting has no effect. As a slave, the Process Bus Module accepts both the Power Profile and the Power Utility Profile.

### PTP DOMAIN NUMBER

This sets the PTP domain number. Set this to the domain number of the grandmaster-capable clock(s) to synchronize to. A network can support multiple time distribution domains, each distinguished with a unique domain number. The Power Utility Profile recommends 93 as the value for the domain number.

### PTP VLAN PRIORITY

This setting selects the value of the priority field in the 802.1Q VLAN tag in PTP request messages issued by the relay.

### PTP VLAN ID

This setting selects the value of the ID field in the 802.1Q VLAN tag in PTP request messages issued by the relay. As these messages have a destination address that indicates they are not to be bridged, their VLAN ID serves no function, and so the setting can be left at its default value. Depending on the characteristics of the device to which the relay is directly linked, VLAN ID can have no effect.

### PTP MASTER PRIO1

**Priority1** is used in the execution of the best master clock algorithm and lower values take precedence. The operation of the best master clock algorithm selects clocks from a set with a lower value of priority1 over clocks



from a set greater than priority1. The setting values Priority1 and Priority2 decide when the UR Process Bus Module ports are selected as grandmaster clock. In a single LAN, we recommend the following:

- Set **PTP MASTER PRIO1** higher than the actual grandmaster, so that the grandmaster(s) takes precedence over the relay
- Set **PTP MASTER PRIO1** the same as all the Process Bus Module ports participating in one communication path
- Use **PTP MASTER PRIO2** to further prioritize the Process Bus Module ports in the network. The relay with lower value is selected as best master when **Priority1**, **clockClass**, **clockAccuracy**, and **scaledOffsetLogVariance** are the same. The setting is editable in the software when the **PTP FUNCTION** setting is *Master-Slave*.

### PTP MASTER PRIO2


**Priority2** is used in the execution of the best master clock algorithm and lower values take precedence. If the operation of the best master clock algorithm fails to order the clocks based on the values of **priority1**, **clockClass**, **clockAccuracy**, and **scaledOffsetLogVariance**, the **priority2** attribute allows the creation of up to 256 priorities to further fine-tune the selection of best clocks. If **Priority2** is configured the same for two URs in the same communication path, best master clock algorithm uses clockidentity to resolve the tie-breaker. The setting is editable in the software when the **PTP FUNCTION** setting is *Master-Slave*.

*Note:*

Independent of the **NETWORK CONFIG** and **PTP FUNCTION** settings, the enabled transceiver ports on the Process Bus Module operate in stateless transparent clock mode. We recommend always setting the **NETWORK CONFIG** setting to match with the network topology to avoid unnecessary data storms. For example, if the PRP network has multiple relays connected on a PRP LAN and if the **NETWORK CONFIG** setting is misconfigured to *Independent*, PTP messages other than *PDelay* messages are forwarded between the connected ports, which can create a PTP data storm.

### Sub-menus for ports 1a to 4b

The **PBM PTP** menu also has sub-menus for eight different port settings; Port 1a, 1b, 2a, 2b, 3a, 3b, 4a and 4b. Only one is shown here.



These setting are editable in the software when the **PTP FUNCTION** setting is not disabled.

Up to eight ports display here, depending on the Process Bus Module.

Default port assignments for the Process Bus Module are as follows:

- Parallel Redundancy Protocol (PRP) — Ports 1a and 1b are enabled
- High-Availability Seamless Redundancy (HSR) — Ports 1a and 1b are enabled
- Dual HSR — Ports 1a and 1b support HSR-1, and ports 3a and 3b support HSR-2
- INDEPENDENT — Ports 1a to 4b are enabled

Port availability by order code is as follows:

- 85 — Ports 1a and 1b, or 3a and 3b
- 86 — All eight ports
- 87 — All eight ports

For the following two settings, there is no dependency on the **NETWORK CONFIG** setting. For order code 85, ports 1a, 1b, 3a, and 3b settings are available. For order codes 86 and 87, all the port settings are available. Configure



these settings as per your network. For example, for order code 85, while ports 1a, 1b, 3a, and 3b settings display, configure ports 1a and 1b when your network uses these two ports.

### PATH DELAY ADDER

This setting sets the time compensation for the path delay. The time delivered by PTP is advanced by the set time value prior to the time being used to synchronize the relay's real time clock. This is to compensate for time delivery delays not compensated for in the network. In a fully compliant PP network, the peer delay and the processing delay mechanisms compensate for all the delays between the grandmaster and the relay. In such networks, make this setting zero. In networks containing one or more switches and/or clocks that do not implement both of these mechanisms, not all delays are compensated, so the time of message arrival at the relay is later than the time indicated in the message. This setting can be used to approximately compensate for this delay. However, as the relay is not aware of network switching that dynamically changes the amount of uncompensated delay, there is no setting that always and completely corrects for uncompensated delay. A setting can be chosen that reduces the worst-case error to half of the range between minimum and maximum uncompensated delay, if these values are known.

Restart the relay after changing this setting, for example using **Maintenance > Reboot Relay**.

### PATH DELAY ASYMMETRY

This setting corresponds to *delayAsymmetry* in PTP, which is used by the peer delay mechanism to compensate for any difference in the propagation delay between the two directions of a link. Except in unusual cases, the two fibers are of essentially identical length and composition, so make this setting zero. In unusual cases where the length of the link is different in different directions, set this setting to the number of nanoseconds the Ethernet propagation delay to the relay is longer than the mean of path propagation delays to and from the relay. For instance, if it is known say from the physical length of the fibers and the propagation speed in the fibers that the delay from the relay to the Ethernet switch it is connected to is 9000 ns and that the delay from the switch to the relay is 11000 ns, then the mean delay is 10000 ns, and the path delay asymmetry is 11000 - 10000 = +1000 ns.

#### 8.4.6.5 IRIG-B

**Setting path: SETTINGS > PRODUCT SETUP > REAL TIME CLOCK > IRIG-B**

|                                                                        |   |                                        |                                            |
|------------------------------------------------------------------------|---|----------------------------------------|--------------------------------------------|
| <input checked="" type="checkbox"/> IRIG-B<br><input type="checkbox"/> | ⇔ | IRIG B SIGNAL TYPE:<br>None            | Range: None, DC Shift, Amplitude Modulated |
|                                                                        | ↑ | UTC OFFSET USE:<br>LOCAL TIME SETTINGS | Range: Local Time settings, IRIG-B Time    |

### IRIG B SIGNAL TYPE

This setting enables IRIG B synchronization. The input IRIG B signal type must be set to DC Shift or Amplitude Modulated using the **Settings > Product Setup > Real Time Clock > IRIG-B > IRIG B Signal Type** setting. IRIG B synchronization may be disabled by making this setting None.

### UTC OFFSET

This setting defines how the Local Time is derived from the IRIG-B time.

When set to *LOCAL TIME SETTINGS*, the time offset code in the IRIG control bits is used as follows (to ensure backward compatibility for Firmware versions prior to 8.6):

$$\text{UTC\_Time} = \text{IRIG-B\_Time} - \text{Time\_Offset (IRIG-B CF bits, including the DST)}$$

Use the following equation to get local time:

$$\text{Local\_Time} = \text{UTC\_Time} + \text{LOCAL TIME OFFSET FROM UTC(setting under REAL TIME CLOCK/LOCAL TIME menu)}$$

Finally, the DST time is determined by the Relay DST setting.

When set to *IRIG-B TIME*, the relay derives UTC time and Local Time from IRIG-B time itself and doesn't need relay **LOCAL TIME** settings.

$$\text{UTC\_Time} = \text{IRIG-B\_Time} - \text{Time\_Offset} \text{ (IRIG-B CF bits, including the DST)}$$

$$\text{Local\_Time} = \text{IRIG-B\_Time}$$

### 8.4.7 USER-PROGRAMMABLE FAULT REPORTS

Setting path: **SETTINGS > PRODUCT SETUP > FAULT REPORT 1(2)**

|                                                                      |   |                                      |                                               |
|----------------------------------------------------------------------|---|--------------------------------------|-----------------------------------------------|
| <div><div>■ USER-PROGRAMMABLE</div><div>■ FAULT REPORT 1</div></div> | ⇔ | FAULT REPORT 1<br>FUNCTION: Disabled | Range: Disabled, Enabled                      |
|                                                                      | ⇕ | PRE-FAULT 1 TRIGGER:<br>Off          | Range: FlexLogic operand                      |
|                                                                      | ⇕ | FAULT 1 TRIGGER<br>Off               | Range: FlexLogic operand                      |
|                                                                      | ↑ | FAULT REPORT <n><br>Off              | Range: Off, any actual value analog parameter |

When enabled, this function monitors the pre-fault trigger. The pre-fault data are stored in the memory for prospective creation of the fault report on the rising edge of the pre-fault trigger. The element waits for the fault trigger as long as the pre-fault trigger is asserted, but not shorter than 1 second. When the fault trigger occurs, the fault data is stored and the complete report is created. If the fault trigger does not occur within 1 second after the pre-fault trigger drops out, the element resets and no record is created.

The user programmable record contains the following information: the user-programmed relay name, detailed firmware revision (x.xx, for example) and relay model (Product), the date and time of trigger, the name of pre-fault trigger (a specific FlexLogic operand), the name of fault trigger (a specific FlexLogic operand), the active setting group at pre-fault trigger, the active setting group at fault trigger, pre-fault values of all programmed analog channels (one cycle before pre-fault trigger), and fault values of all programmed analog channels (at the fault trigger).

Each fault report is stored as a file to a maximum capacity of ten files. An eleventh trigger overwrites the oldest file. The EnerVista software is required to view all captured data. A FAULT RPT TRIG event is automatically created when the report is triggered.

The relay includes two user-programmable fault reports to enable capture of two types of trips (for example, trip from thermal protection with the report configured to include temperatures, and short-circuit trip with the report configured to include voltages and currents). Both reports feed the same report file queue.

The last record is available as individual data items via communications protocols.

#### PRE-FAULT 1 TRIGGER

Specifies the FlexLogic operand to capture the pre-fault data. The rising edge of this operand stores one cycle-old data for subsequent reporting. The element waits for the fault trigger to actually create a record as long as the operand selected as PRE-FAULT 1 TRIGGER is "On." If the operand remains "Off" for 1 second, the element resets and no record is created.

#### FAULT 1 TRIGGER

Specifies the FlexLogic operand to capture the fault data. The rising edge of this operand stores the data as fault data and results in a new report. The trigger (not the pre-fault trigger) controls the date and time of the report.

#### FAULT REPORT 1 # 1 to FAULT REPORT 1 #32

These settings specify an actual value such as voltage or current magnitude, true RMS, phase angle, frequency, temperature, and so on, to be stored when the report is created. Up to 32 channels can be configured. Two reports are configurable to cope with variety of trip conditions and items of interest.

### 8.4.8 OSCILLOGRAPHY

Setting path: **SETTINGS > PRODUCT SETUP > OSCILLOGRAPHY**

|                                                      |   |                                         |                                         |
|------------------------------------------------------|---|-----------------------------------------|-----------------------------------------|
| <div> <div>■ OSCILLOGRAPHY</div> <div>■</div> </div> | ⇔ | NUMBER OF RECORDS:<br><n>               | Range: 3 to 64 in steps of 1            |
|                                                      | ⇕ | TRIGGER MODE:<br>Automatic Overwrite    | Range: Automatic Overwrite, Protected   |
|                                                      | ⇕ | TRIGGER POSITION:<br>50%                | Range: 0 to 100% in steps of 1          |
|                                                      | ⇕ | TRIGGER SOURCE:<br>Off                  | Range: FlexLogic operand                |
|                                                      | ⇕ | AC INPUT WAVEFORMS:<br>64 samples/cycle | Range: Off, 8, 16, 32, 64 samples/cycle |
|                                                      | ⇕ | ■ DIGITAL CHANNELS<br>■                 |                                         |
|                                                      | ⇕ | ■ ANALOG CHANNELS<br>■                  |                                         |

Oscillography records contain waveforms captured at the sampling rate as well as other relay data at the point of trigger. Oscillography records are triggered by a programmable FlexLogic operand. Multiple oscillography records can be captured simultaneously.

To retrieve an Oscillography record from a relay:

1. If not yet set up for oscillography, configure settings under **Settings > Product Setup > Oscillography** in the EnerVista software.
2. Access **Actual Values > Records > Oscillography** in the EnerVista software.
3. In the window that opens, select the record number. The highest number is the most recent record (Newest Record Number).
4. Click the **Read** button to get the waveform. When available, waveforms are displayed graphically, and otherwise error messages display.
5. In the waveform window that opens, you can save the file, for example with the CFG extension.

When EnerVista UR Setup creates a new settings file, a Smart defaults feature automatically enters a basic oscillography configuration. The basic configuration changes the factory default values to make the number of samples per cycle 32, adds a selection of digital and analog channels that are often of interest, and adds a FlexLogic equation to trigger oscillography. Review and update this basic configuration as required for the application at hand.

#### NUMBER OF RECORDS

The number of records is selectable, but the number of cycles captured in a single record varies considerably based on other factors, such as sample rate and the number of operational modules. There is a fixed amount of data storage for oscillography; the more data captured, the less the number of cycles captured per record. See the **ACTUAL VALUES > RECORDS > OSCILLOGRAPHY** menu to view the number of cycles captured per record. The following table provides sample configurations with corresponding cycles/record. The minimum number of oscillographic records is three.

| Records | CT/VTs | Sample rate | Digital channels | Analog channels | Cycles per record |
|---------|--------|-------------|------------------|-----------------|-------------------|
| 3       | 1      | 32          | 32               | 16              | 2399              |

| Records | CT/VTs | Sample rate | Digital channels | Analog channels | Cycles per record |
|---------|--------|-------------|------------------|-----------------|-------------------|
| 3       | 1      | 64          | 32               | 16              | 1450              |
| 16      | 1      | 32          | 32               | 16              | 666               |
| 16      | 1      | 64          | 32               | 16              | 402               |
| 32      | 1      | 32          | 32               | 16              | 352               |
| 32      | 1      | 64          | 32               | 16              | 213               |
| 3       | 2      | 32          | 32               | 16              | 1516              |
| 3       | 2      | 64          | 32               | 16              | 851               |
| 16      | 2      | 32          | 32               | 16              | 421               |

### TRIGGER MODE

A new record automatically overwrites an older record when **TRIGGER MODE** is set to *Automatic Overwrite*. This keeps the number of available records equal to the **NUMBER OF RECORDS** setting value. When **TRIGGER MODE** is set to *Protected*, new records stop being captured once the number of captured records becomes equal to the **NUMBER OF RECORDS** value.

### TRIGGER POSITION

Set this to a percentage of the total buffer size (for example, 10%, 50%, 75%, and so on). A trigger position of 25% consists of 25% pre- and 75% post-trigger data.

### TRIGGER SOURCE

Always captured in oscillography and can be any FlexLogic parameter (element state, contact input, virtual output, and so on). The relay sampling rate is 64 samples per cycle.

### AC INPUT WAVEFORMS

Determines the sampling rate at which AC input signals (that is, current and voltage) are stored. Reducing the sampling rate allows longer records to be stored. This setting has no effect on the internal sampling rate of the relay, which is always 64 samples per cycle. That is, it has no effect on the fundamental calculations of the device.

For products with the 9-2LE hardware and software options, this setting is fixed at 64 samples/cycle.

*Note:*

*When changes are made to the oscillography settings, all existing oscillography records are cleared*

#### 8.4.8.1 DIGITAL CHANNELS

☐ DIGITAL Channels  
☐

⇔

Digital CHANNEL <n>  
Off

Range: FlexLogic operand

#### DIGITAL CHANNEL <n>

These settings select the FlexLogic operand state recorded in an oscillography trace. The length of each oscillography trace depends in part on the number of parameters selected here. Parameters set to *Off* are ignored. There are 127 channels and one trigger, for a total of 128.

To populate quickly the rows in the Offline Window, use Ctrl C/V to copy/paste, or click then double-click a row to display a quick selection window




Figure 205: Quick selection window

8.4.8.2 ANALOG CHANNELS

■ DIGITAL Channels

■

⇔

Digital CHANNEL <n>

Off

Range: Off, any FlexAnalog/actual value parameter

See Appendix for list

where n = 1 to 32

ANALOG CHANNEL <n>

These settings select the metering actual value recorded in an oscillography trace. The length of each oscillography trace depends in part on the number of parameters selected here. Parameters set to *Off* are ignored. The parameters available in a given relay depend on

- the type of relay,
- the type and number of CT/VT hardware modules installed, and
- the type and number of analog input hardware modules installed

A list of all possible analog metering actual value parameters is presented in Appendix A: FlexAnalog Parameters. All eight CT/VT module channels are stored in the oscillography file. The CT/VT module channels are named as follows:

<slot\_letter><terminal\_number>—<I or V><phase A, B, or C, or 4th input>

The fourth current input in a bank is called IG, and the fourth voltage input in a bank is called VX. For example, F2-IB designates the IB signal on terminal 2 of the CT/VT module in slot F.

If there are no CT/VT modules and analog input modules, no analog traces appear in the file; only the digital traces appear.

The source harmonic indices appear as oscillography analog channels numbered from 0 to 23. These correspond directly to the 2nd to 25th harmonics in the relay as follows:

Analog channel 0 « 2nd harmonic

Analog channel 1 « 3rd harmonic

...

Analog channel 23 « 25th harmonic

**Note:**  
*In addition to the standard COMTRADE files \*.hdr, \*.cfg & \*.dat, a file with extension '\*.set' is also recorded. This file contains the active settings of the protection and control elements of the relay upon triggering of the oscillography file. The '\*.set' can be opened in Enervista. The setting names are captured in English language only.*

## 8.4.9 DATA LOGGER

Setting path: **SETTINGS > PRODUCT SETUP > DATA LOGGER**

|                                                    |   |                                          |                                                                              |
|----------------------------------------------------|---|------------------------------------------|------------------------------------------------------------------------------|
| <div> <div>■ DATA LOGGER</div> <div>■</div> </div> | ↔ | DATA LOGGER MODE:<br>Continuous          | Range: Continuous, Trigger                                                   |
|                                                    | ⇅ | DATA LOGGER TRIGGER:<br>Off              | Range: FlexLogic operand                                                     |
|                                                    | ⇅ | DATA LOGGER RATE:<br>60000 msec          | Range: 15 to 3600000 ms in steps of 1                                        |
|                                                    | ⇅ | DATA LOGGER CHNL <N>:<br>Off             | Range: Off, any FlexAnalog/actual value parameter<br>See Appendix A for list |
|                                                    | ↑ | DATA LOGGER CONFIG:<br>0 CHNL x 0.0 DAYS | Range: Not applicable - shows computed data only                             |

where n = 1 to 16

The data logger samples and records up to 16 analog parameters at a user-defined sampling rate. This recorded data can be downloaded to EnerVista UR Setup and displayed with parameters on the vertical axis and time on the horizontal axis. All data is stored in non-volatile memory, so the information is retained when power to the relay is lost. For a fixed sampling rate, the data logger can be configured with a few channels over a long period or a larger number of channels for a shorter period. The relay automatically partitions the available memory between the channels in use. The following table outlines examples of storage capacities for a system frequency of 60 Hz.

### Data logger storage capacity example

| Sampling rate | Channels | Days   | Storage capacity |
|---------------|----------|--------|------------------|
| 15 ms         | 1        | 0.1    | 482 s            |
|               | 8        | 0.1    | 60 s             |
|               | 9        | 0.1    | 54 s             |
|               | 16       | 0.1    | 30 s             |
| 1,000 ms      | 1        | 0.3    | 32729 s          |
|               | 8        | 0.1    | 4091 s           |
|               | 9        | 0.1    | 3637 s           |
|               | 16       | 0.1    | 2046 s           |
| 60,000 ms     | 1        | 22.7   | 1963710 s        |
|               | 8        | 2.8    | 245460 s         |
|               | 9        | 2.5    | 218190 s         |
|               | 16       | 1.4    | 127230 s         |
| 3,600,000 ms  | 1        | 1362.1 | 117822600 s      |
|               | 8        | 170.2  | 14727600 s       |
|               | 9        | 151.3  | 13091400 s       |

*Note:*  
Changing any setting affecting data logger operation clears data in the log

DATA LOGGER MODE

This setting configures the mode in which the data logger operates. When set to *Continuous*, the data logger actively records any configured channels at the rate as defined by the **DATA LOGGER RATE**. The data logger is idle in this mode when no channels are configured. When set to *Trigger*, the data logger records any configured channels at the instance of the rising edge of the DATA LOGGER TRIGGER source FlexLogic operand. The data logger ignores all subsequent triggers and continues to record data until the active record is full. Once the data logger is full, a **CLEAR DATA LOGGER** command is required to clear the data logger record before a new record can be started. Performing the **CLEAR DATA LOGGER** command also stops the current record and resets the data logger to be ready for the next trigger.

DATA LOGGER TRIGGER

This setting selects the signal used to trigger the start of a new data logger record. Any FlexLogic operand can be used as the trigger source. This setting only applies when the mode is set to *Trigger*.

DATA LOGGER RATE

This setting selects the time interval at which the actual value data is recorded.

DATA LOGGER CHNL <n>

These settings select the metering actual value that is to be recorded in Channel <n> of the data log. The parameters available in a given relay are dependent on: the type of relay, the type and number of CT/VT hardware modules installed, and the type and number of Analog Input hardware modules installed. Upon startup, the relay automatically prepares the parameter list. A list of all possible analog metering actual value parameters is shown in the FlexAnalog appendix.

DATA LOGGER CONFIG

This display presents the total amount of time that the Data Logger can record the channels not selected to *Off* without overwriting old data.

8.4.10 DEMAND

Setting path: *SETTINGS > PRODUCT SETUP > DEMAND*

|          |   |                                             |                                                                   |
|----------|---|---------------------------------------------|-------------------------------------------------------------------|
| ■ DEMAND | ⇔ | CRNT DEMAND METHOD:<br>Thermal Exponential  | Range: Thermal Exponential, Block Interval, Rolling Demand        |
| ■        | ⇕ | POWER DEMAND METHOD:<br>Thermal Exponential | Range: Thermal Exponential, Block Interval, Rolling Demand        |
|          | ⇕ | DEMAND INTERVAL:<br>15 MIN                  | Range: 5, 10, 15, 20, 30, 60 minutes                              |
|          | ↑ | DEMAND TRIGGER:<br>Off                      | Range: FlexLogic operand<br>Note: for calculation using method 2a |

The relay measures current demand on each phase, and three-phase demand for real, reactive, and apparent power. Current and Power methods can be chosen separately. Settings are provided to allow you to emulate common electrical utility demand measuring techniques, for statistical or control purposes.

CRNT DEMAND METHOD

Here you can set the calculation method for the current demand

## POWER DEMAND METHOD

Here you can set the calculation method for the power demand

### DEMAND INTERVAL

Use this setting to set the required demand interval

### DEMAND TRIGGER

Use this setting to define whether a demand trigger is required or not. If the demand trigger is On, a variation of the Block interval method is used as described later.

The relay can be set to calculate demand by any of the following methods.

- Thermal exponential
- Block Interval
- Rolling demand

These are described in the following sections

#### 8.4.10.1 THERMAL EXPONENTIAL CALCULATION METHOD


This method emulates the action of an analog peak-recording thermal demand meter. The relay measures the quantity (RMS current, real power, reactive power, or apparent power) on each phase every second and assumes that the circuit quantity remains at this value until updated by the next measurement. It calculates the 'thermal demand equivalent' based on the following equation:

$$d(t) = D(1 - e^{-kt})$$

where:

- $d$  = demand value after applying input quantity for time  $t$  (in minutes)
- $D$  = input quantity (constant)
- $k = 2.3 / \text{thermal } 90\% \text{ response time}$

The figure shows the 90% thermal response time characteristic of 15 minutes. A setpoint establishes the time to reach 90% of a steady-state value, just as the response time of an analog instrument. A steady state value applied for twice the response time indicates 99% of the value.



842787A1.CDR

Figure 206: Thermal demand characteristic

#### 8.4.10.2 BLOCK INTERVAL CALCULATION METHOD

There are two Block Interval calculation methods as follows:

If **CRNT DEMAND METHOD** is set to *Block Interval* and **DEMAND TRIGGER** is set to *Off*, method 1 is used as follows.



If **DEMAND TRIGGER** is assigned to any other FlexLogic operand, Method 2 is used as follows.

**1) Block interval calculation method without demand trigger**

This method calculates a linear average of the quantity (RMS current, real power, reactive power, or apparent power) over the programmed demand time interval, starting daily at 00:00:00 (that is, 12:00 am). The 1440 minutes per day is divided into the number of blocks as set by the programmed time interval. Each new value of demand becomes available at the end of each time interval.

**2) Block Interval calculation method with demand trigger**

This method calculates a linear average of the quantity (RMS current, real power, reactive power, or apparent power) over the interval between successive Start Demand Interval logic input pulses. Each new value of demand becomes available at the end of each pulse. Assign a FlexLogic operand to the DEMAND TRIGGER setting to program the input for the new demand interval pulses.

*Note:*  
If a trigger is assigned, the maximum allowed time between two trigger signals is 60 minutes. If no trigger signal appears within 60 minutes, demand calculations are performed and available, and the algorithm resets and starts the new cycle of calculations. The minimum required time for trigger contact closure is 20  $\mu$ s.


**8.4.10.3 ROLLING DEMAND CALCULATION METHOD**

This method calculates a linear average of the quantity (RMS current, real power, reactive power, or apparent power) over the programmed demand time interval, in the same way as Block Interval. The value is updated every minute and indicates the demand over the time interval just preceding the time of update.

**8.4.11 USER-PROGRAMMABLE LEDS**


**Basic and Enhanced front panels**

Setting path: **SETTINGS > PRODUCT SETUP > USER-PROGRAMMABLE LEDS**



8.4.11.1 LED TEST

Setting path: **SETTINGS > PRODUCT SETUP > USER-PROGRAMMABLE LEDs > LED TEST**



When enabled, the LED test can be initiated from any digital input or user-programmable condition, such as a user-programmable pushbutton. The control operand is configured under the **LED TEST CONTROL** setting. The test covers all LEDs, including the LEDs of the optional user-programmable pushbuttons. For the enhanced and basic front panels, the test consists of the following three stages:

1. All 62 LEDs on the relay are illuminated. This is a quick test to verify if any of the LEDs is faulty. This stage lasts as long as the control input is on, up to a maximum of one minute. After one minute, the test ends.
2. All the LEDs are turned off, and then one LED at a time turns on for one second, then back off. The test routine starts at the top left panel, moving from the top to bottom of each LED column. This test checks for hardware failures that lead to more than one LED being turned on from a single logic point. This stage can be interrupted at any time.
3. All the LEDs are turned on. One LED at a time turns off for one second, then back on. The test routine starts at the top left panel moving from top to bottom of each column of the LEDs. This test checks for hardware failures that lead to more than one LED being turned off from a single logic point. This stage can be interrupted at any time.


For the graphical front panel, the test consists of the following stages:

1. All 22 LEDs on the relay are illuminated. This is a quick test to verify if any of the LEDs is faulty. This stage lasts as long as the control input is on, up to a maximum of one minute. After one minute, the test ends.
2. All the LEDs are turned off, and then one LED at a time turns on with the orange color for one second, then back off. The test routine starts at the top left panel, moving from the top to bottom for all 14 LEDs. Then the eight pushbutton LEDs are tested in the same manner. This test checks for hardware failures that lead to more than one LED being turned on from a single logic point. This stage can be interrupted at any time.
3. All the LEDs are turned on with the orange color. One LED at a time turns off for one second, then back on. The test routine starts at the top left panel moving from top to bottom for all 14 LEDs. Then the eight pushbutton LEDs are tested in the same manner. This test checks for hardware failures that lead to more than one LED being turned off from a single logic point. This stage can be interrupted at any time.
4. Additionally, stages 2 and 3 are repeated twice for the five device status LEDs and nine event cause LEDs, one time with green color on and the other with red color on.

When testing is in progress, the LEDs are controlled by the test sequence, rather than the protection, control, and monitoring features. However, the LED control mechanism accepts all the changes to LED states generated by the relay and stores the actual LED states (on or off) in memory. When the test completes, the LEDs reflect the actual state resulting from relay response during testing. The reset pushbutton does not clear any targets when the LED Test is in progress.

A dedicated FlexLogic operand, LED TEST IN PROGRESS, is set for the duration of the test. When the test sequence is initiated, the **LED TEST INITIATED** event is stored in the event recorder.

The entire test procedure is user-controlled. In particular, stage 1 can last as long as necessary, and stages 2 and 3 can be interrupted. The test responds to the position and rising edges of the control input defined by the LED TEST CONTROL setting. The control pulses must last at least 250 ms to take effect. The following diagram explains how the test is executed.



842011A1.CDR

**Figure 207: LED test sequence****Application example 1**

Assume one needs to check if any of the LEDs is faulty through user-programmable pushbutton 1. Apply the following settings.

Configure user-programmable pushbutton 1 by making the following entries in the **SETTINGS > PRODUCT SETUP > USER-PROGRAMMABLE PUSHBUTTONS > USER PUSHBUTTON 1** menu. (The option does not display when not purchased.)

- **PUSHBUTTON 1 FUNCTION:** *Self-reset*
- **PUSHBTN 1 DROP-OUT TIME:** *0.10 s*

Configure the LED test to recognize user-programmable pushbutton 1 by making the following entries in the **SETTINGS > PRODUCT SETUP > USER-PROGRAMMABLE LEDS > LED TEST** menu:

- **LED TEST FUNCTION:** *Enabled*
- **LED TEST CONTROL:** *PUSHBUTTON 1 ON*

The test is initiated when the user-programmable pushbutton 1 is pressed. Keep the pushbutton pressed for as long as the LEDs are being visually inspected. When finished, release the pushbutton. The relay then automatically starts stage 2. At this point, test can be canceled by pressing the pushbutton.

### Application example 2

Assume you need to check whether any LEDs are faulty as well as check one LED at a time to check for other failures. This is to be performed via user-programmable pushbutton 1.

After applying the settings in application example 1, hold down the pushbutton as long as necessary to test all LEDs. When finished, release the pushbutton so that the relay then automatically starts stage 2. When stage 2 is completed, stage 3 starts automatically. The test can be canceled at any time by pressing the pushbutton.

#### 8.4.11.2 TRIP AND ALARM LEDS

Setting path: **SETTINGS > PRODUCT SETUP > USER-PROGRAMMABLE LEDS > TRIP & ALARMS LEDS**

|                          |   |                         |                          |
|--------------------------|---|-------------------------|--------------------------|
| ■ TRIP & ALARM LEDS<br>■ | ↔ | TRIP LED INPUT:<br>Off  | Range: FlexLogic operand |
|                          | ↑ | ALARM LED INPUT:<br>Off | Range: FlexLogic operand |

The trip and alarm LEDs are in the first LED column (enhanced and graphical front panels) and on LED panel 1 (basic front panel). Each LED can be programmed to turn on when the selected FlexLogic operand is in the logic 1 state.

#### 8.4.11.3 USER-PROGRAMMABLE LED <N>

Setting path: **SETTINGS > PRODUCT SETUP > USER-PROGRAMMABLE LEDS > USER-PROGRAMMABLE LED <n>**

|                                  |   |                             |                          |
|----------------------------------|---|-----------------------------|--------------------------|
| ■ USER-PROGRAMMABLE<br>■ LED <n> | ↔ | LED <n> OPERAND:<br>Off     | Range: FlexLogic operand |
|                                  | ↑ | LED <n> TYPE:<br>Self-Reset | Range: FlexLogic operand |

where n = 1 to 48

For the enhanced and basic front panels, there are 48 amber LEDs across the relay LED panels. Each of these indicators can be programmed to illuminate when the selected FlexLogic operand is in the logic 1 state.

For the basic front panel, the LEDs are located as follows:

- LED Panel 2 — User-programmable LEDs 1 through 24
- LED Panel 3 — User programmable LEDs 25 through 48

For the enhanced front panel, the LEDs are located as follows:

- LED column 2 — User-programmable LEDs 1 through 12
- LED column 3 — User-programmable LEDs 13 through 24
- LED column 4 — User-programmable LEDs 25 through 36
- LED column 5 — User-programmable LEDs 37 through 48

See the LED Indicators section in chapter 4 for information on the location of these indexed LEDs.

The user-programmable LED settings select the FlexLogic operands that control the LEDs. If the **LED <n> TYPE** setting is *Self-Reset* (the default setting), the LED illumination tracks the state of the selected LED operand. If the **LED <n> TYPE** setting is *Latched*, the LED, once lit, remains so until reset by the front panel **RESET** button, from a remote device via a communications channel, or from any programmed operand, even if the LED operand state de-asserts.

#### 8.4.11.3.1 RECOMMENDED SETTINGS FOR USER-PROGRAMMABLE LEDS

| Setting        | Parameter           |
|----------------|---------------------|
| LED 1 operand  | SETTING GROUP ACT 1 |
| LED 2 operand  | SETTING GROUP ACT 2 |
| LED 3 operand  | SETTING GROUP ACT 3 |
| LED 4 operand  | SETTING GROUP ACT 4 |
| LED 5 operand  | SETTING GROUP ACT 5 |
| LED 6 operand  | SETTING GROUP ACT 6 |
| LED 7 operand  | Off                 |
| LED 8 operand  | Off                 |
| LED 9 operand  | Off                 |
| LED 10 operand | Off                 |
| LED 11 operand | Off                 |
| LED 12 operand | Off                 |
| LED 13 operand | Off                 |
| LED 14 operand | Off                 |
| LED 15 operand | Off                 |
| LED 16 operand | Off                 |
| LED 17 operand | SYNC 1 SYNC OP      |
| LED 18 operand | SYNC 2 SYNC OP      |
| LED 19 operand | Off                 |
| LED 20 operand | Off                 |
| LED 21 operand | Off                 |
| LED 22 operand | Off                 |
| LED 23 operand | Off                 |
| LED 24 operand | Off                 |

#### 8.4.11.4 EVENT CAUSE LED <N>

Setting path: **SETTINGS > PRODUCT SETUP > USER-PROGRAMMABLE LEDS > EVENT CAUSE LED <n>**

|                                                                  |   |                                |                            |
|------------------------------------------------------------------|---|--------------------------------|----------------------------|
| <div> <div>■ EVENT CAUSE</div> <div>■ LED &lt;n&gt;</div> </div> | ⇔ | LED <n> OPERAND:<br>LED PICKUP | Range: FlexLogic operand   |
|                                                                  | ⇕ | LED 1 COLOR:<br>Green          | Range: Red, Green, Orange  |
|                                                                  | ↑ | LED 1 TYPE:<br>Self-Reset      | Range: Self-Reset, Latched |

where n = 1 to 9

For the graphical front panel, the event cause LED settings select the FlexLogic operands that control the LEDs.

## LED <n> TYPE

If set to *Self-Reset*, the LED illumination tracks the state of the selected LED operand. If set to *Latched*, the LED, once lit, remains so even the LED operand state already de-asserts, until reset by the front panel RESET button, from a remote device via a communications channel, or from any programmed operand.

The table outlines default input operand and output operands for each event cause LED.

### Default input and output operand for event cause LEDs

| LED               | Default input operand | Output operand    | Default color |
|-------------------|-----------------------|-------------------|---------------|
| Event Cause LED 1 | LED PICKUP            | EVENT CAUSE LED 1 | Green         |
| Event Cause LED 2 | LED VOLTAGE           | EVENT CAUSE LED 2 | Orange        |
| Event Cause LED 3 | LED CURRENT           | EVENT CAUSE LED 3 | Orange        |
| Event Cause LED 4 | LED FREQUENCY         | EVENT CAUSE LED 4 | Orange        |
| Event Cause LED 5 | LED OTHER             | EVENT CAUSE LED 5 | Orange        |
| Event Cause LED 6 | LED PHASE A           | EVENT CAUSE LED 6 | Orange        |
| Event Cause LED 7 | LED PHASE B           | EVENT CAUSE LED 7 | Orange        |
| Event Cause LED 8 | LED PHASE C           | EVENT CAUSE LED 8 | Orange        |
| Event Cause LED 9 | LED NEUTRAL/GROUND    | EVENT CAUSE LED 9 | Orange        |

## 8.4.12 USER-PROGRAMMABLE SELF-TESTS

Setting path: **SETTINGS > PRODUCT SETUP > USER-PROGRAMMABLE SELF TESTS**

|                                                                     |   |                                           |                                                                                     |
|---------------------------------------------------------------------|---|-------------------------------------------|-------------------------------------------------------------------------------------|
| <div> <div>■ USER-PROGRAMMABLE</div> <div>■ SELF TESTS</div> </div> | ↔ | DIRECT RING BREAK<br>FUNCTION: Enabled    | Range: Disabled, Enabled. Valid for units equipped with Direct Input/Output module. |
|                                                                     | ⇅ | DIRECT DEVICE OFF<br>FUNCTION: Enabled    | Range: Disabled, Enabled. Valid for units equipped with Direct Input/Output module. |
|                                                                     | ⇅ | RxGOOSE OFF<br>FUNCTION: Enabled          | Range: Disabled, Enabled                                                            |
|                                                                     | ⇅ | FIRST ETHERNET FAIL<br>FUNCTION: Disabled | Range: Disabled, Enabled                                                            |
|                                                                     | ⇅ | SEC. ETHERNET FAIL<br>FUNCTION: Disabled  | Range: Disabled, Enabled                                                            |
|                                                                     | ⇅ | THIRD ETHERNET FAIL<br>FUNCTION: Disabled | Range: Disabled, Enabled                                                            |
|                                                                     | ⇅ | SFP MODULE FAIL<br>FUNCTION: Disabled     | Range: Disabled, Enabled                                                            |
|                                                                     | ⇅ | BATTERY FAIL<br>FUNCTION: Enabled         | Range: Disabled, Enabled                                                            |
|                                                                     | ⇅ | SNTP FAIL<br>FUNCTION: Enabled            | Range: Disabled, Enabled                                                            |
|                                                                     | ⇅ | IRIG-B FAIL<br>FUNCTION: Enabled          | Range: Disabled, Enabled                                                            |
|                                                                     | ⇅ | PTP FAIL<br>FUNCTION: Enabled             | Range: Disabled, Enabled                                                            |
|                                                                     | ⇅ | SV STREAM TROUBLE<br>FUNCTION: Enabled    | Range: Disabled, Enabled                                                            |

|   |                                              |                          |
|---|----------------------------------------------|--------------------------|
| ⇅ | PB ETH PORT <nm> FAIL<br>FUNCTION: Disabled  | Range: Disabled, Enabled |
| ↑ | PB SFP MODUL <nm> FAIL<br>FUNCTION: Disabled | Range: Disabled, Enabled |

where n = 1 to 4, and m = a to b

All major self-test alarms are reported automatically with their corresponding FlexLogic operands, events, and targets.

This settings menu allows enabling and disabling of most minor self-test alarms. When in the Disabled mode, minor alarms do not assert a FlexLogic operand, write to the event recorder, or display target messages. Moreover, they do not trigger the `ANY MINOR ALARM` or `ANY SELF-TEST` messages. When enabled, minor alarms continue to function along with other major and minor alarms. When using the graphical front panel and setting annunciator alarms, the function needs to be enabled here too, else the alarm is not triggered.

*Note:*  
*PB SFP MODUL # FAIL FUNCTION — For order code H85, ports 2a, 2b, 4a, 4b are not available.*

### 8.4.13 CONTROL PUSHBUTTONS

Setting path: **SETTINGS > PRODUCT SETUP > CONTROL PUSHBUTTONS > CONTROL PUSHBUTTON <n>**

|                               |   |                                              |                                         |
|-------------------------------|---|----------------------------------------------|-----------------------------------------|
| ■ CONTROL<br>■ PUSHBUTTON <n> | ⇅ | CNTRL PUSHBUTTON <n> ID<br>CTRL PB 1         | Range: up to 20 alphanumeric characters |
|                               | ⇅ | CONTROL PUSHBUTTON <n><br>FUNCTION: Disabled | Range: Disabled, Enabled                |
|                               | ↑ | CONTROL PUSHBUTTON <n><br>EVENTS: Disabled   | Range: Disabled, Enabled                |

where n = 1 to 7

This feature is supported with enhanced and basic front panels.

There are three standard control pushbuttons, labeled **USER 1**, **USER 2**, and **USER 3**, on the basic and enhanced front panels. These are user-programmable and can be used for various applications such as performing an LED test, switching setting groups, and invoking and scrolling through user-programmable displays.

The control pushbuttons are easily identifiable on the front panel with the labels **USER 1**, **USER 2** and **USER 3** for the standard option, and with the additional **USER 4**, **USER 5**, **USER 6** and **USER 7** as an optional extra for some models.

Control pushbuttons are not typically used for critical operations and are not protected by the control password. However, by supervising their output operands, the user can dynamically enable or disable control pushbuttons for security reasons.

Each control pushbutton asserts its own FlexLogic operand. Each operand need to be configured appropriately to perform the required function. Each operand remains asserted as long as the pushbutton is pressed and resets when the pushbutton is released. A dropout delay of 100 ms is incorporated to ensure fast pushbutton manipulation is recognized by various features that can use control pushbuttons as inputs.

An event is logged in the event record (as per user setting) when a control pushbutton is pressed. No event is logged when the pushbutton is released. The front panel keys (including control keys) cannot be operated simultaneously.

### 8.4.14 USER-PROGRAMMABLE PUSHBUTTONS

This feature is optional, specified at the time of ordering.

Setting path: **SETTINGS > PRODUCT SETUP > USER-PROGRAMMABLE PUSHBUTTONS > USER PUSHBUTTON <n>**

|                                                                  |   |                                          |                                         |
|------------------------------------------------------------------|---|------------------------------------------|-----------------------------------------|
| <div> <div>■ USER PUSHBUTTON &lt;n&gt;</div> <div>■</div> </div> | ⇔ | PUSHBUTTON <1><br>FUNCTION: Disabled     | Range: Self-Reset, Latched, Disabled    |
|                                                                  | ⇕ | PUSHBTN <n> ID TEXT:<br>USER PB 1        | Range: up to 20 alphanumeric characters |
|                                                                  | ⇕ | PUSHBTN <n> ON TEXT:<br>PUSHBTN <n> ON   | Range: up to 20 alphanumeric characters |
|                                                                  | ⇕ | PUSHBTN <n> OFF TEXT:<br>PUSHBTN <n> OFF | Range: up to 20 alphanumeric characters |
|                                                                  | ⇕ | PUSHBTN <n> HOLD:<br>0.1 s               | Range: 0.0 to 10.0 s in steps of 0.1    |
|                                                                  | ⇕ | PUSHBTN <n> SET:<br>Off                  | Range: FlexLogic operand                |
|                                                                  | ⇕ | PUSHBTN <n> RESET:<br>Off                | Range: FlexLogic operand                |
|                                                                  | ⇕ | PUSHBTN <n> AUTORST:<br>Disabled         | Range: Disabled, Enabled                |
|                                                                  | ⇕ | PUSHBTN <n> AUTORST<br>DELAY: 1.0 s      | Range: 0.2 to 600.0 s in steps of 0.1   |
|                                                                  | ⇕ | PUSHBTN <n> REMOTE:<br>Off               | Range: FlexLogic operand                |
|                                                                  | ⇕ | PUSHBTN <n> LOCAL:<br>Off                | Range: FlexLogic operand                |
|                                                                  | ⇕ | PUSHBTN <n> DROP-OUT<br>TIME: 0.00 s     | Range: 0 to 60.00 s in steps of 0.05    |
|                                                                  | ⇕ | PUSHBTN <n> LED CTL:<br>Off              | Range: FlexLogic operand                |
|                                                                  | ⇕ | PUSHBTN <n> MESSAGE:<br>Disabled         | Range: Disabled, Normal, High Priority  |
|                                                                  | ↑ | PUSHBUTTON <1><br>EVENTS: Disabled       | Range: Disabled, Enabled                |

where n depends on the front panel ordered (12, 6, 16 or 48)

User-programmable pushbuttons provide an easy and error-free method of entering digital state (on, off) information. The number depends on the front panel ordered.

- Enhanced horizontal front panel — 16 user-programmable pushbuttons
- Enhanced vertical front panel — 6 user-programmable pushbuttons
- Basic horizontal front panel — 12 user-programmable pushbuttons
- Graphical front panel — 48 user-programmable pushbuttons (eight physical pushbuttons, 40 graphical interface pushbuttons)

**Note:**

User-programmable pushbuttons require a front panel with that option. If the front panel was ordered separately, update the EnerVista software under Maintenance > Change Front Panel.

The digital state can be entered locally (by directly pressing the front panel pushbutton or optional graphical front panel interface) or remotely (via FlexLogic operands) into FlexLogic equations, protection elements, and control elements. Typical applications include breaker control, autorecloser blocking, and setting groups changes. For




example, set pushbuttons 1 to 5 to select settings groups 1 to 5, or set pushbutton 1 to clear event records. The user-programmable pushbuttons are under the control level of password protection.

### Example

To clear event records using pushbutton 1, set **Settings > Product Setup > Clear Relay Records > Clear Event Records** to FlexLogic operand PUSHBUTTON 1 ON. Then program the pushbutton by setting **Settings > Product Setup > User-Programmable Pushbuttons > Pushbutton 1 Function** to *Self-reset*. For a graphical front panel, to use a side pushbutton to clear the event records, it also needs to be programmed in a single-line diagram.


The figures show user-configurable pushbuttons for the front panels.



**Figure 208: User-programmable pushbuttons (enhanced front panel)**



**Figure 209: User-programmable pushbuttons (basic front panel)**



**Figure 210: User-programmable pushbuttons (graphical front panel)**

Each pushbutton asserts its own On and Off FlexLogic operands (for example, PUSHBUTTON 1 ON and PUSHBUTTON 1 OFF). These operands are available for each pushbutton and are used to program specific actions. If any pushbutton is active, the ANY PB ON operand is asserted.

Each pushbutton has an associated LED indicator. By default, this indicator displays the present status of the corresponding pushbutton (on or off). However, each LED indicator can be assigned to any FlexLogic operand through the **PUSHBTN 1 LED CTL** setting.

The activation and deactivation of user-programmable pushbuttons depends on whether latched or self-reset mode is programmed.

- Latched mode** — In latched mode, a pushbutton can be set (activated) by asserting the operand assigned to the **PUSHBTN 1 SET** setting, by directly pressing the associated front panel pushbutton, or with the graphical front panel interface. The state of each pushbutton is stored in non-volatile memory and maintained through a loss of control power. The pushbutton is reset (deactivated) in latched mode by asserting the operand assigned to the **PUSHBTN 1 RESET** setting, by directly pressing the active front panel pushbutton, or with the graphical front panel interface. It can also be programmed to reset automatically through the **PUSHBTN 1 AUTORST** and **PUSHBTN 1 AUTORST DELAY** settings. These settings enable the autoreset timer and specify the associated time delay. The autoreset timer can be used in select-before-operate (SBO) breaker control applications, where the command type (close/open) or breaker location (feeder number) must be selected prior to command execution. The selection must reset automatically if control is not executed within a specified time period.
- Self-reset mode** — In self-reset mode, a user-programmable pushbutton can be set (activated) by asserting the operand assigned to the **PUSHBTN 1 SET** setting, by pressing the front panel pushbutton, or by the graphical front panel interface. A pushbutton remains active for the time it is pressed physically or pressed in the graphical front panel interface, plus the dropout time specified in the **PUSHBTN 1 DROP-OUT TIME** setting. If the pushbutton is activated via FlexLogic, the pulse duration is specified by the **PUSHBTN 1 DROP-OUT TIME** setting only. The time the operand assigned to the **PUSHBTN 1 SET** setting remains On has no effect on the pulse duration.

**Note:**

*The pulse duration of the remote set or local front panel pushbutton must be at least 56 ms for a 60 Hz system or 60 ms for a 50 Hz system to operate the pushbutton. This allows the user-programmable pushbuttons to properly operate during power cycling events and various system disturbances that can cause transient assertion of the operating signals.*

The local and remote operation of each user-programmable pushbutton can be inhibited through the **PUSHBTN 1 LOCAL** and **PUSHBTN 1 REMOTE** settings. If local inhibit is applied, the pushbutton ignores set and reset commands executed through the front panel pushbuttons. If remote inhibit is applied, the pushbutton ignores set and reset commands executed through FlexLogic operands.

The inhibit functions are not applied to the autoreset feature. The inhibit function can be used in SBO control operations to prevent user-programmable pushbutton activation and ensuring 'one-at-a-time' select operation. The inhibit functions can also be used to prevent pushbutton activation from the accidental pressing of the front panel pushbuttons. The separate inhibit of the local and remote operation simplifies the implementation of local/remote control supervision.

Pushbutton states can be logged by the event recorder. User-defined messages can also be associated with each pushbutton and displayed on basic and enhanced front panels when the user-programmable pushbutton is activated, and when in the latched mode when the user-programmable pushbutton is deactivated. With the graphical front panel interface, instead of messages, the status of user-programmable pushbuttons can display on a single-line diagram and can also display in annunciator page windows and in actual values page cells.

For the graphical front panel, the pushbuttons 1 to 8 are linked to the eight physical pushbuttons, and pushbuttons 9 and above are mapped to the graphical interface pushbuttons. To set the buttons for pushbuttons 9 and above, access **Settings > Product Setup > Graphical Panel > Single Line Diagram Editor**, click the PB symbol in the toolbox, then configure pushbuttons 9 and above.

## PUSHBUTTON 1 FUNCTION

This setting selects the mode of the pushbutton (Self-Reset, Latched, Disabled). If set to *Disabled*, the pushbutton is not active and the corresponding FlexLogic operands (both *On* and *Off*) are de-asserted. If set to *Latched*, the pushbutton remains on until reset.

## PUSHBTN 1 ID TEXT

This setting specifies the top 20-character line of the user-programmable pushbutton message and is intended to provide ID information of the pushbutton. For example, the text displays in the Event Record. See the User-

definable Displays section in this chapter for instructions on how to enter alphanumeric characters from the keypad. On a graphical front panel, this setting instead controls the label of the user-programmable pushbutton component on single-line diagrams.

### PUSHBTN 1 ON TEXT

This setting specifies the bottom 20-character line of the user-programmable pushbutton message and is displayed when the pushbutton is in the On position. See the User-definable Displays section for instructions on entering alphanumeric characters from the keypad. On a graphical front panel, this setting instead controls the on status text of the user-programmable pushbutton component on single-line diagrams. This setting is not applied to the physical pushbuttons on the graphical front panel.

### PUSHBTN 1 OFF TEXT

This setting specifies the bottom 20-character line of the user-programmable pushbutton message and displays when the pushbutton is deactivated and the **PUSHBUTTON 1 FUNCTION** is *latched*. A message does not display when the **PUSHBUTTON 1 FUNCTION** is *Self-reset* as the pushbutton operand status is implied to be *Off* upon its release. The length of the *Off* message is configured with the **PRODUCT SETUP > DISPLAY PROPERTIES > FLASH MESSAGE > TIME** setting. On a graphical front panel, this setting instead controls the off status text of the user-programmable pushbutton component on single-line diagrams. This setting is not applied to the physical pushbuttons on the graphical front panel.

### PUSHBTN 1 HOLD

This setting specifies the time required for a front panel pushbutton to be pressed before it is deemed active. This timer is reset upon release of the pushbutton. Note that user-programmable pushbutton operation requires the front panel pushbutton to be pressed a minimum of 56 ms for a 60 Hz system or 60 ms for a 50 Hz system. This minimum time is required prior to activating the user-programmable pushbutton hold timer.

### PUSHBTN 1 SET

This setting assigns the FlexLogic operand serving to activate the user-programmable pushbutton element. The duration of the incoming set signal must be at least 56 ms for a 60 Hz system or 60 ms for a 50 Hz system.

### PUSHBTN 1 RESET

This setting assigns the FlexLogic operand serving to deactivate the user-programmable pushbutton element. This setting is applicable only if the user-programmable pushbutton is in *Latched* mode.

### PUSHBTN 1 AUTORST

This setting enables the user-programmable pushbutton autoreset feature. This setting is applicable only if the pushbutton is in *Latched* mode.

### PUSHBTN 1 AUTORST DELAY

This setting specifies the time delay for automatic reset of the pushbutton when in *Latched* mode.

### PUSHBTN 1 REMOTE

This setting assigns the FlexLogic operand serving to inhibit user-programmable pushbutton operation from the operand assigned to the **PUSHBTN 1 SET** or **PUSHBTN 1 RESET** settings.

### PUSHBTN 1 LOCAL

This setting assigns the FlexLogic operand serving to inhibit user-programmable pushbutton operation from the front panel pushbuttons. This inhibit functionality is not applicable to pushbutton autoreset.

### PUSHBTN 1 DROP-OUT TIME

This setting applies only to *Self-Reset* mode and specifies the duration of the user-programmable pushbutton active status after the front panel pushbutton or graphical front panel interface pushbutton has been released. When activated remotely, this setting specifies the entire activation time of the pushbutton; the length of time the operand selected by **PUSHBTN 1 SET** remains on has no effect on the pulse duration.

### PUSHBTN 1 LED CTL

This setting assigns the FlexLogic operand serving to drive the front panel pushbutton LED. If this setting is *OFF*, then LED operation is directly linked to the PUSHBUTTON 1 ON operand. This setting is not applied to Pushbuttons 9 and above on the graphical front panel, where the label background shows the orange glow color for the *On* state.

### PUSHBTN 1 MESSAGE

This setting controls the behavior of the user-programmable pushbutton on message that is programmed in the **PUSHBTN 1 ID** and **PUSHBTN 1 ON TEXT** settings, and the behavior of the user-programmable pushbutton off message that is programmed in the **PUSHBTN 1 ID** and **PUSHBTN 1 OFF TEXT** settings. This setting has no effect on the graphical front panel.

When set to *Disabled*, user-programmable pushbutton messages do not display. Otherwise the on message displays when the user-programmable pushbutton becomes activated, and if in the *Latched* mode the off message displays when the user-programmable pushbutton becomes deactivated.


When set to *Normal*, the duration the message displays is as specified by the **FLASH MESSAGE TIME** setting.

When set to *High Priority*, the duration of the off message is as specified by the **FLASH MESSAGE TIME** setting, but the on message is displayed as long as the user-programmable pushbutton is activated. While activated, target and other messages are suppressed. To allow front panel keypad operation, when a keypad button is pressed the message is suppressed for 10 seconds.

### PUSHBUTTON 1 EVENTS

If this setting is enabled, each user-programmable pushbutton state change is logged as an event into the event recorder.

The figures show the user-programmable pushbutton logic.



84 223 7A3.cdr

Figure 211: User-programmable pushbutton logic (Sheet 1 of 2)




Figure 212: User-programmable pushbutton logic (Sheet 2 of 2)

### 8.4.15 FLEX STATE PARAMETERS

Setting path: **SETTINGS > PRODUCT SETUP > FLEX STATE PARAMETERS**

■ FLEX STATE  
■ PARAMETERS

⇔

PARAMETER <n>:  
Off

Range: FlexLogic operand


where n = 1 to 256

This feature provides a mechanism where any of 256 selected FlexLogic operand states can be used for efficient monitoring. The feature allows user-customized access to the FlexLogic operand states in the relay. The state bits are packed so that 16 states are readable in a single Modbus register. The state bits can be configured so that all states of interest are available in a minimum number of Modbus registers.

The state bits can be read out in the Flex States register array beginning at Modbus address 0900h. Sixteen states are packed into each register, with the lowest-numbered state in the lowest-order bit. Sixteen registers accommodate the 256 state bits.

### 8.4.16 USER-DEFINABLE DISPLAYS

Setting path: **SETTINGS > PRODUCT SETUP > USER-DEFINABLE DISPLAYS**



where n = 1 to 16

This feature is supported with enhanced and basic front panels. It is not supported with the optional graphical front panel.

This menu provides a mechanism for manually creating up to 16 user-defined information displays in a convenient viewing sequence in the **USER DISPLAY** menu (between the **TARGETS** and **ACTUAL VALUES** top-level menus). The sub-menus facilitate text entry and Modbus register data pointer options for defining the user display content.

Once programmed, the user-definable displays can be viewed in two ways:

- Keypad
- User-programmable control input

### Keypad

Use the **MENU** key to select the **USER DISPLAY** menu item to access the first user-definable display (note that only the programmed screens are displayed). The screens can be scrolled using the up and down arrow keys. The display disappears after the default message time-out period specified by the **PRODUCT SETUP > DISPLAY PROPERTIES > DEFAULT MESSAGE TIMEOUT** setting.

### User-programmable control input


The user-definable displays also respond to the **INVOKE AND SCROLL** setting. Any FlexLogic operand (in particular, the user-programmable pushbutton operands), can be used to navigate the programmed displays.

On the rising edge of the configured operand (such as when the pushbutton is pressed), the displays are invoked by showing the last user-definable display shown during the previous activity. From this moment onward, the operand acts exactly as the down key and allows scrolling through the configured displays. The last display wraps up to the first one. The **INVOKE AND SCROLL** input and the down arrow key operate concurrently.

When the default timer expires (set by the **DEFAULT MESSAGE TIMEOUT** setting), the relay starts to cycle through the user displays. The next activity of the **INVOKE AND SCROLL** input stops the cycling at the currently displayed user display, not at the first user-defined display. The **INVOKE AND SCROLL** pulses must last for at least 250 ms to take effect.

#### 8.4.16.1 USER DISPLAY <N>

Setting path: **SETTINGS > PRODUCT SETUP > USER-DEFINABLE DISPLAYS USER DISPLAY <n>**



where n = 1 to 16, m = 1 to 5

Any existing system display can be automatically copied into an available user display by selecting the existing display and pressing the **ENTER** key. The display then prompts with **ADD TO USER DISPLAY LIST?** After selecting **Yes**, a message indicates that the selected display has been added to the user display list. When this type of entry occurs, the sub-menus are automatically configured with the proper content—this content can be edited subsequently.

This menu is used to enter user-defined text and user-selected Modbus-registered data fields into the particular user display. Each user display consists of two 20-character lines (top and bottom). The tilde (~) character is used

to mark the start of a data field – the length of the data field needs to be accounted for. Up to five separate data fields can be entered in a user display – the nth tilde (~) refers to the nth item.

A user display can be entered from the front panel keypad or the EnerVista interface (preferred for convenience). The following procedure shows how to enter text characters in the top and bottom lines from the front panel keypad. Press the **HELP** key at any time for context sensitive help information.

1. Select the line to be edited.
2. Press the decimal key to enter text edit mode.
3. Use either **VALUE** key to scroll through the characters. A space is selected like a character.
4. Press the decimal key to advance the cursor to the next position.
5. Repeat step 3 and continue entering characters until the desired text is displayed.
6. Press the **ENTER** key to store the new settings.

To enter a numerical value for any of the five items (the decimal form of the selected Modbus address) from the front panel keypad, use the number keypad. Use the value of “0” for any items not being used. Use the **HELP** key at any selected system display (setting, actual value, or command) which has a Modbus address, to view the hexadecimal form of the Modbus address, then manually convert it to decimal form before entering it (EnerVista usage conveniently facilitates this conversion). See the Modbus Memory Map section earlier in this chapter for information on how to calculate the decimal value to enter on the front panel.

Use the **MENU** key to go to the user displays menu to view the user-defined content. The current user displays show in sequence, changing every four seconds. While viewing a user display, press the **ENTER** key and confirm to remove the display from the user display list. Use the **MENU** key again to exit the user displays menu.

An example of user display setup and result is shown as follows.

|                       |   |                                      |                                                                                                   |
|-----------------------|---|--------------------------------------|---------------------------------------------------------------------------------------------------|
| ■ USER DISPLAY 1<br>■ | ↔ | DISP 1 TOP LINE:<br>Current X ~ A    | Shows user-defined text with first tilde marker                                                   |
|                       | ↕ | DISP 1 BOTTOM LINE:<br>Current Y ~ A | Shows user-defined text with second tilde marker                                                  |
|                       | ↕ | DISP 1 ITEM 1:<br>6016               | Shows decimal form of user-selected Modbus register address, corresponding to first tilde marker  |
|                       | ↕ | DISP 1 ITEM 2:<br>6357               | Shows decimal form of user-selected Modbus register address, corresponding to second tilde marker |
|                       | ↕ | DISP 1 ITEM 3:<br>0                  | This item is not being used. There is no corresponding tilde marker in top or bottom lines.       |
|                       | ↕ | DISP 1 ITEM 4:<br>0                  | This item is not being used. There is no corresponding tilde marker in top or bottom lines.       |
|                       |   | DISP 1 ITEM 5:<br>0                  | This item is not being used. There is no corresponding tilde marker in top or bottom lines.       |
|                       |   |                                      |                                                                                                   |
| ■ USER DISPLAYS<br>■  | ↔ | Current X 0.850<br>Current Y 0.327 A | Shows the resultant display content                                                               |

If the parameters for the top line and the bottom line items have the same units, then the unit is displayed on the bottom line only. The units are only displayed on both lines if the units specified both the top and bottom line items are different.

### 8.4.17 DIRECT INPUTS AND OUTPUTS

Setting path: **SETTINGS > PRODUCT SETUP > DIRECT I/O**



|              |   |                                            |                              |
|--------------|---|--------------------------------------------|------------------------------|
| ■ DIRECT I/O | ↔ | DIRECT OUTPUTS<br>DEVICE ID: 1             | Range: 1 to 16 in steps of 1 |
|              | ⇅ | DIRECT I/O CH1 RING<br>CONFIGURATION: Yes  | Range: Yes, No               |
|              | ⇅ | DIRECT I/O CH2 RING<br>CONFIGURATION: Yes  |                              |
|              | ⇅ | DIRECT I/O DATA<br>RATE: 64 kbps           |                              |
|              | ⇅ | DIRECT I/O CHANNEL<br>CROSSOVER: Disabled  |                              |
|              | ⇅ | ■ CRC ALARM CH1<br>■                       |                              |
|              | ⇅ | ■ CRC ALARM CH2<br>■                       |                              |
|              | ⇅ | ■ UNRETURNED<br>■ MESSAGES ALARM CHANNEL 1 |                              |
|              | ⇅ | ■ UNRETURNED<br>■ MESSAGES ALARM CHANNEL 2 |                              |

**Note:**

*This option is available when an Inter-Relay Communications card is specified at the time of ordering. With the option, direct inputs/outputs display by default. When you enable the teleprotection feature, direct I/O is not visible.*

Direct inputs and outputs provide the ability to exchange status information between relays connected together with type 7 digital communications cards. The mechanism is very similar to IEC 61850 GOOSE, except that communications takes place over a non-switchable isolated network and is optimized for speed. On type 7 cards that support two channels, messages are sent from both channels simultaneously. This effectively sends direct output messages both ways around a ring configuration. On type 7 cards that support one channel, messages are sent only in one direction. Messages are resent (forwarded) when it is determined that the message did not originate at the receiver.

Direct Inputs and Outputs are initiated automatically and start running when at least one Direct Output in the given UR is set to anything but Off.

For the direct I/Os to function properly, all UR devices sending I/Os using an Inter-Relay Communications card must have identical firmware revisions.

**Note:**

*Teleprotection inputs/outputs and direct inputs/outputs are mutually exclusive. As such, they cannot be used simultaneously. Once teleprotection inputs and outputs are enabled, direct inputs and outputs are disabled, and vice versa.*

Direct output message timing is similar to GOOSE message timing. Integrity messages (with no state changes) are sent at least every 1000 ms. Messages with state changes are sent within the main pass scanning the inputs and asserting the outputs unless the communication channel bandwidth has been exceeded. Two self-tests are performed and signaled by the following FlexLogic operands:

**DIRECT RING BREAK** (direct input/output ring break) — Indicates that direct output messages sent from a UR-series relay are not being received back by the relay

**DIRECT DEVICE 1 OFF to DIRECT DEVICE 16 OFF** (direct device offline) — Indicate that direct output messages from at least one direct device are not being received

Direct input and output settings are similar to remote input and output settings. The equivalent of the remote device name strings for direct inputs and outputs is the ***DIRECT OUTPUT DEVICE ID*** setting, which identifies the relay in all direct output messages. All UR-series IEDs in a ring need to have unique numbers assigned. The IED ID is used to identify the sender of the direct input and output message.

If the direct input and output scheme is configured to operate in a ring, all direct output messages are received back. If not, the direct input/output ring break self-test is triggered. The self-test error is signaled by the **DIRECT RING BREAK** FlexLogic operand.

Select the ***DIRECT I/O DATA RATE*** to match the data capabilities of the communications channel. All relays communicating over direct inputs and outputs must be set to the same data rate. UR-series relays equipped with dual-channel communications cards apply the same data rate to both channels. Delivery time for direct input and output messages is approximately 0.2 or 0.4 of a power system cycle, depending on the data rate.

### Direct input and output data rates


| Module                  | Supported data rates                   |
|-------------------------|----------------------------------------|
| 2A, 2B                  | 64 kbps                                |
| 2E, 2F (legacy modules) | 64 kbps                                |
| 2G, 2H                  | 128 kbps                               |
| 2I, 2J                  | 64 kbps, 128 kbps                      |
| 72, 73                  | 64 kbps, 128 kbps, 213 kbps (B90 only) |
| 74, 75                  | 64 kbps                                |
| 76, 77                  | 64 kbps                                |
| 7A, 7B, 7C, 7D          | 64 kbps, 128 kbps, 213 kbps (B90 only) |
| 7E, 7F, 7G              | 64 kbps                                |
| 7H, 7I, 7J, 7K          | 64 kbps, 128 kbps, 213 kbps (B90 only) |
| 7L, 7M, 7N, 7P, 7Q      | 64 kbps                                |
| 7R, 7S                  | 64 kbps                                |
| 7T, 7W                  | 64 kbps                                |

The ***DIRECT I/O CHANNEL CROSSOVER*** setting applies to a Product with dual-channel communication cards and allows crossing over messages from channel 1 to channel 2. This places all UR-series relays into one direct input and output network regardless of the physical media of the two communication channels.

The following application examples illustrate the basic concepts for direct input and output configuration. See the Inputs and Outputs section for information on configuring FlexLogic operands (flags, bits) to be exchanged.

### Example 1: Extending the input/output capabilities of a UR-series relay

Consider an application that requires additional quantities of contact inputs or output contacts or lines of programmable logic that exceed the capabilities of a single UR-series chassis. The problem is solved by adding an extra UR-series IED, such as the C30, to satisfy the additional input and output and programmable logic requirements. The two IEDs are connected via single-channel digital communication cards as shown in the figure.



**Figure 213: Input and output extension via direct inputs and outputs**


In this application, apply the following settings. For relay 1:

- DIRECT OUTPUT DEVICE ID: "1"
- DIRECT I/O CH1 RING CONFIGURATION: "Yes"
- DIRECT I/O DATA RATE: "128 kbps"
- For UR-series IED 2:
- DIRECT OUTPUT DEVICE ID: "2"
- DIRECT I/O CH1 RING CONFIGURATION: "Yes"
- DIRECT I/O DATA RATE: "128 kbps"

The message delivery time is about 0.2 of power cycle in both ways (at 128 kbps); that is, from device 1 to device 2, and from device 2 to device 1. Different communications cards can be selected by the user for this back-to-back connection (for example: fiber, or RS422).


#### Example 2: Interlocking busbar protection

A simple interlocking busbar protection scheme could be accomplished by sending a blocking signal from downstream devices, say 2, 3, and 4, to the upstream device that monitors a single incomer of the busbar, as shown.



**Figure 214: Sample interlocking busbar protection scheme**

For increased reliability, a dual-ring configuration (shown as follows) is recommended for this application.



**Figure 215: Interlocking bus protection scheme via direct inputs/outputs**

In this application, apply the following settings. For relay :

- DIRECT OUTPUT DEVICE ID: "1"
- DIRECT I/O CH1 RING CONFIGURATION: "Yes"
- DIRECT I/O CH2 RING CONFIGURATION: "Yes"

For relay 2:

- DIRECT OUTPUT DEVICE ID: "2"
- DIRECT I/O CH1 RING CONFIGURATION: "Yes"
- DIRECT I/O CH2 RING CONFIGURATION: "Yes"

For relay 3:

- DIRECT OUTPUT DEVICE ID: "3"
- DIRECT I/O CH1 RING CONFIGURATION: "Yes"
- DIRECT I/O CH2 RING CONFIGURATION: "Yes"

For relay 4:

- DIRECT OUTPUT DEVICE ID: "4"
- DIRECT I/O CH1 RING CONFIGURATION: "Yes"
- DIRECT I/O CH2 RING CONFIGURATION: "Yes"

The Message delivery time is approximately 0.2 of power system cycle (at 128 kbps) times number of 'bridges' between the origin and destination. Dual-ring configuration effectively reduces the maximum 'communications distance' by a factor of two.

In this configuration the following delivery times are expected (at 128 kbps) if both rings are healthy:

Relay 1 to Relay 2: 0.2 of power system cycle

Relay 1 to Relay 3: 0.4 of power system cycle

Relay 1 to Relay 4: 0.2 of power system cycle

Relay 2 to Relay 3: 0.2 of power system cycle

Relay 2 to Relay 4: 0.4 of power system cycle

Relay 3 to Relay 4: 0.2 of power system cycle

If one ring is broken (say TX2-RX2) the delivery times are as follows:

Relay 1 to Relay 2: 0.2 of power system cycle

Relay 1 to Relay 3: 0.4 of power system cycle

Relay 1 to Relay 4: 0.6 of power system cycle

Relay 2 to Relay 3: 0.2 of power system cycle


Relay 2 to Relay 4: 0.4 of power system cycle

Relay 3 to Relay 4: 0.2 of power system cycle

A coordinating timer for this bus protection scheme could be selected to cover the worst case scenario (0.4 of a power system cycle). Upon detecting a broken ring, the coordination time is adaptively increased to 0.6 of a power system cycle. The complete application requires addressing a number of issues, such as failure of both the communications rings, failure or out-of-service conditions of one of the relays, and so on. Self-monitoring flags of the direct inputs and outputs feature primarily are used to address these concerns.


### Example 3: Pilot-aided schemes

Consider the three-terminal line protection application shown.



**Figure 216: Three-terminal line application**

A permissive pilot-aided scheme can be implemented in a two-ring configuration, shown as follows (Relays 1 and 2 constitute a first ring, while Relays 2 and 3 constitute a second ring).



**Figure 217: Single-channel open loop configuration**

In this application, apply the following settings. For UR-series Relay 1:

- DIRECT OUTPUT DEVICE ID: "1"
- DIRECT I/O CH1 RING CONFIGURATION: "Yes"
- DIRECT I/O CH2 RING CONFIGURATION: "Yes"

For UR-series Relay 2:

- DIRECT OUTPUT DEVICE ID: "2"
- DIRECT I/O CH1 RING CONFIGURATION: "Yes"
- DIRECT I/O CH2 RING CONFIGURATION: "Yes"


For UR-series Relay 3:

- DIRECT OUTPUT DEVICE ID: "3"
- DIRECT I/O CH1 RING CONFIGURATION: "Yes"
- DIRECT I/O CH2 RING CONFIGURATION: "Yes"

In this configuration the following delivery times are expected (at 128 kbps):

- Relay 1 to Relay 2: 0.2 of power system cycle
- Relay 1 to Relay 3: 0.5 of power system cycle
- Relay 2 to Relay 3: 0.2 of power system cycle

In this scheme, Relays 1 and 3 do not communicate directly. Relay 2 must be configured to forward the messages as explained in the Inputs and Outputs section. Implement a blocking pilot-aided scheme with more security and, ideally, faster message delivery time. This is accomplished using a dual-ring configuration as shown here.



**Figure 218: Dual-channel closed loop (dual-ring) configuration**

In this application, apply the following settings. For UR-series Relay 1:

- DIRECT OUTPUT DEVICE ID: "1"
- DIRECT I/O CH1 RING CONFIGURATION: "Yes"
- DIRECT I/O CH2 RING CONFIGURATION: "Yes"

For UR-series Relay 2:

- DIRECT OUTPUT DEVICE ID: "2"
- DIRECT I/O CH1 RING CONFIGURATION: "Yes"
- DIRECT I/O CH2 RING CONFIGURATION: "Yes"

For UR-series Relay 3:

- DIRECT OUTPUT DEVICE ID: "3"
- DIRECT I/O CH1 RING CONFIGURATION: "Yes"
- DIRECT I/O CH2 RING CONFIGURATION: "Yes"

In this configuration the following delivery times are expected (at 128 kbps) if both the rings are healthy:

- Relay 1 to Relay 2: 0.2 of power system cycle
- Relay 1 to Relay 3: 0.2 of power system cycle
- Relay 2 to Relay 3: 0.2 of power system cycle

The two communications configurations can be applied to both permissive and blocking schemes. Take speed, reliability, and cost into account when selecting the required architecture.

#### 8.4.17.1 CRC ALARM

Setting path: **SETTINGS > PRODUCT SETUP > DIRECT I/O > CRC ALARM CH1(2)**

*Note:*  
Only channel 1 is shown

■ CRC ALARM CH 1



CRC ALARM CH 1:  
FUNCTION: Disabled

Range: Enabled, Disabled

|   |                                      |                                   |
|---|--------------------------------------|-----------------------------------|
| ⇅ | CRC ALARM CH 1<br>MESSAGE COUNT: 600 | Range: 100 to 10000 in steps of 1 |
| ⇅ | CRC ALARM CH 1<br>THRESHOLD: 10      | Range: 1 to 1000 in steps of 1    |
| ↑ | CRC ALARM CH 1<br>EVENTS: Disabled   | Range: Enabled, Disabled          |

The relay checks the integrity of the incoming Direct I/O messages using a 32-bit CRC. The CRC alarm function is available for monitoring the communication medium noise by tracking the rate of messages failing the CRC check. The monitoring function counts all incoming messages, including messages that failed the CRC check. A separate counter adds up messages that failed the CRC check. When the failed CRC counter reaches the user-defined level specified by the **CRC ALARM CH1 THRESHOLD** setting, the DIR IO CH1 CRC ALARM FlexLogic operand is set.

When the total message counter reaches the user-defined maximum specified by the **CRC ALARM CH1 MESSAGE COUNT** setting, both the counters reset and the monitoring process is restarted.

You configure the operand to drive an output contact, user-programmable LED, or selected communication-based output.

The CRC alarm function is available on a per-channel basis. The total number of Direct I/O messages that failed the CRC check is available as an Actual Value **ACTUAL VALUES > STATUS > DIRECT INPUTS > CRC FAIL COUNT CH1**.

#### Message count and length of the monitoring window

To monitor communications integrity, the relay sends 1 message per second at 64 kbps, 2 messages per second at 128 kbps, or for the B90 only, 3 messages per second at 213 kbps, even if there is no change in the direct outputs. If the messages are sent faster as a result of direct outputs activity, the monitoring time interval shortens. Take this into account when determining the **CRC ALARM CH1 MESSAGE COUNT** setting. For example, if the requirement is a maximum monitoring time interval of 10 minutes at 64 kbps, then the **CRC ALARM CH1 MESSAGE COUNT** is set to  $10 \times 60 \times 1 = 600$ .

#### Correlation of failed CRC and bit error rate (BER)

The CRC check can fail if one or more bits in a packet are corrupted. Therefore, an exact correlation between the CRC fail rate and the BER is not possible. Under certain assumptions an approximation can be made as follows. A direct input and output packet containing 20 bytes results in 160 bits of data being sent and therefore, a transmission of 63 packets is equivalent to 10,000 bits. A BER of  $10^{-4}$  implies 1 bit error for every 10000 bits sent or received. Assuming the best case of only 1 bit error in a failed packet, having 1 failed packet for every 63 received is about equal to a BER of  $10^{-4}$ .

#### 8.4.17.2 UNRETURNED MESSAGES ALARM

Setting path: **SETTINGS > PRODUCT SETUP > DIRECT I/O > UNRETURNED MESSAGES ALARM CH 1(2)**

|                                      |   |                                            |                                   |
|--------------------------------------|---|--------------------------------------------|-----------------------------------|
| ■ UNRETURNED<br>■ MESSAGES ALARM CH1 | ↔ | UNRET MSGS ALARM CH1<br>FUNCTION: Disabled | Range: Enabled, Disabled          |
|                                      | ⇅ | UNRET MSGS ALARM CH1<br>MESSAGE COUNT: 600 | Range: 100 to 10000 in steps of 1 |
|                                      | ⇅ | UNRET MSGS ALARM CH1<br>THRESHOLD: 10      | Range: 1 to 1000 in steps of 1    |
|                                      | ↑ | UNRET MSGS ALARM CH1<br>EVENTS: Disabled   | Range: Enabled, Disabled          |

The relay checks the integrity of the direct input and output communication ring by counting unreturned messages. In the ring configuration, all messages originating at a given device should return within a pre-defined period of time.

The unreturned messages alarm function is available for monitoring the integrity of the communication ring by tracking the rate of unreturned messages. This function counts all the outgoing messages and a separate counter adds the messages have failed to return. When the unreturned messages counter reaches the user-definable level specified by the **UNRET MSGS ALARM CH1 THRESHOLD** setting and within the user-defined message count **UNRET MSGS ALARM CH1 COUNT**, the DIR IO CH1 UNRET ALM FlexLogic operand is set.

When the total message counter reaches the user-defined maximum specified by the **UNRET MSGS ALARM CH1 MESSAGE COUNT** setting, both the counters reset and the monitoring process is restarted.

Configure the operand to drive an output contact, user-programmable LED, or selected communication-based output. Latching and acknowledging conditions, if required, are programmed accordingly.

The unreturned messages alarm function is available on a per-channel basis and is active only in the ring configuration. The total number of unreturned input and output messages is available as the **ACTUAL VALUES > STATUS > DIRECT INPUTS > UNRETURNED MSG COUNT CH1** actual value.

8.4.18 TELEPROTECTION

Setting path: **SETTINGS > PRODUCT SETUP > DIRECT I/O > CRC ALARM CH <n>**

|                  |   |                                      |                              |
|------------------|---|--------------------------------------|------------------------------|
| ■ TELEPROTECTION | ↔ | TELEPROTECTION<br>FUNCTION: Disabled | Range: Enabled, Disabled     |
|                  | ↕ | NUMBER OF TERMINALS<br>2             | Range: 2, 3                  |
|                  | ↕ | NUMBER OF COMM<br>CHANNELS: 1        | Range: 1, 2                  |
|                  |   | LOCAL RELAY ID<br>NUMBER: 0          | Range: 0 to 63 in steps of 1 |
|                  |   | TERMINAL 1 RELAY ID<br>NUMBER: 0     | Range: 0 to 63 in steps of 1 |
|                  | ↑ | TERMINAL 2 RELAY ID<br>NUMBER: 0     | Range: 0 to 63 in steps of 1 |

*Note:*  
This option is available when an Inter-Relay Communications card is specified at the time of ordering. With the option, direct inputs/outputs display by default. When you enable the teleprotection feature, direct I/O is not visible.

Digital teleprotection transfers protection commands between two or three relays in a secure, fast, dependable, and deterministic way. Possible applications are permissive or blocking pilot schemes and direct transfer trip (DTT). Teleprotection can be applied over any analog or digital channels and any communications media, such as direct fiber, copper wires, optical networks, or microwave radio links. A mixture of communication media is possible.

Once teleprotection is enabled and the teleprotection input/outputs are configured, data packets are transmitted continuously every 1/4 cycle (3/8 cycle if using C37.94 modules) from peer-to-peer. Security of communication channel data is achieved by using CRC-32 on the data packet.

*Note:*  
Teleprotection inputs/outputs and direct inputs/outputs are mutually exclusive. As such, they cannot be used simultaneously. Once teleprotection inputs and outputs are enabled, direct inputs and outputs are blocked, and vice versa.



### NUMBER OF TERMINALS

Specifies whether the teleprotection system operates between two peers or three peers.

### NUMBER OF CHANNELS

Specifies how many channels are used. If the **NUMBER OF TERMINALS** is 3 (three-terminal system), set the **NUMBER OF CHANNELS** to 2. For a two-terminal system, the **NUMBER OF CHANNELS** can set to 1 or 2 (redundant channels).

### LOCAL RELAY ID NUMBER, TERMINAL 1 RELAY ID NUMBER, and TERMINAL 2 RELAY ID NUMBER

In installations that use multiplexers or modems, you should make sure that the data used by the relays protecting a given line is from the correct relays. The teleprotection function performs this check by reading the message ID sent by transmitting relays and comparing it to the programmed ID in the receiving relay. This check is also used to block inputs if inadvertently set to loopback mode, or data is being received from a wrong relay by checking the ID on a received channel. If an incorrect ID is found on a channel during normal operation, the TELEPROT CH1 ID FAIL or TELEPROT CH2 ID FAIL FlexLogic operand is set, driving the event with the same name and blocking the teleprotection inputs. For commissioning purposes, the result of channel identification is also shown in the **STATUS > CHANNEL TESTS > VALIDITY OF CHANNEL CONFIGURATION** actual value. The default value of 0 for the **LOCAL RELAY ID NUMBER** indicates that relay ID is not to be checked. On two-terminals two-channel systems, the same **LOCAL RELAY ID NUMBER** is transmitted over both channels; as such, only the **TERMINAL 1 ID NUMBER** has to be programmed on the receiving end.

## 8.4.19 INSTALLATION

Setting path: **SETTINGS > PRODUCT SETUP > INSTALLATION**

|                |   |                                   |                                         |
|----------------|---|-----------------------------------|-----------------------------------------|
| ■ INSTALLATION | ⇔ | RELAY SETTINGS:<br>Not Programmed | Range: Not Programmed, Programmed       |
|                | ⇕ | RELAY NAME:<br>Relay-1:           | Range: up to 20 alphanumeric characters |
|                | ↑ | STATION NAME<br>Station-1         | Range: up to 20 alphanumeric characters |

### RELAY SETTINGS

To safeguard against the installation of a relay without any entered settings, the unit does not allow signaling of any output relay until **RELAY SETTINGS** is set to *Programmed*. This setting is *Not Programmed* by default. The UNIT NOT PROGRAMMED self-test error message displays until the relay is put into the *Programmed* state.

### RELAY NAME

This setting allows the user to uniquely identify a relay. This name appears on generated reports.

### STATION NAME

This setting allows the user to associate the relay with the installed substation.

# 8.5 SYSTEM SETUP

This section describes all the settings necessary for setting up the system:

## 8.5.1 AC INPUTS

Setting path: **SETTINGS > SYSTEM SETUP > AC INPUTS**

|                  |   |                            |
|------------------|---|----------------------------|
| ■ AC INPUTS<br>■ | ↔ | ■ CURRENT BANK F1(M5)<br>■ |
|                  | ↑ | ■ VOLTAGE BANK F1(M5)<br>■ |

### 8.5.1.1 CURRENT BANKS

Setting path: **SETTINGS > SYSTEM SETUP > AC INPUTS> CURRENT BANK <X,Y>**

Upto six banks are available with designations dependent on the configuration. Only bank F1 is shown here.

|                        |   |                                |                                                                               |
|------------------------|---|--------------------------------|-------------------------------------------------------------------------------|
| ■ CURRENT BANK F1<br>■ | ↔ | PHASE CT F1<br>PRIMARY: 1 A    | Range: 1 to 65000 A in steps of 1                                             |
|                        | ↕ | PHASE CT F1<br>SECONDARY: 1 A  | Range: 1 A, 5 A: 0 to 65535 in steps of 1                                     |
|                        | ↕ | PHASE CT F1 POL:<br>STANDARD   | Range: Standard, Inverted-3Ph, Inverted Ph-A,<br>Inverted Ph-B, Inverted Ph-C |
|                        | ↕ | GROUND CT F1<br>PRIMARY: 1 A   | Range: 1 to 65000 A in steps of 1                                             |
|                        | ↕ | GROUND CT F1<br>SECONDARY: 1 A | Range: 1 A, 5 A                                                               |
|                        | ↑ | GROUND CT F1 POL:<br>STANDARD  | Range: Standard, Inverted                                                     |

For a Product with -9-2LE hardware and software options, this element is not present.

If applicable, record the value of any energy parameters and then reset immediately prior to changing any CT characteristics.

Depending on the model, either two, four or six banks of phase and ground CTs can be set, where the current banks are denoted in the following format Xa, where X = the slot designation, and a is the AC quantity group designation.

These settings are critical for all features that have settings dependent on current measurements. When the relay is ordered, the CT module must be specified to include a standard or sensitive ground input. As the phase CTs are connected in wye (star), the calculated phasor sum of the three phase currents ( $I_A + I_B + I_C = \text{neutral current} = 3I_0$ ) is used as the input for the neutral overcurrent elements. In addition, a zero-sequence (core balance) CT which senses current in all of the circuit primary conductors, or a CT in a neutral grounding conductor can also be used. For this configuration, the ground CT primary rating must be entered. To detect low level ground fault currents, the sensitive ground input can be used. In this case, the sensitive ground CT primary rating must be entered. See chapter 3 for more details on CT connections.

Enter the rated CT primary current values. For both 1000:5 and 1000:1 CTs, the entry would be 1000. For correct operation, the CT secondary rating must match the setting (which must also correspond to the specific CT connections used).

The following example illustrates how multiple CT inputs (current banks) are summed as one source current. Given the following current banks:

F1: CT bank with 500:1 ratio

F5: CT bank with 1000:1 ratio

The source current is  $SRC I = F1 + F5$

The highest primary current (in F5) is 1 pu, so the secondary current from the other two CTs are adjusted accordingly before summation. If a protection element is set up to act on SRC 1 currents, then a pickup level of 1 pu operates on 1000 A primary.

The same rule applies for current sums from CTs with different secondary taps (5 A and 1 A).

**Warning:**

**In case of current sums from CTs with the same primary current but different secondary current, the first CT bank becomes a base and second CT bank current is-rescaled to the first CT bank (for example F1+M1, F1 is a base for the settings and actual values).**

The relay allows the reversal of the CT polarity for a single phase or three phases without changing the wiring. You do this using the settings **PHASE CT F1 (Xa) POL** and **GROUND CT F1 (Xa) POL**.

### PHASE CT F1 POL

If CTs are wired with the correct polarity in all phases, i.e. CT polarity reversal is not required; the *Standard* value should be selected. If the CT polarity is incorrect in just one phase, let's say phase A, then select *Inverted Ph-A*. If CT polarities of all three phases are incorrect, select *Inverted-3Ph* to correct the CT polarities for all three phases. Note that the oscillography record will capture the CTs current signal as applied to the relay terminal irrespective of this setting. This ensures correct relay behavior when recorded oscillography is played back to the relay.

### GROUND CT F1 POL

The same principles described above apply.

**Note:**

*It is important that the settings PHASE CT F1 POL and GROUND CT F1 POL are set to the correct values before putting the relay into operation. Selecting the wrong value or changing this setting whilst relay is in operation would result in undesirable operation of the protection and control functions.*

## 8.5.1.2 VOLTAGE BANKS

Setting path: **SETTINGS > SYSTEM SETUP > AC INPUTS > VOLTAGE BANK <X,Y>**

Up to six banks are available. Only bank F5 is shown here.

|                                                        |   |                                      |                                          |
|--------------------------------------------------------|---|--------------------------------------|------------------------------------------|
| <div> <div>■ VOLTAGE BANK F5</div> <div>■</div> </div> | ⇔ | PHASE VT F5<br>CONNECTION: Wye       | Range: Wye, Delta                        |
|                                                        | ⇕ | PHASE VT F5<br>SECONDARY: 66.4 V     | Range: 25.0 to 240.0 V in steps of 0.1   |
|                                                        | ⇕ | PHASE VT F5<br>RATIO: 1.00 :1        | Range: 1.00 to 24000.00 in steps of 0.01 |
|                                                        | ⇕ | AUXILIARY VT F5<br>CONNECTION: Vag   | Range: Vn, Vag, Vbg, Vcg, Vab, Vbc, Vca  |
|                                                        | ⇕ | AUXILIARY VT F5<br>SECONDARY: 66.4 V | Range: 25.0 to 240.0 V in steps of 0.1   |
|                                                        | ↑ | AUXILIARY VT F5<br>RATIO: 1.00 :1    | Range: 1.00 to 24000.00 in steps of 0.01 |

If applicable, record the value of any energy parameters and then reset immediately prior to changing any VT characteristics.

Depending on the model, either one, two, three or twenty four banks of phase/auxiliary VTs can be set.

With VTs installed, the relay can perform voltage measurements as well as power calculations.

**PHASE VT F5 CONNECTION**

You can set this to *Wye* or *Delta*

**PHASE VT F5 SECONDARY**

Here, you set the secondary value of the phase VT in bank F5

**PHASE VT F5 RATIO**

Here you set the VT ratio of the phase VT in bank F5

**AUXILIARY VT F5 CONNECTION**

Here you set the connection of the auxiliary VT (Vn, Vag, Vbg, Vcg, Vab, Vbc, Vca)

**AUXILIARY VT F5 SECONDARY**

Here, you set the secondary value of the auxiliary VT in bank F5

**AUXILIARY VT F5 RATIO**

Here you set the VT ratio of the auxiliary VT in bank F5

*Note:*  
The nominal **PHASE VT F5 SECONDARY** voltage setting is the voltage across the relay input terminals when nominal voltage is applied to the VT primary.

*Note:*  
For example, on a system with a 13.8 kV nominal primary voltage and with a 14400:120 volt VT in a delta connection, the secondary voltage is 115; that is,  $(13800 / 14400) \times 120$ . For a wye connection, the voltage value entered must be the phase to neutral voltage, which is  $115 / \sqrt{3} = 66.4$ .

*Note:*  
On a 14.4 kV system with a delta connection and a VT primary to secondary turns ratio of 14400:120, the voltage value entered is 120; that is,  $14400 / 120$ .

**8.5.2 POWER SYSTEM**

Setting path: **SETTINGS > SYSTEM SETUP > POWER SYSTEM**

|                                        |   |                                         |                                     |
|----------------------------------------|---|-----------------------------------------|-------------------------------------|
| <div>■ POWER SYSTEM</div> <div>■</div> | ↔ | NOMINAL FREQUENCY:<br>60 Hz             | Range: 25 to 60 Hz in steps of 1    |
|                                        | ⇅ | PHASE ROTATION:<br>ABC                  | Range: ABC, ACB                     |
|                                        | ⇅ | FREQUENCY AND PHASE<br>REFERENCE: SRC 1 | Range: SRC <n> (depending on model) |

|   |                                           |                                                 |
|---|-------------------------------------------|-------------------------------------------------|
| ⇅ | SIGNAL TO TRACK:<br>Auto                  | Range: Auto, 3-ph VT, 1-ph VT, 3-ph CT, 1-ph CT |
| ⇅ | ALTERNATE FREQ AND PHS<br>REFERENCE: None | Range: SRC 1, SRC 2, SRC 3, SRC 4, SRC 5, SRC 6 |
| ⇅ | ALT SIGNAL TO TRACK:<br>3-ph VT           | Range: 3-ph VT, 1-ph VT, 3-ph CT, 1-ph CT       |
| ⇅ | REVERSE ROTATION:<br>Off                  | Range: FlexLogic operand                        |
| ↑ | FREQUENCY TRACKING:<br>Enabled            | Range: Disabled, Enabled                        |

## NOMINAL FREQUENCY

The power system **NOMINAL FREQUENCY** value is used as a default to set the digital sampling rate if the system frequency cannot be measured from available signals. This can happen if the signals are not present or are heavily distorted. Before reverting to the nominal frequency, the frequency tracking algorithm holds the last valid frequency measurement for a safe period of time while waiting for the signals to reappear or for the distortions to decay. When using a Process Bus Module and SV streams, the SV streams need to be defaulted before changing this setting, under **Settings > Process Bus Module > SV Stream Config**. After changing the nominal frequency, restart the relay using **Maintenance > Reboot Relay Command**.

## PHASE ROTATION

The phase sequence of the power system is required to properly calculate sequence components and power parameters. The **PHASE ROTATION** setting matches the power system phase sequence and informs the relay of the actual system phase sequence, either *ABC* or *ACB*. CT and VT inputs on the relay, labeled as A, B, and C, must be connected to system phases A, B, and C for correct operation.

## REVERSE PH ROTATION

This setting allows you to dynamically change the phase rotation used for phasor calculations. This allows the relay to follow the current phase rotation of the protected generator. For example, if the **PHASE ROTATION** setting is *ABC* but the condition defined for opposite phase rotation is true, then the phase rotation used for phasor calculation switches to *ACB*. This feature is only intended for use in special applications, such as pumped storage schemes.

Typical application of using Reverse Phase Rotation is the pumped-storage hydroelectricity application. Water is pumped (motor mode) from a lower elevation reservoir to a higher elevation during the off-peak period when low-cost surplus electricity is available. During periods of high electrical demand, the stored water is released through turbines to produce electricity (generator mode). The hydraulic units are designed to operate as turbines when rotating in one direction and as pumps when rotating in the opposite direction.

When the operand assigned to the **REVERSE PH ROTATION** setting is logical *0*, the phase rotation matches the one defined by the **PHASE ROTATION** setting. When this operand is logical *1*, the phase rotation changes to the opposite.

### Note:

After successful rotation switching, the next switching operation is allowed only after nine power cycles.

Typically, different relay setting groups are used to protect pumping operation mode and generating operation mode of the hydraulic units respectively, therefore the logic for switching setting groups can be directly used to control the **REVERSE PH ROTATION**.

Every time there is a rotation change, protection is blocked for three power cycles.

## FREQUENCY AND PHASE REFERENCE

This setting determines which signal source is used for frequency tracking and phase angle reference. Within this source, a specific signal shall be selected for tracking frequency calculation and for the phase angle reference, and such selection will be determined by the **SIGNAL TO TRACK** setting below.

### SIGNAL TO TRACK

This setting specifies the signal in a source to be used for tracking frequency calculation and for phase angle reference. When *Auto* is selected, the AC signal to be used in a source is prioritized based on the AC inputs configuration in this source, in which phase voltages takes precedence, followed by the auxiliary voltage, then phase currents, and finally ground current, as it was in legacy UR f/w releases. With *Auto*, the signal selection is static rather than dynamic, i.e. AC signals are selected, based upon the source configuration only, regardless of whether a particular signal is applied to the relay or not. If VT or CT is selected (3-ph VT, 1-ph VT, 3-ph CT, 1-ph CT), the AC signal to be used is directly based on this selection and will revert to nominal frequency if the selected signal is below 0.06pu.

For the three-phase selection, phase A is used for angle referencing (ANGLE REF = VA or IA). Clarke transformation of the phase signals is used for frequency metering and tracking ( $VFREQUENCY = (2VA - VB - VC) / 3$ ) for better performance during fault, open pole, and VT and CT fail conditions.

Phase angle of the reference signal always displays zero degrees and all other phase angles are relative to this signal. If the pre-selected reference signal is not measurable at a given time, the phase angles are not referenced to any external AC signal and are referenced to the internal reference to continue maintaining proper phase relationship between all other measured AC signal. The phase angle referencing is done via a phase locked loop, which can synchronize independent UR-series relays if they have the same AC signal reference. This results in very precise correlation of phase angle indications between different UR series relays.

### ALTERNATE FREQ AND PHS REFERENCE

This setting determines the alternative source for frequency tracking and phase angle reference. If the signal specified by the main **FREQUENCY AND PHASE REFERENCE** setting is lost, the reference will be switched to this alternative reference. Switching between the main reference and the alternative reference is allowed (activated) only if the following conditions are true:

- Frequency tracking is enabled, AND
- The alternative reference is set to a source other than None, AND
- The selected signals between main and alternative **FREQUENCY AND PHASE REFERENCE** are different.

Switching is also allowed (activated) even if the same source is selected in both the **FREQUENCY AND PHASE REFERENCE** setting and in the **ALTERNATE FREQ AND PHS REFERENCE** setting, given that different signals are selected in the **SIGNAL TO TRACK** and **ALT SIGNAL TO TRACK** settings.

When the main source signal becomes available again, the relay will switch back to the main source.

### ALT SIGNAL TO TRACK

This is the same as the **SIGNAL TO TRACK** setting in the main **FREQUENCY AND PHASE REFERENCE** setting, but the signal defined here is used for the **ALTERNATE FREQ AND PHS REFERENCE** setting. When the same source is selected for both main and alternate reference quantities, the signal selected in this setting must be different from the signal selected in the main reference, otherwise no switching is performed.

If neither main nor alternate signals are available, tracking frequency is reverting to nominal until either main or alternate signals are available and measurable.

## FREQUENCY TRACKING

This enables or disables frequency tracking. It is only disabled in unusual circumstances. Please consult GE for special variable frequency applications.

**Note:**

The frequency tracking feature functions only when the relay is in the *Programmed* mode. Otherwise, the metering values are available but can exhibit significant errors.

**Note:**

Systems with an ACB phase sequence require special consideration. See the *Phase Relationships of Three-phase Transformers* section.

### 8.5.3 SIGNAL SOURCES

Setting path: **SETTINGS > SYSTEM SETUP > SOURCE <n>**

where n, number of sources depend on the model. Only Source 1 is shown here

|                                                 |   |                              |                                                                                         |
|-------------------------------------------------|---|------------------------------|-----------------------------------------------------------------------------------------|
| <div> <div>■ SOURCE 1</div> <div>■</div> </div> | ⇔ | SOURCE 1 NAME:<br>SRC 1      | Range: up to 20 alphanumeric characters                                                 |
|                                                 | ⇕ | SOURCE 1 PHASE CT:<br>None   | Range: None, F1,... up to any 6 CTs.<br>Only Phase CT inputs are displayed.             |
|                                                 | ⇕ | SOURCE 1 GROUND CT:<br>None  | Range: None, F1,... up to any 6 CTs.<br>Only Ground CT inputs are displayed.            |
|                                                 | ⇕ | SOURCE 1 PHASE VT:<br>None   | Range: None, <relevant slot designation><br>Only phase voltage inputs are displayed     |
|                                                 | ⇕ | SOURCE 1 AUX VT:<br>None     | Range: None, <relevant slot designation><br>Only auxiliary voltage inputs are displayed |
|                                                 | ⇕ | SRC 1 ALT PHASE CT:<br>None  | Range: None, F1,... up to any 6 CTs                                                     |
|                                                 | ⇕ | SRC 1 ALT GROUND CT:<br>None | Range: None, F1,... up to any 6 CTs                                                     |
|                                                 | ⇕ | SRC 1 SWITCH ALT CT:<br>Off  | Range: FlexLogic operand                                                                |
|                                                 | ⇕ | SRC 1 ALT PHASE VT:<br>None  | Range: None, <relevant slot designation>                                                |
|                                                 | ⇕ | SRC 1 ALT AUX VT:<br>None    | Range: None, <relevant slot designation>                                                |
|                                                 | ⇕ | SRC 1 SWITCH ALT VT:<br>Off  | Range: FlexLogic operand                                                                |

Identical menus are available for each source. You can replace *SRC <n>* with any text up to 20 characters.

The first letter in the source identifier represents the module slot position. The number directly following this letter represents either the first bank of four channels (1, 2, 3, 4) called “1” or the second bank of four channels (5, 6, 7, 8) called “5” in a particular CT/VT module.

It is possible to select the sum of all CT combinations. The first channel displayed is the CT to which all others are referred. For example, the selection “F1+F5” indicates the sum of each phase from banks F1 and F5, scaled to whichever CT has the higher ratio. Selecting *None* hides the associated actual values.

The approach used to configure the AC sources consists of several steps:

- Specify the information about each CT input. This is the nominal primary and secondary current.
- Specify the information about each VT input. This is the connection type, ratio and nominal secondary voltage.
- Specify the configuration for each source, including specifying which CTs are summed together.

### 8.5.3.1 USER SELECTION OF AC PARAMETERS FOR COMPARATOR ELEMENTS

CT/VT modules automatically calculate all current and voltage parameters from the available inputs. You must select the specific input parameters to be measured by every element in the relevant settings menu. The internal design of the element specifies which type of parameter to use and provides a setting for source selection. In elements where the parameter can be either fundamental or RMS magnitude, such as phase time overcurrent, two settings are provided. One setting specifies the source, the second setting selects between fundamental phasor and RMS.

### 8.5.3.2 AC INPUT ACTUAL VALUES

The calculated parameters associated with the configured voltage and current inputs are displayed in the current and voltage sections of actual values. Only the phasor quantities associated with the actual AC physical input channels display here. All parameters contained within a configured source are displayed in the sources section of the actual values.

### 8.5.3.3 DISTURBANCE DETECTORS (INTERNAL)

The disturbance detector (ANSI 50DD) element is a sensitive current disturbance detector that detects any disturbance on the protected system. The 50DD function is used directly in some elements in the relay, for example VT Fuse Failure detector or Fault Report. It can also be used to supervise current-based elements to prevent maloperation as a result of the wrong settings or external CT wiring problem. A disturbance detector is provided for each source.

The 50DD function responds to the changes in magnitude of the sequence currents. The disturbance detector logic is as follows.






Figure 219: Disturbance detector logic (example using six sources)

The disturbance detector responds to the change in currents of twice the current cut-off level. The default cut-off threshold is 0.02 pu; thus by default the disturbance detector responds to a change of 0.04 pu. The metering sensitivity setting **PRODUCT SETUP > DISPLAY PROPERTIES > CURRENT CUT-OFF LEVEL** controls the sensitivity of the disturbance detector accordingly.

### 8.5.3.4 EXAMPLE FOR USE OF SOURCES

An example of the use of sources is shown in the following figure. A relay can have the following hardware configuration:

| UR                                          | Increasing slot position letter > |                |                |
|---------------------------------------------|-----------------------------------|----------------|----------------|
|                                             | CT/VT module 1                    | CT/VT module 2 | CT/VT module 3 |
| B30, B90, C70, F35, N60, T35                | 8 CTs                             | 4 CTs, 4 VTs   | 4 CTs, 4 VTs   |
| C60, C95, D60, G30, G60, L30, L90, M60, T60 | CTs                               | VTs            | not applicable |

This configuration can be used on a two-winding transformer, with one winding connected into a breaker-and-a-half system. The following figure shows the arrangement of sources used to provide the functions required in this application, and the CT/VT inputs that are used to provide the data.





Figure 220: Example of use of sources

|           | Y LV  | D HV  | AUX   |
|-----------|-------|-------|-------|
|           | SRC 1 | SRC 2 | SRC 3 |
| Phase CT  | M1    | F1+F5 | None  |
| Ground CT | M1    | None  | None  |
| Phase VT  | M5    | None  | None  |
| Aux VT    | None  | None  | U1    |


### 8.5.3.5 SOURCE SWITCHING

The UR supports current and voltage signals input from both main and alternate CTs and VTs, with user-defined switching capability. This is beneficial in applications, where the relay can provide protection when the main CT or VT is not available due to station re-configuration. The following figure shows examples of VT switching from VT1 to VT2 when Bus 1 is de-energized, and the line is energized via Bus 2. The CT switching example in (b) shows the connection of the bus transfer breaker CT to the line relay, when the line is energized via the transfer bus. This could be for example, when the main line breaker is taken out of commission for maintenance. In this case, the relay senses current from either CT 1 when the line is energized via main line breaker or CT 2 when the line is energized via the transfer bus breaker.



**Figure 221: Examples of VTs (a) and CTs (b) switching from the main to alternate**

The following figure shows the logic diagram for switching from main banks to alternate banks.



**Figure 222: Logic diagram of switching CTs and VTs from the main to alternate banks**


When a FlexLogic operand assigned to the setting **SRC 1 SWITCH ALT CT/VT** is at logical 0, the analog data is processed from the main CT and VT analog data banks. When this operand is logical 1, the analog data is processed from the alternate CT and VT analog data banks.

Note that:

- Banks assigned to the same function for the main and alternate input data must have the same CT and VT nominal values and connections. If this is not the case, a warning is generated and switching functionality is prohibited. For example, banks assigned to the **PHASE CT** and **ALT PHASE CT** must have same primary and secondary CT values. The ground CT input has to be of the identical type.
- During switching to/from the main CT/VT input data from/to the alternate input data and vice versa, all relay functions are blocked for two power cycles, and metering data is not updated.
- CT bank switching is allowed if both main and alternate CT banks have the exact same combination for CT summation.
- Use Non-volatile Latches if you need the switching state to be remembered.
- Since switching occurs in both the Phase and Ground CT, it is possible to keep the same set under both the main source and alternate source, but a different set for the ground/aux signal.


## 8.5.4 TRANSFORMER

Setting path: **SETTINGS > SYSTEM SETUP > TRANSFORMER**



### 8.5.4.1 GENERAL TRANSFORMER SETTINGS

Setting path: **SETTINGS > SYSTEM SETUP > TRANSFORMER > GENERAL**



The general transformer settings apply to all windings. Settings specific to each winding are shown in the following section.

#### REFERENCE WINDING

The reference winding is the winding to which all other winding currents are scaled. That is, the currents from all other windings are normalized (magnitude compensation) to this winding, and the per unit value of the differential currents, the restraint currents, and the corresponding differential characteristics (pickup, break points, and so on) are all based on the CT Nominal of this winding. The reference winding can be selected either automatically or manually. When automatic reference winding selection is chosen, the winding with the smallest margin of CT primary current with respect to the winding rated current is selected as the reference winding (see details in Magnitude Compensation section later in this chapter). The selected reference winding can be viewed under **Actual Values > Metering > Transformer > Differential and Restraint**.

**Note:**  
*In some applications where the CT primary of the winding is much higher than the winding rated current, automatic selection of the reference winding can result in excessive magnitude compensation factor. This may cause clipping of the winding current clipping. In this case, further checking is required to ensure no winding currents exceed 46 pu after magnitude compensation. If this happens, manually select the reference winding to avoid this. See the T35/T60 Reference Winding Selection and CT Ratio Mismatch Application Note (GET-8548) for information*

#### PHASE COMPENSATION

This setting selects the type of phase compensation to be performed by the relay.

If set to *Internal (software)*, the transformer phase shift is compensated internally by the relay algorithm.

If set to *External (with CTs)*, the transformer phase shift is externally compensated by the CT connections. The Delta connected CTs on the Wye winding compensate the phase shift of the currents between the transformer primary and secondary windings (see the following figure). This is the old way of phase compensation.

And also to measure the currents on both sides of the transformer that correspond to the transformation ratio, divide the CT primary by  $\sqrt{3}$ . This compensates for the increase of  $\sqrt{3}$  caused by the Delta CT connection.

Therefore, the Actual Value of current and power cannot be used for measurements in this case.




Figure 223: Wye winding and Delta CT connection

8.5.4.2 WINDINGS 1 TO 2

Setting path: **SETTINGS > SYSTEM SETUP > TRANSFORMER > WINDING 1(2)**

*Note:*  
Only winding 1 is shown

■ WINDING 1

■

|   |                                                      |                                                                                                  |
|---|------------------------------------------------------|--------------------------------------------------------------------------------------------------|
| ⇔ | WINDING 1 SOURCE:<br>SRC 1                           | Range: SRC 1, SRC 2, SRC 3, SRC 4<br>(or the user-defined name)                                  |
| ⇕ | WINDING 1 RATED MVA:<br>100.000 MVA                  | Range: 0.001 to 2000.000 MVA in steps of 0.001                                                   |
| ⇕ | WINDING 1 NOM $\phi$ - $\phi$<br>VOLTAGE: 220.000 kV | Range: 0.001 to 2000.000 kV in steps of 0.001                                                    |
| ⇕ | WINDING 1<br>CONNECTION: Wye                         | Range: Wye, Delta, Zig-zag                                                                       |
| ⇕ | WINDING 1 GROUNDING:<br>Not within zone              | Range: Not within zone, Within zone                                                              |
| ⇕ | WINDING ~ ANGLE WRT<br>WINDING 1: 0.0°               | Range: -359.9 to 0.0° in steps of 0.1, ('~' > 1)<br>(shown when viewed Winding is not Winding 1) |

The settings specific to each winding are shown in the table.

The following discussion applies to a device protecting the generator step-up (GSU) transformer, assuming that the LV winding CTs are on the neutral side of the generator and the HV winding CTs are on the system side of the step-up delta-wye transformer. It is also assumed that CTs are differentially connected as per regular transformer differential applications, as shown in the Typical Wiring, VT on the LV Side of the Transformer diagram in the Applications of Settings chapter.

The flexibility of phase compensation allows the wiring of CTs to have polarities looking inside the protected zone or looking into the system. This can be needed to provide correct forward metered power at both sides of the GSU. When CTs are differentially connected (wired with polarities both pointing inside the zone), the angle between winding currents should be  $0^\circ$  plus an additional phase shift caused by the wye-delta connection of the transformer. When CTs are wired to point into the system, the angle between winding currents should be  $180^\circ$  plus an additional phase shift caused by the wye-delta connection of the transformer. Therefore, the adopted CTs polarities must be taken into account in the **SYSTEM SETUP > TRANSFORMER** settings menu. See the Applications of Settings chapter for examples of setting up Product transformer differential protection with different CT polarity options.

Transformer differential protection uses the following calculated quantities (per phase): fundamental, second harmonic, and fifth harmonic differential current phasors, and restraint current phasors. This information is extracted from the current transformers (CTs) connected to the relay by correcting the magnitude and phase relationships of the currents for each winding, so as to obtain zero (or near zero) differential currents under normal operating conditions. Traditionally, these corrections were accomplished by interposing CTs and tapped relay windings with some combination of CT connections.

The relay simplifies these configuration issues. All CTs at the transformer are connected wye (polarity markings pointing away from the transformer). User-entered settings in the relay characterizing the transformer being protected and allow the relay to automatically perform all necessary magnitude, phase angle, and zero-sequence compensation.

This section describes the algorithms in the relay that perform this compensation and produce the required calculated quantities for transformer differential protection, by means of the following example of a delta-wye (D-Y) connected power transformer with the following data:

| Data                   | Winding 1: delta connection                                                        | Winding 2: wye connection                                                                            |
|------------------------|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------|
| Voltage Phasor Diagram |  |                   |
| Phase Shift            | $0^\circ$                                                                          | $30^\circ$ lag (i.e. phases of wye winding lag corresponding phases of delta winding by $30^\circ$ ) |
| Grounding              | In-zone grounding bank                                                             | Ungrounded                                                                                           |
| Rated MVA              | 100/133/166 MVA                                                                    | 100/133/166 MVA                                                                                      |
| Nominal f-f Voltage    | 220 kV                                                                             | 69 kV                                                                                                |
| CT Connection          | Wye                                                                                | Wye                                                                                                  |
| CT Ratio               | 500/5                                                                              | 1500/5                                                                                               |
| Auxiliary Cooling      | Two stages of forced air                                                           | Two stages of forced air                                                                             |

**Figure 224: Example of delta-wye connected power transformer data**

The abbreviated nomenclature for applicable relay settings is as follows

- Rotation: PHASE ROTATION
- $w_{total}$  : NUMBER OF WINDINGS
- Compensation: PHASE COMPENSATION
- Source [w]: SOURCE
- $P_{rated}$  [w]: WINDING w RATED MVA
- $V_{nominal}$  [w]: WINDING w NOM F-F VOLTAGE
- Connection [w]: WINDING w CONNECTION
- Grounding [w]: WINDING w GROUNDING
- $\Phi$ [w]: WINDING w ANGLE WRT WINDING 1
- CT primary [w]: the phase CT primary associated with Source [w]

Note:

Note that  $w$  = winding number, 1 to  $w_{total}$

The following transformer setup rules must be observed:

- The angle for the first winding from the transformer setup must be  $0^\circ$ , and the angles for the following windings must be entered as negative (lagging) with respect to (WRT) the winding 1 angle
- The *Within zone* and *Not within zone* setting values refer to whether the winding is grounded. Select *Within zone* if a neutral of a wye type winding, or a corner of a delta winding, is grounded within the zone, or whenever a grounding transformer falls into the zone of protection.

### 8.5.4.3 PHASE RELATIONSHIPS OF THREE-PHASE TRANSFORMERS

Power transformers that are built in accordance with ANSI and IEC standards are required to identify winding terminals and phase relationships among the windings of the transformer.

ANSI standard C.37.12.70 requires that the terminal labels include the characters 1, 2, 3 to represent the names of the individual phases. The phase relationship among the windings must be shown as a phasor diagram on the nameplate, with the winding terminals clearly labeled. This standard states that the phase relationships are established for a condition where the source phase sequence of 1-2-3 is connected to transformer windings labeled 1, 2, and 3 respectively.

IEC standard 60076-1 (1993) states that the terminal markings of the three phases follow national practice. The phase relationship among the windings is shown as a specified notation on the nameplate, and there can be a phasor diagram. In this standard, the arbitrary labeling of the windings is shown as I, II, and III. This standard states that the phase relationships are established for a condition where a source phase sequence of I-II-III is connected to transformer windings labeled I, II, and III respectively.

The reason the source phase sequence must be stated when describing the winding phase relationships is that these relationships change when the phase sequence changes. The following example shows why this happens, using a transformer described in IEC nomenclature as a type “Yd1” or in GE Multilin nomenclature as a “Y/d30.”

The example shows the physical connections within the transformer that produce a phase angle in the delta winding that lag the respective wye winding by  $30^\circ$ . The currents in the windings are also identified. Note that the total current out of the delta winding is described by an equation.





Figure 225: Example of transformer


Now assume that a source, with a sequence of ABC, is connected to transformer terminals ABC respectively. The currents then present for a balanced load are shown in the following figure.



**Figure 226: Phasors for ABC sequence**

Note that the delta winding currents lag the wye winding currents by  $30^\circ$  (in agreement with the transformer nameplate).

Now assume that a source, with a sequence of ACB is connected to transformer terminals ACB respectively. The currents present for a balanced load are shown in the following figure.



**Figure 227: Phasors for ACB sequence**

Note that the delta winding currents leads the wye winding currents by  $30^\circ$ , (which is a type Yd11 in IEC nomenclature and a type Y/d330 in GE Multilin nomenclature) and which is in disagreement with the transformer nameplate. This is because the physical connections and hence the equations used to calculate current for the delta winding have not changed. The transformer nameplate phase relationship information is only correct for a stated phase sequence.

Phase relationship for the ACB sequence can be returned the transformer nameplate values by connecting source phases A, B, and C to transformer terminals A, C, and B respectively. Although this restores the nameplate phase shifts, it causes incorrect identification of phases B and C within the relay and is therefore not recommended.

All information presented in this manual is based on connecting the relay phase A, B, and C terminals to the power system phases A, B, and C respectively. The transformer types and phase relationships presented are for a system phase sequence of ABC, in accordance with the standards for power transformers. Users with a system phase sequence of ACB must determine the transformer type for this sequence.

If a power system with ACB rotation is connected to the Wye winding terminals 1, 2, and 3, respectively, from a Y/d30 transformer, select a Power Rotation setting of ACB in the relay and enter data for the Y/d330 transformer type.



#### 8.5.4.4 MAGNITUDE COMPENSATION

Transformer protection presents problems in the application of current transformers. CTs should be matched to the current rating of each transformer winding, so that normal current through the power transformer is equal on the secondary side of the CT on different windings. However, because only standard CT ratios are available, this matching is not always exact.

In our example, the transformer has a voltage ratio of 220 kV / 69 kV (that is, about 3.188 to 1) and a compensating CT ratio is 500 A to 1500 A (that is, 1 to 3). Historically, this would have resulted in a steady state current at the differential relay. Interposing CTs or tapped relay windings were used to minimize this error.

The Product automatically corrects for CT mismatch errors. All currents are magnitude compensated to be in units of the CTs of one winding before the calculation of differential and restraint quantities.

The reference winding ( $w_{ref}$ ) is the winding to which all currents are referred. This means that the differential and restraint currents are in per unit of nominal of the CTs on the reference winding. This is important to know because the settings of the operate characteristic of the percent differential element (pickup, breakpoints 1 and 2) are entered in terms of the same per unit of nominal.

The reference winding is chosen by the relay to be the winding that has the smallest margin of CT primary current with respect to winding rated current, meaning that the CTs on the reference winding most likely begin to saturate before those on other windings with heavy through currents. The characteristics of the reference winding CTs determine how the percent differential element operate characteristic need to be set.

The Product determines the reference winding as follows:

1. Calculate the rated current ( $I_{rated}$ ) for each winding:

$$I_{rated}[w] = P_{rated}[w] / \sqrt{3} V_{nom}[w], \text{ where } w = 1, 2 \dots w_{total}$$

Note: enter the self-cooled MVA rating for the  $P_{rated}$  setting

2. Calculate the CT margin ( $I_{margin}$ ) for each winding:

$$I_{margin} = CT_{primary}[w] / I_{rated}[w], \text{ where } w = 1, 2 \dots w_{total}$$

3. Choose the winding with the lowest CT margin.

In our example, the reference winding is chosen as follows.

1. Calculate the rated current for windings 1 and 2:

$$I_{rated}[1] = P_{rated}[1] / \sqrt{3} V_{nom}[1] = 100 \text{ MVA} / (\sqrt{3} \text{ V} \times 220 \text{ kV}) = 262.4 \text{ A}$$

$$I_{rated}[2] = P_{rated}[2] / \sqrt{3} V_{nom}[2] = 100 \text{ MVA} / (\sqrt{3} \text{ V} \times 69 \text{ kV}) = 836.7 \text{ A}$$

2. With these rated currents, calculate the CT margin for windings 1 and 2:

$$I_{margin}[1] = CT_{primary}[1] / I_{rated}[1] = 500 / 262.4 = 1.91$$

$$I_{margin}[2] = CT_{primary}[2] / I_{rated}[2] = 1500 / 836.7 = 1.79$$

3. Since  $I_{margin}[2] < I_{margin}[1]$ , the reference winding  $w_{ref}$  is winding 2.

The reference winding is shown in **ACTUAL VALUES > METERING > TRANSFORMER > DIFFERENTIAL AND RESTRAINT > REFERENCE WINDING**.

The unit for calculation of the differential and restraint currents and base for the differential restraint settings is the CT primary associated with the reference winding. In this example, the unit CT is 1500:5 on winding 2.

Magnitude compensation factors (M) are the scaling values by which each winding current is multiplied to refer it to the reference winding. The relay calculates magnitude compensation factors for each winding as follows:

$$M[w] = (I_{primary}[w] \times V_{nom}[w]) / (I_{primary}[w_{ref}] \times V_{nom}[w_{ref}]), \text{ where } w = 1, 2 \dots w_{total}$$

In our example, the magnitude compensation factors are calculated as follows:

$$M[1] = (I_{primary}[1] \times V_{nom}[1]) / (I_{primary}[2] \times V_{nom}[2]) = (500 \times 220) / (1500 \times 69) = 1.0628$$

$$M[2] = (I_{\text{primary}}[2] \times V_{\text{nom}}[2]) / (I_{\text{primary}}[2] \times V_{\text{nom}}[2]) = (1500 \times 69 / (1500 \times 69)) = 1.000$$

The maximum allowed magnitude compensation factor (and hence the maximum allowed CT ratio mismatch) is 32.

#### 8.5.4.5 PHASE AND ZERO SEQUENCE COMPENSATION

Power transformers can be connected to provide phase shift, such as the common D-Y connection with its 30° phase shift. Historically, CT connections were arranged to compensate for this phase error so that the relaying operated correctly.

In our example, the transformer has the D-Y connection. Traditionally, CTs on the Wye connected transformer winding (winding 2) are connected in a delta arrangement, which compensates for the phase angle lag introduced in the Delta connected winding (winding 1), so that line currents from both windings can be compared at the relay. The Delta connection of CTs, however, inherently has the effect of removing the zero sequence components of the phase currents. If there is a grounding bank on the Delta winding of the power transformer within the zone of protection, a ground fault results in differential (zero sequence) current and false trips. In such a case, it is necessary to insert a zero sequence current trap with the Wye connected CTs on the Delta winding of the transformer.

In general, zero sequence removal is necessary if zero sequence can flow into and out of one transformer winding but not the other winding. Transformer windings that are grounded inside the zone of protection allow zero sequence current flow in that winding, and therefore it is from these windings that zero sequence removal is necessary.

The Product performs this phase angle compensation and zero sequence removal automatically, based on the settings entered for the transformer. All CTs are connected Wye (polarity markings pointing away from the transformer). All currents are phase and zero sequence compensated internally before the calculation of differential and restraint quantities.

The phase reference winding ( $w_f$ ) is the winding to have a phase shift of 0° applied to it. For the ease of entering settings, the Product allows the user to enter the phase angles with respect to Winding 1. Internally, however, the delta or zigzag (non-wye) winding with the lowest winding index is selected as a reference winding and all other winding angles are adjusted to this reference based on **WINDING ~ ANGLE WRT WINDING 1**. For a transformer that has no delta or zigzag windings, Winding 1 is chosen as a phase reference winding.

The phase compensation angle ( $\Phi_{\text{comp}}$ ), the angle by which a winding current is shifted to refer it to the phase reference winding, is calculated by the relay for each winding as follows:

$$\Phi_{\text{comp}}[w] = | \Phi[w_f] - \Phi[w] | \text{ where Rotation} = \text{ABC}$$

$$\Phi_{\text{comp}}[w] = | \Phi[w] - \Phi[w_f] | \text{ where Rotation} = \text{ACB}$$

In our example, the phase reference winding is winding 1, the first delta winding (that is,  $w_f = 1$ ). The phase compensation angle for each winding is then calculated as follows (assuming Rotation = ABC):

$$\Phi_{\text{comp}}[1] = 0^\circ - 0^\circ = 0^\circ$$

$$\Phi_{\text{comp}}[2] = 0^\circ - (-30^\circ) = 30^\circ = 330^\circ \text{ lag}$$

The following table shows the linear combination of phases of a transformer winding that achieves the phase shift and zero sequence removal for typical values of  $\Phi_{\text{comp}}$

where:

$I_A[w]$  = uncompensated winding 'w' phase A current

$I_A^p[w]$  = phase and zero sequence compensated winding 'w' phase A current

| $\Phi_{\text{comp}}[w]$ | Grounding[w] = "Not within zone"                                                                                                                                                                   | Grounding[w] = "Within zone"                                                                                                                                                                                            |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0°                      | $I_A^p[w] = I_A[w]$ $I_B^p[w] = I_B[w]$ $I_C^p[w] = I_C[w]$                                                                                                                                        | $I_A^p[w] = \frac{2}{3}I_A[w] - \frac{1}{3}I_B[w] - \frac{1}{3}I_C[w]$ $I_B^p[w] = \frac{2}{3}I_B[w] - \frac{1}{3}I_A[w] - \frac{1}{3}I_C[w]$ $I_C^p[w] = \frac{2}{3}I_C[w] - \frac{1}{3}I_A[w] - \frac{1}{3}I_B[w]$    |
| 30° lag                 | $I_A^p[w] = \frac{1}{\sqrt{3}}I_A[w] - \frac{1}{\sqrt{3}}I_C[w]$ $I_B^p[w] = \frac{1}{\sqrt{3}}I_B[w] - \frac{1}{\sqrt{3}}I_A[w]$ $I_C^p[w] = \frac{1}{\sqrt{3}}I_C[w] - \frac{1}{\sqrt{3}}I_B[w]$ | $I_A^p[w] = \frac{1}{\sqrt{3}}I_A[w] - \frac{1}{\sqrt{3}}I_C[w]$ $I_B^p[w] = \frac{1}{\sqrt{3}}I_B[w] - \frac{1}{\sqrt{3}}I_A[w]$ $I_C^p[w] = \frac{1}{\sqrt{3}}I_C[w] - \frac{1}{\sqrt{3}}I_B[w]$                      |
| 60° lag                 | $I_A^p[w] = -I_C[w]$ $I_B^p[w] = -I_A[w]$ $I_C^p[w] = -I_B[w]$                                                                                                                                     | $I_A^p[w] = -\frac{2}{3}I_C[w] + \frac{1}{3}I_A[w] + \frac{1}{3}I_B[w]$ $I_B^p[w] = -\frac{2}{3}I_A[w] + \frac{1}{3}I_B[w] + \frac{1}{3}I_C[w]$ $I_C^p[w] = -\frac{2}{3}I_B[w] + \frac{1}{3}I_A[w] + \frac{1}{3}I_C[w]$ |
| 90° lag                 | $I_A^p[w] = \frac{1}{\sqrt{3}}I_B[w] - \frac{1}{\sqrt{3}}I_C[w]$ $I_B^p[w] = \frac{1}{\sqrt{3}}I_C[w] - \frac{1}{\sqrt{3}}I_A[w]$ $I_C^p[w] = \frac{1}{\sqrt{3}}I_A[w] - \frac{1}{\sqrt{3}}I_B[w]$ | $I_A^p[w] = \frac{1}{\sqrt{3}}I_B[w] - \frac{1}{\sqrt{3}}I_C[w]$ $I_B^p[w] = \frac{1}{\sqrt{3}}I_C[w] - \frac{1}{\sqrt{3}}I_A[w]$ $I_C^p[w] = \frac{1}{\sqrt{3}}I_A[w] - \frac{1}{\sqrt{3}}I_B[w]$                      |
| 120° lag                | $I_A^p[w] = I_B[w]$ $I_B^p[w] = I_C[w]$ $I_C^p[w] = I_A[w]$                                                                                                                                        | $I_A^p[w] = \frac{2}{3}I_B[w] - \frac{1}{3}I_A[w] - \frac{1}{3}I_C[w]$ $I_B^p[w] = \frac{2}{3}I_C[w] - \frac{1}{3}I_A[w] - \frac{1}{3}I_B[w]$ $I_C^p[w] = \frac{2}{3}I_A[w] - \frac{1}{3}I_B[w] - \frac{1}{3}I_C[w]$    |
| 150° lag                | $I_A^p[w] = \frac{1}{\sqrt{3}}I_B[w] - \frac{1}{\sqrt{3}}I_A[w]$ $I_B^p[w] = \frac{1}{\sqrt{3}}I_C[w] - \frac{1}{\sqrt{3}}I_B[w]$ $I_C^p[w] = \frac{1}{\sqrt{3}}I_A[w] - \frac{1}{\sqrt{3}}I_C[w]$ | $I_A^p[w] = \frac{1}{\sqrt{3}}I_B[w] - \frac{1}{\sqrt{3}}I_A[w]$ $I_B^p[w] = \frac{1}{\sqrt{3}}I_C[w] - \frac{1}{\sqrt{3}}I_B[w]$ $I_C^p[w] = \frac{1}{\sqrt{3}}I_A[w] - \frac{1}{\sqrt{3}}I_C[w]$                      |
| 180° lag                | $I_A^p[w] = -I_A[w]$ $I_B^p[w] = -I_B[w]$ $I_C^p[w] = -I_C[w]$                                                                                                                                     | $I_A^p[w] = -\frac{2}{3}I_A[w] + \frac{1}{3}I_B[w] + \frac{1}{3}I_C[w]$ $I_B^p[w] = -\frac{2}{3}I_B[w] + \frac{1}{3}I_A[w] + \frac{1}{3}I_C[w]$ $I_C^p[w] = -\frac{2}{3}I_C[w] + \frac{1}{3}I_A[w] + \frac{1}{3}I_B[w]$ |
| 210° lag                | $I_A^p[w] = \frac{1}{\sqrt{3}}I_C[w] - \frac{1}{\sqrt{3}}I_A[w]$ $I_B^p[w] = \frac{1}{\sqrt{3}}I_A[w] - \frac{1}{\sqrt{3}}I_B[w]$ $I_C^p[w] = \frac{1}{\sqrt{3}}I_B[w] - \frac{1}{\sqrt{3}}I_C[w]$ | $I_A^p[w] = \frac{1}{\sqrt{3}}I_C[w] - \frac{1}{\sqrt{3}}I_A[w]$ $I_B^p[w] = \frac{1}{\sqrt{3}}I_A[w] - \frac{1}{\sqrt{3}}I_B[w]$ $I_C^p[w] = \frac{1}{\sqrt{3}}I_B[w] - \frac{1}{\sqrt{3}}I_C[w]$                      |

| $\Phi_{\text{comp}}[w]$ | Grounding[w] = "Not within zone"                                                                                                                                                                   | Grounding[w] = "Within zone"                                                                                                                                                                                            |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 240° lag                | $I_A^P[w] = I_C[w]$ $I_B^P[w] = I_A[w]$ $I_C^P[w] = I_B[w]$                                                                                                                                        | $I_A^P[w] = \frac{2}{3}I_C[w] - \frac{1}{3}I_A[w] - \frac{1}{3}I_B[w]$ $I_B^P[w] = \frac{2}{3}I_A[w] - \frac{1}{3}I_B[w] - \frac{1}{3}I_C[w]$ $I_C^P[w] = \frac{2}{3}I_B[w] - \frac{1}{3}I_A[w] - \frac{1}{3}I_C[w]$    |
| 270° lag                | $I_A^P[w] = \frac{1}{\sqrt{3}}I_C[w] - \frac{1}{\sqrt{3}}I_B[w]$ $I_B^P[w] = \frac{1}{\sqrt{3}}I_A[w] - \frac{1}{\sqrt{3}}I_C[w]$ $I_C^P[w] = \frac{1}{\sqrt{3}}I_B[w] - \frac{1}{\sqrt{3}}I_A[w]$ | $I_A^P[w] = \frac{1}{\sqrt{3}}I_C[w] - \frac{1}{\sqrt{3}}I_B[w]$ $I_B^P[w] = \frac{1}{\sqrt{3}}I_A[w] - \frac{1}{\sqrt{3}}I_C[w]$ $I_C^P[w] = \frac{1}{\sqrt{3}}I_B[w] - \frac{1}{\sqrt{3}}I_A[w]$                      |
| 300° lag                | $I_A^P[w] = -I_B[w]$ $I_B^P[w] = -I_C[w]$ $I_C^P[w] = -I_A[w]$                                                                                                                                     | $I_A^P[w] = -\frac{2}{3}I_B[w] + \frac{1}{3}I_A[w] + \frac{1}{3}I_C[w]$ $I_B^P[w] = -\frac{2}{3}I_C[w] + \frac{1}{3}I_A[w] + \frac{1}{3}I_B[w]$ $I_C^P[w] = -\frac{2}{3}I_A[w] + \frac{1}{3}I_B[w] + \frac{1}{3}I_C[w]$ |
| 330° lag                | $I_A^P[w] = \frac{1}{\sqrt{3}}I_A[w] - \frac{1}{\sqrt{3}}I_B[w]$ $I_B^P[w] = \frac{1}{\sqrt{3}}I_B[w] - \frac{1}{\sqrt{3}}I_C[w]$ $I_C^P[w] = \frac{1}{\sqrt{3}}I_C[w] - \frac{1}{\sqrt{3}}I_A[w]$ | $I_A^P[w] = \frac{1}{\sqrt{3}}I_A[w] - \frac{1}{\sqrt{3}}I_B[w]$ $I_B^P[w] = \frac{1}{\sqrt{3}}I_B[w] - \frac{1}{\sqrt{3}}I_C[w]$ $I_C^P[w] = \frac{1}{\sqrt{3}}I_C[w] - \frac{1}{\sqrt{3}}I_A[w]$                      |

**Figure 228: Phase and zero sequence compensation for typical values of  $\Phi_{\text{comp}}$**

In our example, the following phase and zero-sequence compensation equations would be used:

For Winding 1:

$$I_A^P[1] = (2/3)I_A[1] - (1/3)I_B[1] - (1/3)I_C[1]$$

$$I_B^P[1] = (2/3)I_B[1] - (1/3)I_A[1] - (1/3)I_C[1]$$

$$I_C^P[1] = (2/3)I_C[1] - (1/3)I_B[1] - (1/3)I_A[1]$$

For Winding 2:

$$I_A^P[w] = (1/\sqrt{3})I_A[2] - (1/\sqrt{3})I_B[2]$$

$$I_B^P[w] = (1/\sqrt{3})I_B[2] - (1/\sqrt{3})I_C[2]$$

$$I_C^P[w] = (1/\sqrt{3})I_C[2] - (1/\sqrt{3})I_A[2]$$

#### 8.5.4.6 MAGNITUDE, PHASE ANGLE, AND ZERO SEQUENCE COMPENSATION

Complete magnitude, phase angle, and zero sequence compensation is as follows:

$$I_A^c[w] = M[w] \times I_A^P[w], \text{ where } w = 1, 2$$

$$I_B^c[w] = M[w] \times I_B^P[w], \text{ where } w = 1, 2$$

$$I_C^c[w] = M[w] \times I_C^P[w], \text{ where } w = 1, 2$$

where:

- $I_A^c[w]$ ,  $I_B^c[w]$ , and  $I_C^c[w]$  = magnitude, phase, and zero-sequence compensated winding w phase currents
- $M[w]$  = magnitude compensation factor for winding w (see previous sections)
- $I_A^p[w]$ ,  $I_B^p[w]$ , and  $I_C^p[w]$  = phase and zero sequence compensated winding w phase currents (see earlier)

#### 8.5.4.7 DIFFERENTIAL AND RESTRAINT CURRENT CALCULATIONS

Differential and restraint currents are calculated as follows:

$$Id_A = I_A^c[1] + I_A^c[2]$$

$$Id_B = I_B^c[1] + I_B^c[2]$$

$$Id_C = I_C^c[1] + I_C^c[2]$$

$$Ir_A = \max(|I_A^c[1]|, |I_A^c[2]|)$$

$$Ir_B = \max(|I_B^c[1]|, |I_B^c[2]|)$$

$$Ir_C = \max(|I_C^c[1]|, |I_C^c[2]|, \dots, I_C^c[w_{total}])$$

where:

- $Id_A$ ,  $Id_B$ , and  $Id_C$  are the phase differential currents
- $Ir_A$ ,  $Ir_B$ , and  $Ir_C$  are the phase restraint currents

#### 8.5.4.8 TRANSFORMER WINDINGS BETWEEN TWO BREAKERS

When the relay is to protect a transformer with windings connected between two breakers, such as in a ring bus or breaker-and-a-half station configuration, one of the methods for configuring currents into the relay presented as follows should be used (see the Breaker-and-a-Half Scheme diagram in the Overview section of this chapter).

For this example, assumed that winding 1 is connected between two breakers and winding 2 is connected to a single breaker. The CTs associated with winding 1 are CTX, at 1200/5 A and CTY, at 1000/5 A. CTX is connected to current input channels 1 through 3 inclusive and CTY is connected to current input channels 5 through 7 inclusive on a type 8H CT/VT module in relay slot F. The CT2 on winding 2 is 5000/5 A and is connected to current input channels 1 through 4 inclusive on a type 8F CT/VT module in relay slot M.

##### Setup method A (preferred)

This approach is preferred because it provides increased sensitivity as the current from each individual set of CTs participates directly in the calculation of CT ratio mismatch, phase compensation, zero-sequence removal (if required) and the differential restraint current. The concept used in this approach is to consider that each set of CTs connected to winding 1 represents a connection to an individual winding. For our example, consider the two-winding transformer to be a three-winding transformer.

1. Enter the settings for each set of CTs in the **SYSTEM SETUP > AC INPUTS > CURRENT BANK** settings menu.
  - PHASE CT F1 PRIMARY: 1200 A
  - PHASE CT F1 SECONDARY: 5 A
  - GROUND CT F1 PRIMARY: 1 A (default value)
  - GROUND CT F1 SECONDARY: 1 A (default value)
  - PHASE CT F5 PRIMARY: 1000 A
  - PHASE CT F5 SECONDARY: 5 A

GROUND CT F5 PRIMARY: 1 A (default value)

GROUND CT F5 SECONDARY: 1 A (default value)

PHASE CT M1 PRIMARY: 5000 A

PHASE CT M1 SECONDARY: 5 A

GROUND CT M5 PRIMARY: 5000 A

GROUND CT M5 SECONDARY: 5 A

2. Configure source n (source 1 for this example) as the current from CTX in Winding 1 in the **SYSTEM SETUP > SIGNAL SOURCES > SOURCE <n>** settings menu.

SOURCE 1 NAME: *WDG 1X*

SOURCE 1 PHASE CT: *F1*

SOURCE 1 GROUND CT: *None*

SOURCE 1 PHASE VT: *None*

SOURCE 1 AUX VT: *None*

3. Configure source n (source 2 for this example) as the current from CTY in Winding 1 in the **SYSTEM SETUP > SIGNAL SOURCES > SOURCE <n>** settings menu.

SOURCE 2 NAME: *WDG 1Y*

SOURCE 2 PHASE CT: *F5*

SOURCE 2 GROUND CT: *None*

SOURCE 2 PHASE VT: *None*

SOURCE 2 AUX VT: *None*

4. Configure source n (source 3 for this example) to be used as the current in Winding 2 in the **SYSTEM SETUP > SIGNAL SOURCES > SOURCE <n>** settings menu.

SOURCE 3 NAME: *WDG 2*

SOURCE 3 PHASE CT: *M1*

SOURCE 3 GROUND CT: *M1*

SOURCE 3 PHASE VT: *None*

SOURCE 3 AUX VT: *None*

5. Configure the source setting of the transformer windings in the **SYSTEM SETUP > TRANSFORMER > WINDING <n>** settings menu.

WINDING 1 SOURCE: *WDG 1X*

WINDING 2 SOURCE: *WDG 1Y*

WINDING 3 SOURCE: *WDG 2*

### Setup method B (alternate)

This approach adds the current from each phase of the CT1 and CT2 together to represent the total winding 1 current. The procedure is outlined as follows.

1. Enter the settings for each set of CTs in the **SYSTEM SETUP > AC INPUTS > CURRENT BANK** settings menu, as shown for method A.
2. Configure Source n (Source 1 for this example) to be used as the summed current in Winding 1 in the **SYSTEM SETUP > SIGNAL SOURCES > SOURCE n** settings menu.  
SOURCE 1 NAME: *WDG 1*

SOURCE 1 PHASE CT: *F1 + F5*

SOURCE 1 GROUND CT: *None*

SOURCE 1 PHASE VT: *None*

SOURCE 1 AUX VT: *None*

3. Configure Source n (Source 2 for this example) to be used as the Winding 2 current in the **SYSTEM SETUP > SIGNAL SOURCES > SOURCE n** settings menu.

SOURCE 2 NAME: *WDG 2*

SOURCE 2 PHASE CT: *M1*

SOURCE 2 GROUND CT: *M1*

SOURCE 2 PHASE VT: *None*

SOURCE 2 AUX VT: *None*

8.5.4.9 TRANSFORMER THERMAL INPUTS

SETTINGS > SYSTEM SETUP > TRANSFORMER THERMAL INPUTS

|                       |   |                                         |                                                                                                                                 |
|-----------------------|---|-----------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| ■ THERMAL INPUTS<br>■ | ⇔ | WINDING CURRENTS:<br>SRC 1              | Range: SRC <n> (or the user-defined name)                                                                                       |
|                       | ⇕ | AMBIENT TEMPERATURE:<br>Monthly Average | Range: RTD Input 1,..., RTD Input 8, dcmA Input 1,..., dcmA Input 8, RRTD Input 1,..., RRTD Input 12, Monthly Average           |
|                       | ⇕ | TOP OIL TEMPERATURE:<br>RTD Input 1     | Range: RTD Input 1,..., RTD Input 8, dcmA Input 1,..., dcmA Input 8, RRTD Input 1,..., RRTD Input 12, Monthly Average, Computed |

The thermal inputs settings are used for computation of hottest-spot winding temperature, aging factor, and accumulated loss of life.

WINDING CURRENTS

Enter a source that represents the true winding load currents.

In cases where two or more sets of CTs are associated to the winding and where thermal elements are to be set (for example, in a breaker-and-a-half scheme), use a spare source for current summation from these CTs to obtain the total true winding current. Otherwise, select the only source representing the other winding current.

AMBIENT TEMPERATURE

Select an RTD, DCmA, or remote RTD (RRTD) input if the ambient temperature is to be measured directly. Otherwise, select “Monthly Average” and enter an average temperature for each month of the year if a directlymeasured device output is not available (see the monthly settings that follow).

TOP OIL TEMPERATURE

Select RTD, DCmA, or remote RTD input for direct measurement of top-oil temperature. If an RTD or DCmA input is not available, select *Computed*.

The following menu displays when **AMBIENT TEMPERATURE** is *Monthly Average*.

|                                         |   |                           |                                  |
|-----------------------------------------|---|---------------------------|----------------------------------|
| AMBIENT TEMPERATURE:<br>Monthly Average | ⇔ | JANUARY AVERAGE:<br>-10°C | Range: -60 to 60°C in steps of 1 |
|                                         | ⇕ | ...                       | Range: -60 to 60°C in steps of 1 |

|   |                           |                                  |
|---|---------------------------|----------------------------------|
| ↑ | DECEMBER AVERAGE<br>-10°C | Range: -60 to 60°C in steps of 1 |
|---|---------------------------|----------------------------------|

### 8.5.5 BREAKERS

The breaker control element contains the auxiliary logic for status and serves as the interface for opening and closing of a circuit breaker from protection, autoreclose, SCADA, or through the front panel interface. The breaker control element can be used to create interlocking functionality. For greater security in determination of the breaker position, both the 52/a and 52/b auxiliary contacts are used with reporting of the discrepancy between them.

To use this element, configure the contact outputs that trip and close the breaker to use FlexLogic operands BREAKER 1 OFF CMD (or BREAKER 1 TRIP A/B/C in the case of single-pole tripping) and BREAKER 1 ON CMD, and configure the breaker control element inputs as described here.

Setting path: **SETTINGS > SYSTEM SETUP > BREAKERS**

|                 |   |                        |
|-----------------|---|------------------------|
| ■ BREAKERS<br>■ | ↔ | ■ COMMON SETTINGS<br>■ |
|                 | ↑ | ■ BREAKER <n><br>■     |

The **SYSTEM SETUP > BREAKERS** menu has two sub-menus:

- COMMON SETTINGS
- BREAKER <n>, where n = 1 to 6

#### COMMON SETTINGS

There is only one common setting amongst circuit breakers; **BKR INTERM & BAD ST TIMERS**:

This can be set to *Common* or *Distinct*. When set to *Common*, the breaker element considers both *00* and *11* states of 52a and 52b as an intermediate state and when the Toperate timer expires, declares the breaker as bad status. When set to *Distinct* the breaker element considers *00* state of 52a and 52b as an intermediate state and *11* as bad status. When the breaker status detected is *00*, the breaker element waits for the Toperate timer to expire before declaring the intermediate state. When the breaker status detected is *11*, the breaker element waits for the Bad ST Tsuppress timer to expire before declaring the bad state. See breaker logic diagrams 2 and 4.

#### BREAKER <n>

Each breaker has the following settings. Only Breaker 1 is shown here.

Setting path: **SETTINGS > SYSTEM SETUP > BREAKERS > BREAKER 1(6)**

|                  |   |                                 |                                             |
|------------------|---|---------------------------------|---------------------------------------------|
| ■ BREAKER 1<br>■ | ↔ | BREAKER 1<br>FUNCTION: Disabled | Range: Disabled, Enabled                    |
|                  | ↕ | BREAKER 1 NAME:<br>Bkr 1s       | Range: up to six alphanumeric characters    |
|                  | ↕ | BREAKER 1 MODE:<br>3-Pole       | Range: 3-Pole, 1-Pole                       |
|                  | ↕ | BREAKER1 ΦA/3P DPS<br>INP:Off   | Range: Off, RxGOOSE DPS 1, RxGOOSE DPS 2... |
|                  | ↕ | BREAKER1 ΦA/3P OPND:<br>Off     | Range: FlexLogic operand                    |
|                  | ↕ | BREAKER1 ΦA/3P CLSD:<br>Off     | Range: FlexLogic operand                    |



|   |                                         |                                             |
|---|-----------------------------------------|---------------------------------------------|
| ⇅ | BREAKER1 ΦB DPS<br>INP:Off              | Range: Off, RxGOOSE DPS 1, RxGOOSE DPS 2... |
| ⇅ | BREAKER 1 ΦB OPENED:<br>Off             | Range: FlexLogic operand                    |
| ⇅ | BREAKER 1 ΦB CLOSED:<br>Off             | Range: FlexLogic operand                    |
| ⇅ | BREAKER1 ΦC DPS<br>INP:Off              | Range: Off, RxGOOSE DPS 1, RxGOOSE DPS 2... |
| ⇅ | BREAKER 1 ΦC OPENED:<br>Off             | Range: FlexLogic operand                    |
| ⇅ | BREAKER 1 ΦC CLOSED:<br>Off             | Range: FlexLogic operand                    |
| ⇅ | BREAKER 1 ALARM PDisc DELAY:<br>0.000 s | Range: 0.000 to 65.535 s in steps of 0.001  |
| ⇅ | BREAKER 1 EXT ALARM:<br>Off             | Range: FlexLogic operand                    |
| ⇅ | BREAKER 1 RACKED-IN:<br>Off             | Range: FlexLogic operand                    |
| ⇅ | BREAKER 1 OUT OF SV:<br>Off             | Range: FlexLogic operand                    |
| ⇅ | BREAKER 1 OPEN CMD:<br>Off              | Range: FlexLogic operand                    |
| ⇅ | BRK1 COMMS OPEN CMD:<br>Off             | Range: FlexLogic operand                    |
| ⇅ | BREAKER 1 CLOSE CMD:<br>Off             | Range: FlexLogic operand                    |
| ⇅ | BRK1 COMMS CLS CMD:<br>Off              | Range: FlexLogic operand                    |
| ⇅ | BREAKER1 PB CONTROL:<br>Off             | Range: FlexLogic operand                    |
| ⇅ | BREAKER1 TOPERATE:<br>70 ms             | Range: 0 to 65535 ms in steps of 1          |
| ⇅ | BREAKER 1 BAD ST TSUPPRESS:<br>0 ms     | Range: 0 to 65535 ms in steps of 1          |
| ⇅ | MANUAL CLOSE RECAL1 TIME:<br>0.000 s    | Range: 0.000 to 65.535 s in steps of 0.001  |
| ⇅ | BREAKER 1 OPEN SEAL-IN:<br>0.000 s      | Range: 0.000 to 65.535 s in steps of 0.001  |
| ⇅ | BREAKER 1 BLK OPEN:<br>Off              | Range: FlexLogic operand                    |
| ⇅ | BREAKER 1 BLK CLOSE:<br>Off             | Range: FlexLogic operand                    |
| ⇅ | BRK1 BLK BYPASS:<br>Disabled            | Range: Disabled, Enabled                    |
| ⇅ | BREAKER 1 TAGGING:<br>Disabled          | Range: Disabled, Enabled                    |
| ⇅ | BREAKER 1 SUBSTITUTN:<br>Disabled       | Range: Disabled, Enabled                    |

|   |                                             |                          |
|---|---------------------------------------------|--------------------------|
| ⇅ | BREAKER 1 EVENTS:<br>Disabled               | Range: Disabled, Enabled |
| ⇅ | BRK1 CILO INTERLOCK GFP<br>BYPASS: Disabled | Range: Disabled, Enabled |
| ⇅ | BREAKER 1 LOCAL:<br>Off                     | Range: FlexLogic operand |
| ⇅ | BRK1 BLK ML CMD IN LOCAL:<br>Disabled       | Range: Disabled, Enabled |
| ⇅ | BRK1 CSWI LOC STAT:<br>Off                  | Range: FlexLogic operand |
| ⇅ | BRK1 STATION AUTHOR:<br>Off                 | Range: FlexLogic operand |
| ⇅ | BREAKER 1 OPEN INTERLOCK:<br>Off            | Range: FlexLogic operand |
| ⇅ | BREAKER 1 CLOSE INTERLOCK:<br>Off           | Range: FlexLogic operand |
| ⇅ | BREAKER 1 SYNCHECK CLOSE:<br>Off            | Range: FlexLogic operand |
|   | BREAKER 1 POS-REACHED<br>CHECK: Enabled     | Range: Enabled, Disabled |

For relays that support 9-2LE, use **SETTINGS > SYSTEM SETUP > BREAKERS > BAY1(28) BREAKER**.

The following settings are available for each breaker control element.

### BREAKER 1 FUNCTION

This setting enables and disables the operation of the breaker 1 control feature.

### BREAKER 1 NAME

This setting allows you to assign a user-defined name (up to six characters) to the breaker. This name is used in flash messages related to breaker 1.

### BREAKER 1 MODE

This setting sets either *3-Pole* mode, where all breaker poles are operated simultaneously, or *1-Pole* mode, where all breaker poles are operated independently.

### BREAKER1 $\Phi$ A/3P DPS INP

This setting selects a double point status input (RxGOOSE# DPS Input) that is subscribed via GOOSE. Each received RxGOOSE# DPS Input consist of 2 bits. The derived switch status is shown in the logic diagram.

When the IEC61850 RxGOOSE# DPS is mapped to **BREAKER1  $\Phi$ A/3P DPS INP**, the switch status (Open/Close/Intermediate/Bad) will be based on the RxGOOSE DPS # value.

If the **BREAKER1  $\Phi$ A/3P DPS INP** selects a RxGOOSE DPS Input:

- the respective **BREAKER1  $\Phi$ A/3P OPND** and **BREAKER1  $\Phi$ A/3P CLSD** settings are not considered.
- the respective **BREAKER T OPERATE** and **BREAKER BAD ST TSUPPRESS** settings are also not considered in the receiving relay

**BREAKER1  $\Phi$ A/3P OPND**

This setting selects an operand (usually a contact input), which is for a normally-closed 52/b status input. This activates a logic 1 when the breaker is open. If a separate 52/b contact input is not available, then the inverted 52/a status signal or the inverted **BREAKER 1 CLOSED** status signal can be used.

**BREAKER1  $\Phi$ A/3P CLSD**

This setting selects an operand (usually a contact input) connected to a breaker auxiliary position tracking mechanism. This input is for a normally-open 52/a status input that creates a logic 1 when the breaker is closed. If the **BREAKER 1 MODE** setting is selected as *3-Pole*, this setting selects a single 52/a input as the operand used to track the breaker open or closed position. If the mode is selected as *1-Pole*, the input mentioned is used to track phase A and the **BREAKER 1  $\Phi$ B** and **BREAKER 1  $\Phi$ C** settings select operands to track phases B and C, respectively.

**BREAKER1  $\Phi$ B DPS INP**

If the mode is selected as three-pole, this setting has no function. If the mode is selected as single-pole, this input is used to track the switch phase B position as outlined for phase A.

**BREAKER1  $\Phi$ B OPENED**

In three-pole mode, this setting has no function. In single-pole mode, this input is used to track the breaker phase B opened position as outlined for phase A.

**BREAKER1  $\Phi$ B CLOSED**

In three-pole mode, this setting has no function. In single-pole mode, this input is used to track the breaker phase B closed position as outlined for phase A.

**BREAKER1  $\Phi$ c DPS INP**

If the mode is selected as three-pole, this setting has no function. If the mode is selected as single-pole, this input is used to track the switch phase C position as outlined for phase A.

**BREAKER1  $\Phi$ C OPENED**

In three-pole mode, this setting has no function. In single-pole mode, this input is used to track the breaker phase C opened position as outlined for phase A.

**BREAKER1  $\Phi$ C CLOSED**

In three-pole mode, this setting has no function. In single-pole mode, this input is used to track the breaker phase C closed position as outlined for phase A.

**BREAKER 1 ALARM PDisc DELAY**

This setting specifies the delay interval during which a conflict of status among the pole position tracking operands does not declare a pole discrepancy. This allows for non-simultaneous operation of the poles. If single-pole tripping and reclosing is used, the breaker can trip unsymmetrically for faults. In this case, the minimum alarm delay setting must exceed the maximum time required for fault clearing and reclosing by a suitable margin.

**BREAKER 1 EXT ALARM**

This setting selects an operand, usually an external contact input connected to a breaker alarm reporting contact. While the selected operand is active, the **BREAKER 1 TROUBLE** operand is activated.

### BREAKER 1 RACKED-IN

This setting selects a contact input to show whether the breaker is racked-in or racked-out. The racked-in or racked-out status is used to indicate dynamically the status of breaker symbol, only applied in the single-line diagram on the graphical front panel. If this setting is set to Off, the racked status is not considered.

### BREAKER 1 OUT OF SV

This setting selects an operand indicating that breaker 1 is out-of-service.

### BREAKER 1 OPEN CMD

This setting selects an operand that initiates a Breaker 1 open/trip command. The command is not executed when blocked by the operand assigned to **BREAKER 1 BLK OPEN** setting.

### BRK1 COMMS OPEN CMD

This setting selects an operand that initiates a Breaker 1 open command. The setting is intended for commands received via communication protocols (DNP3, IEC104 and Modbus) to be supervised by IED Local/Remote status. The command is not executed if the relay is in local mode or blocked by the operand assigned to the **BREAKER 1 BLK OPEN** setting.

### BREAKER 1 CLOSE CMD

This setting selects an operand that initiates a Breaker 1 close command. The command is not executed when blocked by an operand assigned to the **BREAKER 1 BLK CLOSE** setting.

### BKR 1 COMMS CLS CMD

This setting selects an operand that initiates a Breaker 1 close command. The setting is intended for commands received via communication protocols (DNP3, IEC104 and Modbus) to be supervised by IED Local/Remote status. The command is not executed if the relay is in local mode or blocked by the operand assigned to the **BREAKER 1 BLK CLOSE** setting.

### BREAKER 1 PB CONTROL

When the selected operand value is high, local breaker control operations are allowed from front panel pushbuttons.

### BREAKER 1 TOPERATE

This setting specifies the required interval to overcome transient conflict between the 52/a and 52/b auxiliary contacts during breaker operation. If transient conflict still exists after this time has expired, the BREAKER 1 BAD STATUS FlexLogic operand is asserted for alarm or blocking purposes.

### BREAKER 1 BAD ST TSUPPRESS

When the **BKR INTERM & BAD ST TIMERS** setting is set to *Distinct*, this setting specifies the required interval to overcome the transient state of *11* during the breaker operation. If the *11* state still exists after this time, the BREAKER 1 BAD STATUS FlexLogic operand is asserted. When the **BKR INTERM & BAD ST TIMERS** setting is set to *Common*, this setting is not used.

### MANUAL CLOSE RECAL1 TIME

This setting specifies the seal-in time of the close commands due to an operator-initiated manual close command to the circuit breaker.

### BREAKER 1 OPEN SEAL-IN

This setting specifies the seal-in time of the three-pole open command initiated by either the Trip Out element or a manual open command to the circuit breaker.

### BREAKER 1 BLK OPEN

This setting selects an operand that prevents initiation of Breaker 1 open and individual phase trip commands. This setting can be used for blocking circuit breaker tripping for instance when breaker monitoring detects conditions such as low SF6 gas density.

### BREAKER 1 BLK CLOSE

This setting selects an operand that prevents initiation of Breaker 1 close commands. This setting can be used for blocking circuit breaker closing, for instance to prevent closing into a closed ground switch.

### BRK1 BLK BYPASS

This setting is only available for relays with a graphical front panel. When enabled, this setting allows the graphical front panel to bypass breaker 1 blocking. When asserted, **BREAKER 1 BLK OPEN** and **BREAKER 1 BLK CLOSE** settings are bypassed.

### BREAKER 1 TAGGING

This setting is only available for relays with a graphical front panel. Breaker tagging is used to block certain operation when it is tagged for safety purposes. No other action is needed after enabling the function; it is handled internally where certain functions are blocked.

Set to *Enable No Override* to allow the graphical front panel or IEC 61850 MMS control to tag breaker 1. When tagged from the graphical front panel, tagging can be removed only from the graphical front panel, and an attempt to remove tagging using IEC 61850 MMS control results in a negative response (-Rsp). When tagged from IEC 61850 MMS control, tagging can be removed only by MMS control.

Set to *Enable With Override* to allow the graphical front panel or IEC 61850 MMS control to tag breaker 1. When tagged from the graphical front panel, tagging can be removed only from the graphical front panel, and an attempt to remove tagging using IEC 61850 MMS control results in a negative response (-Rsp). When tagged from IEC 61850 MMS control, tagging can be removed by MMS control or from the graphical front panel. That is, the graphical front panel has an override function.

When tagged, the following operations are disabled:

- Pushbutton open/close
- IEC 61850 open/close
- Autoreclose command issued by the Autoreclose element (if applicable to model)
- Close command initiated by BREAKER 1 CLOSE setting.

The trip command issued by the **Trip Out** element or **BREAKER 1 OPEN** setting is not affected.

### BREAKER1 SUBSTITUTN

This setting is only available for relays with a graphical front panel. When enabled, this setting allows the graphical front panel/IEC 61850 to substitute breaker 1 status. When substituted, breaker 1 control open/close status is forced to the substituted value.

### BRK1 CILO INTRLK TO LOCAL CTRL

When enabled, this setting allows CILO interlock to apply to front panel and FlexLogic operand controls. This setting is available only if the order code includes IEC 61850.

### BRK1 CILO INTERLOCK GFP BYPASS

When enabled, this setting allows the graphical front panel to bypass the CILO interlock for front panel and FlexLogic operand controls. This setting is available only if the order code includes IEC 61850 and graphical front panel.

## BREAKER 1 LOCAL

This setting selects an operand that indicates the Breaker in the switch yard is in Local or Remote mode. When the operand value is set, it indicates that the Breaker is in Local mode. You set this setting using the EnerVista software or with an SCL file.

## BRK1 BLK MNL CMD IN LOCAL

When this setting is enabled, and the BREAKER 1 LOCAL operand state is logic *1* (i.e. the Breaker is in Local mode and Bkr0XCBR1.Loc is TRUE), manual commands originating from the front panel pushbuttons, graphical front panel and **BREAKER 1 OPEN/CLOSE CMD** are blocked. When disabled, manual commands originating from the relay are allowed even when the Breaker is in Local mode. This setting is available only if the order code includes IEC 61850.

## BKR1 CSWI LOC STAT

This setting selects an operand that indicates the breaker residing in that bay is in Local or Remote mode. When the operand state is logic *1*, the bay is considered to be in Local mode, otherwise it is considered to be in Remote mode. The operand status is modeled in the IEC 61850 server using the respective breaker's CSWI Loc data object and you should refer to the operand status in the Control Authority table to determine the control authority for different levels. This setting is available only if the order code includes IEC 61850.

## BKR1 STATION AUTHOR

This setting selects an operand that indicates the Station level authority status. The operand status is modeled in the IEC 61850 server using the respective breaker's CSWI LocSta data object the user should refer to the operand status in the Control Authority table to determine the control authority for different levels. This setting is available only if the order code includes IEC 61850.

## BREAKER 1 OPEN INTERLOCK

This setting selects an operand that indicates the interlock status for the Breaker Open commands. This operand state is mapped directly to the IEC 61850 BkrCILO1.EnaOpn.stVal, which is used to reject the IEC 61850 open command when the selected operand state is at logic *0* (BkrCILO1.EnaOpn.stVal is set to false). However, the IEC 61850 client can choose to check or skip the interlock condition to execute the command using the *Check* parameter. In addition, the interlock condition can be applied to the local commands, which can originate from the front local HMI, front panel push buttons, graphical front panel (GFP) and FlexLogic Operands assigned to the **BREAKER 1 OPEN CMD** setting. This is achieved by enabling **BRK1 CILO INTRLK TO LOCAL CTRL**. This setting is available only if the order code includes IEC 61850.

## BREAKER 1 CLOSE INTERLOCK

This setting selects an operand that indicates the interlock status for the Breaker Open commands. This operand state is mapped directly to the IEC 61850 BkrCILO1.EnaCls.stVal, which is used to reject the IEC 61850 close command when the selected operand state is at logic *0* (BkrCILO1.EnaCls.stVal is set to false). However, the IEC 61850 client can choose to check or skip the interlock condition to execute the command using the *Check* parameter. In addition, the interlock condition can be applied to the local commands, which can originate from the front local HMI, front panel push buttons, graphical front panel (GFP) and FlexLogic Operands assigned to the **BREAKER 1 CLOSE CMD** setting. This is achieved by enabling **BRK1 CILO INTRLK TO LOCAL CTRL**. This setting is available only if the order code includes IEC 61850.

## BREAKER 1 SYNCHECK CLOSE

This setting selects an operand that indicates the status of the synchrocheck function of the Breaker. When the operand value is set, the remote commands from IEC 61850 client are rejected if the IEC 61850 client set the synchrocheck bit in the *Check* parameter. This setting is only available if the order code includes IEC 61850.

## BREAKER 1 POS-REACHED CHECK

When enabled, the IEC 61850 control value is checked for current Breaker status and is rejected if the command value (Open/Close) from IEC 61850 client match with the present Breaker status. When disabled, the current Breaker status is not verified to accept the control. This setting is only available if the order code includes IEC 61850.

**Note:**

Before software release version 7.90, **ST.LOC OPERAND**, **INTERLOCK OPN**, **INTERLOCK CLS** and **SYNCHECK CLOSE** settings were available in IEC 61850 configurator under **System Setup > Breaker**. From version 7.90 onwards, the above mentioned settings were removed from the IEC 61850 configurator and merged with the Breaker settings screen under **Settings > System Setup > Breakers** (outside the IEC 61850 configurator). Also, the name of the setting **ST.LOC OPERAND** has been changed to **LOCAL**.

**Note:**

**BREAKER 1 LOCAL**, **INTERLOCK OPEN**, **INTERLOCK CLOSE**, **SYNCHECK CLOSE** settings are not available on the front panel and can be configured either from EnerVista Software or via SCL files. Refer to the MICS document online for respective settings modeling in SCL files. **BREAKER 1 POS-REACHED CHECK** is only configurable via EnerVista software.

### 8.5.5.1 CONTROL AUTHORITY

Within the substation, control commands to the primary equipment, such as the breaker or disconnect switch, can originate from one of three levels: Station, Remote or Bay.

- Station level commands are those originating from either the substation gateway or from the station HMI
- Remote commands are from the remote Network Control Center (NCC).
- Bay level commands, are commands originating from bay devices such as bay controllers (e.g. C264) or IEDs (protection relays), either using 61850 control services or using non-61850 control methods (front panel pushbuttons, graphical front panel or commands initiated through FlexOperands).

Under certain operational conditions, such as during maintenance, it is necessary to block commands from one or more of these levels. The local/remote control feature (described in IEC61850 7-4: Annex B) allows you to enable or disable control authority from one or more of the three levels, as illustrated in the below table. IEC61850 commands originating from the various levels are differentiated using the Origin.OrCat attribute value in the 61850 command. The IEC61850 7-4 Local/Remote table is extended with Bay level non-61850 commands and those commands are only allowed when the Bay level has the control authority.

|                                 | Switch           | Bay Control                                   |                        |                                    |                                    | Command from          |                 |         |        |
|---------------------------------|------------------|-----------------------------------------------|------------------------|------------------------------------|------------------------------------|-----------------------|-----------------|---------|--------|
|                                 |                  |                                               |                        |                                    |                                    | Bay                   |                 | Station | NCC    |
|                                 |                  | Mode of switching authority for local control | Local Control Behavior | Control Authority At Station Level | Manual Control at Switch (process) |                       | orCat           |         |        |
| BKR1 BLK<br>MNL CMD<br>IN LOCAL | XCBR.LocXSWI.Loc | LLN0.MitLev                                   | CSWI.Loc               | CSWI.LocSta                        |                                    | Non 61850 Bay Control | Local Ctl (Bay) | Station | Remote |
| Enabled                         | T                | F                                             | n.a.                   | n.a.                               | AA                                 | NA                    | NA              | NA      | NA     |
| Disabled                        | T                | F                                             | n.a.                   | n.a.                               | AA                                 | AA                    | NA              | NA      | NA     |
| n.a.                            | F                | F                                             | T                      | n.a.                               | AA                                 | AA                    | AA              | NA      | NA     |
| n.a.                            | F                | F                                             | F                      | T                                  | AA                                 | NA                    | NA              | AA      | NA     |
| n.a.                            | F                | F                                             | F                      | F                                  | AA                                 | NA                    | NA              | NA      | AA     |
| Enabled                         | T                | T                                             | n.a.                   | n.a.                               | AA                                 | NA                    | NA              | NA      | NA     |
| Disabled                        | T                | T                                             | n.a.                   | n.a.                               | AA                                 | AA                    | NA              | NA      | NA     |
| n.a.                            | F                | T                                             | T                      | n.a.                               | AA                                 | AA                    | AA              | NA      | NA     |

|      | Switch | Bay Control |   |   |    | Command from |    |         |     |
|------|--------|-------------|---|---|----|--------------|----|---------|-----|
|      |        |             |   |   |    | Bay          |    | Station | NCC |
| n.a. | F      | T           | F | T | AA | AA           | AA | AA      | NA  |
| n.a. | F      | T           | F | F | AA | AA           | AA | AA      | AA  |


### Key

- n.a. - not applicable
- AA - Always Allowed
- NA - Not Allowed
- Non-61850 Bay Control - Any manual control from the relay, i.e. from the front panel, the relay push buttons or a FlexOperand initiated command.
- Manual Control at Switch (process) - Control external to the IED, e.g. the breaker may be controlled directly from the control panel.
- Cells highlighted in gray are not defined in the standard and reflect UR's commitment to maintaining backwards compatibility

### 8.5.5.2 DUAL BREAKER CONTROL LOGIC

The following diagrams show the dual breaker control logic:





859826A1.vsdX

Figure 229: Dual breaker control logic (Sheet 1 of 5)





Figure 230: Dual breaker control logic (Sheet 2 of 5)



**Figure 231: Dual breaker control logic (Sheet 3 of 5)**

The breaker element has direct hard-coded connections to the IEC 61850 model as shown in the logic diagram. This allows remote open/close operation of each breaker, using either CSWI or XCBR IEC 61850 logical nodes. IEC 61850 'select-before-operate' functionality, local/remote switch functionality, along with blocking of open/close commands are provided. Note that the dwell time for the IEC 61850 trip and close commands shown is one protection pass only. To maintain the close/open command for a certain time, do so by setting the seal-in timers **BREAKER 1 OPEN SEAL-IN** and **MANUAL CLOSE RECAL1TIME**, on the contact outputs using the **Seal-in** setting, in the Trip Output element, and/or in FlexLogic.




Figure 232: Dual breaker control logic (Sheet 4 of 5)





Figure 233: Dual breaker control logic (Sheet 5 of 5)

## 8.5.6 DISCONNECT SWITCH CONTROL

For relays with 9-2LE hardware and software options, this element is not present.

The disconnect switch control element contains the auxiliary logic for status. It serves as the interface for opening and closing disconnect switches through SCADA control or through the front panel interface. The disconnect switch control element can be used to create interlocking functionality. For greater security in determination of the switch pole position, both the 89/a and 89/b auxiliary contacts are used to report any discrepancy between them. The number of available disconnect switches is four per breaker. The disconnect switch control element is executed and status updated every 1/2 power cycle. To use this element, configure the contact outputs that open and close the disconnect switch to use FlexLogic operands SWITCH 1 OFF CMD and SWITCH 1 ON CMD, and configure the disconnect switch control element's inputs as outlined here.

Setting path: **SETTINGS > SYSTEM SETUP > SWITCHES**



The **SYSTEM SETUP > SWITCHES** menu has two sub-menus:

- COMMON SETTINGS
- SWITCH <n>, where n = 1 to 24

### COMMON SETTINGS

There is only one common setting amongst switches ; **SW INTERM & BAD ST TIMERS**:

This can be set to *Common* or *Distinct*. When set to *Common*, the switch element considers both *00* and *11* states of 89/a and 89/b as an intermediate state and when the Toperate timer expires, declares the switch as bad status. When set to *Distinct* the switch element considers 00 state of 89/a and 89/b as an intermediate state and 11 as bad status. When the switch status detected is 00, the switch element waits for the Toperate timer to expire before declaring the intermediate state. When the switch status detected is 11, the switch element waits for the Bad ST Tsuppress timer to expire before declaring the bad state. See switch logic diagrams 2 and 4.

### SWITCH <n>

Each switch (1 to 24) has the following settings. Only switch 1 is shown here.

Setting path: **SETTINGS > SYSTEM SETUP > SWITCHES > SWITCH 1**

|                                    |   |                                        |                                             |
|------------------------------------|---|----------------------------------------|---------------------------------------------|
| <div>■ SWITCH 1</div> <div>■</div> | ⇔ | SWITCH 1 FUNCTION:<br>Disabled         | Range: Disabled, Enabled                    |
|                                    | ⇕ | SWITCH 1 NAME:<br>SW 1                 | Range: up to six alphanumeric characters    |
|                                    | ⇕ | SWITCH 1 MODE:<br>3-Pole               | Range: 3-Pole, 1-Pole                       |
|                                    | ⇕ | SWITCH 1 ΦA/3P DPS<br>INP: Off         | Range: Off, RxGOOSE DPS 1, RxGOOSE DPS 2... |
|                                    | ⇕ | SWITCH 1 ΦA/3P OPND:<br>Off            | Range: FlexLogic operand                    |
|                                    | ⇕ | SWITCH 1 ΦA/3P CLSD:<br>Off            | Range: FlexLogic operand                    |
|                                    | ⇕ | SWITCH 1 ΦB DPS:<br>INP: Off           | Range: Off, RxGOOSE DPS 1, RxGOOSE DPS 2... |
|                                    | ⇕ | SWITCH 1 ΦB OPENED:<br>Off             | Range: FlexLogic operand                    |
|                                    | ⇕ | SWITCH 1 ΦB CLOSED:<br>Off             | Range: FlexLogic operand                    |
|                                    | ⇕ | SWITCH 1 ΦC DPS:<br>INP: Off           | Range: Off, RxGOOSE DPS 1, RxGOOSE DPS 2... |
|                                    | ⇕ | SWITCH 1 ΦC OPENED:<br>Off             | Range: FlexLogic operand                    |
|                                    | ⇕ | SWITCH 1 ΦC CLOSED:<br>Off             | Range: FlexLogic operand                    |
|                                    | ⇕ | SWITCH 1 ALARM PDisc DELAY:<br>0.000 s | Range: 0.000 to 65.535 s in steps of 0.001  |

|   |                                            |                                                           |
|---|--------------------------------------------|-----------------------------------------------------------|
| ⇅ | SWITCH 1 OPEN CMD:<br>Off                  | Range: FlexLogic operand                                  |
| ⇅ | SW1 COMMS OPEN CMD:<br>Off                 | Range: FlexLogic operand                                  |
| ⇅ | SWITCH 1 CLOSE CMD:<br>Off                 | Range: FlexLogic operand                                  |
| ⇅ | SW1 COMMS CLS CMD:<br>Off                  | Range: FlexLogic operand                                  |
| ⇅ | SWITCH 1 PB CONTROL:<br>Off                | Range: FlexLogic operand                                  |
| ⇅ | SWITCH 1 TOPERATE:<br>70 ms                | Range: 0 to 65535 ms in steps of 1                        |
| ⇅ | SWITCH 1 BAD ST TSUPPRESS:<br>0 ms         | Range: 0 to 65535 ms in steps of 1                        |
| ⇅ | SWITCH 1 OPEN SEAL-IN:<br>0.000 s          | Range: 0.000 to 65.535 s in steps of 0.001                |
| ⇅ | SWITCH 1 CLOSE SEAL-IN:<br>0.000 s         | Range: 0.000 to 65.535 s in steps of 0.001                |
| ⇅ | SWITCH 1 BLK OPEN:<br>Off                  | Range: FlexLogic operand                                  |
| ⇅ | SWITCH 1 BLK CLOSE:<br>Off                 | Range: FlexLogic operand                                  |
| ⇅ | SWITCH 1 BLK BYPASS:<br>Disabled           | Range: Disabled, Enabled                                  |
| ⇅ | SWITCH 1 TAGGING:<br>Disabled              | Range: Disabled, Enable No Override, Enable with Override |
| ⇅ | BSWITCH 1 SUBSTITUTN:<br>Disabled          | Range: Disabled, Enabled                                  |
| ⇅ | SWITCH 1 EVENTS:<br>Disabled               | Range: Disabled, Enabled                                  |
| ⇅ | SW1 CILO INTRLK TO LOCAL<br>CTRL: Disabled | Range: Disabled, Enabled                                  |
| ⇅ | SW1 CILO INTERLOCK GFP<br>BYPASS: Disabled | Range: Disabled, Enabled                                  |
| ⇅ | SWITCH 1 LOCAL:<br>Off                     | Range: FlexLogic operand                                  |
| ⇅ | SW1 BLK MNL CMD IN LOCAL:<br>Disabled      | Range: Disabled, Enabled                                  |
| ⇅ | SW1 CSWI LOC STAT:<br>Off                  | Range: FlexLogic operand                                  |
| ⇅ | SW1 STATION AUTHOR:<br>Off                 | Range: FlexLogic operand                                  |
| ⇅ | SWITCH 1 OPEN INTERLOCK:<br>Off            | Range: FlexLogic operand                                  |
| ⇅ | SWITCH 1 CLOSE INTERLOCK:<br>Off           | Range: FlexLogic operand                                  |

$\updownarrow$

SWITCH 1 POS-REACHED  
 CHECK:  
 Enabled

Range: Disabled, Enabled

The following settings are available for each switch control element.

### SWITCH 1 FUNCTION

This setting enables and disables the operation of the disconnect switch element.

### SWITCH 1 NAME

This setting allows you to assign a user-defined name (up to six characters) to the switch. This name is used in flash messages related to switch 1.

### SWITCH 1 MODE

This setting sets either *3-Pole* mode, where all disconnect switch poles are operated simultaneously, or *1-Pole* mode, where each disconnect switch pole has its own auxiliary switch.

### SWITCH 1 $\Phi$ A/3P DPS INP

This setting selects a double point status input (RxGOOSE# DPS Input) that is subscribed via GOOSE. Each received RxGOOSE# DPS Input consist of 2 bits. The derived switch status is shown in the logic diagram.

When the IEC61850 RxGOOSE# DPS is mapped to **SWITCH1  $\Phi$ A/3P DPS INP**, the switch status (Open/Close/Intermediate/Bad) will be based on the RxGOOSE DPS # value.

If the **SWITCH1  $\Phi$ A/3P DPS INP** selects a RxGOOSE DPS Input:

- the respective **SWITCH1  $\Phi$ A/3P OPND** and **SWITCH1  $\Phi$ A/3P CLSD** settings are not considered.
- the respective **SWITCH T OPERATE** and **SWITCH BAD ST TSUPPRESS** settings are also not considered in the receiving relay

### SWITCH 1 $\Phi$ A/3P OPND

This setting selects an operand (usually a contact input), which is for a normally-closed 89/a status input. This activates a logic 1 when the breaker is open. If a separate 89/b contact input is not available, then the inverted 89/a status signal or the inverted **SWITCH 1 CLOSED** status signal can be used.

### SWITCH 1 $\Phi$ A/3P CLSD

This setting selects an operand (usually a contact input) connected to a disconnect switch auxiliary position tracking mechanism. This input is for a normally-open 89/a status input that creates a logic 1 when the disconnect switch is closed. If the **SWITCH 1 MODE** setting is *3-Pole*, this setting selects a single 89/a input as the operand used to track the breaker open or closed position. In *1-Pole* mode, the input mentioned is used to track phase A and the **SWITCH 1  $\Phi$ B** and **SWITCH 1  $\Phi$ C** settings select operands to track phases B and C, respectively.

### SWITCH1 $\Phi$ B DPS INP

If the mode is selected as three-pole, this setting has no function. If the mode is selected as single-pole, this input is used to track the switch phase B position as outlined for phase A.

### SWITCH 1 $\Phi$ B OPENED

In three-pole mode, this setting has no function. In single-pole mode, this input is used to track the disconnect switch phase B opened position as outlined for phase A.

**SWITCH 1  $\Phi$ B CLOSED**

In three-pole mode, this setting has no function. In single-pole mode, this input is used to track the disconnect switch phase B closed position as outlined for phase A.

**SWITCH1  $\Phi$ C DPS INP**

If the mode is selected as three-pole, this setting has no function. If the mode is selected as single-pole, this input is used to track the switch phase C position as outlined for phase A.

**SWITCH 1  $\Phi$ C OPENED**

In three-pole mode, this setting has no function. In single-pole mode, this input is used to track the disconnect switch phase C opened position as outlined for phase A.

**SWITCH 1  $\Phi$ C CLOSED**

In three-pole mode, this setting has no function. In single-pole mode, this input is used to track the disconnect switch phase C closed position as outlined for phase A.

**SWITCH 1 ALARM PDisc DELAY**

This setting specifies the delay interval during which a conflict of status among the pole position tracking operands does not declare a pole discrepancy. This allows for non-simultaneous operation of the poles.

**SWITCH 1 OPEN CMD**

This setting selects an operand that initiates a Switch 1 Open command. The command is not executed when blocked by the operand assigned to **SWITCH1 BLK OPEN** setting.

**SW1 COMMS OPEN CMD**

This setting selects an operand that initiates a Switch 1 Open command. The setting is intended for commands received via communication protocols (DNP3, IEC104 and Modbus) to be supervised by IED Local/Remote status. The command is not executed if the relay is in local mode or blocked by the operand assigned to the **SWITCH 1 BLK OPEN** setting.

**SWITCH 1 CLOSE CMD**

This setting selects an operand that initiates a Switch 1 Close command. The command is not executed when blocked by an operand assigned to the **SWITCH 1 BLK CLOSE** setting.

**SW1 COMMS CLS CMD**

This setting selects an operand that initiates a Switch 1 Close command. The setting is intended for commands received via communication protocols (DNP3, IEC104 and Modbus) to be supervised by IED Local/Remote status. The command is not executed if the relay is in local mode or blocked by the operand assigned to the **SWITCH 1 BLK CLOSE** setting.

**SWITCH 1 PB CONTROL**

When the selected operand value is high, local disconnect switch operations are allowed from front panel pushbuttons .

**SWITCH 1 TOPERATE**

This setting specifies the required interval to overcome transient conflict between the 89/a and 89/b auxiliary contacts during disconnect switch operation. If transient conflict still exists after this time has expired, the SWITCH 1 BAD STATUS FlexLogic operand is asserted for alarm or blocking purposes.



### SWITCH 1 BAD ST TSUPPRESS

When the **SW INTERM & BAD ST TIMERS** setting is set to *Distinct*, this setting specifies the required interval to overcome the transient state of *11* during the breaker operation. If the *11* state still exists after this time, the SWITCH 1 BAD STATUS FlexLogic operand is asserted. When the **SW INTERM & BAD ST TIMERS** setting is set to *Common*, this setting is not used.

### SWITCH 1 OPEN SEAL-IN

This setting specifies the seal-in time of the open command due to an operator-initiated manual open command to the disconnect switch.

### SWITCH 1 CLOSE SEAL-IN

This setting specifies the seal-in time of the close command due to an operator-initiated manual close command to the disconnect switch.

### SWITCH 1 BLK OPEN

This setting selects an operand that prevents initiation of the disconnect Switch 1 command. This setting can be used to block the disconnect switch from opening, for instance when switch yard monitoring indicates that current exceeding the switch's interrupting rating can be flowing through the switch.

### SWITCH 1 BLK CLOSE

This setting selects an operand that prevents initiation of disconnect Switch 1 close commands. This setting can be used to block the disconnect switch from closing, for instance to prevent closing into a closed ground switch.

### SWITCH 1 BLK BYPASS

This setting is only available for relays with a graphical front panel. When enabled, this setting allows the graphical front panel to bypass switch 1 interlocking. When asserted, **SWITCH 1 BLK OPEN** and **SWITCH 1 BLK CLOSE** settings are bypassed.

### SWITCH 1 TAGGING

This setting is only available for relays with a graphical front panel. Switch tagging is used to block certain operations for safety purposes. No other action is needed after enabling the function; it is handled internally where certain functions are blocked.

Set to *Enable No Override* to allow the graphical front panel or IEC 61850 MMS control to tag switch 1. When tagged from the graphical front panel, tagging can be removed only from the graphical front panel, and an attempt to remove tagging using IEC 61850 MMS control results in a negative response (-Rsp). When tagged from IEC 61850 MMS control, tagging can be removed only by MMS control.

Set to *Enable With Override* to allow the graphical front panel or IEC 61850 MMS control to tag switch 1. When tagged from the graphical front panel, tagging can be removed only from the graphical front panel, and an attempt to remove tagging using IEC 61850 MMS control results in a negative response (-Rsp). When tagged from IEC 61850 MMS control, tagging can be removed by MMS control or from the graphical front panel. That is, the graphical front panel has an override function.

When tagged, the following operations are disabled:

- Pushbutton open/close
- IEC 61850 open/close
- Open command initiated by SWITCH 1 OPEN setting
- Close command initiated by SWITCH 1 CLOSE setting.

## SWITCH 1 SUBSTITUTN

This setting is only available for relays with a graphical front panel. When enabled, this setting allows the graphical front panel/IEC 61850 to substitute switch 1 status. When substituted, switch 1 control open/close status is forced to the substituted value.

## SWITCH 1 LOCAL

This setting selects an operand that indicates the Switch control behavior from an IEC 61850 client. When the operand value is set, it indicates the Switch in Local mode and the remote commands from IEC 61850 client are blocked. You set this setting using the EnerVista software or with an SCL file.

## SW1 BLK MNL CMD IN LOCAL

When this setting is enabled, and the SWITCH 1 LOCAL operand state is logic 1 (i.e. the Switch is in Local mode and Disc0XSW11.Loc is TRUE), manual commands originating from the front panel pushbuttons, graphical front panel and **SWITCH 1 OPEN/CLOSE CMD** are blocked. When disabled, manual commands originating from the relay are allowed even when the switch is in Local mode. This setting is available only if the order code includes IEC 61850.

## SW1CSWI LOC STAT

This setting selects an operand that indicates the switch residing in that bay is in Local or Remote mode. When the operand state is logic 1, the bay is considered to be in Local mode, otherwise it is considered to be in Remote mode. The operand status is modeled in the IEC 61850 server using the respective Switch CSWI Loc data objects. You should refer to the operand status in the Control Authority table to determine the control authority for different levels. This setting is available only if the order code includes IEC 61850.

## SW1 STATION AUTHOR

This setting selects an operand that indicates the Station level authority status. The operand status is modeled in the IEC 61850 server using the respective CSWI LocSta data objectS. Refer to the operand status in the Control Authority table to determine the control authority for different levels. This setting is available only if the order code includes IEC 61850.

## SWITCH 1 OPEN INTERLOCK

This setting selects an operand that indicates the interlock status for the Switch Open commands. This operand state is mapped directly to the IEC 61850 DiscCILO1.EnaOpn.stVal, which is used to reject the IEC 61850 open command when the selected operand state is at logic 0 (DiscCILO1.EnaOpn.stVal is set to false). However, the IEC 61850 client can choose to check or skip the interlock condition to execute the command using the *Check* parameter. In addition, the interlock condition can be applied to the local commands, which can originate from the front local HMI, front panel push buttons, graphical front panel and FlexLogic Operands assigned to the **SWITCH 1 OPEN CMD** setting. This is achieved by enabling **SW1 CILO INTRLK TO LOCAL CTRL**. This setting is available only if the order code includes IEC 61850.

## SWITCH 1 CLOSE INTERLOCK

This setting selects an operand that indicates the interlock status for the Switch Open commands. This operand state is mapped directly to the IEC 61850 DiscCILO1.EnaCls.stVal, which is used to reject the IEC 61850 close command when the selected operand state is at logic 0 (DiscCILO1.EnaCls.stVal is set to false). However, the IEC 61850 client can choose to check or skip the interlock condition to execute the command using the *Check* parameter. In addition, the interlock condition can be applied to the local commands, which can originate from the front local HMI, front panel push buttons, graphical front panel and FlexLogic Operands assigned to the **SWITCH 1 CLOSE CMD** setting. This is achieved by enabling **SW1 CILO INTRLK TO LOCAL CTRL**. This setting is available only if the order code includes IEC 61850.

### SWITCH 1 POS-REACHED CHECK

When enabled, the IEC 61850 control value is checked for current switch status and is rejected if the command value (Open/Close) from IEC 61850 client matches with the present switch status. When disabled, the current switch status is not verified to accept the control. This setting is only available if the order code includes IEC 61850. It is set using the EnerVista software.

**Note:**

Before software release version 7.90, **ST.LOC OPERAND**, **INTERLOCK OPN**, **INTERLOCK CLS** and **SYNCHECK CLOSE** settings were available in IEC 61850 configurator under **System Setup > Switches**. From version 7.90 onwards, the above mentioned settings were removed from the IEC 61850 configurator and merged with the Breaker settings screen under **Settings > System Setup > Switches** (outside the IEC 61850 configurator). Also, the name of the setting **ST.LOC OPERAND** has been changed to **LOCAL**.


**Note:**

**SWITCH 1 LOCAL**, **INTERLOCK OPEN**, **INTERLOCK CLOSE**, **SYNCHECK CLOSE** settings are not available on the front panel and can be configured either from EnerVista Software or via SCL files. Refer to the MICS document online for respective settings modeling in SCL files. **SWITCH 1 POS-REACHED CHECK** is only configurable via EnerVista software.

The switch element has direct hard-coded connections to the IEC 61850 model as shown in the logic diagrams. This allows remote open/close operation of each switch, using either CSWI or XSWI IEC 61850 logical nodes. IEC 61850 select-before-operate functionality, local/remote switch functionality, along with blocking open/close commands are provided. Note that the dwell time for the IEC 61850 trip and close commands shown is one protection pass only. To maintain close/open command for a certain time, do so using the seal-in timers **SWITCH 1 OPEN SEAL-IN** and **SWITCH 1 CLOSE SEAL-IN**, on the contact outputs using the setting, or in FlexLogic.

#### 8.5.6.1 DISCONNECT SWITCH CONTROL LOGIC

The following diagrams show the disconnect switch control logic:



859828B1.vsdX

Figure 234: Disconnect switch control logic (Sheet 1 of 5)




Figure 235: Disconnect switch control logic (Sheet 2 of 5)




Figure 236: Disconnect switch control logic (Sheet 3 of 5)




Figure 237: Disconnect switch control logic (Sheet 4 of 5)






Figure 238: Disconnect switch control logic (Sheet 5 of 5)

### 8.5.7 FLEXCURVES

Setting path: **SETTINGS > SYSTEM SETUP > FLEXCURVES > FLEXCURVE <n>**

where n = A to D





FlexCurves A through D have settings for entering times to reset and operate at the following pickup levels: 0.00 to 0.98 and 1.03 to 20.00. This data is converted into two continuous curves by linear interpolation between data points. To enter a custom FlexCurve, enter the reset and operate times (using the **VALUE** keys) for each selected pickup point (using the **MESSAGE** up/down keys) for the required protection curve (A, B, C, or D).

| Reset | Time ms | Reset | Time ms | Operate | Time ms | Operate | Time ms | Operate | Time ms | Operate | Time ms |
|-------|---------|-------|---------|---------|---------|---------|---------|---------|---------|---------|---------|
| 0.00  |         | 0.68  |         | 1.03    |         | 2.9     |         | 4.9     |         | 10.5    |         |
| 0.05  |         | 0.70  |         | 1.05    |         | 3.0     |         | 5.0     |         | 11.0    |         |
| 0.10  |         | 0.72  |         | 1.1     |         | 3.1     |         | 5.1     |         | 11.5    |         |
| 0.15  |         | 0.74  |         | 1.2     |         | 3.2     |         | 5.2     |         | 12.0    |         |
| 0.20  |         | 0.76  |         | 1.3     |         | 3.3     |         | 5.3     |         | 12.5    |         |
| 0.25  |         | 0.78  |         | 1.4     |         | 3.4     |         | 5.4     |         | 13.0    |         |
| 0.30  |         | 0.80  |         | 1.5     |         | 3.5     |         | 5.5     |         | 13.5    |         |
| 0.35  |         | 0.82  |         | 1.6     |         | 3.6     |         | 5.6     |         | 14.0    |         |
| 0.40  |         | 0.84  |         | 1.7     |         | 3.7     |         | 5.7     |         | 14.5    |         |
| 0.45  |         | 0.86  |         | 1.8     |         | 3.8     |         | 5.8     |         | 15.0    |         |
| 0.48  |         | 0.88  |         | 1.9     |         | 3.9     |         | 5.9     |         | 15.5    |         |
| 0.50  |         | 0.90  |         | 2.0     |         | 4.0     |         | 6.0     |         | 16.0    |         |
| 0.52  |         | 0.91  |         | 2.1     |         | 4.1     |         | 6.5     |         | 16.5    |         |
| 0.54  |         | 0.92  |         | 2.2     |         | 4.2     |         | 7.0     |         | 17.0    |         |
| 0.56  |         | 0.93  |         | 2.3     |         | 4.3     |         | 7.5     |         | 17.5    |         |
| 0.58  |         | 0.94  |         | 2.4     |         | 4.4     |         | 8.0     |         | 18.0    |         |
| 0.60  |         | 0.95  |         | 2.5     |         | 4.5     |         | 8.5     |         | 18.5    |         |
| 0.62  |         | 0.96  |         | 2.6     |         | 4.6     |         | 9.0     |         | 19.0    |         |
| 0.64  |         | 0.97  |         | 2.7     |         | 4.7     |         | 9.5     |         | 19.5    |         |
| 0.66  |         | 0.98  |         | 2.8     |         | 4.8     |         | 10.0    |         | 20.0    |         |

**Note:**

The relay using a given FlexCurve applies linear approximation for intervals between the user-entered points. Take care when setting the two points that are closest to the multiple of pickup of 1 (0.98 pu and 1.03 pu). We recommend that you set the two times to a similar value, otherwise the linear approximation can result in undesired behavior for the operating quantity that is close to 1.00 pu.

### 8.5.7.1 FLEXCURVE CONFIGURATION WITH ENERVISTA SOFTWARE

The EnerVista software allows for easy configuration and management of FlexCurves and their associated data points. You can configure FlexCurves from a selection of standard curves to provide the best approximate fit, then edit specific data points afterwards. Alternately, you can import curve data from a specified file (.csv format) by




selecting the EnerVista Import Data From setting (**Settings > System Setup > FlexCurves > FlexCurve**). You customize FlexCurves by editing the operating time (ms) values at pre-defined per-unit current multiples.

**Note:**

*Note that the pickup multiples start at zero (implying the "reset time"), operating time below pickup, and operating time above pickup.*

### 8.5.7.2 RECLOSER CURVE EDITING

You can shape recloser curves into a composite curve with a minimum response time and a fixed time above a specified pickup multiples. 41 recloser curve types supported. These definite operating times are useful to coordinate operating times, typically at higher currents and where upstream and downstream protective devices have different operating characteristics. The recloser curve configuration window shown here appears when you set the **Initialize From** setting in the EnerVista software to *Recloser Curve* and clicking the **Initialize FlexCurve** button.



842721A1.CDR

**Figure 239: Recloser curve initialization**

**Note:**

*The Multiplier and Adder settings only affect the curve portion of the characteristic and not the MRT and HCT settings. The HCT settings override the MRT settings for multiples of pickup greater than the HCT ratio.*

### Example

A composite curve is created from the GE\_111 standard with MRT = 200 ms and HCT initially disabled. HCT is then enabled at eight times pickup with an operating time of 30 ms. At approximately four times pickup, the curve operating time is equal to the MRT and from then onwards the operating time remains at 200 ms.

**Recloser Curve Initialization**

Standard Recloser Curve: **GE\_111**

Multiplier: **1**    Adder (seconds): **0**

Minimum Response Time

☒ Use MRT

MRT (seconds): **0.2**


High Current Time

☐ Use HCT

HCT Ratio (Multiple of Pickup): **20**

HCT (seconds): **0.016**

Defaults    OK    Apply    Cancel



### Composite recloser curve with HCT disabled

With the HCT feature enabled, the operating time reduces to 30 ms for pickup multiples exceeding eight times pickup

**Recloser Curve Initialization**

Standard Recloser Curve: **GE\_111**

Multiplier: **1**    Adder (seconds): **0**

Minimum Response Time

☒ Use MRT

MRT (seconds): **0.2**


High Current Time

☒ Use HCT

HCT Ratio (Multiple of Pickup): **8**

HCT (seconds): **0.03**

Defaults    OK    Apply    Cancel



### Composite recloser curve with HCT enabled

**Note:**  
Configuring a composite curve with an increase in operating time at increased pickup multiples is not allowed. If you attempt this, the EnerVista software will generate an error message and discard the proposed changes

### 8.5.7.3 STANDARD RECLOSER CURVES

The following graphs display standard recloser curves available.




Figure 240: Recloser curves GE101 to GE106




Figure 241: Recloser curves GE113, GE120, GE138, and GE142




Figure 242: Recloser curves GE134, GE137, GE140, GE151, and GE201




Figure 243: Recloser curves GE131, GE141, GE152, and GE200




Figure 244: Recloser curves GE133, GE161, GE162, GE163, GE164, and GE165




Figure 245: Recloser curves GE116, GE117, GE118, GE132, GE136, and GE139




Figure 246: Recloser curves GE107, GE111, GE112, GE114, GE115, GE121, and GE122





Figure 247: Recloser curves GE119, GE135, and GE202

### 8.5.8 PMU INSTANCE SETTINGS

Setting path: **SETTINGS > SYSTEM SETUP > PHASOR MEASUREMENT UNIT > PHASOR MEASUREMENT UNIT <n>**

Up to six PMUs are available, depending on UR model and option choice. Only one is shown here.



The PMU instance menu consists of the following sub-menus.

### PMU 1 BASIC CONFIGURATION

This submenu invokes the basic configuration settings for PMU 1.

### PMU 1 CALIBRATION

This submenu invokes the calibration settings for PMU 1.

### PMU 1 TRIGGERING

This submenu invokes the triggering settings for PMU 1.

### PMU 1 RECORDING

This submenu invokes the recording settings for PMU 1.

#### 8.5.8.1 BASIC CONFIGURATION

Setting path: **SETTINGS > SYSTEM SETUP > PHASOR MEASUREMENT UNIT > PHASOR MEASUREMENT UNIT <n>**

Up to six PMUs are available, depending on UR model and option choice. Only one is shown here.

|                                  |   |                                          |                                                                                                       |
|----------------------------------|---|------------------------------------------|-------------------------------------------------------------------------------------------------------|
| ■ PMU 1 BASIC<br>■ CONFIGURATION | ↔ | PMU 1<br>FUNCTION: Disabled              | Range: Enabled, Disabled                                                                              |
|                                  | ⇅ | PMU 1 IDCODE:<br>1                       | Range: 1 to 65534 in steps of 1                                                                       |
|                                  | ⇅ | PMU 1 STN:<br>GE-UR-PMU                  | Range: 32-character ASCII string truncated to 16 characters if mapped into C37.118 Default: GE-UR-PMU |
|                                  | ⇅ | PMU 1 GLOBAL PMU ID:<br>GE-UR-PMU-000001 | Range: 16-character ASCII string                                                                      |
|                                  | ⇅ | PMU 1 LATITUDE:<br>0.00000 °             | Range: -90.00000 to 90.00000 in steps of 0.00001°                                                     |
|                                  | ⇅ | PMU 1 LONGITUDE:<br>0.00000 °            | Range: -179.99999 to 180.00000 in steps of 0.00001°                                                   |
|                                  | ⇅ | PMU 1 ELEVATION:<br>0.000 m              | Range: -9999.999 to 9999.999 in steps of 0.001 meters                                                 |
|                                  | ⇅ | PMU 1 SIGNAL SOURCE:<br>SRC 1            | Range: available signal sources                                                                       |
|                                  | ⇅ | PMU 1 CLASS:<br>M-CLASS                  | Range: None, M-CLASS, P-CLASS                                                                         |

|   |                                        |                                                                     |
|---|----------------------------------------|---------------------------------------------------------------------|
| ⇅ | PMU 1 FORMAT:<br>Integer               | Range: Integer, Floating-point                                      |
| ⇅ | PMU 1 STYLE:<br>Polar                  | Range: Polar, Rectangular                                           |
| ⇅ | PMU 1 RATE:<br>10/sec                  | Range: 1, 2, 4, 5, 10, 12, 15, 20, 25, 30, 50, 60, 100, 120         |
| ⇅ | PMU 1 f & df/dt<br>FILTER: None        | Range: None, 10Hz/s <10Hz, 10Hz/s <20Hz, 20Hz/s <10Hz, 20Hz/s <20Hz |
| ⇅ | ■ C37.118 PMU 1<br>■ CONFIGURATION     |                                                                     |
| ⇅ | PMU 1 PHS- 1:<br>Off                   | Range: available synchrophasor values                               |
| ⇅ |                                        |                                                                     |
| ⇅ | PMU 1 PHS- 14:<br>Off                  | Range: available synchrophasor values                               |
| ⇅ | PMU 1 PHS- 1:<br>NM: GE-UR-PMU-PHS 1   | Range: 16-character ASCII string                                    |
| ⇅ |                                        |                                                                     |
| ⇅ | PMU 1 PHS- 14:<br>NM: GE-UR-PMU-PHS 14 | Range: 16-character ASCII string                                    |
|   | PMU 1 A-CH- 1:<br>Off                  | Range: available FlexAnalog values                                  |
| ⇅ |                                        |                                                                     |
| ⇅ | PMU 1 A-CH-8:<br>Off                   | Range: available FlexAnalog values                                  |
| ⇅ | PMU 1 A-CH- 1:<br>NM: AnalogChannel 1  | Range: 16-character ASCII string                                    |
| ⇅ |                                        |                                                                     |
| ⇅ | PMU 1 A-CH-8:<br>NM: AnalogChannel 8   | Range: 16-character ASCII string                                    |
|   | PMU 1 D-CH- 1:<br>Off                  | Range: available FlexLogic operands                                 |
| ⇅ |                                        |                                                                     |
| ⇅ | PMU 1 D-CH-16:<br>Off                  | Range: available FlexLogic operands                                 |
| ⇅ | PMU 1 D-CH- 1:<br>NM: Dig Channel 1    | Range: 16-character ASCII string                                    |
| ⇅ |                                        |                                                                     |
| ⇅ | PMU 1 D-CH-16<br>NM: Dig Channel 16    | Range: 16-character ASCII string                                    |
| ⇅ | PMU 1 D-CH- 1<br>NORMAL STATE: Off     | Range: Off, On                                                      |
| ⇅ |                                        |                                                                     |



|   |                                     |                |
|---|-------------------------------------|----------------|
| ↕ | PMU 1 D-CH-16:<br>NORMAL STATE: Off | Range: Off, On |
| ↑ | ■ 90-5 PMU 1<br>■ CONFIGURATION     |                |

## PMU 1 FUNCTION

This setting enables the LOGICAL Device PMU 1 functionality. Use this setting to permanently enable or disable the feature.

## PMU 1 IDCODE

This setting assigns a numerical ID to the PMU. It corresponds to the IDCODE field of the data, configuration, header, and command frames of the IEEE C37.118 protocol. The PMU uses this value when sending data, configuration, and header frames; and it responds to this value when receiving the command frame. This is used when only data from one PMU is present.

## PMU 1 STN

This setting assigns an alphanumeric ID to the PMU station. It corresponds to the STN field of the configuration frame of the IEEE C37.118 protocol. This value is a 16-character ASCII string as per the IEEE C37.118 standard.

## PMU 1 GLOBAL PMU ID

This setting is used to assign a global ID to the PMU and corresponds to the G\_PMU\_ID field in configuration 3 (CFG-3) message per the C37.118 protocol. This ID allows uniquely identifying PMUs in a system that has more than 65535 PMUs.

## PMU 1 LATITUDE:

This setting is used to assign PMU Latitude in degrees, where positive values are N of equator, and negative values are S of equator.

## PMU 1 LONGITUDE:

This setting is used to assign PMU longitude in degrees, where positive values are E of the prime meridian, and negative values are W of the prime meridian.

## PMU 1 ELEVATION:

This setting is used to assign PMU elevation in meters, where positive values are above sea level, and negative values are below sea level.

## PMU 1 SIGNAL SOURCE

This setting specifies one of the available L90 signal sources for processing in the PMU. Any combination of voltages and currents can be configured as a source. The current channels can be configured as sums of physically connected currents. This facilitates PMU applications in breaker-and-a-half, ring-bus, and similar arrangements. The PMU feature calculates voltage phasors for actual voltage (A, B, C, and auxiliary) and current (A, B, C, and ground) channels of the source, as well as symmetrical components (0, 1, and 2) of both voltages and currents. When configuring communication and recording features of the PMU, the user can select, from the above superset, the content to be sent out or recorded. When one source is selected by one PMU, it cannot be selected by another PMU.

## PMU 1 CLASS (Range P, M, None)

This setting selects the synchrophasor class. A reporting rate of 100 or 120 can only be selected for class P synchrophasors and if the system frequency is 50 or 60 Hz, respectively.

## PMU 1 NETWORK REPORTING FORMAT

This setting selects between reporting synchrophasors as 16-bit integer or 32-bit IEEE floating point numbers. This setting complies with bit-1 of the FORMAT field of the C37.118 configuration frame. Note that this setting applies to synchrophasors only; the user-selectable FlexAnalog channels are always transmitted as 32-bit integer values.

## PMU 1 NETWORK REPORTING STYLE

This setting selects between reporting synchrophasors in rectangular (real and imaginary) or in polar (magnitude and angle) coordinates. This setting complies with bit-0 of the FORMAT field of the C37.118 configuration frame.

## PMU 1 RATE

This setting specifies the reporting rate for the network (Ethernet) port. This value applies to all PMU streams of the device that are assigned to transmit over this aggregator. For a system frequency of 60 Hz (50 Hz), the L90 generates a reporting mismatch message if the selected rate is not set as 10 Hz, 12 Hz, 15 Hz, 20 Hz, 30 Hz, 60 Hz, or 120 Hz (or 10 Hz, 25 Hz, 50 Hz, or 100 Hz when the system frequency is 50 Hz) when entered via the keypad or software; and the L90 stops the transmission of reports. Note that 4 Hz is not allowed for an M-class 50 Hz system.

## PMU 1 f & df/dt FILTER

This setting allows applying post-filtering to the frequency and rate-of-change of-frequency to avoid reporting erroneous values, which can possibly happen during fault, switching, and other system disturbances. For example, choosing 20Hz/s <10Hz setting ensures that if rate-of-change of-frequency between current reporting instance and previous one exceeds 20Hz/s or frequency deviation from the nominal frequency exceeds 10Hz, then new frequency and rate-of-change of-frequency value are invalidated. If this happens, the previous valid value of the frequency is maintained and rate-of-change of-frequency value is forced to 0 at this reporting instance.

## PMU 1 PHS-1 to PMU 1 PHS-14

These settings specify synchrophasors to be transmitted from the superset of all synchronized measurements. The table outlines available synchrophasor values.

| Selection | Meaning                                                                   |
|-----------|---------------------------------------------------------------------------|
| Va        | First voltage channel, either Va or Vab                                   |
| Vb        | Second voltage channel, either Vb or Vbc                                  |
| Vc        | Third voltage channel, either Vc or Vca                                   |
| Vx        | Fourth voltage channel                                                    |
| Ia        | Phase A current, physical channel or summation as per the source settings |
| Ib        | Phase B current, physical channel or summation as per the source settings |
| Ic        | Phase C current, physical channel or summation as per the source settings |
| Ig        | Fourth current channel, physical or summation as per the source settings  |
| V1        | Positive-sequence voltage, referenced to Va                               |
| V2        | Negative-sequence voltage, referenced to Va                               |
| V0        | Zero-sequence voltage                                                     |
| I1        | Positive-sequence current, referenced to Ia                               |
| I2        | Negative-sequence current, referenced to Ia                               |
| I0        | Zero-sequence current                                                     |

These settings allow for optimizing the frame size and maximizing transmission channel usage, depending on a given application. Select "Off" to suppress transmission of a given value.

**PMU 1 PHS-1 NM to PMU 1 PHS-14 NM**

These settings allow for custom naming of the synchrophasor channels. Sixteen-character ASCII strings are allowed as in the CHNAM field of the configuration frame. These names are typically based on station, bus, or breaker names.

**PMU 1 A-CH-1 to PMU 1 A-CH-16**

These settings specify any analog data measured by the relay to be included as a user-selectable analog channel of the data frame. Up to eight analog channels can be configured to send any FlexAnalog value from the relay. Examples include frequency, rate of frequency change, active and reactive power, per phase or three-phase power, power factor, temperature via RTD inputs, and THD. The configured analog values are sampled concurrently with the synchrophasor instant and sent as 32-bit floating-point values scaled to Engineering units.

**PMU 1 A-CH-1 NM to PMU 1 A-CH-16 NM**

These settings allow for custom naming of the analog channels. Sixteen-character ASCII strings are allowed as in the CHNAM field of the configuration frame.

**PMU 1 D-CH-1 to PMU 1 D-CH-16**

These settings specify any digital flag measured by the relay to be included as a user-selectable digital channel of the data frame. Up to 16 digital channels can be configured to send any FlexLogic operand from the relay. The configured digital flags are sampled concurrently with the synchrophasor instant. These values are mapped into a two-byte integer number, with byte 1 LSB corresponding to the digital channel 1 and byte 2 MSB corresponding to digital channel 16.

**PMU 1 D-CH-1 NM to PMU 1 D-CH-16 NM**

These settings allow for custom naming of the digital channels. Sixteen-character ASCII strings are allowed as in the CHNAM field of the configuration frame.

**PMU 1 D-CH-1 NORMAL STATE to PMU 1 D-CH-16 NORMAL STATE**

These settings allow for specifying a normal state for each digital channel. These states are transmitted in configuration frames to the data concentrator.

**Submenu for C37.118 configuration**

The basic configuration menu also contains a submenu for the C37.118 configuration as follows:

Setting path: **SETTINGS > SYSTEM SETUP > PHASOR MEASUREMENT UNIT > PHASOR MEASUREMENT UNIT > PMU 1 BASIC CONFIGURATION > C37.118 PMU 1 CONFIGURATION**

|                                                                 |   |                               |                                |
|-----------------------------------------------------------------|---|-------------------------------|--------------------------------|
| <div><div>■ C37.118 PMU 1</div><div>■ CONFIGURATION</div></div> | ↔ | PMU 1 FORMAT:<br>Integer      | Range: Integer, Floating-point |
|                                                                 | ⇅ | PMU 1 FREQ FORMAT:<br>Integer | Range: Integer, Floating-point |
|                                                                 | ⇅ | PMU 1 STYLE:<br>Polar         | Range: Polar, Rectangular      |

**PMU 1 FORMAT**

This setting selects whether synchrophasors are reported as 16-bit integers or 32-bit IEEE floating point numbers. This setting complies with bit-1 of the FORMAT field of the IEEE C37.118 configuration frame. This setting applies to synchrophasors only; user-selectable FlexAnalog channels are always transmitted as 16-bit integer values.

## PMU 1 FREQ FORMAT

This setting selects between reporting frequency and rate-of-change-of-frequency as 16-bit integer or 32-bit IEEE floating point numbers. This setting complies with bit 3 of the FORMAT field of the C37.118 configuration frame.

## PMU 1 STYLE

This setting selects whether synchrophasors are reported in rectangular (real and imaginary) coordinates or in polar (magnitude and angle) coordinates. This setting complies with bit-0 of the FORMAT field of the IEEE C37.118 configuration frame.

The basic configuration menu also contains a submenu for the IEC61850-90-5 configuration as follows:

Setting path: **SETTINGS > SYSTEM SETUP > PHASOR MEASUREMENT UNIT > PHASOR MEASUREMENT UNIT > PMU 1 BASIC CONFIGURATION > 90-5 PMU 1 CONFIGURATION**

|                                                                                         |   |                                   |                           |
|-----------------------------------------------------------------------------------------|---|-----------------------------------|---------------------------|
| <ul style="list-style-type: none"> <li>■ 90-5 PMU 1</li> <li>■ CONFIGURATION</li> </ul> | ↔ | <div>PMU 1 LDINST:<br/>PMU1</div> | Range: 64 char ASCII text |
|-----------------------------------------------------------------------------------------|---|-----------------------------------|---------------------------|

*Note:*

*With 90-5 PMU, the FORMAT and STYLE are Floating-point and Polar respectively, as specified in the IEC 61850-90-5 technical report.*

### 8.5.8.2 PMU CALIBRATION

Up to six PMUs are available, depending on UR model and option choice. Only one is shown here.

Setting path: **SETTINGS > SYSTEM SETUP > PHASOR MEASUREMENT UNIT > PHASOR MEASUREMENT UNIT <n> PMU <n> CALIBRATION**

|                                                                                  |   |                                      |                                        |
|----------------------------------------------------------------------------------|---|--------------------------------------|----------------------------------------|
| <ul style="list-style-type: none"> <li>■ PMU 1</li> <li>■ CALIBRATION</li> </ul> | ↔ | PMU 1 VA CALIBRATION<br>ANGLE: 0.00° | Range: -5.00 to 5.00° in steps of 0.05 |
|                                                                                  | ⇅ | PMU 1 VA CALIBRATION<br>MAG: 100.0%  | Range: 95.0 to 105.0 in steps of 0.1%  |
|                                                                                  | ⇅ | PMU 1 VB CALIBRATION<br>ANGLE: 0.00° | Range: -5.00 to 5.00° in steps of 0.05 |
|                                                                                  | ⇅ | PMU 1 VB CALIBRATION<br>MAG: 100.0%  | Range: 95.0 to 105.0 in steps of 0.1%  |
|                                                                                  | ⇅ | PMU 1 VC CALIBRATION<br>ANGLE: 0.00° | Range: -5.00 to 5.00° in steps of 0.05 |
|                                                                                  | ⇅ | PMU 1 VC CALIBRATION<br>MAG: 100.0%  | Range: 95.0 to 105.0 in steps of 0.1%  |
|                                                                                  | ⇅ | PMU 1 VX CALIBRATION<br>ANGLE: 0.00° | Range: -5.00 to 5.00° in steps of 0.05 |
|                                                                                  | ⇅ | PMU 1 VX CALIBRATION<br>MAG: 100.0%  | Range: 95.0 to 105.0 in steps of 0.1%  |
|                                                                                  | ⇅ | PMU 1 IA CALIBRATION<br>ANGLE: 0.00° | Range: -5.00 to 5.00° in steps of 0.05 |
|                                                                                  | ⇅ | PMU 1 IA CALIBRATION<br>MAG: 100.0%  | Range: 95.0 to 105.0 in steps of 0.1%  |
|                                                                                  | ⇅ | PMU 1 IB CALIBRATION<br>ANGLE: 0.00° | Range: -5.00 to 5.00° in steps of 0.05 |

|   |                                      |                                        |
|---|--------------------------------------|----------------------------------------|
| ⇅ | PMU 1 IB CALIBRATION<br>MAG: 100.0%  | Range: 95.0 to 105.0 in steps of 0.1%  |
| ⇅ | PMU 1 IC CALIBRATION<br>ANGLE: 0.00° | Range: -5.00 to 5.00° in steps of 0.05 |
| ⇅ | PMU 1 IC CALIBRATION<br>MAG: 100.0%  | Range: 95.0 to 105.0 in steps of 0.1%  |
| ⇅ | PMU 1 IG CALIBRATION<br>ANGLE: 0.00° | Range: -5.00 to 5.00° in steps of 0.05 |
| ⇅ | PMU 1 IG CALIBRATION<br>MAG: 100.0%  | Range: 95.0 to 105.0 in steps of 0.1%  |
| ⇅ | PMU 1 SEQ VOLT SHIFT<br>ANGLE: 0°    | Range: -180 to 180° in steps of 30     |
| ↑ | PMU 1 SEQ CURR SHIFT<br>ANGLE: 0°    | Range: -180 to 180° in steps of 30     |

This menu contains user angle and magnitude calibration data for the Phasor Measurement Unit (PMU). This data is combined with the factory adjustments to shift the phasors for better accuracy.

### PMU 1 VA... IG CALIBRATION ANGLE

These settings recognize applications with protection class voltage and current sources, and they allow you to calibrate each channel (four voltages and four currents) individually to offset errors introduced by VTs, CTs, and cabling. The setting values are effectively added to the measured angles. Therefore, enter a positive correction when the secondary signal lags the true signal and a negative value when the secondary signal leads the true signal.

### PMU 1 VA... IG CALIBRATION MAGNITUDE

These settings recognize applications with protection class voltage and current sources, and they allow you to calibrate each channel (four voltages and four currents) individually to offset errors introduced by VTs, CTs. The setting values are effectively a multiplier of the measured magnitudes. Therefore, entering a multiplier greater than 100% of the secondary signal increases the true signal, and a multiplier less than 100% value of the secondary signal reduces the true signal.

### PMU 1 SEQ VOLT SHIFT ANGLE

This setting allows you to correct positive- and negative-sequence voltages for vector groups of power transformers located between the PMU voltage point and the reference node. This angle is effectively added to the positive-sequence voltage angle and subtracted from the negative-sequence voltage angle. Note that:

- When this setting is not "0°", the phase and sequence voltages do not agree. Unlike sequence voltages, the phase voltages cannot be corrected in a general case and therefore are reported as measured.
- When receiving synchrophasor data at multiple locations, with possibly different reference nodes, it can be more beneficial to allow the central locations to perform the compensation of sequence voltages.
- This setting applies to PMU data only. The relay calculates symmetrical voltages independently for protection and control purposes without applying this correction.
- When connected to line-to-line voltages, the PMU calculates symmetrical voltages with the reference to the AG voltage and not to the physically connected AB voltage.


### PMU 1 SEQ CURR SHIFT ANGLE

This setting allows you to correct positive and negative-sequence currents for vector groups of power transformers located between the PMU current point and the reference node. The setting has the same meaning for currents as the **PMU 1 SEQ VOLT SHIFT ANGLE** setting has for voltages. Normally, you would set the two correcting angles

identically, except in rare applications when the voltage and current measuring points are located at different windings of a power transformer.

### 8.5.8.3 PMU TRIGGERING OVERVIEW


Setting path: **SETTINGS > SYSTEM SETUP > PHASOR MEASUREMENT UNIT > PHASOR MEASUREMENT UNIT 1 > PMU TRIGGERING**



Each Phasor Measurement Unit (PMU) contains five triggering mechanisms to facilitate triggering of the associated PMU recorder, or cross-triggering of other PMUs in the system. They are

- Overfrequency and underfrequency
- Overvoltage and undervoltage
- Overcurrent
- Overpower
- High rate of change of frequency

The pre-configured triggers can be augmented with a user-specified condition built freely using programmable logic of the relay. The entire triggering logic is refreshed once every two power system cycles. All five triggering functions and the user-definable condition are consolidated (ORed) and connected to the PMU recorder. Each trigger can be programmed to log its operation into the event recorder and to signal its operation via targets. The five triggers drive the STAT bits of the data frame to inform the destination of the synchrophasor data regarding the cause of trigger. The following convention is adopted to drive bits 11, 3, 2, 1, and 0 of the STAT word.



**Figure 248: STAT bits logic**

The trigger reset (drop-off) timer is available for all five triggering functions (FREQ, ROCOF, VOLT, CURR, POWER) in individual trigger settings under the **TRIGGER DPO TIME** setting. This asserts individual trigger operand and overall PMU x TRIGGERED operand with stat bits 3 and 11 for a fixed interval defined by this setting. If it is required that PMU x TRIGGERED operand with stat bits 3 and 11 stay longer than the individual reset timer, then use the **PMU x USER TRIGGER** setting assigned with appropriate elements and FlexLogic. In short, in case of **USER TRIGGER**, the drop-off time needs to be implemented using FlexLogic.

8.5.8.3.1 USER TRIGGERING

Setting path: **SETTINGS > SYSTEM SETUP > PHASOR MEASUREMENT UNIT > PHASOR MEASUREMENT UNIT 1 > PMU TRIGGERING > PMU 1 USER TRIGGER**

|                                                        |   |                                                            |                          |
|--------------------------------------------------------|---|------------------------------------------------------------|--------------------------|
| <div><div>■ PMU 1 USER</div><div>■ TRIGGER</div></div> | ⇔ | <div><div>■ PMU 1 USER TRIGGER</div><div>■ Off</div></div> | Range: FlexLogic operand |
|--------------------------------------------------------|---|------------------------------------------------------------|--------------------------|

The user trigger allows you to construct customized triggering from FlexLogic. The entire triggering logic is refreshed every two power system cycles.

8.5.8.3.2 FREQUENCY TRIGGERING

Setting path: **SETTINGS > SYSTEM SETUP > PHASOR MEASUREMENT UNIT > PHASOR MEASUREMENT UNIT 1 > PMU TRIGGERING > PMU 1 TRIGGERING > PMU 1 FREQUENCY TRIGGER**

|                                                             |   |                                           |                                           |
|-------------------------------------------------------------|---|-------------------------------------------|-------------------------------------------|
| <div><div>■ PMU 1 FREQUENCY</div><div>■ TRIGGER</div></div> | ⇔ | PMU 1 FREQ TRIGGER<br>FUNCTION: Disabled  | Range: Enabled, Disabled                  |
|                                                             | ⇕ | PMU 1 FREQ TRIGGER<br>LOW-FREQ: 49.00 Hz  | Range: 20.00 to 70.00 Hz in steps of 0.01 |
|                                                             | ⇕ | PMU 1 FREQ TRIGGER<br>HIGH-FREQ: 61.00 Hz | Range: 20.00 to 70.00 Hz in steps of 0.01 |
|                                                             | ⇕ | PMU 1 FREQ TRIGGER<br>PKP TIME: 0.10 s    | Range: 0.00 to 600.00 s in steps of 0.01  |
|                                                             | ⇕ | PMU 1 FREQ TRIGGER<br>DPO TIME: 1.00 s    | Range: 0.00 to 600.00 s in steps of 0.01  |
|                                                             | ⇕ | PMU 1 FREQ TRIG BLK:<br>Off               | Range: FlexLogic operand                  |
|                                                             | ⇕ | PMU 1 FREQ TRIGGER<br>TARGET: Self-reset  | Range: Self-reset, Latched, Disabled      |
|                                                             | ↑ | PMU 1 FREQ TRIGGER<br>EVENTS: Disabled    | Range: Enabled, Disabled                  |

The trigger responds to the frequency signal of the Phasor Measurement Unit (PMU) source. The frequency is calculated from a selection of phase voltages, auxiliary voltage, phase currents, and ground current, depending on the source configuration. This element requires that the frequency is above the minimum measurable value. If the frequency is below this value, the trigger drops out.

PMU 1 FREQ TRIGGER FUNCTION

This setting enables or disabled the frequency trigger function.

PMU 1 FREQ TRIGGER LOW-FREQ

This setting specifies the low threshold for the abnormal frequency trigger. The comparator applies a 0.02 Hz hysteresis.

PMU 1 FREQ TRIGGER HIGH-FREQ

This setting specifies the high threshold for the abnormal frequency trigger. The comparator applies a 0.02 Hz hysteresis.

PMU 1 FREQ TRIGGER PKP TIME

This setting is used to filter out spurious conditions and avoid unnecessary triggering of the recorder.

### PMU 1 FREQ TRIGGER DPO TIME

This setting is used to extend the trigger after the situation returns to normal. This setting is important when using the recorder in forced mode (recording as long as the triggering condition is asserted).




Figure 249: Frequency trigger logic

### 8.5.8.3.3 VOLTAGE TRIGGERING

Setting path: **SETTINGS > SYSTEM SETUP > PHASOR MEASUREMENT UNIT > PHASOR MEASUREMENT UNIT 1 > PMU TRIGGERING > PMU 1 TRIGGERING > PMU 1 VOLTAGE TRIGGER**

|                                                          |   |                                        |                                            |
|----------------------------------------------------------|---|----------------------------------------|--------------------------------------------|
| <div> <div>PMU 1 VOLTAGE</div> <div>TRIGGER</div> </div> | ⇔ | PMU 1 VOLT TRIGGER FUNCTION: Disabled  | Range: Enabled, Disabled                   |
|                                                          | ⇕ | PMU 1 VOLT TRIGGER LOW-VOLT: 0.800 pu  | Range: 0.250 to 1.250 pu in steps of 0.001 |
|                                                          | ⇕ | PMU 1 VOLT TRIGGER HIGH-VOLT: 1.200 pu | Range: 0.750 to 1.750 pu in steps of 0.001 |
|                                                          | ⇕ | PMU 1 VOLT TRIGGER PKP TIME: 0.10 s    | Range: 0.00 to 600.00 s in steps of 0.01   |
|                                                          | ⇕ | PMU 1 VOLT TRIGGER DPO TIME: 1.00 s    | Range: 0.00 to 600.00 s in steps of 0.01   |
|                                                          | ⇕ | PMU 1 VOLT TRIG BLK: Off               | Range: FlexLogic operand                   |
|                                                          | ⇕ | PMU 1 VOLT TRIGGER TARGET: Self-reset  | Range: Self-reset, Latched, Disabled       |
|                                                          | ↑ | PMU 1 VOLT TRIGGER EVENTS: Disabled    | Range: Enabled, Disabled                   |

This element responds to abnormal voltage. Separate thresholds are provided for low and high voltage. In terms of signaling its operation, the element does not differentiate between the undervoltage and overvoltage events. The trigger responds to the phase voltage signal of the Phasor Measurement Unit (PMU) source. All voltage channels (A, B, and C or AB, BC, and CA) are processed independently and can trigger the recorder. A minimum voltage supervision of 0.1 pu is implemented to prevent pickup on a de-energized circuit, similarly to the undervoltage protection element.

### PMU 1 VOLT TRIGGER FUNCTION

This setting enables or disabled the voltage trigger function.



## PMU 1 VOLT TRIGGER LOW-VOLT

This setting specifies the low threshold for the abnormal voltage trigger, in per-unit of the PMU source. 1 pu is a nominal voltage value defined as the nominal secondary voltage times VT ratio. The comparator applies a 1% hysteresis.

## PMU 1 VOLT TRIGGER HIGH-VOLT


This setting specifies the high threshold for the abnormal voltage trigger, in per-unit of the PMU source. 1 pu is a nominal voltage value defined as the nominal secondary voltage times VT ratio. The comparator applies a 1% hysteresis.

### PMU 1 VOLT TRIGGER PKP TIME

This setting is used to filter out spurious conditions and avoid unnecessary triggering of the recorder.

## PMU 1 VOLT TRIGGER DPO TIME

This setting is used to extend the trigger after the situation returns to normal. This setting is important when using the recorder in the forced mode (recording as long as the triggering condition is asserted).



### Figure 250: Voltage trigger logic

#### 8.5.8.3.4 CURRENT TRIGGERING

Setting path: **SETTINGS > SYSTEM SETUP > PHASOR MEASUREMENT UNIT > PHASOR MEASUREMENT UNIT 1 > PMU TRIGGERING > PMU 1 TRIGGERING > PMU 1 CURRENT TRIGGER**

|                                                          |   |                                          |                                             |
|----------------------------------------------------------|---|------------------------------------------|---------------------------------------------|
| <div> <div>PMU 1 CURRENT</div> <div>TRIGGER</div> </div> | ↔ | PMU 1 CURR TRIGGER<br>FUNCTION: Disabled | Range: Enabled, Disabled                    |
|                                                          | ↕ | PMU 1 CURR TRIGGER<br>PICKUP: 1.800 pu   | Range: 0.100 to 30.000 pu in steps of 0.001 |
|                                                          | ↕ | PMU 1 CURR TRIGGER<br>PKP TIME: 0.10 s   | Range: 0.00 to 600.00 s in steps of 0.01    |
|                                                          | ↕ | PMU 1 CURR TRIGGER<br>DPO TIME: 1.00 s   | Range: 0.00 to 600.00 s in steps of 0.01    |
|                                                          | ↕ | PMU 1 CURR TRIG BLK:<br>Off              | Range: FlexLogic operand                    |
|                                                          | ↕ | PMU 1 CURR TRIGGER<br>TARGET: Self-reset | Range: Self-reset, Latched, Disabled        |
|                                                          | ↑ | PMU 1 CURR TRIGGER<br>EVENTS: Disabled   | Range: Enabled, Disabled                    |

This element responds to elevated current. The trigger responds to the phase current signal of the Phasor Measurement Unit (PMU) source. All current channel (A, B, and C) are processed independently and can trigger the recorder.

### PMU 1 CURR TRIGGER FUNCTION

This setting enables or disabled the current trigger function.

### PMU 1 CURR TRIGGER PICKUP

This setting specifies the pickup threshold for the overcurrent trigger, in per unit of the PMU source. A value of 1 pu is a nominal primary current. The comparator applies a 3% hysteresis.

### PMU 1 CURR TRIGGER PKP TIME

This setting is used to filter out spurious conditions and avoid unnecessary triggering of the recorder.

### PMU 1 CURR TRIGGER DPO TIME

This setting is used to extend the trigger after the situation returns to normal. This setting is important when using the recorder in the forced mode (recording as long as the triggering condition is asserted).




Figure 251: Current trigger logic

### 8.5.8.3.5 POWER TRIGGERING

Setting path: **SETTINGS > SYSTEM SETUP > PHASOR MEASUREMENT UNIT > PHASOR MEASUREMENT UNIT 1 > PMU TRIGGERING > PMU 1 TRIGGERING > PMU 1 POWER TRIGGER**

|               |   |                                        |                                            |
|---------------|---|----------------------------------------|--------------------------------------------|
| ■ PMU 1 POWER | ⇔ | PMU 1 POWER TRIGGER FUNCTION: Disabled | Range: Enabled, Disabled                   |
| ■ TRIGGER     | ⇕ | PMU 1 POWER TRIGGER ACTIVE: 1.250 pu   | Range: 0.250 to 3.000 pu in steps of 0.001 |
|               | ⇕ | PMU 1 POWER TRIGGER REACTIVE: 1.250 pu | Range: 0.250 to 3.000 pu in steps of 0.001 |
|               | ⇕ | PMU 1 POWER TRIGGER APPARENT: 1.250 pu | Range: 0.250 to 3.000 pu in steps of 0.001 |
|               | ⇕ | PMU 1 POWER TRIGGER PKP TIME: 0.10 s   | Range: 0.00 to 600.00 s in steps of 0.01   |
|               | ⇕ | PMU 1 POWER TRIGGER DPO TIME: 1.00 s   | Range: 0.00 to 600.00 s in steps of 0.01   |
|               | ⇕ | PMU 1 PWR TRIG BLK: Off                | Range: FlexLogic operand                   |
|               | ⇕ | PMU 1 POWER TRIGGER TARGET: Self-reset | Range: Self-reset, Latched, Disabled       |

↑

PMU 1 POWER TRIGGER

EVENTS: Disabled

Range: Enabled, Disabled

This element responds to abnormal power. Separate thresholds are provided for active, reactive, and apparent powers. In terms of signaling its operation, the element does not differentiate among the three types of power. The trigger responds to the single-phase and three-phase power signals of the Phasor Measurement Unit (PMU) source.

PMU 1 POWER TRIGGER FUNCTION

This setting enables or disabled the power trigger function.

PMU 1 POWER TRIGGER ACTIVE

This setting specifies the pickup threshold for the active power of the source. For single-phase power, 1 pu is a product of 1 pu voltage and 1 pu current, or the product of nominal secondary voltage, the VT ratio and the nominal primary current. For the three-phase power, 1 pu is three times that for a single-phase power. The comparator applies a 3% hysteresis.

PMU 1 POWER TRIGGER REACTIVE

This setting specifies the pickup threshold for the reactive power of the source. For single-phase power, 1 pu is a product of 1 pu voltage and 1 pu current, or the product of nominal secondary voltage, the VT ratio and the nominal primary current. For the three-phase power, 1 pu is three times that for a single-phase power. The comparator applies a 3% hysteresis.

PMU 1 POWER TRIGGER APPARENT

This setting specifies the pickup threshold for the apparent power of the source. For single-phase power, 1 pu is a product of 1 pu voltage and 1 pu current, or the product of nominal secondary voltage, the VT ratio and the nominal primary current. For the three-phase power, 1 pu is three times that for a single-phase power. The comparator applies a 3% hysteresis.

PMU 1 POWER TRIGGER PKP TIME

This setting is used to filter out spurious conditions and avoid unnecessary triggering of the recorder.

PMU 1 POWER TRIGGER DPO TIME

This setting is used to extend the trigger after the situation returns to normal. This setting is of particular importance when using the recorder in the forced mode (recording as long as the triggering condition is asserted).




Figure 252: Power trigger logic

### 8.5.8.3.6 RATE OF CHANGE OF FREQUENCY TRIGGERING

Setting path: **SETTINGS > SYSTEM SETUP > PHASOR MEASUREMENT UNIT > PHASOR MEASUREMENT UNIT 1 > PMU TRIGGERING > PMU 1 TRIGGERING > PMU 1 df/dt TRIGGER**

|                                                            |   |                                           |                                            |
|------------------------------------------------------------|---|-------------------------------------------|--------------------------------------------|
| <div> <div>■ PMU 1 df/dt</div> <div>■ TRIGGER</div> </div> | ⇔ | PMU 1 df/dt TRIGGER<br>FUNCTION: Disabled | Range: Enabled, Disabled                   |
|                                                            | ⇕ | PMU 1 df/dt TRIGGER<br>RAISE: 0.25 Hz/s   | Range: 0.10 to 15.00 Hz/s in steps of 0.01 |
|                                                            | ⇕ | PMU 1 df/dt TRIGGER<br>FALL: 0.25 Hz/s    | Range: 0.10 to 15.00 Hz/s in steps of 0.01 |
|                                                            | ⇕ | PMU 1 df/dt TRIGGER<br>PKP TIME: 0.10 s   | Range: 0.00 to 600.00 s in steps of 0.01   |
|                                                            | ⇕ | PMU 1 df/dt TRIGGER<br>DPO TIME: 1.00 s   | Range: 0.00 to 600.00 s in steps of 0.01   |
|                                                            | ⇕ | PMU 1 df/dt TRG BLK:<br>Off               | Range: FlexLogic operand                   |
|                                                            | ⇕ | PMU 1 df/dt TRIGGER<br>TARGET: Self-reset | Range: Self-reset, Latched, Disabled       |
|                                                            | ⇕ | PMU 1 df/dt TRIGGER<br>EVENTS: Disabled   | Range: Enabled, Disabled                   |

This element responds to frequency rate of change. Separate thresholds are provided for rising and dropping frequency. The trigger responds to the rate of change of frequency (df/dt) of the Phasor Measurement Unit (PMU) source.

#### PMU 1 df/dt TRIGGER FUNCTION

This setting enables or disabled the power trigger function.

#### PMU 1 df/dt TRIGGER RAISE

This setting specifies the pickup threshold for the rate of change of frequency in the raising direction (positive df/dt). The comparator applies a 4% hysteresis.

#### PMU 1 df/dt TRIGGER FALL

This setting specifies the pickup threshold for the rate of change of frequency in the falling direction (negative df/dt). The comparator applies a 4% hysteresis.

#### PMU 1 df/dt TRIGGER PKP TIME

This setting is used to filter out spurious conditions and avoid unnecessary triggering of the recorder.

#### PMU 1 df/dt TRIGGER DPO TIME

This setting is used to extend the trigger after the situation returns to normal. This setting is of importance when using the recorder in the forced mode (recording as long as the triggering condition is asserted).




Figure 253: Rate of Change of frequency trigger logic

### 8.5.8.4 PMU RECORDING

Setting path: **SETTINGS > SYSTEM SETUP > PHASOR MEASUREMENT UNIT > PHASOR MEASUREMENT UNIT 1 > PMU TRIGGERING > PMU 1 RECORDING**

|                                                    |   |                                            |                                       |
|----------------------------------------------------|---|--------------------------------------------|---------------------------------------|
| <div> <div>PMU 1</div> <div>RECORDING</div> </div> | ⇔ | PMU 1 FUNCTION:<br>Disabled                | Range: Enabled, Disabled              |
|                                                    | ⇕ | PMU 1 NO OF TIMED<br>RECORDS: 10           | Range: 2 to 128 in steps of 1         |
|                                                    | ⇕ | PMU 1 TRIGGER MODE:<br>Automatic Overwrite | Range: Automatic Overwrite, Protected |
|                                                    | ↑ | PMU 1 TIMED TRIGGER<br>POSITION: 10%       | Range: 1 to 50% in steps of 1         |

The length of the PMU record is variable. It depends on some settings and configuration, such as **PMU 1 NO OF TIMED RECORDS**, **PMU 1 RATE**, the number of Synchrophasors etc. There is a fixed amount of data storage for PMU recording. The more records captured, the less the recording length captured per record. See the **ACTUAL VALUES > RECORDS > PMU RECORDS > PMU 1 RECORDING** menu to view the actual PMU record length captured per record. The following table provides sample configurations with corresponding seconds per record. The minimum number of PMU records is two. The third to fifth columns is the number of configured values recorded in each record.

| Records | Frames per sec. | Synchrophasors | Analogs | Digitals | Record length |
|---------|-----------------|----------------|---------|----------|---------------|
| 3       | 30              | 14             | 8       | 16       | 590.4         |
| 16      | 30              | 14             | 8       | 16       | 138.9         |
| 32      | 30              | 14             | 8       | 16       | 71.5          |
| 64      | 30              | 14             | 8       | 16       | 36.3          |
| 3       | 60              | 14             | 8       | 16       | 295.2         |
| 16      | 60              | 14             | 8       | 16       | 69.4          |
| 32      | 60              | 14             | 8       | 16       | 35.7          |
| 64      | 60              | 14             | 8       | 16       | 18.1          |

### PMU 1 FUNCTION

This setting enables or disables the recorder for PMU 1. The rate is fixed at the reporting rate set within the aggregator.

### PMU 1 NO OF TIMED RECORDS

This setting specifies the number of timed records that are available for a given logical PMU 1. The length of each record is equal to the available memory divided by the content size and number of records. As the number of records is increased, the available storage for each record is reduced. The relay supports a maximum of 128 records in either timed or forced mode.

### PMU 1 TRIGGER MODE

This setting specifies what happens when the recorder uses its entire available memory storage. With *Automatic Overwrite*, the last record is erased to facilitate new recording, when triggered. Under the “Protected” selection, the recorder stops creating new records when the entire memory is used up by the old uncleared records.


### PMU 1 TIMED TRIGGER POSITION

This setting specifies the amount of pre-trigger data as a percent of the entire record. This setting applies only to the timed mode of recording.

## 8.6 FLEXLOGIC SETTINGS

### 8.6.1 FLEXLOGIC EQUATION EDITOR

**SETTINGS > FLEXLOGIC > FLEXLOGIC EQUATION EDITOR**



There are 1,024 FlexLogic entries available, numbered from 1 to 1024, with default END entry settings. If a *Disabled* element is selected as a FlexLogic entry, the associated state flag is never set to 1. Press the +/- key when editing FlexLogic equations to quickly scan through the major parameter types.

There are two ways to create, edit and maintain the FlexLogic equations:

1. Using the FlexLogic Equation Editor available at **FlexLogic > FlexLogic Equation Editor**
2. Using the Logic Designer available at **Engineer > Logic Designer**


**Note:**  
*EnerVista Engineer is only available through the offline window of the EnerVista UR Setup.*

**Note:**  
*FlexLogic Equation Editor and Logic Designer are designed to be mutually exclusive as using them interchangeably to create, edit and maintain the FlexLogic equations may cause inconsistencies in the resulting equations. We recommend using only one of the two methods throughout the process.*

### 8.6.2 FLEXLOGIC TIMERS

**SETTINGS > FLEXLOGIC > FLEXLOGIC TIMERS > FLEXLOGIC TIMER <n>**

**Note:**  
*Only FLEXLOGIC TIMER 1 is shown*



There are a number of identical FlexLogic timers available. These timers are used as operators for FlexLogic equations.

#### TIMER 1 TYPE

Selects the time measurement unit.

**TIMER 1 PICKUP DELAY**

Sets the time delay to pickup. If a pickup delay is not required, set this function to 0.

**TIMER 1 DROPOUT DELAY**

Sets the time delay to dropout. If a dropout delay is not required, set this function to 0.

**8.6.3 FLEXELEMENTS****SETTINGS > FLEXLOGIC > FLEXELEMENTS > FLEXELEMENT <n>**

*Note:*  
Only FLEXELEMENT 1 is shown


|                                                      |   |                                        |                                               |
|------------------------------------------------------|---|----------------------------------------|-----------------------------------------------|
| <div> <div>■ FLEXELEMENT 1</div> <div>■</div> </div> | ⇔ | FLEXELEMENT 1<br>FUNCTION: Disabled    | Range: Disabled, Enabled                      |
|                                                      | ⇕ | FLEXELEMENT 1 NAME:<br>FxE 1           | Range: up to six alphanumeric characters      |
|                                                      | ⇕ | FLEXELEMENT 1 +IN:<br>Off              | Range: Off, any analog actual value parameter |
|                                                      | ⇕ | FLEXELEMENT 1 -IN:<br>Off              | Range: Off, any analog actual value parameter |
|                                                      | ⇕ | FLEXELEMENT 1 INPUT<br>MODE: SIGNED    | Range: SIGNED, ABSOLUTE                       |
|                                                      | ⇕ | FLEXELEMENT 1 COMP<br>MODE: LEVEL      | Range: LEVEL, DELTA                           |
|                                                      | ⇕ | FLEXELEMENT 1<br>DIRECTION: OVER       | Range: OVER, UNDER                            |
|                                                      | ⇕ | FLEXELEMENT 1<br>PICKUP: 1.000 pu      | Range: -90.000 to 90.000 pu in steps of 0.001 |
|                                                      |   | FLEXELEMENT 1<br>HYSTERESIS: 3.0%      | Range: 0.1 to 50.0% in steps of 0.1           |
|                                                      |   | FLEXELEMENT 1 dt<br>UNIT: Milliseconds | Range: Milliseconds, Seconds, Minutes         |
|                                                      |   | FLEXELEMENT 1 dt:<br>20                | Range: 20 to 86400 in steps of 1              |
|                                                      |   | FLEXELEMENT 1 PKP<br>DELAY: 0.000 s    | Range: 0.000 to 65.535 s in steps of 0.001    |
|                                                      |   | FLEXELEMENT 1 RST<br>DELAY: 0.000 s    | Range: 0.000 to 65.535 s in steps of 0.001    |
|                                                      |   | FLEXELEMENT 1 BLK:<br>Off              | Range: FlexLogic operand                      |
|                                                      |   | FLEXELEMENT 1<br>TARGET: Self-reset    | Range: Self-reset, Disabled, Latched          |
|                                                      | ↑ | FLEXELEMENT 1<br>EVENTS: Disabled      | Range: Disabled, Enabled                      |



A FlexElement is a universal comparator used to monitor any analog actual value calculated by the relay or a net difference of any two analog actual values of the same type. The effective operating signal can be treated as a signed number or its absolute value can be used.

FlexElements run every half power cycle (every four protection passes).

The element can be programmed to respond either to a signal level or to a rate-of-change (delta) over a pre-defined period of time. The output operand is asserted when the operating signal is higher than a threshold or lower than a threshold, as per your choice.



842004A4.CDR

Figure 254: FlexElement logic

### FLEXELEMENT 1 +IN

This setting specifies the first (non-inverted) input to the FlexElement. Zero is assumed as the input if this setting is set to *Off*. For proper operation of the element, at least one input must be selected. Otherwise, the element does not assert its output operands.

**Note:**

Filter the *InputPlus* or *InputMinus* field in the software by double-clicking it, then entering a value.

### FLEXELEMENT 1 -IN

Specifies the second (inverted) input to the FlexElement. Zero is assumed as the input if this setting is set to *Off*. For proper operation of the element, at least one input must be selected. Otherwise, the element does not assert its output operands. This input is used to invert the signal if needed for convenience, or to make the element respond to a differential signal, such as for a top-bottom oil temperature differential alarm. The element does not operate if the two input signals are of different types, for example if one tries to use active power and phase angle to build the effective operating signal.


The element responds directly to the differential signal if the **FLEXELEMENT 1 INPUT MODE** setting is set to *Signed*. The element responds to the absolute value of the differential signal if this setting is set to *Absolute*. Sample applications for the *Absolute* setting include monitoring the angular difference between two phasors with a symmetrical limit angle in both directions, monitoring power regardless of its direction, or monitoring a trend.

The element responds directly to its operating signal—as defined by the **FLEXELEMENT 1 +IN**, **FLEXELEMENT 1 -IN** and **FLEXELEMENT 1 INPUT MODE** settings—if the **FLEXELEMENT 1 COMP MODE** setting is set to *Level*. The element responds to the rate of change of its operating signal if the **FLEXELEMENT 1 COMP MODE** setting is

set to *Delta*. In this case, the **FLEXELEMENT 1 dt UNIT** and **FLEXELEMENT 1 dt** settings specify how the rate of change is derived.


### FLEXELEMENT 1 DIRECTION

Enables the relay to respond to either high or low values of the operating signal. The following figure explains the application of the **FLEXELEMENT 1 DIRECTION**, **FLEXELEMENT 1 PICKUP**, and **FLEXELEMENT 1 HYSTERESIS** settings.



**Figure 255: FlexElement direction, pickup, and hysteresis**

In conjunction with the **FLEXELEMENT 1 INPUT MODE** setting, the element can be programmed to provide two extra characteristics, as shown in the following figure.



**Figure 256: FlexElement input mode setting**

### FLEXELEMENT 1 PICKUP

This setting specifies the operating threshold for the effective operating signal of the element. If set to *Over*, the element picks up when the operating signal exceeds the **FLEXELEMENT 1 PICKUP** value. If set to *Under*, the element picks up when the operating signal falls below the **FLEXELEMENT 1 PICKUP** value.

When using FlexElements for Voltage Elements, 1 pu is always equal to phase to ground voltage nominal secondary voltage, even if you select a phase to phase voltage as an operating quantity. The **FLEXELEMENT 1 PICKUP** setting is entered in per-unit values using the definitions of the base units, as described later.

### FLEXELEMENT 1 HYSTERESIS

This setting defines the pickup–dropout relation of the element by specifying the width of the hysteresis loop as a percentage of the pickup value as shown in the FlexElement Direction, Pickup, and Hysteresis diagram. The **FLEXELEMENT 1 PICKUP** setting is entered in per-unit values using the following definitions of the base units, shown in the next section.

### FLEXELEMENT 1 dt UNIT

Specifies the time unit for the setting **FLEXELEMENT 1 dt**. This setting is applicable only if **FLEXELEMENT 1 COMP MODE** is set to *Delta*.

**FLEXELEMENT 1 dt**

Specifies duration of the time interval for the rate of change mode of operation. This setting is applicable only if **FLEXELEMENT 1 COMP MODE** is set to *Delta*.

**FLEXELEMENT 1 PKP DELAY**

Specifies the pickup delay of the element.

**FLEXELEMENT 1 RST DELAY**

Specifies the reset delay of the element.

**Note:**

The Bus Differential FlexAnalog parameters applied in the settings **FLEXELEMENT 1 +IN** and **FLEXELEMENT 1 -IN** must be from the same zone.

**8.6.3.1 FLEXELEMENT BASE UNITS**

| Unit                                                                                                                                             | Description                                                                                                                                                                                                                        |
|--------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 87L SIGNALS<br>(Local IA Mag, IB, and IC)<br>(Diff Curr IA Mag, IB, and IC)<br>(Terminal 1 IA Mag, IB, and IC)<br>(Terminal 2 IA Mag, IB and IC) | IBASE = maximum primary RMS value of the +IN and -IN inputs<br>(CT primary for source currents, and 87L source primary current for line differential currents)<br>(L30, L90)                                                       |
| 87L SIGNALS<br>(Op Square Curr IA, IB, and IC)<br>(Rest Square Curr IA, IB, and IC)                                                              | BASE = Squared CT secondary of the 87L source<br>(L30, L90)                                                                                                                                                                        |
| BREAKER ACC ARCING AMPS<br>(Brk X Acc Arc Amp A, B, and C)                                                                                       | BASE = 2000 kA <sup>2</sup> · cycle<br>(All but B90, C30, N60)                                                                                                                                                                     |
| BREAKER ARCING AMPS<br>(Brk X Arc Amp A, B, and C)                                                                                               | BASE = 1 kA <sup>2</sup> · cycle<br>(All but B90, C30, N60)                                                                                                                                                                        |
| BUS DIFFERENTIAL DIFFERENTIAL CURRENT<br>(Bus Diff Mag)                                                                                          | IBASE = maximum phase CT primary current of all configured bays (sources) for a given bus differential zone of the +IN and -IN inputs<br>(B30)                                                                                     |
| BUS DIFFERENTIAL RESTRAINING CURRENT<br>(Bus Rest Mag)                                                                                           | IBASE = maximum phase CT primary current of all configured bays (sources) for a given bus differential zone of the +IN and -IN inputs<br>(B30)                                                                                     |
| BUS GROUND DIFFERENTIAL DIFFERENTIAL CURRENT<br>(Bus Ground Diff Mag)                                                                            | IBASE = maximum ground CT primary current of all configured bays (sources) for a given bus differential zone of the +IN and -IN inputs for "Measured" option or maximum phase CT primary current for "Calculated" option.<br>(B30) |
| BUS GROUND DIFFERENTIAL RESTRAINING CURRENT (Bus Ground Rest Mag)                                                                                | IBASE = maximum ground CT primary current of all configured bays (sources) for a given bus differential zone of the +IN and -IN inputs for "Measured" option or maximum phase CT primary current for "Calculated" option.<br>(B30) |
| CURRENT UNBALANCE<br>(Amp Unbalance)                                                                                                             | BASE = 100%<br>(M60)                                                                                                                                                                                                               |
| DCmA                                                                                                                                             | BASE = maximum value of the DCMA INPUT MAX setting for the two transducers configured under the +IN and -IN inputs<br>(All UR products)                                                                                            |
| DELTA TIME                                                                                                                                       | BASE = 1 μs<br>(All UR products)                                                                                                                                                                                                   |
| FAULT LOCATION                                                                                                                                   | BASE = Line Length as specified in Fault Report<br>(C60, C95, D30, D60, F35, F60, L30, L60, L90)                                                                                                                                   |

| Unit                                                                                  | Description                                                                                                                                                                                      |
|---------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FIELD CURRENT                                                                         | IBASE = maximum value setting defined for the specific transducer input configured<br>(G60 only)                                                                                                 |
| FIELD GROUND CURRENT                                                                  | IBASE = 5 mA<br>(G60 only)                                                                                                                                                                       |
| FIELD GROUND FAULT LOCATION                                                           | BASE = 100%<br>(G60 only)                                                                                                                                                                        |
| FIELD GROUND INJECTED VOLTAGE                                                         | VBASE = 15 V<br>(G60 only)                                                                                                                                                                       |
| FIELD GROUND RESISTANCE                                                               | RBASE = 250 KΩ<br><br>(G60 only)                                                                                                                                                                 |
| FIELD VOLTAGE                                                                         | VBASE = 500 V<br><br>(G60 only)                                                                                                                                                                  |
| FREQUENCY                                                                             | fBASE = 1 Hz<br>(All UR products)                                                                                                                                                                |
| FREQUENCY RATE OF CHANGE                                                              | df/dtBASE = 1 Hz/s<br>(D30, D60, F60, G30, G60, L30, L90, N60, T60)                                                                                                                              |
| MSOD FREQ_OSC                                                                         | 1 Hz<br>(D60, G30, G60, L90, N60, T60)                                                                                                                                                           |
| MSOD MAG_OSC                                                                          | 1 pu<br>(D60, G30, G60, L90, N60, T60)                                                                                                                                                           |
| MSOD PHASE_OSC                                                                        | 360 degrees<br>(D60, G30, G60, L90, N60, T60)                                                                                                                                                    |
| MSOD DAMPR_OSC                                                                        | 1%<br>(D60, G30, G60, L90, N60, T60)                                                                                                                                                             |
| PHASE ANGLE                                                                           | jBASE = 360 degrees (see the UR angle referencing convention)<br>(All UR products)                                                                                                               |
| POWER FACTOR                                                                          | PFBASE = 1.00<br>(All UR products)                                                                                                                                                               |
| RTDs                                                                                  | BASE = 100°C<br>(All UR products)                                                                                                                                                                |
| SENSITIVE DIR POWER<br>(Sns Dir Power)                                                | PBASE = maximum value of 3 x VBASE x IBASE for the +IN and –IN inputs of the sources configured for the sensitive power directional element(s).<br>(C60, C95, D60, F60, G30, G60, L90, N60, T60) |
| SOURCE CURRENT                                                                        | IBASE = maximum nominal primary RMS value of the +IN and –IN inputs<br>(All UR products)                                                                                                         |
| SOURCE ENERGY<br>(Positive and Negative Watthours,<br>Positive and Negative Varhours) | EBASE = 10000 MWh or MVAh, respectively<br>(B30, C60, C95, D60, F35, F60, G30, G60, L90, M60, N60, T60)                                                                                          |
| SOURCE POWER                                                                          | PBASE = maximum value of VBASE x IBASE for the +IN and –IN inputs<br>(All UR products)                                                                                                           |
| SOURCE THD & HARMONICS                                                                | BASE = 1%<br>C70, D60, F35, F60, G30, G60, L30, L90, N60, T60                                                                                                                                    |
| SOURCE VOLTAGE                                                                        | VBASE = maximum nominal primary RMS value of the +IN and –IN inputs<br>(All UR products)                                                                                                         |
| STATION BATTERY VOLTAGE<br>MEASUREMENT                                                | V <sub>DC_BASE</sub> = <b>STATION BATTERY NOM VOLTAGE</b> setting<br>(All UR products)                                                                                                           |

| Unit                                                                                                                   | Description                                                                                                                                                                                         |
|------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| STATOR DIFFERENTIAL CURRENT<br>(Stator Diff Iar, Ibr, and Icr)                                                         | IBASE = maximum primary RMS value of the +IN and -IN inputs<br>(CT primary for source currents, and bus reference primary current for bus differential currents)<br>(G60, M60)                      |
| STATOR GROUND 3RD HARMONIC VOLTAGES<br>(Stator Gnd Vn/V0 3rd)                                                          | VBASE = Primary auxiliary voltage of the STATOR GROUND SOURCE<br>(G60, M60)                                                                                                                         |
| STATOR GROUND RESISTANCE                                                                                               | RBASE = 10 K $\Omega$<br>(G60)                                                                                                                                                                      |
| STATOR GROUND SUB-HARMONIC VOLTAGE                                                                                     | VBASE = nominal secondary voltage of auxiliary VT for the stator ground source<br>(G60)                                                                                                             |
| STATOR GROUND SUB-HARMONIC CURRENT                                                                                     | IBASE = ground CT primary current of stator ground source<br>(G60)                                                                                                                                  |
| STATOR RESTRAINING CURRENT<br>(Stator Diff Iad, Ibd, and Icd)                                                          | IBASE = maximum primary RMS value of the +IN and -IN inputs<br>(CT primary for source currents, and bus reference primary current for bus differential currents)<br>(G60, M60)                      |
| SYNCHROCHECK<br>(Max Delta Volts)                                                                                      | VBASE = maximum primary RMS value of all the sources related to the +IN and -IN inputs<br>(B30, C60, C95, D30, D60, F60, G30, G60, L30, L60, L90, N60, T60)                                         |
| THERMAL MODEL<br>(Model Capacity Used)<br>(Model Motor Unbalance)                                                      | BASE = 100%<br>(M60)                                                                                                                                                                                |
| THERMAL MODEL<br>(Model Lockout Time)                                                                                  | BASE = 10 minutes<br>(M60)                                                                                                                                                                          |
| THERMAL MODEL<br>(Thermal Model Load)<br>(Biased Motor Load)                                                           | BASE = 1.00 pu of FLA<br>(M60)                                                                                                                                                                      |
| THERMAL MODEL<br>(Trip Time on Overload)                                                                               | BASE = 10 seconds<br>(M60)                                                                                                                                                                          |
| THRU FLT x TOT ACC A<br>THRU FLT x TOT ACC B<br>THRU FLT x TOT ACC C<br>Transformer total thermal/mechanical damage    | BASE = 1.00 pu<br>(T35, T60)                                                                                                                                                                        |
| VOLTS PER HERTZ                                                                                                        | BASE = 1.00 pu<br>(G30, G60, L90, T60)                                                                                                                                                              |
| XFMR DIFFERENTIAL CURRENT<br>(Xfmr Iad, Ibd, and Icd Mag)                                                              | IBASE = maximum primary RMS value of the +IN and -IN inputs<br>(CT primary for source currents, and transformer reference primary current for transformer differential currents)<br>(G30, T35, T60) |
| XFMR VOLTAGE COMPENSATED DIFFERENTIAL CURRENT<br>(Intturn# Cmp Iad Mag, Intturn# Cmp IBd Mag and Intturn# Cmp Icd Mag) | IBASE = maximum primary RMS value of the +IN and -IN inputs<br>(CT primary for source currents, and transformer reference primary current for transformer differential currents)<br>(T35, T60)      |
| XFMR RAW DIFFERENTIAL CURRENT<br>(Intturn# Raw Iad Mag, Intturn# Raw IBd Mag and Intturn# Raw Icd Mag)                 | IBASE = maximum primary RMS value of the +IN and -IN inputs<br>(CT primary for source currents, and transformer reference primary current for transformer differential currents)<br>(T35, T60)      |
| INTERTURN FAULT DETECTION COEFFICIENTS<br>(Intturn# Coef Ka Mag, Intturn# Coef Kb Mag, Intturn# Coef Kc Mag)           | BASE=0.1<br>(T35, T60)                                                                                                                                                                              |
| XFMR DIFFERENTIAL HARMONIC CONTENT<br>(Xfmr Harm2 Iad, Ibd, and Icd Mag)<br>(Xfmr Harm5 Iad, Ibd, and Icd Mag)         | BASE = 10%<br>(G30, T35, T60)                                                                                                                                                                       |

| Unit                                                     | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|----------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| XFMR RESTRAINING CURRENT<br>(Xfmr Iar, Ibr, and Icr Mag) | IBASE = maximum primary RMS value of the +IN and -IN inputs<br>(CT primary for source currents, and transformer reference primary current for transformer differential currents)<br>(G30, T35, T60)                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| ZBASE                                                    | ZBASE = PhaseVTSecondary / PhaseCTSecondary, where PhaseVTSecondary and PhaseCTSecondary are the secondary nominal voltage and the secondary nominal current of the distance source. In case multiple CT inputs are summed as one source current and mapped as the distance source, use the PhaseCTSecondary value from the CT with the highest primary nominal current.<br>Distance source is specified in setting under SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > DISTANCE.<br>PhaseVTSecondary and PhaseCTSecondary are specified in setting under SETTINGS > SYSTEM SETUP > AC INPUTS.<br>(D30, D60, G60, L60, L90, T60) |

### 8.6.4 NON-VOLATILE LATCHES

**SETTINGS > FLEXLOGIC > NON-VOLATILE LATCHES > LATCH <n>**

*Note:*  
Only Latch 1 is shown

|                                                |   |                                 |                                         |
|------------------------------------------------|---|---------------------------------|-----------------------------------------|
| <div> <div>■ LATCH 1</div> <div>■</div> </div> | ⇔ | LATCH 1<br>FUNCTION: Disabled   | Range: Disabled, Enabled                |
|                                                | ⇕ | LATCH 1 ID:<br>NV Latch 1       | Range: up to 20 alphanumeric characters |
|                                                | ⇕ | LATCH 1 TYPE:<br>Reset Dominant | Range: Reset Dominant, Set Dominant     |
|                                                | ⇕ | LATCH 1 SET:<br>Off             | Range: FlexLogic operand                |
|                                                | ⇕ | LATCH 1 RESET:<br>Off           | Range: FlexLogic operand                |
|                                                | ⇕ | LATCH 1<br>TARGET: Self-reset   | Range: Self-reset, Latched, Disabled    |
|                                                | ↑ | LATCH 1<br>EVENTS: Disabled     | Range: Disabled, Enabled                |

The non-volatile latches provide a permanent logical flag that is stored safely and do not reset upon restart after the relay is powered down. Typical applications include sustaining operator commands or permanently blocking relay functions, such as Autorecloser, until a deliberate interface action resets the latch.

#### LATCH 1 TYPE

This setting characterizes Latch 1 to be Set- or Reset-dominant.

#### LATCH 1 SET

If asserted, the specified FlexLogic operands sets Latch 1.

#### LATCH 1 RESET

If asserted, the specified FlexLogic operand resets Latch 1.




Figure 257: Non-volatile latch operation table and latch logic



# 8.7 GROUPED ELEMENTS

Each protection element can be assigned up to six sets of settings with designations 1 to 6. The performance of these elements is defined by the active setting group at a given time. Multiple setting groups allow the user to conveniently change protection settings for different operating situations (for example, altered power system configuration or season of the year). The active setting group can be preset or selected in the SETTING GROUPS menu.

## 8.7.1 SETTING GROUP 1

Each of the six setting group menus is identical. Setting group 1 (the default active group) is active automatically when no other group is active.

Setting path: **SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6)**

|                                           |   |                                                     |
|-------------------------------------------|---|-----------------------------------------------------|
| <div>■ SETTING GROUP 1</div> <div>■</div> | ⇔ | <div>■ TRANSFORMER</div> <div>■</div>               |
|                                           | ⇕ | <div>■ PHASE CURRENT</div> <div>■</div>             |
|                                           | ⇕ | <div>■ NEUTRAL CURRENT</div> <div>■</div>           |
|                                           | ⇕ | <div>■ GROUND CURRENT</div> <div>■</div>            |
|                                           | ⇕ | <div>■ NEGATIVE SEQUENCE CURRENT</div> <div>■</div> |
|                                           | ⇕ | <div>■ GENERATOR UNBALANCE</div> <div>■</div>       |
|                                           | ⇕ | <div>■ SPLIT PHASE</div> <div>■</div>               |
|                                           | ⇕ | <div>■ VOLTAGE ELEMENTS</div> <div>■</div>          |
|                                           | ⇕ | <div>■ LOSS OF EXCITATION</div> <div>■</div>        |
|                                           | ⇕ | <div>■ ACCIDENTAL ENERGIZATION</div> <div>■</div>   |
|                                           | ⇕ | <div>■ POWER</div> <div>■</div>                     |
|                                           | ↑ | <div>■ STATOR</div> <div>■ GROUND</div>             |

## 8.7.2 TRANSFORMER

### 8.7.2.1 TRANSFORMER MENU

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > TRANSFORMER**

|                                       |   |                                                |
|---------------------------------------|---|------------------------------------------------|
| <div>■ TRANSFORMER</div> <div>■</div> | ⇔ | <div>■ PERCENT DIFFERENTIAL</div> <div>■</div> |
|---------------------------------------|---|------------------------------------------------|

|   |                                 |
|---|---------------------------------|
| ⇅ | ■ HOTTEST-SPOT<br>■ TEMPERATURE |
| ⇅ | ■ AGING FACTOR<br>■             |
| ⇅ | ■ LOSS OF LIFE<br>■             |

### 8.7.2.2 TRANSFORMER PERCENT DIFFERENTIAL (ANSI 87T)

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > TRANSFORMER > PERCENT DIFFERENTIAL**

|                             |   |                                                   |                                                       |
|-----------------------------|---|---------------------------------------------------|-------------------------------------------------------|
| ■ PERCENT<br>■ DIFFERENTIAL | ⇅ | PERCENT DIFFERENTIAL<br>FUNCTION: Disabled        | Range: Disabled, Enabled                              |
|                             | ⇅ | PERCENT DIFFERENTIAL<br>PICKUP: 0.100 pu          | Range: 0.050 to 1.000 pu in steps of 0.001            |
|                             | ⇅ | PERCENT DIFFERENTIAL<br>SLOPE 1: 25%              | Range: 15 to 100% in steps of 1                       |
|                             | ⇅ | PERCENT DIFFERENTIAL<br>BREAK 1: 2.000 pu         | Range: 1.000 to 2.000 pu in steps of 0.001            |
|                             | ⇅ | PERCENT DIFFERENTIAL<br>BREAK 2: 8.000 pu         | Range: 2.000 to 30.000 pu in steps of 0.001           |
|                             | ⇅ | PERCENT DIFFERENTIAL<br>SLOPE 2: 90%              | Range: 20 to 100% in steps of 1                       |
|                             | ⇅ | INRUSH INHIBIT<br>FUNCTION: Adapt. 2nd            | Range: Disabled, Adapt. 2nd, Trad. 2nd                |
|                             | ⇅ | INRUSH INHIBIT<br>MODE: Per phase                 | Range: Per phase, 2-out-of-3, Average, 1-out-of-3     |
|                             | ⇅ | INRUSH INHIBIT<br>LEVEL: 20.0% f <sub>0</sub>     | Range: 1.0 to 40.0% of f <sub>0</sub> in steps of 0.1 |
|                             | ⇅ | OVEREXCITN INHIBIT<br>FUNCTION: Disabled          | Range: Disabled, 5th                                  |
|                             | ⇅ | OVEREXCITN INHIBIT<br>LEVEL: 10.0% f <sub>0</sub> | Range: 1.0 to 40.0% of f <sub>0</sub> in steps of 0.1 |
|                             | ⇅ | PERCENT DIFF BLOCK:<br>Off                        | Range: FlexLogic operand                              |
|                             | ⇅ | PERCENT DIFFERENTIAL<br>TARGET: Self-reset        | Range: Self-reset, Latched, Disabled                  |
|                             | ⇅ | PERCENT DIFFERENTIAL<br>EVENTS: Disabled          | Range: Disabled, Enabled                              |

The calculation of differential ( $I_d$ ) and restraint ( $I_r$ ) currents for the purposes of the percent differential element is described by the following block diagram, where “Σ” has as its output the vector sum of inputs, and “max” has as its output the input of maximum magnitude; these calculations are performed for each phase.

The differential current is calculated as a vector sum of currents from all windings after magnitude and angle compensation.

$$I_d = \overrightarrow{I_{1\_comp}} + \overrightarrow{I_{2\_comp}}$$

$$I_d = \overrightarrow{I_{1\_comp}} + \overrightarrow{I_{2\_comp}} + \overrightarrow{I_{3\_comp}} + \overrightarrow{I_{4\_comp}} + I_{5\_comp}$$

$$I_d = \overrightarrow{I_{1\_comp}} + \overrightarrow{I_{2\_comp}} + \overrightarrow{I_{3\_comp}} + \overrightarrow{I_{4\_comp}} + \overrightarrow{I_{5\_comp}} + \overrightarrow{I_{6\_comp}}$$


The restraint current is calculated as a maximum of the same internally compensated currents.

$$I_r = K \times \max(\overrightarrow{I_{1\_comp}}, \overrightarrow{I_{2\_comp}})$$

$$I_r = \max(\overrightarrow{I_{1\_comp}}, \overrightarrow{I_{2\_comp}}, \overrightarrow{I_{3\_comp}}, \overrightarrow{I_{4\_comp}}, \overrightarrow{I_{5\_comp}})$$

$$I_r = \max(\overrightarrow{I_{1\_comp}}, \overrightarrow{I_{2\_comp}}, \overrightarrow{I_{3\_comp}}, \overrightarrow{I_{4\_comp}}, \overrightarrow{I_{5\_comp}}, \overrightarrow{I_{6\_comp}})$$

The element operates if  $I_d > PKP$  and  $I_d / I_r > K$ , where PKP represents a percent differential pickup setting and K is a restraint factor defined by the relays settings Slope 1, Slope 2, and a transition area between breakpoint 1 and breakpoint 2 settings.



828714A1.CDR

**Figure 258: Percent differential calculations**

The percent differential element is based on a configurable dual-breakpoint / dual-slope differential restraint characteristic. The purpose of this characteristic is to define the differential/restraint ratio for the transformer winding currents at different loading and fault conditions to securely distinguish between external and internal faults. Increased differential current can occur under load or external fault conditions due to current unbalance between transformer windings and can be caused by the following:

- Inherent CT inaccuracies
- Onload tap changer operation: it adjusts the transformer ratio and consequently the winding currents
- CT saturation


To provide higher security during CT saturation conditions and to ease CT requirements, the Product incorporates a dedicated CT saturation detection mechanism. The Product CT saturation detector can detect saturation happening after approximately 3 ms from fault inception. In case CT saturation is detected, the percent differential is blocked

instantly and relies further on the directional element in case fault evolved from external to internal to operate without any delays. Directional element supervision is not applied if no CT saturation is detected.

The saturation detector is an integral part of the transformer percent differential element. It has no settings but uses some of the differential characteristic parameters. The flags indicating CT saturation are available on a per-phase basis as FlexLogic operands.

The directional principle is also an integral part of the transformer percent differential element and has no associated settings. The directional element dynamically identifies what appears to be the faulted circuit and compares its current angle with that of the sum of the remaining currents of the protected zone. The element declares a transformer internal fault if the angle is less than 90°. Directional indicating flags signal operation on a per-phase basis and are available as FlexLogic operands.

For more information on CT saturation detection and directional principle, see the Theory of Operation chapter.



828750A2.CDR

**Figure 259: Percent differential operating characteristic**

Settings are defined as follows.

#### PERCENT DIFFERENTIAL PICKUP

This setting defines the minimum differential current required for operation. It is chosen, based on the amount of differential current that can be seen under normal operating conditions. Two factors can create differential current during the normal transformer operation: errors due to CT inaccuracies and current variation due to on-load tap changer operation. To prevent the relay from picking up during normal operating conditions, configure this pickup setting at 10% or higher and take into account maximum magnitude compensation factor, that is

$$\text{PICKUP} \geq 0.1 \times \max(M[w]) \text{ pu}$$

where  $M$  is the magnitude compensation factor and  $w$  is the winding index. The magnitude compensation factor for each winding is explained in the Magnitude Compensation section earlier.

### PERCENT DIFFERENTIAL SLOPE 1

Defines the percentage bias for the restraining currents below the lower breakpoint (BREAK 1). This setting determines the sensitivity of the relay for low current internal faults. The setting must be set high enough to cope with the spurious differential current resulting from inaccuracy of the CTs operating in their linear mode, that is, in load conditions and during distant external faults.

### PERCENT DIFFERENTIAL BREAK 1

Defines the lower breakpoint of the dual-slope differential operating characteristic. This setting needs to be set above the maximum load current and can be moved to the AC current under which all the CTs are guaranteed to transform without saturation. This includes the effect of DC components and/or residual magnetism. The latter can be as high as 80% of the nominal flux, effectively reducing the CT capabilities by the factor of five. When adjusting this setting, it must be kept in mind that the restraining signal is created as the maximum of all the input currents.

### PERCENT DIFFERENTIAL BREAK 2

Defines the higher breakpoint of the dual-slope operating characteristic. Set **PERCENT DIFFERENTIAL BREAK 2** setting below the fault current that is likely to saturate the weakest CT feeding the relay. When adjusting this setting, keep in mind that the restraining signal is created as the maximum of all the input currents.

**Note:**

*You should allow enough separation between the breakpoint 1 and breakpoint 2 settings. This is required to correctly construct cubic spline characteristics between these two setpoints. If these two breakpoints are set to less than 0.3pu difference, breakpoint 2 will be forced to be higher than breakpoint 1 by 0.3pu.*

### PERCENT DIFFERENTIAL SLOPE 2

Defines the percentage bias for the restraining currents above the higher breakpoint (BREAK 2). This setting affects stability of the relay for heavy external faults. Traditionally, the value chosen for this setting needs to be high enough to accommodate the spurious differential current resulting from saturation of the CTs during heavy external faults. This requirement can be considerably relaxed in favor of sensitivity and speed of operation as the relay detects CT saturation and upon detection applies the directional principle to prevent maloperation. When adjusting this setting, keep in mind that the restraining signal is created as the maximum of all the input currents.

### INRUSH INHIBIT FUNCTION

This setting provides a choice for 2nd harmonic differential protection blocking during magnetizing inrush conditions. Two choices are available:

- *Adapt. 2nd* – adaptive 2nd harmonic
- *Trad. 2nd* – traditional 2nd harmonic blocking.

The adaptive 2nd harmonic restraint responds to magnitudes and phase angles of the 2nd harmonic and the fundamental frequency component. The traditional 2nd harmonic restraint responds to the ratio of magnitudes of the 2nd harmonic and fundamental frequency components. If low second harmonic ratios during magnetizing inrush conditions are not expected, set the relay to a traditional way of restraining.

### INRUSH INHIBIT MODE

This setting specifies mode of blocking on magnetizing inrush conditions. Modern transformers can produce small 2nd harmonic ratios during inrush conditions. This can result in undesired tripping of the protected transformer. Reducing the 2nd harmonic inhibit threshold can jeopardize dependability and speed of protection. The 2nd harmonic ratio, if low, causes problems in one phase only. This can be utilized as a means to ensure security by applying cross-phase blocking rather than lowering the inrush inhibit threshold.

If set to *Per phase*, the relay performs inrush inhibit individually in each phase. If used on modern transformers, combine this setting with adaptive 2nd harmonic function.

If set to *2-out-of-3*, the relay checks 2nd harmonic level in all three phases individually. If any two phases establish a blocking condition, the remaining phase is restrained automatically. Note that in this mode, the *2-out-of-3* logic is used only if all three phases of differential currents exceed the hardcoded cutoff level of 0.04 pu, otherwise, *1-out-of-3* logic is used.

If set to *Average*, the relay first calculates the average 2nd harmonic ratio, then applies the inrush threshold to the calculated average. This mode works only in conjunction with the traditional 2nd harmonic function.

If set to *1-out-of-3*, the relay checks 2nd harmonic level in all three phases individually. If any phase establishes a blocking condition, differential protection in all three phases are blocked. This mode is also known as "cross-blocking" method.

### INRUSH INHIBIT LEVEL

Specifies the level of 2nd harmonic component in the transformer magnetizing inrush current above which the percent differential element is inhibited from operating. The value of the **INRUSH INHIBIT MODE** setting must be taken into account when programming this value. The **INRUSH INHIBIT LEVEL** is set typically to 20%.


### OVEREXCITATION INHIBIT MODE

An overexcitation condition resulting from an increased volts/hertz ratio poses a danger to the protected transformer, hence the volts/hertz protection. A given transformer can, however, tolerate an overfluxing condition for a limited time, as the danger is associated with thermal processes in the core. Instantaneous tripping of the transformer from the differential protection is not desirable. The relay uses a traditional 5th harmonic ratio for inhibiting its differential function during overexcitation conditions.

### OVEREXCITATION INHIBIT LEVEL

This setting is provided to block the differential protection during overexcitation. When the 5th harmonic level exceeds the specified setting (5th harmonic ratio) the differential element is blocked. The overexcitation inhibit works on a per-phase basis.

The relay produces three FlexLogic operands that can be used for testing or for special applications, such as building custom logic (1-out-of-3) or supervising some protection functions (ground time overcurrent, for example) from the 2nd harmonic inhibit.



828004A1.CDR

Figure 260: Percent differential logic

### 8.7.2.3 HOTTEST-SPOT TEMPERATURE

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > TRANSFORMER > HOTTEST-SPOT TEMPERATURE**

|                                                                 |   |                                                                |                                      |
|-----------------------------------------------------------------|---|----------------------------------------------------------------|--------------------------------------|
| <div> <div>■ HOTTEST-SPOT</div> <div>■ TEMPERATURE</div> </div> | ⇔ | <div> <div>XFMR HST FUNCTION:</div> <div>Disabled</div> </div> | Range: Disabled, Enabled             |
|                                                                 | ⇕ | <div> <div>XFMR HST PICKUP:</div> <div>140°C</div> </div>      | Range: 50 to 300°C in steps of 1     |
|                                                                 | ⇕ | <div> <div>XFMR HST DELAY:</div> <div>1 min</div> </div>       | Range: 0 to 30000 min. in steps of 1 |
|                                                                 | ⇕ | <div> <div>XFMR HST BLOCK:</div> <div>Off</div> </div>         | Range: FlexLogic operand             |
|                                                                 | ⇕ | <div> <div>XFMR HST TARGET:</div> <div>Self-reset</div> </div> | Range: Self-reset, Latched, Disabled |
|                                                                 | ↑ | <div> <div>XFMR HST EVENTS:</div> <div>Disabled</div> </div>   | Range: Disabled, Enabled             |


The Hottest-Spot Temperature element provides a mechanism to detect abnormal winding hottest-spot temperatures inside the transformer. It can be set to alarm or trip in cases where the computed hottest-spot temperature is above the pickup threshold for a user-specified time (considered as transformer overheating).

### XFMR HST PICKUP

Enter the hottest-spot temperature required for operation of the element. Base this setting on the maximum permissible hottest-spot temperature under emergency transformer loading conditions and maximum ambient temperature.

### XFMR HST DELAY

Enter an appropriate time delay before operation of the element.



828731A4.cdr

Figure 261: Transformer hottest-spot temperature logic

### 8.7.2.4 AGING FACTOR

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > TRANSFORMER > AGING FACTOR**

|                                                     |   |                                                                    |                                       |
|-----------------------------------------------------|---|--------------------------------------------------------------------|---------------------------------------|
| <div> <div>■ AGING FACTOR</div> <div>■</div> </div> | ⇔ | <div> <div>AGING FACTOR</div> <div>FUNCTION: Disabled</div> </div> | Range: Disabled, Enabled              |
|                                                     | ⇕ | <div> <div>AGING FACTOR</div> <div>PICKUP: 2.0 pu</div> </div>     | Range: 1.1 to 10.0 pu in steps of 0.1 |



|   |                                    |                                      |
|---|------------------------------------|--------------------------------------|
| ⇅ | AGING FACTOR<br>DELAY: 10 min      | Range: 0 to 30000 min. in steps of 1 |
| ⇅ | AGING FACTOR BLOCK:<br>Off         | Range: FlexLogic operand             |
| ⇅ | AGING FACTOR TARGET:<br>Self-reset | Range: Self-reset, Latched, Disabled |
| ↑ | AGING FACTOR EVENTS:<br>Disabled   | Range: Disabled, Enabled             |

The Aging Factor element detects transformer aging in per-unit normal insulation aging. The element can be set to alarm or trip whenever the computed aging factor is greater than the user-defined pickup setting for the specified time delay.

### AGING FACTOR PICKUP

Enter a value above which the aging factor element is to operate. Enter a setting greater than the maximum permissible aging factor under emergency loading conditions and maximum ambient temperature.




Figure 262: Transformer aging factor logic

### 8.7.2.5 LOSS OF LIFE

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > TRANSFORMER > LOSS OF LIFE**

|                |   |                                      |                                       |
|----------------|---|--------------------------------------|---------------------------------------|
| ■ LOSS OF LIFE | ⇅ | LOSS OF LIFE<br>FUNCTION: Disabled   | Range: Disabled, Enabled              |
| ■              | ⇅ | LOSS OF LIFE INITIAL<br>VALUE: 0 hrs | Range: 0 to 500000 hrs. in steps of 1 |
|                | ⇅ | LOSS OF LIFE<br>PICKUP: 180000 hrs   | Range: 0 to 500000 hrs. in steps of 1 |
|                | ⇅ | LOSS OF LIFE BLOCK:<br>Off           | Range: FlexLogic operand              |
|                | ⇅ | LOSS OF LIFE TARGET:<br>Self-reset   | Range: Self-reset, Latched, Disabled  |
|                | ↑ | LOSS OF LIFE EVENT:<br>Disabled      | Range: Disabled, Enabled              |

The Loss of Life element detects the accumulated total consumed transformer life. This element can be set to issue an alarm or trip when the actual accumulated transformer life becomes larger than the user-specified loss of life

pickup value. For new transformers installations, set the **XFMR INITIAL LOSS OF LIFE** setting to 0. For previously installed transformers, pre-determine the consumed transformer life in hours.

### LOSS OF LIFE INITIAL VALUE

Enter a setting for the consumed transformer life in hours. When the Loss of Life element is enabled, the computed loss of life is added to the initial loss of life.

### LOSS OF LIFE PICKUP

Enter the expended life, in hours, required for operation of the element. Set this setting above the total transformer life set as a reference based on nominal loading conditions and a 30°C ambient temperature, as outlined in the IEEE standards.





Figure 263: Transformer loss of life logic

## 8.7.3 PHASE CURRENT

### SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > PHASE CURRENT



Note:  
n = number of elements

### 8.7.3.1 INVERSE TOC CURVE CHARACTERISTICS

The inverse time overcurrent curves used by the time overcurrent elements are the IEEE, IEC, GE Type IAC, and I2t standard curve shapes. This allows for simplified coordination with downstream devices.

If none of these curve shapes is adequate, FlexCurves can be used to customize the inverse time curve characteristics. The definite time curve is also an option that can be appropriate if only simple protection is required.

#### Overcurrent curve types

| IEEE                   | IEC                 | GE type IAC           | Other |
|------------------------|---------------------|-----------------------|-------|
| IEEE Extremely Inverse | IEC Curve A (BS142) | IAC Extremely Inverse | I2t   |

| IEEE                    | IEC                 | GE type IAC       | Other                     |
|-------------------------|---------------------|-------------------|---------------------------|
| IEEE Very Inverse       | IEC Curve B (BS142) | IAC Very Inverse  | FlexCurves A, B, C, and D |
| IEEE Moderately Inverse | IEC Curve C (BS142) | IAC Inverse       | Recloser Curves           |
|                         | IEC Short Inverse   | IAC Short Inverse | Definite Time             |

A time dial multiplier setting allows selection of a multiple of the base curve shape (where the time dial multiplier = 1) with the curve shape setting (**CURVE**). Unlike the electromechanical time dial equivalent, operate times are directly proportional to the time multiplier setting (**TD MULTIPLIER**). For example, all times for a multiplier of 10 are 10 times the multiplier 1 or base curve values. Setting the multiplier to zero results in an instantaneous response to all current levels above pickup.

Time overcurrent time calculations are made with an internal energy capacity memory variable. When this variable indicates that the energy capacity has reached 100%, a time overcurrent element operates. If less than 100% energy capacity is accumulated in this variable and the current falls below the dropout threshold of 97 to 98% of the pickup value, the variable must be reduced. Two methods of this resetting operation are available: “Instantaneous” and “Timed.” The “Instantaneous” selection is intended for applications with other relays, such as most static relays, which set the energy capacity directly to zero when the current falls below the reset threshold. The “Timed” selection can be used where the relay must coordinate with electromechanical relays.

The URs calculate operate time corresponding to the values in the range of 1.03 to 20 multiples of the pickup current. Above 20 multiples of the pickup current, URs clamp the operate time to the value at a multiple of 20, resulting in the flat part of the characteristics. Reset time is calculated in the range of 0 to 0.97 multiples of the pickup current.

### IEEE Curves

The IEEE time overcurrent curve shapes conform to industry standards and the IEEE C37.112-1996 curve classifications for extremely, very, and moderately inverse curves. The IEEE curves are derived from the operate and reset time equations.

$$T = \text{TDM} \times \left[ \frac{A}{\left( \frac{I}{I_{\text{pickup}}} \right)^p - 1} + B \right], T_{\text{RESET}} = \text{TDM} \times \left[ \frac{t_r}{1 - \left( \frac{I}{I_{\text{pickup}}} \right)^2} \right]$$

where:

- T = operate time (in seconds)
- TDM = Multiplier setting
- I = input current
- $I_{\text{pickup}}$  = Pickup Current setting
- A, B, p = constants defined in the table
- $T_{\text{RESET}}$  = reset time in seconds (assuming energy capacity is 100% and RESET is “Timed”)
- $t_r$  = characteristic constant defined in the table

### IEEE inverse time curve constants

| IEEE curve shape        | A      | B      | p       | $t_r$ |
|-------------------------|--------|--------|---------|-------|
| IEEE Extremely Inverse  | 28.2   | 0.1217 | 2.0000  | 29.1  |
| IEEE Very Inverse       | 19.61  | 0.491  | 2.0000  | 21.6  |
| IEEE Moderately Inverse | 0.0515 | 0.1140 | 0.02000 | 4.85  |

## IEEE curve trip times (in seconds)

| Multiplier<br>(TDM)     | Current ( I / I <sub>pickup</sub> ) |        |        |        |        |        |        |        |        |        |
|-------------------------|-------------------------------------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
|                         | 1.5                                 | 2.0    | 3.0    | 4.0    | 5.0    | 6.0    | 7.0    | 8.0    | 9.0    | 10.0   |
| IEEE Extremely Inverse  |                                     |        |        |        |        |        |        |        |        |        |
| 0.5                     | 11.341                              | 4.761  | 1.823  | 1.001  | 0.648  | 0.464  | 0.355  | 0.285  | 0.237  | 0.203  |
| 1.0                     | 22.682                              | 9.522  | 3.647  | 2.002  | 1.297  | 0.927  | 0.709  | 0.569  | 0.474  | 0.407  |
| 2.0                     | 45.363                              | 19.043 | 7.293  | 4.003  | 2.593  | 1.855  | 1.418  | 1.139  | 0.948  | 0.813  |
| 4.0                     | 90.727                              | 38.087 | 14.587 | 8.007  | 5.187  | 3.710  | 2.837  | 2.277  | 1.897  | 1.626  |
| 6.0                     | 136.090                             | 57.130 | 21.880 | 12.010 | 7.780  | 5.564  | 4.255  | 3.416  | 2.845  | 2.439  |
| 8.0                     | 181.454                             | 76.174 | 29.174 | 16.014 | 10.374 | 7.419  | 5.674  | 4.555  | 3.794  | 3.252  |
| 10.0                    | 226.817                             | 95.217 | 36.467 | 20.017 | 12.967 | 9.274  | 7.092  | 5.693  | 4.742  | 4.065  |
| IEEE Very Inverse       |                                     |        |        |        |        |        |        |        |        |        |
| 0.5                     | 8.090                               | 3.514  | 1.471  | 0.899  | 0.654  | 0.526  | 0.450  | 0.401  | 0.368  | 0.345  |
| 1.0                     | 16.179                              | 7.028  | 2.942  | 1.798  | 1.308  | 1.051  | 0.900  | 0.802  | 0.736  | 0.689  |
| 2.0                     | 32.358                              | 14.055 | 5.885  | 3.597  | 2.616  | 2.103  | 1.799  | 1.605  | 1.472  | 1.378  |
| 4.0                     | 64.716                              | 28.111 | 11.769 | 7.193  | 5.232  | 4.205  | 3.598  | 3.209  | 2.945  | 2.756  |
| 6.0                     | 97.074                              | 42.166 | 17.654 | 10.790 | 7.849  | 6.308  | 5.397  | 4.814  | 4.417  | 4.134  |
| 8.0                     | 129.432                             | 56.221 | 23.538 | 14.387 | 10.465 | 8.410  | 7.196  | 6.418  | 5.889  | 5.513  |
| 10.0                    | 161.790                             | 70.277 | 29.423 | 17.983 | 13.081 | 10.513 | 8.995  | 8.023  | 7.361  | 6.891  |
| IEEE Moderately Inverse |                                     |        |        |        |        |        |        |        |        |        |
| 0.5                     | 3.220                               | 1.902  | 1.216  | 0.973  | 0.844  | 0.763  | 0.706  | 0.663  | 0.630  | 0.603  |
| 1.0                     | 6.439                               | 3.803  | 2.432  | 1.946  | 1.688  | 1.526  | 1.412  | 1.327  | 1.260  | 1.207  |
| 2.0                     | 12.878                              | 7.606  | 4.864  | 3.892  | 3.377  | 3.051  | 2.823  | 2.653  | 2.521  | 2.414  |
| 4.0                     | 25.756                              | 15.213 | 9.729  | 7.783  | 6.753  | 6.102  | 5.647  | 5.307  | 5.041  | 4.827  |
| 6.0                     | 38.634                              | 22.819 | 14.593 | 11.675 | 10.130 | 9.153  | 8.470  | 7.960  | 7.562  | 7.241  |
| 8.0                     | 51.512                              | 30.426 | 19.458 | 15.567 | 13.507 | 12.204 | 11.294 | 10.614 | 10.083 | 9.654  |
| 10.0                    | 64.390                              | 38.032 | 24.322 | 19.458 | 16.883 | 15.255 | 14.117 | 13.267 | 12.604 | 12.068 |

## IEC Curves:IEC; Overcurrent curves:IEC; Equations:IEC curves

For European applications, the relay offers three standard curves defined in IEC 255-4 and British standard BS142. These are defined as IEC Curve A, IEC Curve B, and IEC Curve C. The IEC curves are derived by the operate and reset time equations.

$$T = \text{TDM} \times \left[ \frac{K}{(I/I_{\text{pickup}})^E - 1} \right], \quad T_{\text{RESET}} = \text{TDM} \times \left[ \frac{t_r}{1 - (I/I_{\text{pickup}})^2} \right]$$

where:

- T = operate time (in seconds)
- TDM = Multiplier setting
- I = input current
- I<sub>pickup</sub> = Pickup Current setting
- K, E = constants defined in the table
- t<sub>r</sub> = characteristic constant defined in the table
- T<sub>RESET</sub> = reset time in seconds (assuming energy capacity is 100% and RESET is “Timed”)

**IEC (BS) inverse time curve constants**

| IEC (BS) curve shape | K      | E     | tr    |
|----------------------|--------|-------|-------|
| IEC Curve A (BS142)  | 0.140  | 0.020 | 9.7   |
| IEC Curve B (BS142)  | 13.500 | 1.000 | 43.2  |
| IEC Curve C (BS142)  | 80.000 | 2.000 | 58.2  |
| IEC Short Inverse    | 0.050  | 0.040 | 0.500 |

**IEC curve trip times (in seconds)**

| Multiplier<br>(TDM) | Current ( I / Ipickup) |        |        |       |       |       |       |       |       |       |
|---------------------|------------------------|--------|--------|-------|-------|-------|-------|-------|-------|-------|
|                     | 1.5                    | 2.0    | 3.0    | 4.0   | 5.0   | 6.0   | 7.0   | 8.0   | 9.0   | 10.0  |
| IEC Curve A         |                        |        |        |       |       |       |       |       |       |       |
| 0.05                | 0.860                  | 0.501  | 0.315  | 0.249 | 0.214 | 0.192 | 0.176 | 0.165 | 0.156 | 0.149 |
| 0.10                | 1.719                  | 1.003  | 0.630  | 0.498 | 0.428 | 0.384 | 0.353 | 0.330 | 0.312 | 0.297 |
| 0.20                | 3.439                  | 2.006  | 1.260  | 0.996 | 0.856 | 0.767 | 0.706 | 0.659 | 0.623 | 0.594 |
| 0.40                | 6.878                  | 4.012  | 2.521  | 1.992 | 1.712 | 1.535 | 1.411 | 1.319 | 1.247 | 1.188 |
| 0.60                | 10.317                 | 6.017  | 3.781  | 2.988 | 2.568 | 2.302 | 2.117 | 1.978 | 1.870 | 1.782 |
| 0.80                | 13.755                 | 8.023  | 5.042  | 3.984 | 3.424 | 3.070 | 2.822 | 2.637 | 2.493 | 2.376 |
| 1.00                | 17.194                 | 10.029 | 6.302  | 4.980 | 4.280 | 3.837 | 3.528 | 3.297 | 3.116 | 2.971 |
| IEC Curve B         |                        |        |        |       |       |       |       |       |       |       |
| 0.05                | 1.350                  | 0.675  | 0.338  | 0.225 | 0.169 | 0.135 | 0.113 | 0.096 | 0.084 | 0.075 |
| 0.10                | 2.700                  | 1.350  | 0.675  | 0.450 | 0.338 | 0.270 | 0.225 | 0.193 | 0.169 | 0.150 |
| 0.20                | 5.400                  | 2.700  | 1.350  | 0.900 | 0.675 | 0.540 | 0.450 | 0.386 | 0.338 | 0.300 |
| 0.40                | 10.800                 | 5.400  | 2.700  | 1.800 | 1.350 | 1.080 | 0.900 | 0.771 | 0.675 | 0.600 |
| 0.60                | 16.200                 | 8.100  | 4.050  | 2.700 | 2.025 | 1.620 | 1.350 | 1.157 | 1.013 | 0.900 |
| 0.80                | 21.600                 | 10.800 | 5.400  | 3.600 | 2.700 | 2.160 | 1.800 | 1.543 | 1.350 | 1.200 |
| 1.00                | 27.000                 | 13.500 | 6.750  | 4.500 | 3.375 | 2.700 | 2.250 | 1.929 | 1.688 | 1.500 |
| IEC Curve C         |                        |        |        |       |       |       |       |       |       |       |
| 0.05                | 3.200                  | 1.333  | 0.500  | 0.267 | 0.167 | 0.114 | 0.083 | 0.063 | 0.050 | 0.040 |
| 0.10                | 6.400                  | 2.667  | 1.000  | 0.533 | 0.333 | 0.229 | 0.167 | 0.127 | 0.100 | 0.081 |
| 0.20                | 12.800                 | 5.333  | 2.000  | 1.067 | 0.667 | 0.457 | 0.333 | 0.254 | 0.200 | 0.162 |
| 0.40                | 25.600                 | 10.667 | 4.000  | 2.133 | 1.333 | 0.914 | 0.667 | 0.508 | 0.400 | 0.323 |
| 0.60                | 38.400                 | 16.000 | 6.000  | 3.200 | 2.000 | 1.371 | 1.000 | 0.762 | 0.600 | 0.485 |
| 0.80                | 51.200                 | 21.333 | 8.000  | 4.267 | 2.667 | 1.829 | 1.333 | 1.016 | 0.800 | 0.646 |
| 1.00                | 64.000                 | 26.667 | 10.000 | 5.333 | 3.333 | 2.286 | 1.667 | 1.270 | 1.000 | 0.808 |
| IEC Short Inverse   |                        |        |        |       |       |       |       |       |       |       |
| 0.05                | 0.153                  | 0.089  | 0.056  | 0.044 | 0.038 | 0.034 | 0.031 | 0.029 | 0.027 | 0.026 |
| 0.10                | 0.306                  | 0.178  | 0.111  | 0.088 | 0.075 | 0.067 | 0.062 | 0.058 | 0.054 | 0.052 |
| 0.20                | 0.612                  | 0.356  | 0.223  | 0.175 | 0.150 | 0.135 | 0.124 | 0.115 | 0.109 | 0.104 |
| 0.40                | 1.223                  | 0.711  | 0.445  | 0.351 | 0.301 | 0.269 | 0.247 | 0.231 | 0.218 | 0.207 |
| 0.60                | 1.835                  | 1.067  | 0.668  | 0.526 | 0.451 | 0.404 | 0.371 | 0.346 | 0.327 | 0.311 |
| 0.80                | 2.446                  | 1.423  | 0.890  | 0.702 | 0.602 | 0.538 | 0.494 | 0.461 | 0.435 | 0.415 |
| 1.00                | 3.058                  | 1.778  | 1.113  | 0.877 | 0.752 | 0.673 | 0.618 | 0.576 | 0.544 | 0.518 |

$$T = TDM \times \left( A + \frac{B}{(I/I_{pkp}) - C} + \frac{D}{((I/I_{pkp}) - C)^2} + \frac{E}{((I/I_{pkp}) - C)^3} \right) \cdot T_{RESET} = TDM \times \left[ \frac{t_r}{1 - (I/I_{pkp})^2} \right]$$

where:

- T = operate time (in seconds)
- TDM = Multiplier setting
- I = Input current
- $I_{pkp}$  = Pickup Current setting
- A to E = constants defined in the table
- $t_r$  = characteristic constant defined in the table
- $T_{RESET}$  = reset time in seconds (assuming energy capacity is 100% and RESET is “Timed”)

### IAC curves

The curves for the GE Vernova type IAC relay family are derived from the formulae:

#### GE type IAC inverse time curve constants

| IAC curve shape     | A      | B      | C      | D       | E      | $t_r$ |
|---------------------|--------|--------|--------|---------|--------|-------|
| IAC Extreme Inverse | 0.0040 | 0.6379 | 0.6200 | 1.7872  | 0.2461 | 6.008 |
| IAC Very Inverse    | 0.0900 | 0.7955 | 0.1000 | -1.2885 | 7.9586 | 4.678 |
| IAC Inverse         | 0.2078 | 0.8630 | 0.8000 | -0.4180 | 0.1947 | 0.990 |
| IAC Short Inverse   | 0.0428 | 0.0609 | 0.6200 | -0.0010 | 0.0221 | 0.222 |

#### GE type IAC curve trip times

| Multiplier<br>(TDM)   | Current ( I / Ipickup) |        |       |       |       |       |       |       |       |       |
|-----------------------|------------------------|--------|-------|-------|-------|-------|-------|-------|-------|-------|
|                       | 1.5                    | 2.0    | 3.0   | 4.0   | 5.0   | 6.0   | 7.0   | 8.0   | 9.0   | 10.0  |
| IAC Extremely Inverse |                        |        |       |       |       |       |       |       |       |       |
| 0.5                   | 1.699                  | 0.749  | 0.303 | 0.178 | 0.123 | 0.093 | 0.074 | 0.062 | 0.053 | 0.046 |
| 1.0                   | 3.398                  | 1.498  | 0.606 | 0.356 | 0.246 | 0.186 | 0.149 | 0.124 | 0.106 | 0.093 |
| 2.0                   | 6.796                  | 2.997  | 1.212 | 0.711 | 0.491 | 0.372 | 0.298 | 0.248 | 0.212 | 0.185 |
| 4.0                   | 13.591                 | 5.993  | 2.423 | 1.422 | 0.983 | 0.744 | 0.595 | 0.495 | 0.424 | 0.370 |
| 6.0                   | 20.387                 | 8.990  | 3.635 | 2.133 | 1.474 | 1.115 | 0.893 | 0.743 | 0.636 | 0.556 |
| 8.0                   | 27.183                 | 11.987 | 4.846 | 2.844 | 1.966 | 1.487 | 1.191 | 0.991 | 0.848 | 0.741 |
| 10.0                  | 33.979                 | 14.983 | 6.058 | 3.555 | 2.457 | 1.859 | 1.488 | 1.239 | 1.060 | 0.926 |
| IAC Very Inverse      |                        |        |       |       |       |       |       |       |       |       |
| 0.5                   | 1.451                  | 0.656  | 0.269 | 0.172 | 0.133 | 0.113 | 0.101 | 0.093 | 0.087 | 0.083 |
| 1.0                   | 2.901                  | 1.312  | 0.537 | 0.343 | 0.266 | 0.227 | 0.202 | 0.186 | 0.174 | 0.165 |
| 2.0                   | 5.802                  | 2.624  | 1.075 | 0.687 | 0.533 | 0.453 | 0.405 | 0.372 | 0.349 | 0.331 |
| 4.0                   | 11.605                 | 5.248  | 2.150 | 1.374 | 1.065 | 0.906 | 0.810 | 0.745 | 0.698 | 0.662 |
| 6.0                   | 17.407                 | 7.872  | 3.225 | 2.061 | 1.598 | 1.359 | 1.215 | 1.117 | 1.046 | 0.992 |
| 8.0                   | 23.209                 | 10.497 | 4.299 | 2.747 | 2.131 | 1.813 | 1.620 | 1.490 | 1.395 | 1.323 |
| 10.0                  | 29.012                 | 13.121 | 5.374 | 3.434 | 2.663 | 2.266 | 2.025 | 1.862 | 1.744 | 1.654 |
| IAC Inverse           |                        |        |       |       |       |       |       |       |       |       |
| 0.5                   | 0.578                  | 0.375  | 0.266 | 0.221 | 0.196 | 0.180 | 0.168 | 0.160 | 0.154 | 0.148 |

| Multiplier<br>(TDM) | Current ( I / Ipickup) |       |       |       |       |       |       |       |       |       |
|---------------------|------------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
|                     | 1.5                    | 2.0   | 3.0   | 4.0   | 5.0   | 6.0   | 7.0   | 8.0   | 9.0   | 10.0  |
| 1.0                 | 1.155                  | 0.749 | 0.532 | 0.443 | 0.392 | 0.360 | 0.337 | 0.320 | 0.307 | 0.297 |
| 2.0                 | 2.310                  | 1.499 | 1.064 | 0.885 | 0.784 | 0.719 | 0.674 | 0.640 | 0.614 | 0.594 |
| 4.0                 | 4.621                  | 2.997 | 2.128 | 1.770 | 1.569 | 1.439 | 1.348 | 1.280 | 1.229 | 1.188 |
| 6.0                 | 6.931                  | 4.496 | 3.192 | 2.656 | 2.353 | 2.158 | 2.022 | 1.921 | 1.843 | 1.781 |
| 8.0                 | 9.242                  | 5.995 | 4.256 | 3.541 | 3.138 | 2.878 | 2.695 | 2.561 | 2.457 | 2.375 |
| 10.0                | 11.552                 | 7.494 | 5.320 | 4.426 | 3.922 | 3.597 | 3.369 | 3.201 | 3.072 | 2.969 |
| IAC Short Inverse   |                        |       |       |       |       |       |       |       |       |       |
| 0.5                 | 0.072                  | 0.047 | 0.035 | 0.031 | 0.028 | 0.027 | 0.026 | 0.026 | 0.025 | 0.025 |
| 1.0                 | 0.143                  | 0.095 | 0.070 | 0.061 | 0.057 | 0.054 | 0.052 | 0.051 | 0.050 | 0.049 |
| 2.0                 | 0.286                  | 0.190 | 0.140 | 0.123 | 0.114 | 0.108 | 0.105 | 0.102 | 0.100 | 0.099 |
| 4.0                 | 0.573                  | 0.379 | 0.279 | 0.245 | 0.228 | 0.217 | 0.210 | 0.204 | 0.200 | 0.197 |
| 6.0                 | 0.859                  | 0.569 | 0.419 | 0.368 | 0.341 | 0.325 | 0.314 | 0.307 | 0.301 | 0.296 |
| 8.0                 | 1.145                  | 0.759 | 0.559 | 0.490 | 0.455 | 0.434 | 0.419 | 0.409 | 0.401 | 0.394 |
| 10.0                | 1.431                  | 0.948 | 0.699 | 0.613 | 0.569 | 0.542 | 0.524 | 0.511 | 0.501 | 0.493 |

## I<sup>2</sup>t curves

The I<sup>2</sup>t curves are derived as follows:

$$T = \text{TDM} \times \left[ \frac{100}{\left( \frac{I}{I_{\text{pickup}}} \right)^2} \right], \quad T_{\text{RESET}} = \text{TDM} \times \left[ \frac{100}{\left( \frac{I}{I_{\text{pickup}}} \right)^{-2}} \right]$$

where:

- T = Operate time (in seconds)
- TDM = Multiplier setting
- I = Input current
- I<sub>pickup</sub> = Pickup Current setting
- T<sub>RESET</sub> = reset time in seconds (assuming energy capacity is 100% and RESET is “Timed”)

## I<sup>2</sup>t curve trip times

| Multiplier<br>(TDM) | Current ( I / Ipickup) |         |        |        |        |        |        |        |        |        |
|---------------------|------------------------|---------|--------|--------|--------|--------|--------|--------|--------|--------|
|                     | 1.5                    | 2.0     | 3.0    | 4.0    | 5.0    | 6.0    | 7.0    | 8.0    | 9.0    | 10.0   |
| 0.01                | 0.44                   | 0.25    | 0.11   | 0.06   | 0.04   | 0.03   | 0.02   | 0.02   | 0.01   | 0.01   |
| 0.10                | 4.44                   | 2.50    | 1.11   | 0.63   | 0.40   | 0.28   | 0.20   | 0.16   | 0.12   | 0.10   |
| 1.00                | 44.44                  | 25.00   | 11.11  | 6.25   | 4.00   | 2.78   | 2.04   | 1.56   | 1.23   | 1.00   |
| 10.00               | 444.44                 | 250.00  | 111.11 | 62.50  | 40.00  | 27.78  | 20.41  | 15.63  | 12.35  | 10.00  |
| 100.00              | 4444.4                 | 2500.0  | 1111.1 | 625.00 | 400.00 | 277.78 | 204.08 | 156.25 | 123.46 | 100.00 |
| 600.00              | 26666.7                | 15000.0 | 6666.7 | 3750.0 | 2400.0 | 1666.7 | 1224.5 | 937.50 | 740.74 | 600.00 |

## FlexCurves

FlexCurves are described in the FlexCurves section later in this chapter. The curve shapes for the FlexCurves are derived from the formulae:

$$T = \text{TDM} \times \left[ \text{FlexCurve Time at } \left( \frac{I}{I_{\text{pickup}}} \right) \right] \text{ when } \left( \frac{I}{I_{\text{pickup}}} \right) \geq 1.00$$

$$T_{\text{RESET}} = \text{TDM} \times \left[ \text{FlexCurve Time at } \left( \frac{I}{I_{\text{pickup}}} \right) \right] \text{ when } \left( \frac{I}{I_{\text{pickup}}} \right) \leq 0.98$$

where:

- T = operate time (in seconds)
- TDM = Multiplier setting
- I = Input Current
- $I_{\text{pickup}}$  = Pickup Current setting
- $T_{\text{RESET}}$  = Reset Time in seconds (assuming energy capacity is 100% and RESET: Timed)

## Definite time curve

The Definite Time curve shape operates as soon as the pickup level is exceeded for a specified period of time. The base definite time curve delay is in seconds. The curve multiplier of 0.00 to 600.00 makes this delay adjustable from instantaneous to 600.00 seconds in steps of 10 ms. The definite time curve shapes are defined as follows:

$$T = \text{TDM in seconds, when } I > I_{\text{pickup}}$$

$$T_{\text{RESET}} = \text{TDM in seconds}$$

where:

- T = Operate Time (in seconds)
- TDM = Multiplier setting
- I = Input Current
- $I_{\text{pickup}}$  = Pickup Current setting
- $T_{\text{RESET}}$  = Reset Time in seconds (assuming energy capacity is 100% and RESET: Timed)

## Recloser curves

The Product uses the FlexCurve feature to facilitate programming of many recloser curves. See the FlexCurves settings section earlier in this chapter for details.

### 8.7.3.2 PHASE TIME OVERCURRENT (ANSI 51P, IEC PTOC)

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > PHASE CURRENT > PHASE TOC 1(16)**

*Note:*  
Only Phase TOC 1 is shown

■ PHASE TOC 1

■



PHASE TOC 1  
FUNCTION: Disabled

Range: Disabled, Enabled




|   |                                           |                                                                             |
|---|-------------------------------------------|-----------------------------------------------------------------------------|
| ⇅ | PHASE TOC 1 SIGNAL<br>SOURCE: SRC 1       | Range: SRC 1 to SRC 4<br>Not applicable to relays with 9-2LE                |
| ⇅ | PHASE TOC 1<br>INPUT: Phasor              | Range: Phasor, RMS                                                          |
| ⇅ | PHASE TOC1<br>PICKUP: 1.000 pu            | Range: 0.020 to 30.000 pu in steps of 0.001                                 |
| ⇅ | PHASE TOC1<br>CURVE: IEEE Mod Inv         | Range: see Overcurrent Curve Types table                                    |
| ⇅ | PHASE TOC1<br>TD MULTIPLIER: 1.00         | Range: 0.00 to 600.00 in steps of 0.01                                      |
| ⇅ | PHASE TOC1<br>RESET: Instantaneous        | Range: Instantaneous, Timed                                                 |
| ⇅ | PHASE TOC1 VOLTAGE<br>RESTRAINT: Disabled | Range: Disabled, Enabled                                                    |
| ⇅ | PHASE TOC1 BLOCK A:<br>Off                | Range: FlexLogic operand                                                    |
| ⇅ | PHASE TOC1 BLOCK B:<br>Off                | Range: FlexLogic operand                                                    |
| ⇅ | PHASE TOC1 BLOCK C:<br>Off                | Range: FlexLogic operand                                                    |
| ⇅ | PHASE TOC1<br>TARGET: Self-reset          | Range: Self-reset, Latched, Disabled<br>Not applicable to relays with 9-2LE |
| ↑ | PHASE TOC1<br>EVENTS: Disabled            | Range: Disabled, Enabled<br>Not applicable to relays with 9-2LE             |

The phase time overcurrent element can provide a specified time-delay operating characteristic versus the applied current or be used as a simple definite time element. The phase current input quantities can be programmed as fundamental phasor magnitude or total waveform RMS magnitude as required by the application.

Two methods of resetting operation are available: *Timed* and *Instantaneous* (see the Inverse TOC Curve Characteristics section earlier for details on curve setup, trip times, and reset operation). When the element is blocked, the time accumulator resets according to the reset characteristic. For example, if the element reset characteristic is set to “Instantaneous” and the element is blocked, the time accumulator clears immediately.

The **PHASE TOC1 PICKUP** setting can be reduced dynamically by a voltage restraint feature (when enabled). This is accomplished via the multipliers (Mvr) corresponding to the phase-phase voltages of the voltage restraint characteristic curve (see the figure); the pickup level is calculated as Mvr times the **PHASE TOC1 PICKUP** setting. If the voltage restraint feature is disabled, the pickup level always remains at the setting value.



**Figure 264: Phase time overcurrent voltage restraint characteristic**

### FUNCTION

This setting enables and disables the phase time overcurrent protection element.

### SIGNAL SOURCE

Selects the signal source for the phase time overcurrent protection element.

### INPUT

Selects how phase current input quantities are interpreted by the Product. Inputs can be selected as fundamental phasor magnitudes or total waveform RMS magnitudes as required by the application.

### PICKUP

Specifies the phase time overcurrent pickup level in per-unit values.

### CURVE

Selects the time inverse overcurrent curve style.

### TD MULTIPLIER

When TOC1 CURVE setting is set to Definite Time, this setting defines time delay to element pickup. When TOC1 CURVE setting is set to any inverse time curve, this setting defines inverse curve multiplier, used in the chosen curve equation.

### RESET

The “Instantaneous” reset method is intended for applications with other relays, such as most static relays, which set the energy capacity directly to zero when the current falls below the reset threshold. The “Timed” reset method can be used where the relay must coordinate with electromechanical relays.

### VOLTAGE RESTRAINT


Enables and disables the phase time overcurrent voltage restraint feature.

### BLOCK A

Assertion of the operand assigned to this setting blocks phase A of the phase time overcurrent element.

### EVENTS

Enables and disables the logging of phase time overcurrent events in the sequence of events recorder



827072A5.CDR

Figure 265: Phase time overcurrent 1 logic

### 8.7.3.3 PHASE INSTANTANEOUS OVERCURRENT (ANSI 50P, IEC PIOC)

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > PHASE CURRENT > PHASE IOC 1(8)**

**Note:**  
Only Phase IOC 1 is shown

■ PHASE IOC 1  
■

|   |                                     |                                                       |
|---|-------------------------------------|-------------------------------------------------------|
| ⇔ | PHASE IOC 1<br>FUNCTION: Disabled   | Range: Disabled, Enabled                              |
| ⇕ | PHASE IOC 1 SIGNAL<br>SOURCE: SRC 1 | Range: SRC <n><br>Not applicable to relays with 9-2LE |
| ⇕ | PHASE IOC1<br>PICKUP: 1.000 pu      | Range: 0.005 to 30.000 pu in steps of 0.001           |
| ⇕ | PHASE IOC1 PICKUP<br>DELAY: 0.00 s  | Range: 0.00 to 600.00 s in steps of 0.01              |
| ⇕ | PHASE IOC1 RESET<br>DELAY : 0.00 s  | Range: 0.00 to 600.00 in steps of 0.01                |
| ⇕ | PHASE IOC1 BLOCK A:<br>Off          | Range: FlexLogic operand                              |
| ⇕ | PHASE IOC1 BLOCK B:<br>Off          | Range: FlexLogic operand                              |

|   |                                  |                                                                             |
|---|----------------------------------|-----------------------------------------------------------------------------|
| ⇅ | PHASE IOC1 BLOCK C:<br>Off       | Range: FlexLogic operand                                                    |
| ⇅ | PHASE IOC1<br>TARGET: Self-reset | Range: Self-reset, Latched, Disabled<br>Not applicable to relays with 9-2LE |
| ↑ | PHASE IOC1<br>EVENTS: Disabled   | Range: Disabled, Enabled<br>Not applicable to relays with 9-2LE             |

The phase instantaneous overcurrent element can be used as an instantaneous element with no intentional delay or as a definite time element. The input current is the fundamental phasor magnitude.

### FUNCTION

This setting enables and disables the phase instantaneous overcurrent protection element.

### SOURCE

Selects the signal source for the phase instantaneous overcurrent protection element.

### PICKUP

Specifies the phase instantaneous overcurrent pickup level in per-unit values.

### DELAY

Delays the assertion of the PHASE IOC OP operands. It is used to achieve timing coordination with other elements and relays.

### RESET DELAY


Specifies a delay for the reset of the phase instantaneous overcurrent element between the operate output state and the return to logic 0 after the input passes outside the defined pickup range. This setting is used to ensure that the relay output contacts are closed long enough to ensure reception by downstream equipment.

### BLOCK A

Assertion of the operand assigned to this setting block's phase A of the phase instantaneous overcurrent element.

### EVENTS

Enables and disables the logging of phase instantaneous overcurrent events in the sequence of events recorder.



8270 33A8.CDR

Figure 266: Phase instantaneous overcurrent logic

### 8.7.3.4 PHASE DIRECTIONAL OVERCURRENT (ANSI 67P, IEC PDOC/PTOC)


**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > PHASE CURRENT > PHASE DIRECTIONAL 1(2)**

*Note:*  
Only Phase Directional 1 is shown

|                                                            |   |                                         |                                                                             |
|------------------------------------------------------------|---|-----------------------------------------|-----------------------------------------------------------------------------|
| <div> <div>■ PHASE</div> <div>■ DIRECTIONAL 1</div> </div> | ⇔ | PHASE DIR 1<br>FUNCTION: Disabled       | Range: Disabled, Enabled                                                    |
|                                                            | ⇕ | PHASE DIR 1 SIGNAL<br>SOURCE: SRC 1     | Range: SRC <n><br>Not applicable to relays with 9-2LE                       |
|                                                            | ⇕ | PHASE DIR 1 BLOCK:<br>Off               | Range: FlexLogic operand                                                    |
|                                                            | ⇕ | PHASE DIR 1<br>ECA: 30°                 | Range: 0 to 359° in steps of 1                                              |
|                                                            | ⇕ | PHASE DIR POL V1<br>THRESHOLD: 0.700 pu | Range: 0.004 to 3.000 pu in steps of 0.001                                  |
|                                                            | ⇕ | PHASE DIR 1 BLOCK<br>WHEN V MEM EXP: No | Range: No, Yes                                                              |
|                                                            | ⇕ | PHASE DIR 1<br>TARGET: Self-reset       | Range: Self-reset, Latched, Disabled<br>Not applicable to relays with 9-2LE |
|                                                            | ⇕ | PHASE DIR 1<br>EVENTS: Disabled         | Range: Disabled, Enabled<br>Not applicable to relays with 9-2LE             |

*Note:*  
The **TARGET** setting is not user-selectable and forced to *Disabled*. If Targets are required from directional elements, it can be achieved by assigning directional element output to a digital element, where targets selection can be used as required.

The phase directional elements (one for each of phases A, B, and C) determine the phase current flow direction for steady state and fault conditions and can be used to control the operation of the phase overcurrent elements via the BLOCK inputs of these elements.



**Figure 267: Phase A directional polarization**

This element is intended to apply a block signal to an overcurrent element to prevent an operation when current is flowing in a particular direction. The direction of current flow is determined by measuring the phase angle between the current from the phase CTs and the line-line voltage from the VTs, based on the 90° or quadrature connection. If there is a requirement to supervise overcurrent elements for flows in opposite directions, such as can happen through a bus-tie breaker, program two phase directional elements with opposite element characteristic angle (ECA) settings.

To increase security for three phase faults very close to the VTs used to measure the polarizing voltage, a voltage memory feature is incorporated. This feature stores the polarizing voltage the moment before the voltage collapses, and uses it to determine direction. The voltage memory remains valid for one second after the voltage has collapsed.

The main component of the phase directional element is the phase angle comparator with two inputs: the operating signal (phase current) and the polarizing signal (the line voltage, shifted in the leading direction by the characteristic angle, ECA).

The table shows the operating and polarizing signals used for phase directional control.

### Operating and polarizing signals

| Phase | Operating signal | Polarizing signal Vpol |                        |
|-------|------------------|------------------------|------------------------|
|       |                  | ABC phase sequence     | ACB phase sequence     |
| A     | angle of IA      | angle of VBC x (1∠ECA) | angle of VCB x (1∠ECA) |
| B     | angle of IB      | angle of VCA x (1∠ECA) | angle of VAC x 1∠ECA)  |
| C     | angle of IC      | angle of VAB x (1∠ECA) | angle of VBA x (1∠ECA) |

### Mode of operation

- When the function is Disabled or the operating current is below 5% x CT nominal, the element output is logic 0
- When the function is Enabled or the operating current is above 5% x CT nominal, and the polarizing voltage is above the **PRODUCT SETUP > DISPLAY PROPERTIES > VOLTAGE CUT-OFF LEVEL** value, the element output is dependent on the phase angle between the operating and polarizing signals:
  - The element output is logic 0 when the operating current is within polarizing voltage  $\pm 90^\circ$
  - For all other angles, the element output is logic 1
- Once the voltage memory has expired, the phase overcurrent elements under directional control can be set to block or trip on overcurrent as follows:
  - When **BLOCK WHEN V MEM EXP** is set to Yes, the directional element blocks the operation of any phase overcurrent element under directional control when voltage memory expires
  - When **BLOCK WHEN V MEM EXP** is set to No, the directional element allows tripping of phase overcurrent elements under directional control when voltage memory expires

In all cases, directional blocking is permitted to resume when the polarizing voltage becomes greater than the polarizing voltage threshold.

### Settings

#### PHASE DIR 1 FUNCTION

This setting enables and disables the phase directional overcurrent protection element.

#### PHASE DIR 1 SIGNAL SOURCE

This setting is used to select the source for the operating and polarizing signals. The operating current for the phase directional element is the phase current for the selected current source. The polarizing voltage is the line voltage from the phase VTs, based on the  $90^\circ$  or quadrature connection and shifted in the leading direction by the element characteristic angle (ECA).

#### PHASE DIR 1 BLOCK

Assertion of the operand assigned to this setting blocks operation of the phase directional overcurrent element.

#### PHASE DIR 1 ECA

This setting specifies the element characteristic angle, that is, the angle by which the polarizing voltage is shifted in the leading direction to achieve dependable operation. In the design of the UR-series elements, a block is applied to an element by asserting logic 1 at the blocking input. Program the phase directional overcurrent element using this setting so that the output is logic 1 for current in the non-tripping direction.

#### PHASE DIR 1 POL V THRESHOLD

This setting is used to establish the minimum level of voltage for which the phase angle measurement is healthy and reliable. Do not set this setting too low because the element can continue using the actual voltage already distorted by the fault instead of using healthy memory voltage—this can cause wrong directional discrimination.

#### PHASE DIR 1 BLOCK WHEN V MEM EXP


This setting is used to select the required operation upon expiration of voltage memory. When set to "Yes," the directional element blocks the operation of any phase overcurrent element under directional control, when voltage memory expires. When set to "No," the directional element allows tripping of phase overcurrent elements under directional control.

## PHASE DIR 1 EVENTS

This setting enables and disables the logging of phase directional overcurrent events in the sequence of events recorder.

**Note:**  
The phase directional element responds to the forward load current. In the case of a following reverse fault, the element needs some time—in the order of 8 ms—to establish a blocking signal. Some protection elements, such as instantaneous overcurrent, respond to reverse faults before the blocking signal is established. Therefore, a coordination time of at least 10 ms must be added to all the instantaneous protection elements under the supervision of the phase directional element. If current reversal is of concern, a longer delay—in the order of 20 ms—is needed.

### Logic diagram



827078A7.CDR

Figure 268: Phase directional logic

## 8.7.4 NEUTRAL CURRENT

### SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > NEUTRAL CURRENT

|                                           |   |                                                         |                   |
|-------------------------------------------|---|---------------------------------------------------------|-------------------|
| <div>■ NEUTRAL CURRENT</div> <div>■</div> | ⇔ | <div>■ NEUTRAL TOC &lt;n&gt;</div> <div>■</div>         | NOT ALL UR MODELS |
|                                           | ⇕ | <div>■ NEUTRAL IOC &lt;n&gt;</div> <div>■</div>         | NOT ALL UR MODELS |
|                                           | ↑ | <div>■ NEUTRAL</div> <div>■ DIRECTIONAL &lt;n&gt;</div> | NOT ALL UR MODELS |



*Note:*  
*n = number of elements*

#### 8.7.4.1 NEUTRAL TIME OVERCURRENT (ANSI 51N, IEC PTOC)

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > NEUTRAL CURRENT > NEUTRAL TOC 1(6)**

*Note:*  
*Only Neutral TOC 1 is shown*

|                                         |   |                                       |                                                                             |
|-----------------------------------------|---|---------------------------------------|-----------------------------------------------------------------------------|
| <div>■ NEUTRAL TOC 1</div> <div>■</div> | ↔ | NEUTRAL TOC 1<br>FUNCTION: Disabled   | Range: Disabled, Enabled                                                    |
|                                         | ⇅ | NEUTRAL TOC 1 SIGNAL<br>SOURCE: SRC 1 | Range: SRC <n><br>Not applicable to relays with 9-2LE                       |
|                                         | ⇅ | NEUTRAL TOC 1<br>INPUT: Phasor        | Range: Phasor, RMS                                                          |
|                                         | ⇅ | NEUTRAL TOC1<br>PICKUP: 1.000 pu      | Range: 0.020 to 30.000 pu in steps of 0.001                                 |
|                                         | ⇅ | NEUTRAL TOC1<br>CURVE: IEEE Mod Inv   | Range: see Overcurrent Curve Types table                                    |
|                                         | ⇅ | NEUTRAL TOC1<br>TD MULTIPLIER: 1.00   | Range: 0.00 to 600.00 in steps of 0.01                                      |
|                                         | ⇅ | NEUTRAL TOC1<br>RESET: Instantaneous  | Range: Instantaneous, Timed                                                 |
|                                         | ⇅ | NEUTRAL TOC1 BLOCK:<br>Off            | Range: FlexLogic operand                                                    |
|                                         | ⇅ | NEUTRAL TOC1<br>TARGET: Self-reset    | Range: Self-reset, Latched, Disabled<br>Not applicable to relays with 9-2LE |
|                                         | ↑ | NEUTRAL TOC1<br>EVENTS: Disabled      | Range: Disabled, Enabled<br>Not applicable to relays with 9-2LE             |

The neutral time overcurrent element can provide a desired time-delay operating characteristic versus the applied current or be used as a simple definite time element. The neutral current input value is a quantity calculated as 3I0 from the phase currents and can be programmed as fundamental phasor magnitude or total waveform RMS magnitude as required by the application.

Two methods of resetting operation are available: *Timed* and *Instantaneous* (see the Inverse TOC Curve Characteristics section for details on curve setup, trip times, and reset operation). When the element is blocked, the time accumulator resets according to the reset characteristic. For example, if the element reset characteristic is set to “Instantaneous” and the element is blocked, the time accumulator clears immediately.

#### NEUTRAL TOC1 FUNCTION

This setting enables and disables the neutral time overcurrent protection element.

#### NEUTRAL TOC1 SIGNAL SOURCE

this setting selects the signal source for the neutral time overcurrent protection element.

## NEUTRAL TOC1 INPUT

This setting selects how neutral current input quantities are interpreted by the Product. Inputs can be selected as fundamental phasor magnitudes or total waveform RMS magnitudes as required by the application.

## NEUTRAL TOC1 PICKUP

This setting specifies the neutral time overcurrent pickup level in per-unit values.

## NEUTRAL TOC1 CURVE

This setting selects the inverse time overcurrent curve style.

## NEUTRAL TOC1 TD MULTIPLIER

This setting specifies a multiple of the base curve shape specified by the CURVE setting. Programming this value to zero results in an instantaneous response to all current levels above pickup.

## NEUTRAL TOC1 RESET

The “Instantaneous” reset method is intended for applications with other relays, such as most static relays, which set the energy capacity directly to zero when the current falls below the reset threshold. The “Timed” reset method can be used where the relay must coordinate with electromechanical relays.

## NEUTRAL TOC1 BLOCK

Assertion of the operand assigned to this setting blocks operation of the neutral time overcurrent element.

## NEUTRAL TOC1 EVENTS

This setting enables and disables the logging of neutral time overcurrent events in the sequence of events recorder




Figure 269: Neutral time overcurrent 1 logic

### 8.7.4.2 NEUTRAL INSTANTANEOUS OVERCURRENT (ANSI 50N, IEC PIOC)

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > NEUTRAL CURRENT > NEUTRAL IOC 1(8)**

*Note:*  
Only Neutral IOC 1 is shown

|                                                      |   |                                       |                                                                             |
|------------------------------------------------------|---|---------------------------------------|-----------------------------------------------------------------------------|
| <div> <div>■ NEUTRAL IOC 1</div> <div>■</div> </div> | ⇔ | NEUTRAL IOC 1<br>FUNCTION: Disabled   | Range: Disabled, Enabled                                                    |
|                                                      | ⇕ | NEUTRAL IOC 1 SIGNAL<br>SOURCE: SRC 1 | Range: SRC <n><br>Not applicable to relays with 9-2LE                       |
|                                                      | ⇕ | NEUTRAL IOC1<br>PICKUP: 1.000 pu      | Range: 0.020 to 30.000 pu in steps of 0.001                                 |
|                                                      | ⇕ | NEUTRAL IOC1 PICKUP<br>DELAY: 0.00 s  | Range: 0.00 to 600.00 s in steps of 0.01                                    |
|                                                      | ⇕ | NEUTRAL IOC1 RESET<br>DELAY : 0.00 s  | Range: 0.00 to 600.00 in steps of 0.01                                      |
|                                                      | ⇕ | NEUTRAL IOC1 BLOCK:<br>Off            | Range: FlexLogic operand                                                    |
|                                                      | ⇕ | NEUTRAL IOC1<br>TARGET: Self-reset    | Range: Self-reset, Latched, Disabled<br>Not applicable to relays with 9-2LE |
|                                                      | ↑ | NEUTRAL IOC1<br>EVENTS: Disabled      | Range: Disabled, Enabled<br>Not applicable to relays with 9-2LE             |

The neutral instantaneous overcurrent element can be used as an instantaneous function with no intentional delay or as a definite time function. The element essentially responds to the magnitude of a neutral current fundamental frequency phasor calculated from the phase currents. A positive-sequence restraint is applied for better performance. A small portion (6.25%) of the positive-sequence current magnitude is subtracted from the zero-sequence current magnitude when forming the operating quantity of the element as follows:

$$I_{op} = 3 \times (|I_0| - K \times |I_1|) \text{ where } K = 1/16$$

The positive-sequence restraint allows for more sensitive settings by counterbalancing spurious zero-sequence currents resulting from:

- System unbalances under heavy load conditions
- Transformation errors of current transformers (CTs) during double-line and three-phase faults
- Switch-off transients during double-line and three-phase faults

The positive-sequence restraint must be considered when testing for pickup accuracy and response time (multiple of pickup). The operating quantity depends on how test currents are injected into the relay, where single-phase injection is  $I_{op} = 0.9375 \times I_{injected}$  and three-phase pure zero-sequence injection is:

$$I_{op} = 3 \times I_{injected}$$

### NEUTRAL IOC1 FUNCTION

This setting enables and disables the neutral instantaneous overcurrent protection element.

### NEUTRAL IOC1 SIGNAL SOURCE

This setting selects the signal source for the neutral instantaneous overcurrent protection element.

### NEUTRAL IOC1 PICKUP

This setting specifies the neutral instantaneous overcurrent pickup level in per-unit values.

### NEUTRAL IOC1 PICKUP DELAY

This setting delays the assertion of the NEUTRAL IOC OP operands. It is used to achieve timing coordination with other elements and relays.

### NEUTRAL IOC1 RESET DELAY


This setting specifies a delay for the reset of the neutral instantaneous overcurrent element between the operate output state and the return to logic 0 after the input passes outside the defined pickup range. This setting is used to ensure that the relay output contacts are closed long enough to ensure reception by downstream equipment.

### NEUTRAL IOC1 BLOCK

Assertion of the operand assigned to this setting blocks operation of the neutral instantaneous overcurrent element.

### NEUTRAL IOC1 EVENTS

This setting enables and disables the logging of neutral instantaneous overcurrent events in the sequence of events recorder.



827035A5.CDR

Figure 270: Neutral IOC1 logic

### 8.7.4.3 NEUTRAL DIRECTIONAL OVERCURRENT (ANSI 67N, IEC PDEF/PTOC)

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > NEUTRAL CURRENT > NEUTRAL DIRECTIONAL OC 1(2)**

*Note:*  
Only Neutral Directional OC 1 is shown

|                                                                                          |   |                                            |                                                              |
|------------------------------------------------------------------------------------------|---|--------------------------------------------|--------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>■ NEUTRAL</li> <li>■ DIRECTIONAL OC1 1</li> </ul> | ⇔ | NEUTRAL DIR OC1<br>FUNCTION: Disabled      | Range: Disabled, Enabled                                     |
|                                                                                          | ⇕ | NEUTRAL DIR OC1<br>SOURCE: SRC 1           | Range: SRC 1 to SRC 4<br>Not applicable to relays with 9-2LE |
|                                                                                          | ⇕ | NEUTRAL DIR OC1<br>POLARIZING: Voltage     | Range: Voltage, Current, Dual, Dual-V, Dual-I                |
|                                                                                          | ⇕ | NEUTRAL DIR OC1 POL<br>VOLT: Calculated V0 | Range: Calculated V0, Measured VX                            |
|                                                                                          | ⇕ | NEUTRAL DIR OC1 OP<br>CURR: Calculated 3I0 | Range: Calculated 3I0, Measured IG                           |
|                                                                                          | ⇕ | NEUTRAL DIR OC1 POSSEQ<br>RESTRAINT: 0.063 | Range: 0.000 to 0.500 in steps of 0.001                      |
|                                                                                          | ⇕ | NEUTRAL DIR OC1<br>OFFSET: 0.00 Ω          | Range: 0.00 to 250.00 Ω in steps of 0.01                     |
|                                                                                          | ⇕ | NEUTRAL DIR OC1 FWD<br>ECA: 75° Lag        | Range: -90 to 90° in steps of 1                              |

|   |                                         |                                                                             |
|---|-----------------------------------------|-----------------------------------------------------------------------------|
| ↕ | NEUTRAL DIR OC1 FWD<br>LIMIT ANGLE: 90° | Range: 40 to 90° in steps of 1                                              |
| ↕ | NEUTRAL DIR OC1 FWD<br>PICKUP: 0.050 pu | Range: 0.006 to 30.000 pu in steps of 0.001                                 |
| ↕ | NEUTRAL DIR OC1 REV<br>LIMIT ANGLE: 90° | Range: 40 to 90° in steps of 1                                              |
| ↕ | NEUTRAL DIR OC1 REV<br>PICKUP: 0.050 pu | Range: 0.006 to 30.000 pu in steps of 0.001                                 |
| ↕ | NEUTRAL DIR OC1 BLK:<br>Off             | Range: FlexLogic operand                                                    |
| ↕ | NEUTRAL DIR OC1<br>TARGET: Self-reset   | Range: Self-reset, Latched, Disabled<br>Not applicable to relays with 9-2LE |
| ↑ | NEUTRAL DIR OC1<br>EVENTS: Disabled     | Range: Disabled, Enabled<br>Not applicable to relays with 9-2LE             |

The neutral directional overcurrent element provides both forward and reverse fault direction indications for the NEUTRAL DIR OC1 FWD and NEUTRAL DIR OC1 REV operands, respectively. The output operand is asserted if the magnitude of the operating current is above a pickup level (overcurrent unit) and the fault direction is seen as forward or reverse, respectively (directional unit).

The overcurrent unit responds to the magnitude of a fundamental frequency phasor of either the neutral current calculated from the phase currents or the ground current. There are separate pickup settings for the forward-looking and reverse-looking functions. If set to use the calculated  $3I_0$ , the element applies a positive-sequence restraint for better performance: a small user-programmable portion of the positive-sequence current magnitude is subtracted from the zero-sequence current magnitude when forming the operating quantity.

$$I_{op} = 3 \times (|I_0| - K \times |I_1|)$$

The positive-sequence restraint allows for more sensitive settings by counterbalancing spurious zero-sequence currents resulting from

- System unbalances under heavy load conditions
- Transformation errors of current transformers (CTs) during double-line and three-phase faults
- Switch-off transients during double-line and three-phase faults

The positive-sequence restraint must be considered when testing for pickup accuracy and response time (multiple of pickup). The operating quantity depends on the way the test currents are injected into the relay

- Single-phase injection:  $I_{op} = (1 - K) \times I_{injected}$
- Three-phase pure zero-sequence injection:  $I_{op} = 3 \times I_{injected}$ .

The positive-sequence restraint is removed for low currents. If the positive-sequence current is below 0.8 pu, the restraint is removed by changing the constant K to zero. This facilitates better response to high-resistance faults when the unbalance is very small and there is no danger of excessive CT errors as the current is low.

The directional unit uses the zero-sequence current ( $I_0$ ) or ground current (IG) for fault direction discrimination and can be programmed to use either zero-sequence voltage (*Calculated V0* or *Measured VX*), ground current (IG), or both for polarizing. Both zero-sequence current ( $I_0$ ) and ground current (IG) must be greater than the **CUT-OFF LEVEL** setting value to be validated as the operating quantity for directional current. The following tables define the neutral directional overcurrent element. V\_0 is the zero-sequence voltage, I\_0 is the zero-sequence current, ECA is the element characteristic angle, and IG is the ground current.

## Quantities for "calculated 3I0" configuration

| Directional unit quantities |           |                                 |                             | Overcurrent unit quantities                                                                                         |
|-----------------------------|-----------|---------------------------------|-----------------------------|---------------------------------------------------------------------------------------------------------------------|
| Polarizing mode             | Direction | Compared phasors                |                             |                                                                                                                     |
| Voltage                     | Forward   | $-V\_0 + Z\_offset \times I\_0$ | $I\_0 \times 1 \angle ECA$  | $lop = 3( I\_0  - K \times  I\_1 )$ if $ I_1  > 0.8 \text{ pu}$<br>$lop = 3( I\_0 )$ if $ I_1  \leq 0.8 \text{ pu}$ |
|                             | Reverse   | $-V\_0 + Z\_offset \times I\_0$ | $-I\_0 \times 1 \angle ECA$ |                                                                                                                     |
| Current                     | Forward   | IG                              | $I\_0$                      |                                                                                                                     |
|                             | Reverse   | IG                              | $-I\_0$                     |                                                                                                                     |
| Dual, Dual-V, Dual-I        | Forward   | $-V\_0 + Z\_offset \times I\_0$ | $I\_0 \times 1 \angle ECA$  |                                                                                                                     |
|                             |           | or                              |                             |                                                                                                                     |
|                             |           | IG                              | $I\_0$                      |                                                                                                                     |
|                             | Reverse   | $-V\_0 + Z\_offset \times I\_0$ | $-I\_0 \times 1 \angle ECA$ |                                                                                                                     |
|                             |           | or                              |                             |                                                                                                                     |
|                             |           | IG                              | $-I\_0$                     |                                                                                                                     |

## Quantities for "measured IG" configuration

| Directional unit quantities |           |                                           |                            | Overcurrent unit quantities |
|-----------------------------|-----------|-------------------------------------------|----------------------------|-----------------------------|
| Polarizing mode             | Direction | Compared phasors                          |                            |                             |
| Voltage                     | Forward   | $-V_0 + Z_{\text{offset}} \times I_{G/3}$ | $I_G \times 1 \angle ECA$  | $lop =  I_G $               |
|                             | Reverse   | $-V_0 + Z_{\text{offset}} \times I_{G/3}$ | $-I_G \times 1 \angle ECA$ |                             |

where:

$$V_0 = 1/3 \times (V_{AG} + V_{BG} + V_{CG}) = \text{zero sequence voltage}$$

$$I_0 = 1/3 \times I_N = 1/3 \times (I_A + I_B + I_C) = \text{zero sequence current}$$


- ECA = element characteristic angle
- IG = ground current
- $Z_{\text{offset}}$  is the offset impedance, for which magnitude is the OFFSET setting and angle is the FWD ECA

When **NEUTRAL DIR OC1 POL VOLT** is set to *Measured VX*, one-third of this voltage is used in place of  $V_0$ . The following figure explains the usage of the voltage polarized directional unit of the element.

The figure shows the voltage-polarized phase angle comparator characteristics for a phase A to ground fault, with:

- ECA = 90° (element characteristic angle = centerline of operating characteristic)
- FWD LA = 80° (forward limit angle = the ± angular limit with the ECA for operation)
- REV LA = 80° (reverse limit angle = the ± angular limit with the ECA for operation)

Take the bias into account when using the neutral directional overcurrent element to directionalize other protection elements.



**Figure 271: Neutral directional voltage-polarized characteristic**

### NEUTRAL DIR OC1 POLARIZING

This setting selects the polarizing mode for the directional unit.

- If Voltage polarizing is selected, the element uses the zero-sequence voltage angle for polarization. The user can use either the zero-sequence voltage  $V_0$  calculated from the phase voltages, or the zero-sequence voltage supplied externally as the auxiliary voltage  $V_X$ , both from the **NEUTRAL DIR OC1 SOURCE**. The calculated  $V_0$  can be used as polarizing voltage only if the voltage transformers are connected in Wye. The auxiliary voltage can be used as the polarizing voltage provided **SYSTEM SETUP > AC INPUTS > VOLTAGE BANK > AUXILIARY VT CONNECTION** is set to  $V_n$  and the auxiliary voltage is connected to a zero-sequence voltage source (such as broken delta connected secondary of VTs). The zero sequence voltage  $V_0$  must be greater than **PRODUCT SETUP > DISPLAY PROPERTIES > VOLTAGE CUT-OFF LEVEL** to be validated for use as polarizing signal. Additionally, when offset impedance is applied and zero-sequence current is above 0.2 pu, compensated zero-sequence voltage  $-V_0 + Z_{\text{offset}} \times I_0$  must be above 0.02 pu in order to discriminate fault direction; otherwise when zero-sequence current is less than 0.2 pu,  $-V_0$  is then used as the polarizing signal. If the polarizing signal is invalid, neither forward nor reverse indication is given.
- If Current polarizing is selected, the element uses the ground current angle connected externally and configured under **NEUTRAL OC1 SOURCE** for polarization. The ground CT must be connected between the ground and neutral point of an adequate local source of ground current. The ground current must be greater than **PRODUCT SETUP > DISPLAY PROPERTIES > CURRENT CUT-OFF LEVEL** to be validated as a polarizing signal. If the polarizing signal is not valid, neither forward nor reverse indication is given. In addition, the zero-sequence current ( $I_0$ ) must be greater than the **PRODUCT SETUP > DISPLAY PROPERTIES > CURRENT CUT-OFF LEVEL** setting value. For a choice of current polarizing, it is recommended that the polarizing signal be analyzed to ensure that a known direction is maintained irrespective of the fault location. For example, if using an autotransformer neutral current as a polarizing source, ensure that a reversal of the ground current does not occur for a high-side fault. Assume that the low-

side system impedance is minimal when checking for this condition. A similar situation arises for a wye/delta/wye transformer, where current in one transformer winding neutral can reverse when faults on both sides of the transformer are considered.

- If Dual polarizing is selected, the element performs both directional comparisons as described. A given direction is confirmed if either voltage or current comparators indicate so. If a conflicting (simultaneous forward and reverse) indication occurs, the forward direction overrides the reverse direction.
- If Dual-V polarizing is selected, Voltage polarizing is performed and Current polarizing is ignored if the voltage polarizing signal is valid; otherwise Current polarizing is performed if the current polarizing signal is valid. If neither of them is valid, neither forward nor reverse indication is given.
- If Dual-I polarizing is selected, Current polarizing is performed and Voltage polarizing is ignored if the current polarizing signal is valid; otherwise Voltage polarizing is performed if the voltage polarizing signal is valid. If neither of them is valid, neither forward nor reverse indication is given.

### NEUTRAL DIR OC1 POL VOLT

Selects the polarizing voltage used by the directional unit when "Voltage," "Dual," "Dual-V," or "Dual-I" polarizing mode is set. The polarizing voltage can be programmed to be either the zero-sequence voltage calculated from the phase voltages ("Calculated V0") or supplied externally as an auxiliary voltage ("Measured VX").

### NEUTRAL DIR OC1 OP CURR

This setting indicates whether the  $3I_0$  current calculated from the phase currents, or the ground current is used by this protection. This setting acts as a switch between the neutral and ground modes of operation (ANSI devices 67N and 67G). If set to *Calculated  $3I_0$* , the element uses the phase currents and applies the positive-sequence restraint. If set to *Measured IG*, the element uses ground current supplied to the ground CT of the CT bank configured as **NEUTRAL DIR OC1 SOURCE**. If this setting is *Measured IG*, then the **NEUTRAL DIR OC1 POLARIZING** setting must be *Voltage*, as it is not possible to use the ground current as an operating and polarizing signal simultaneously. IG current has to be above **PRODUCT SETUP > DISPLAY PROPERTIES > CURRENT CUT-OFF LEVEL** to be used as an operate quantity.

### NEUTRAL DIR OC1 POS-SEQ RESTRAINT

This setting controls the amount of the positive-sequence restraint. Set it to 0.063 for backward compatibility with firmware revision 3.40 and older. Set it to zero to remove the restraint. Set it higher if large system unbalances or poor CT performance are expected.

### NEUTRAL DIR OC1 OFFSET

This setting specifies the offset impedance used by this protection. The primary application for the offset impedance is to guarantee correct identification of fault direction on series compensated lines. In regular applications, the offset impedance ensures proper operation even if the zero-sequence voltage at the relaying point is very small. If this is the intent, the offset impedance is not to be larger than the zero-sequence impedance of the protected circuit. Practically, it shall be several times smaller. Enter the offset impedance in secondary ohms.

### NEUTRAL DIR OC1 FWD ECA

This setting defines the characteristic angle (ECA) for the forward direction in the Voltage polarizing mode. The Current polarizing mode uses a fixed ECA of 0°. The ECA in the reverse direction is the angle set for the forward direction shifted by 180°.

### NEUTRAL DIR OC1 FWD LIMIT ANGLE

This setting defines a symmetrical (in both directions from the ECA) limit angle for the forward direction.



## NEUTRAL DIR OC1 FWD PICKUP

This setting defines the pickup level for the overcurrent unit of the element in the forward direction. When selecting this setting, keep in mind that the design uses a positive-sequence restraint technique for the *Calculated 3I0* mode of operation.

## NEUTRAL DIR OC1 REV LIMIT ANGLE


This setting defines a symmetrical (in both directions from the ECA) limit angle for the reverse direction.

## NEUTRAL DIR OC1 REV PICKUP

This setting defines the pickup level for the overcurrent unit of the element in the reverse direction. When selecting this setting, keep in mind that the design uses a positive-sequence restraint technique for the *Calculated 3I0* mode of operation.

### Note:

*This element requires that the operating current and the polarizing voltage (or current) be measured from the same side of the transformer.*



827195A1.vsd

Figure 272: Neutral directional overcurrent logic

## 8.7.5 GROUND CURRENT

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > GROUND CURRENT**

|                                          |   |                                                |                   |
|------------------------------------------|---|------------------------------------------------|-------------------|
| <div>■ GROUND CURRENT</div> <div>■</div> | ⇔ | <div>■ GROUND TOC &lt;n&gt;</div> <div>■</div> | NOT ALL UR MODELS |
|                                          | ↑ | <div>■ GROUND IOC &lt;n&gt;</div> <div>■</div> | NOT ALL UR MODELS |

*Note:*  
n = number of elements

### 8.7.5.1 GROUND TIME OVERCURRENT (ANSI 51G, IEC PTOC)

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > GROUND CURRENT > GROUND TOC 1(4)**

*Note:*  
Only Ground TOC 1 is shown

|                                        |   |                                      |                                                                             |
|----------------------------------------|---|--------------------------------------|-----------------------------------------------------------------------------|
| <div>■ GROUND TOC 1</div> <div>■</div> | ⇔ | GROUND TOC 1<br>FUNCTION: Disabled   | Range: Disabled, Enabled                                                    |
|                                        | ⇕ | GROUND TOC 1 SIGNAL<br>SOURCE: SRC 1 | Range: SRC <n><br>Not applicable to relays with 9-2LE                       |
|                                        | ⇕ | GROUND TOC 1<br>INPUT: Phasor        | Range: Phasor, RMS                                                          |
|                                        | ⇕ | GROUND TOC1<br>PICKUP: 1.000 pu      | Range: 0.020 to 30.000 pu in steps of 0.001                                 |
|                                        | ⇕ | GROUND TOC1<br>CURVE: IEEE Mod Inv   | Range: see Overcurrent Curve Types table                                    |
|                                        | ⇕ | GROUND TOC1<br>TD MULTIPLIER: 1.00   | Range: 0.00 to 600.00 in steps of 0.01                                      |
|                                        | ⇕ | GROUND TOC1<br>RESET: Instantaneous  | Range: Instantaneous, Timed                                                 |
|                                        | ⇕ | GROUND TOC1 BLOCK:<br>Off            | Range: FlexLogic operand                                                    |
|                                        | ⇕ | GROUND TOC1<br>TARGET: Self-reset    | Range: Self-reset, Latched, Disabled<br>Not applicable to relays with 9-2LE |
|                                        | ↑ | GROUND TOC1<br>EVENTS: Disabled      | Range: Disabled, Enabled<br>Not applicable to relays with 9-2LE             |

This element can provide a required time-delay operating characteristic versus the applied current or be used as a simple definite time element. The ground current input value is the quantity measured by the ground input CT and is the fundamental phasor or RMS magnitude. Two methods of resetting operation are available: *Timed* and *Instantaneous* (see the Inverse TOC Curve Characteristics section for details). When the element is blocked, the time accumulator resets according to the reset characteristic. For example, if the element reset characteristic is set to *Instantaneous* and the element is blocked, the time accumulator clears immediately.

## GROUND TOC1 FUNCTION

This setting enables and disables the ground time overcurrent protection element.

## GROUND TOC1 SIGNAL SOURCE

This setting selects the signal source for the ground time overcurrent protection element.

## GROUND TOC1 INPUT

This setting selects how ground current input quantities are interpreted by the Product. Inputs can be selected as fundamental phasor magnitudes or total waveform RMS magnitudes as required by the application.

## GROUND TOC1 PICKUP

This setting specifies the ground time overcurrent pickup level in per-unit values. With a Process Bus Module, accuracy of the element is determined by the sum of the relay internal processing errors and input signal from the merging unit errors, which can be significant depending on the merging unit design. For low level pickup settings, especially less than 0.020 pu with a Process Bus Module, ensure that the selected merging unit meets given application accuracy requirements.

## GROUND TOC1 CURVE

This setting selects the inverse time overcurrent curve style.

## GROUND TOC1 TD MULTIPLIER

This setting specifies a multiple of the base curve shape specified by the CURVE setting. Programming this value to zero results in an instantaneous response to all current levels above pickup.

## GROUND TOC1 RESET

The Instantaneous reset method is intended for applications with other relays, such as most static relays, which set the energy capacity directly to zero when the current falls below the reset threshold. The “Timed” reset method can be used where the relay must coordinate with electromechanical relays.

## GROUND TOC1 BLOCK

Assertion of the operand assigned to this setting blocks operation of the ground time overcurrent element.

**Note:**

*These elements measure the current that is connected to the ground channel of a CT/VT module. The conversion range of a standard channel is from 0.02 to 46 times the CT rating.*

**Note:**

*This channel can be also equipped with a sensitive input. The conversion range of a sensitive channel is from 0.002 to 4.6 times the CT rating.*




Figure 273: Ground TOC logic

### 8.7.5.2 GROUND INSTANTANEOUS OVERCURRENT (ANSI 50G, IEC PIOC)

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > GROUND CURRENT > GROUND IOC 1(8)**

*Note:*  
Only Ground IOC 1 is shown

|                                        |   |                                      |                                                                             |
|----------------------------------------|---|--------------------------------------|-----------------------------------------------------------------------------|
| <div>■ GROUND IOC 1</div> <div>■</div> | ⇔ | GROUND IOC 1<br>FUNCTION: Disabled   | Range: Disabled, Enabled                                                    |
|                                        | ⇕ | GROUND IOC 1 SIGNAL<br>SOURCE: SRC 1 | Range: SRC <n><br>Not applicable to relays with 9-2LE                       |
|                                        | ⇕ | GROUND IOC1<br>PICKUP: 1.000 pu      | Range: 0.020 to 30.000 pu in steps of 0.001                                 |
|                                        | ⇕ | GROUND IOC1 PICKUP<br>DELAY: 0.00 s  | Range: 0.00 to 600.00 s in steps of 0.01                                    |
|                                        | ⇕ | GROUND IOC1 RESET<br>DELAY : 0.00 s  | Range: 0.00 to 600.00 in steps of 0.01                                      |
|                                        | ⇕ | GROUND IOC1 BLOCK:<br>Off            | Range: FlexLogic operand                                                    |
|                                        | ⇕ | GROUND IOC1<br>TARGET: Self-reset    | Range: Self-reset, Latched, Disabled<br>Not applicable to relays with 9-2LE |
|                                        | ⇕ | GROUND IOC1<br>EVENTS: Disabled      | Range: Disabled, Enabled<br>Not applicable to relays with 9-2LE             |

The ground instantaneous overcurrent element can be used as an instantaneous element with no intentional delay or as a definite time element. The ground current input is the quantity measured by the ground input CT and is the fundamental phasor magnitude.

#### GROUND IOC1 FUNCTION

This setting enables and disables the element.

GROUND IOC1 SIGNAL SOURCE

This setting selects the signal source for the element.

GROUND IOC1 PICKUP

This setting specifies the pickup level in per-unit values. With a Process Bus Module, accuracy of the element is determined by the sum of the relay internal processing errors and input signal from the merging unit errors, which can be significant depending on the merging unit design. For low level pickup settings, especially less than 0.020 pu with a Process Bus Module, ensure that the selected merging unit meets the given application accuracy requirements.

GROUND IOC1 PICKUP DELAY

This setting specifies the definite time delay after which the operate signal asserts.

GROUND IOC1 RESET DELAY

This setting specifies the reset time delay.

GROUND IOC1 BLOCK

Assertion of the operand assigned to this setting blocks operation of the element.

These elements measure the current that is connected to the ground channel of a CT/VT module. The conversion range of a standard channel is from 0.02 to 46 times the CT rating.

This channel can be also equipped with a sensitive input. The conversion range of a sensitive channel is from 0.002 to 4.6 times the CT rating.




Figure 274: Ground IOC1 logic

8.7.5.3 RESTRICTED GROUND FAULT (ANSI 87RGF, IEC PNDF)

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > GROUND CURRENT > RESTRICTED GROUND FAULT <n>**

*Note:*  
Only Restricted Ground Fault 1 is shown

■ RESTRICTED GROUND  
■ FAULT 1




RESTD GND FT1  
FUNCTION: Disabled

Range: Disabled, Enabled

|   |                                       |                                             |
|---|---------------------------------------|---------------------------------------------|
| ⇅ | RESTD GND FT1<br>SOURCE: SRC 1        | Range: SRC <n>                              |
| ⇅ | RESTD GND FT1<br>PICKUP: 0.080 pu     | Range: 0.005 to 30.000 pu in steps of 0.001 |
| ⇅ | RESTD GND FT1<br>SLOPE: 40%           | Range: 0 to 100% in steps of 1              |
| ⇅ | RESTD GND FT1 PICKUP<br>DELAY: 0.03 s | Range: 0.00 to 600.00 s in steps of 0.01    |
|   | RESTD GND FT1 RESET<br>DELAY: 0.00 s  | Range: 0.00 to 600.00 s in steps of 0.01    |
| ⇅ | RESTD GND FT1 BLOCK:<br>Off           | Range: FlexLogic operand                    |
| ⇅ | RESTD GND FT1<br>TARGET: Self-reset   | Range: Self-reset, Latched, Disabled        |
| ↑ | RESTD GND FT1<br>EVENTS: Disabled     | Range: Disabled, Enabled                    |


Restricted ground fault (RGF) protection provides sensitive ground fault detection for low-magnitude fault currents, primarily faults close to the neutral point of a wye-connected winding. An internal ground fault on an impedance grounded wye winding produces a fault current dependent on the ground impedance value and the fault position on the winding with respect to the neutral point. The resultant primary current is negligible for faults on the lower 30% of the winding since the fault voltage is not the system voltage, but rather the result of the transformation ratio between the primary windings and the percentage of shorted turns on the secondary. Therefore, the resultant differential currents can be below the slope threshold of the main differential element and the fault can go undetected. Application of the restricted ground fault protection extends the coverage towards the neutral point (see the following figure).



842731A1.CDR

**Figure 275: RGF and percent differential zones of protection**


This protection is often applied to transformers having impedance-grounded wye windings. The element can also be applied to the stator winding of a generator having the neutral point grounded with a CT installed in the grounding path, or the ground current obtained by external summation of the neutral-side stator CTs. The following figure shows the basic application and wiring rules.



84273 2A2.CDR


**Figure 276: Typical applications of RGF protection**

The next figures show distribution of the ground fault current through the grounded neutral point of the wye winding and primary delta winding as a function of the fault location as a percentage of the whole wye winding. Magnitude of the transformer winding fault is controlled by several factors, such as supply source impedance, wye winding neutral grounding impedance, transformer leakage reactance, fault voltage windings connection and position of the fault on the winding with respect to the neutral point.



(left is resistance-ground neutral, right is solidly grounded neutral)

**Figure 277: Fault current through transformer neutral against primary current**



(winding current flow during ground)

**Figure 278: Fault current through transformer neutral against primary current**

The settings are as follows.

### RESTD GND FT1 SOURCE

Identifies the signal source for the restricted ground fault (RGF) function. It is important that source includes a set of three-phase CTs on the line side of the wye winding of the transformer assigned to the Phase CT setting of this source and a neutral point CT assigned to the Ground CT setting of this source. In case of more breaker-and-a-half connections on the line side of the transformer or autotransformer application, Phase CT arrangement need to include the sum of CT banks contributing to the differential signal. When the summed CTs have a different ratio, the relay automatically re-scales to the maximum CT primary nominal value.

### RESTD GND FT1 PICKUP

Defines the minimum ground differential current required for operation. The relay automatically matches the CT ratios between the phase and ground CTs by re-scaling the ground CT to the phase CT level, which becomes a base value for the differential and restraint currents. For example, for 10 MVA, 33 kV to 11 kV transformer, 10% impedance, D / Y-1,  $R_G = 6.3\Omega$ , with Phase CT ratio = 600 / 1 A.

$$\text{Maximum phase-to-ground fault current } I_{G_{MAX}} = 11 \text{ kV} / (\sqrt{3} \times 6.3) = 1000 \text{ A primary.}$$

For a winding fault point at 5% distance from the neutral:



$$IG_{PKP} = 0.05 \times IG_{MAX} = 0.05 \times 1000 = 50 \text{ A primary. The pickup setting is chosen as } PKP = 50 \text{ A} / 600 \text{ A} = 0.083 \text{ pu}$$

Note that for correct operation of the element, the **CURRENT CUTOFF** setting under Display Properties has to be set at least two times less than the **PICKUP** setting.

### RESTD GND FT1 SLOPE

Defines the restrain characteristics for this element. Set the slope to provide extra restraint for external faults, but not prevent operation for the winding fault during heavy transformer load. Transformer nominal winding current is  $I_{N(W)} = 10 \text{ MVA} / (\sqrt{3} \times 11 \text{ kV}) = 525 \text{ A} = 525 \text{ A} / 600 \text{ A} = 0.875 \text{ pu}$ . Considering that RGF algorithm restraint is defined by the positive-sequence current during load, and for currents below 2 pu restraint is equal to  $I/8$ , slope can be estimated as follows:

$$\text{Slope} = PKP / (1.2 \times I_{N(W)} / 8) \times 100\% = 0.083 \text{ pu} / (1.2 \times 0.875 / 8) \times 100\% = 63\%$$

where 1.2 factor accounts for 20% temporary overload of the transformer

Because the final slope has to be set lower than this calculated value to have some safety margin, the final setting can be selected as 43%.

### RESTD GND FT1 PICKUP DELAY

Defines element delay from the pickup to assertion of the RESTD GND FT1 OP operand. GE recommends a short time delay to overcome spurious zero-sequence current due to switch-off transients for this sensitive protection.

### RESTD GND FT1 RESET DELAY

Defines how long the RESTD GND FT1 OP operand stays asserted after pickup conditions disappear.

The relay incorporates low-impedance restricted ground fault protection. This low-impedance form of protection faces potential stability problems. An external phase-to-phase fault is an ultimate case. Ideally, there is neither ground (IG) nor neutral (IN = IA + IB + IC) current present. If one or more of the phase CTs saturate, a spurious neutral current is seen by the relay. This is similar to a single infeed situation and can be mistaken for an internal fault. Similar difficulties occur in a breaker-and-a-half application of the restricted ground fault, where any through fault with a weak infeed from the winding itself can cause problems.

The UR uses a novel definition of the restraining signal to cope with the above stability problems while providing fast and sensitive protection. Even with the improved definition of the restraining signal, the breaker-and-a-half application of the restricted ground fault must be approached with care, and is not recommended unless the settings are carefully selected to avoid maloperation due to CT saturation.

The differential current is produced as an unbalance current between the ground current of the neutral CT (IG) and the neutral current derived from the phase CTs (IN = IA + IB + IC):

$$I_{gd} = |IG + IN| = |IG + IA + IB + IC|$$

The restraining signal ensures stability of protection during CT saturation conditions and is produced as a maximum value among three components related to zero, negative, and positive-sequence currents of the three phase CTs as follows:

$$I_{rest} = \max(IR0, IR1, IR2)$$

The zero-sequence component of the restraining signal (IR0) is meant to provide maximum restraint during external ground faults, and therefore is calculated as a vectorial difference of the ground and neutral currents:

$$IR0 = |IG - IN| = |IG - (IA + IB + IC)|$$

The equation above brings an advantage of generating the restraining signal of twice the external ground fault current, while reducing the restraint below the internal ground fault current. The negative-sequence component of the restraining signal (IR2) is meant to provide maximum restraint during external phase-to-phase faults and is calculated as follows:

$$IR2 = |I_{-2}| \text{ or } IR2 = 3 \times |I_{-2}|$$

Following complete de-energization of the windings (all three phase currents below 5% of nominal for at least five cycles), the relay uses a multiplier of 1 in preparation for the next energization. The multiplier of 3 is used during normal operation; that is, two cycles after the winding has been energized. The lower multiplier is used to ensure better sensitivity when energizing a faulty winding.

The positive-sequence component of the restraining signal (IR1) is adaptive and provides restraint during symmetrical conditions, either symmetrical faults or load.

Additionally, the algorithm detects a long-lasting DC during energization, which can saturate line CTs and increase IR1. Long lasting DC in phase A (same in other two phases) is estimated with the following condition:

$$DC\_A = |I\_ARMS - 9 \times I\_AMAG / 8| > 0$$

When this condition is satisfied in any phase for three cycles, DCACTIVE is set and is reset in 60 cycles once the condition disappears. Overall IR1 is calculated according to the following algorithm:

$$\text{IF } |I_{-1}| > 2 \text{ pu AND } |I_{-1}| > |I_{-0}|, \text{ THEN } IR1 = 3 \times (I_{-1MAG} - I_{-0MAG})$$

$$\text{IF DCACTIVE THEN } IR1 = I_{-1MAG} / 2$$

$$\text{OTHERWISE } IR1 = I_{-1MAG} / 8$$

During an external fault involving ground when positive-sequence current exceeds 200% of the phase CT nominal and positive-sequence current exceeds zero-sequence current, IR1 restraint is set to the maximum value. During energization with the long-lasting DC, IR1 is set to half of the positive-sequence current to ensure extra restraint. If none of two conditions are present, then IR1 is set to the minimum value of the 1/8 of the positive-sequence current to ensure sensitivity during load conditions.

The raw restraining signal (Irest) is further post-filtered for better performance during external faults with heavy CT saturation and for better switch-off transient control:

$$I_{gr}(k) = \max(I_{rest}(k), a \times I_{gr}(k - 1))$$


where:

- k represents a present sample
- k – 1 represents the previous sample
- a is a factory constant (a < 1)

The equation above introduces a decaying memory to the restraining signal. Should the raw restraining signal (Irest) disappear or drop significantly, such as when an external fault gets cleared or a CT saturates heavily, the actual restraining signal (Igr(k)) does not reduce instantly but keeps decaying decreasing its value by 50% each 15.5 power system cycles.

For additional security, the element applies a ground current of the transformer neutral CT (IG) supervision by allowing element pickup and operation when the IG magnitude is above 0.8 x Pickup setting.

Having the differential and restraining signals developed, the element applies a single slope differential characteristic with a minimum pickup as shown in the following logic diagram.



828002A4.cdr

**Figure 279: Restricted ground fault logic**

The following examples explain how the restraining signal is created for maximum sensitivity and security. These examples clarify the operating principle and provide guidance for testing of the element.

#### Example 1: External single-line-to-ground fault

Given the following inputs:  $I_A = 1 \text{ pu } \angle 0^\circ$ ,  $I_B = 0$ ,  $I_C = 0$ , and  $I_G = 1 \text{ pu } \angle 180^\circ$

The relay calculates the following values:

$$I_{gd} = 0$$

$$I_{R0} = \text{abs} [(-1) - 1] = 2 \text{ pu}$$

$$I_{R1} = (1/3)/8 = 0.042 \text{ pu}$$

$$I_{R2} = 3 \times 1/3 = 1 \text{ pu}$$

$$I_{gr} = 2 \text{ PU}$$

#### Example 2: External high-current SLG fault

Given the following inputs:  $I_A = 10 \text{ pu } \angle 0^\circ$ ,  $I_B = 0$ ,  $I_C = 0$ , and  $I_G = 10 \text{ pu } \angle -180^\circ$

The relay calculates the following values:

$$I_{gd} = 0$$

$$I_{R0} = \text{abs} [(-10) - 10] = 20 \text{ pu}$$

$$I_{R1} = (10/3 - 10/3) = 0$$

$$I_{R2} = 3 \times 10/3 = 10 \text{ pu}$$

$$I_{gr} = 20 \text{ PU}$$

#### Example 3: External high-current three-phase symmetrical fault

Given the following inputs:  $I_A = 10 \text{ pu } \angle 0^\circ$ ,  $I_B = 10 \text{ pu } \angle -120^\circ$ ,  $I_C = 10 \text{ pu } \angle 120^\circ$ , and  $I_G = 0 \text{ pu}$

$$I_{gd} = 0$$

$$\begin{aligned} IR0 &= \text{abs}[0 - 0] = 0 \text{ pu} \\ IR1 &= 3(10/3 - 0) = 10 \text{ pu} \\ IR2 &= 3 \times 0 = 0 \text{ pu} \\ I_{gr} &= 10 \text{ PU} \end{aligned}$$

#### Example 4: Internal low-current single-line-to-ground fault under full load

Given the following inputs:  $I_A = 1.10 \text{ pu } \angle 0^\circ$ ,  $I_B = 1.0 \text{ pu } \angle -120^\circ$ ,  $I_C = 1.0 \text{ pu } \angle 120^\circ$ , and  $I_G = 0.05 \text{ pu } \angle 0^\circ$

The relay calculates the following values:

$$\begin{aligned} I_0 &= 0.033 \text{ pu } \angle 0^\circ \\ I_1 &= 1.033 \text{ pu } \angle 0^\circ \\ I_2 &= 0.033 \text{ pu } \angle 0^\circ \\ I_{gd} &= \text{abs}(3 \times 0.0333 + 0.05) = 0.15 \text{ pu}, \\ IR0 &= \text{abs}(0.05 - 3 \times 0.033) = 0.05 \text{ pu} \\ IR1 &= 1.033 / 8 = 0.1292 \text{ pu, and} \\ IR2 &= 3 \times 0.033 = 0.10 \text{ pu,} \\ I_{gr} &= 0.1292 \text{ pu} \end{aligned}$$

Despite very low fault current level, the differential current is above 100% of the restraining current.

## 8.7.6 NEGATIVE SEQUENCE CURRENT

### SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > NEGATIVE SEQUENCE CURRENT

|                                                                                                      |   |                                                                                              |
|------------------------------------------------------------------------------------------------------|---|----------------------------------------------------------------------------------------------|
| <input checked="" type="checkbox"/> NEGATIVE SEQUENCE<br><input checked="" type="checkbox"/> CURRENT | ↔ | <input checked="" type="checkbox"/> NEG SEQ TOC<n><br><input checked="" type="checkbox"/>    |
|                                                                                                      | ⇕ | <input checked="" type="checkbox"/> NEG SEQ IOC<n><br><input checked="" type="checkbox"/>    |
|                                                                                                      | ↑ | <input checked="" type="checkbox"/> NEG SEQ DIR OC<n><br><input checked="" type="checkbox"/> |

#### 8.7.6.1 NEGATIVE SEQUENCE DIRECTIONAL OVERCURRENT (ANSI 67Q, IEC PDEF/PTOC)

### SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > NEGATIVE SEQUENCE CURRENT > NEG SEQ DIR OC<n>

Note:  
Only Dir Seq OC 1 is shown

|                                                                                            |   |                                       |                                             |
|--------------------------------------------------------------------------------------------|---|---------------------------------------|---------------------------------------------|
| <input checked="" type="checkbox"/> NEG SEQ DIR OC1<br><input checked="" type="checkbox"/> | ↔ | NEG SEQ DIR OC1<br>FUNCTION: Disabled | Range: Disabled, Enabled                    |
|                                                                                            | ⇕ | NEG SEQ DIR OC1<br>SOURCE: SRC 1      | Range: SRC <n>                              |
|                                                                                            | ⇕ | NEG SEQ DIR OC1<br>OFFSET: 0.00 Ω     | Range: 0.00 to 250.00 ohms in steps of 0.01 |

|   |                                            |                                             |
|---|--------------------------------------------|---------------------------------------------|
| ⇅ | NEG SEQ DIR OC1<br>TYPE: Neg Sequence      | Range: Neg Sequence, Zero Sequence          |
| ⇅ | NEG SEQ DIR OC1 POSSEQ<br>RESTRAINT: 0.063 | Range: 0.000 to 0.500 in steps of 0.001     |
| ⇅ | NEG SEQ DIR OC1 FWD<br>ECA: 75° Lag        | Range: 0 to 90° Lag in steps of 1           |
| ⇅ | NEG SEQ DIR OC1 FWD<br>LIMIT ANGLE: 90°    | Range: 40 to 90° in steps of 1              |
| ⇅ | NEG SEQ DIR OC1 FWD<br>PICKUP: 0.050 pu    | Range: 0.015 to 30.000 pu in steps of 0.005 |
| ⇅ | NEG SEQ DIR OC1 REV<br>LIMIT ANGLE: 90°    | Range: 40 to 90° in steps of 1              |
| ⇅ | NEG SEQ DIR OC1 REV<br>PICKUP: 0.050 pu    | Range: 0.015 to 30.000 pu in steps of 0.005 |
| ⇅ | NEG SEQ DIR OC1 BLK:<br>Off                | Range: FlexLogic operand                    |
| ⇅ | NEG SEQ DIR OC1<br>TARGET: Self-reset      | Range: Self-reset, Latched, Disabled        |
| ⇅ | NEG SEQ DIR OC1<br>EVENTS: Disabled        | Range: Disabled, Enabled                    |

There are two negative-sequence directional overcurrent protection elements available. The element provides both forward and reverse fault direction indications through its output operands NEG SEQ DIR OC1 FWD and NEG SEQ DIR OC1 REV, respectively. The output operand is asserted if the magnitude of the operating current is above a pickup level (overcurrent unit) and the fault direction is seen as forward or reverse, respectively (directional unit).

The overcurrent unit of the element essentially responds to the magnitude of a fundamental frequency phasor of either the negative-sequence or neutral current as per user selection.

A positive-sequence restraint is applied for better performance: a small user-programmable portion of the positive-sequence current magnitude is subtracted from the negative or zero-sequence current magnitude, respectively, when forming the element operating quantity.

$$I_{op} = |I_2| - K \times |I_1| \text{ or } I_{op} = 3 \times (|I_0| - K \times |I_1|)$$

The positive-sequence restraint allows for more sensitive settings by counterbalancing spurious negative-sequence and zero-sequence currents resulting from:

- System unbalances under heavy load conditions
- Transformation errors of current transformers (CTs)
- Fault inception and switch-off transients

The positive-sequence restraint must be considered when testing for pickup accuracy and response time (multiple of pickup). The positive-sequence restraint is removed for low currents. If the positive-sequence current is less than 0.8 pu, then the restraint is removed by changing the constant K to zero. This results in better response to high-resistance faults when the unbalance is very small and there is no danger of excessive CT errors, since the current is low.

The operating quantity depends on the way the test currents are injected into the Product. For single phase injection

$$I_{op} = \frac{1}{3} \times (1 - K) \times I_{injected} \text{ for } I_2 \text{ mode}$$

$$I_{op} = (1 - K) \times I_{injected} \text{ for } I_0 \text{ mode if } I_1 > 0.8 \text{ pu}$$

The directional unit uses the negative-sequence current ( $I_2$ ) and negative-sequence voltage ( $V_2$ ).

The following tables define the negative-sequence directional overcurrent element.

**Negative-sequence directional overcurrent unit**

| Mode              | Operating current                                                                                                                                   |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| Negative-sequence | $I_{op} =  I_{-2}  - K \times  I_{-1} $                                                                                                             |
| Zero-sequence     | $I_{op} = 3 \times ( I_{-0}  - K \times  I_{-1} )$ if $ I_{-1}  > 0.8 \text{ pu}$<br>$I_{op} = 3 \times  I_{-0} $ if $ I_{-1}  \leq 0.8 \text{ pu}$ |

**Negative-sequence directional unit**


| Direction | Compared phasors                                                     |
|-----------|----------------------------------------------------------------------|
| Forward   | $-V_{-2} + Z_{offset} \times I_{-2}$ $I_{-2} \times 1 \angle ECA$    |
| Reverse   | $-V_{-2} + Z_{offset} \times I_{-2}$ $-(I_{-2} \times 1 \angle ECA)$ |

$Z_{offset}$  is the offset impedance, for which magnitude is the OFFSET setting and angle is the FWD ECA.

The negative-sequence voltage must be greater than **PRODUCT SETUP > DISPLAY PROPERTIES > VOLTAGE CUT-OFF LEVEL** to be validated for use as polarizing signal. Additionally, when offset impedance is applied and negative-sequence current is above 0.2 pu, compensated negative-sequence voltage  $-V_{-2} + Z_{offset} \times I_{-2}$  has to be above 0.02 pu in order to discriminate fault direction; otherwise when negative-sequence current is less than 0.2 pu,  $-V_{-2}$  is then used as the polarizing signal. If the polarizing signal is not validated, neither forward nor reverse indication is given. The following figure explains the usage of the voltage polarized directional unit of the element. It shows the phase angle comparator characteristics for a phase A to ground fault, with settings of

- ECA = 75° (element characteristic angle = centerline of operating characteristic)
- FWD LA = 80° (forward limit angle = ± the angular limit with the ECA for operation)
- REV LA = 80° (reverse limit angle = ± the angular limit with the ECA for operation)

The element incorporates a current reversal logic: if the reverse direction is indicated for at least 1.25 of a power system cycle, the prospective forward indication is delayed by 1.5 of a power system cycle. The element emulates an electromechanical directional device. Larger operating and polarizing signals result in faster directional discrimination, bringing more security to the element operation.



### Figure 280: Negative-sequence directional characteristic

The forward-looking function is designed to be more secure compared to the reverse-looking function, so use the forward-looking function for the tripping direction. The reverse-looking function is faster compared to the forward-looking function, so use the reverse-looking function for the blocking direction. This allows for better protection coordination. Take this bias into account when using the negative-sequence directional overcurrent element to directionalize other protection elements. The negative-sequence current must be greater than the **PRODUCT SETUP > DISPLAY PROPERTIES > CURRENT CUT-OFF LEVEL** setting value.

## Settings

## NEG SEQ DIR OC1 OFFSET

Specifies the offset impedance used by this protection. The primary application for the offset impedance is to guarantee correct identification of fault direction on series compensated lines (see the Application of Settings chapter for information on how to calculate this setting). In regular applications, the offset impedance ensures proper operation even if the negative-sequence voltage at the relaying point is very small. If this is the intent, the offset impedance shall not be larger than the negative-sequence impedance of the protected circuit. Practically, it is several times smaller. Enter the offset impedance in secondary ohms.

### NEG SEQ DIR OC1 TYPE

Selects the operating mode for the overcurrent unit of the element. The choices are “Neg Sequence” and “Zero Sequence.” In some applications it is advantageous to use a directional negative-sequence overcurrent function instead of a directional zero-sequence overcurrent function as inter-circuit mutual effects are minimized.

### NEG SEQ DIR OC1 POS-SEQ RESTRAINT

Controls the positive-sequence restraint. Set it to 0.063 (in “Zero Sequence” mode) or 0.125 (in “Neg Sequence” mode) for backward compatibility with revisions 3.40 and earlier. Set it to zero to remove the restraint. Set it higher if large system unbalances or poor CT performance are expected.

### NEG SEQ DIR OC1 FWD ECA

Select the element characteristic angle (ECA) for the forward direction. The element characteristic angle in the reverse direction is the angle set for the forward direction shifted by 180°.

### NEG SEQ DIR OC1 FWD LIMIT ANGLE

Defines a symmetrical limit angle (in both directions from the ECA) for the forward direction.

### NEG SEQ DIR OC1 FWD PICKUP


Defines the pickup level for the overcurrent unit in the forward direction. This pickup threshold applies to zero-sequence or negative-sequence current based on the NEG SEQ DIR OC1 TYPE setting. When specifying this setting, keep in mind that the design uses a positive-sequence restraint technique.

### NEG SEQ DIR OC1 REV LIMIT ANGLE

Defines a symmetrical limit angle (in both directions from the ECA) for the reverse direction.

### NEG SEQ DIR OC1 REV PICKUP

Defines the pickup level for the overcurrent unit in the reverse direction. This pickup threshold applies to zero-sequence or negative-sequence current based on the NEG SEQ DIR OC1 TYPE setting. When selecting this setting, keep in mind that the design uses a positive-sequence restraint technique.




827196A1.vsd

Figure 281: Negative-sequence directional OC1 logic

## 8.7.7 GENERATOR UNBALANCE (ANSI 46)

SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > GENERATOR UNBALANCE





|   |                                     |                                            |
|---|-------------------------------------|--------------------------------------------|
| ⇅ | GEN UNBAL SOURCE:<br>SRC 1          | Range: SRC <n>                             |
| ⇅ | GEN UNBAL INOM:<br>0.800 pu         | Range: 0.000 to 1.250 pu in steps of 0.001 |
| ⇅ | GEN UNBAL STG1<br>PICKUP: 8.00%     | Range: 0.00 to 100.00% in steps of 0.01    |
| ⇅ | GEN UNBAL STG1<br>K-VALUE: 1.00     | Range: 0.00 to 100.00 in steps of 0.01     |
| ⇅ | GEN UNBAL STG1 TMIN:<br>0.250 s     | Range: 0.000 to 50.000 s in steps of 0.001 |
| ⇅ | GEN UNBAL STG1 TMAX:<br>600.00 s    | Range: 0.0 to 1000.0 s in steps of 0.1     |
| ⇅ | GEN UNBAL STG1<br>K-RESET: 240.00 s | Range: 0.0 to 1000.0 s in steps of 0.1     |
| ⇅ | GEN UNBAL STG2<br>PICKUP: 3.0%      | Range: 0.00 to 100.00% in steps of 0.01    |
| ⇅ | GEN UNBAL STG2 PKP<br>DELAY: 5.0 s  | Range: 0.0 to 1000.0 s in steps of 0.1     |
| ⇅ | GEN UNBAL BLK:<br>Off               | Range: FlexLogic operand                   |
| ⇅ | GEN UNBAL TARGET:<br>Self-Reset     | Range: Self-reset, Latched, Disabled       |
| ↑ | GEN UNBAL EVENTS:<br>Disabled       | Range: Disabled, Enabled                   |

The generator unbalance element protects the machine from rotor damage due to excessive negative-sequence current. The element has an inverse time stage that is typically used for tripping and a definite time stage typically used for alarm purposes. The inverse time stage operating characteristic is defined by the following equation:

$$T = K / (I_2 / I_{nom})^2$$

where:

- $I_{nom}$  is the generator rated current
- $K$  is the negative-sequence capability constant normally provided by the generator manufacturer

### GEN UNBAL INOM

This setting is the rated full load current of the machine.

### GEN UNBAL STG1 PICKUP

Defines the pickup of the stage 1 element expressed as a percentage of the nominal current as specified by the **GEN UNBAL INOM** setting. It is set typically at the maximum continuous negative sequence current rating of the machine.

### GEN UNBAL STG1 K-VALUE

The negative sequence capability constant. This value is normally provided by the generator manufacturer (see ANSI C50.13 for details).

**GEN UNBAL STG1 TMIN**

The minimum operate time of the stage 1 element. The stage does not operate before this time expires. This is set to prevent false trips for faults that would be cleared normally by system protections.

**GEN UNBAL STG1 TMAX**

The maximum operate time of the stage 1 element. This setting can be applied to limit the maximum tripping time for low level unbalances.

**GEN UNBAL STG1 K-RESET**


Defines the linear reset rate of the stage 1 element. It is the maximum reset time from the threshold of tripping. This feature provides a thermal memory of previous unbalance conditions.

**GEN UNBAL STG2 PICKUP**

Defines the pickup of the stage 2 element expressed as a percentage of the nominal current as specified by the **GEN UNBAL INOM** setting. The definite time element is used to generate an alarm to prompt an operator to take some corrective action. The stage 2 element is set typically at a safe margin below the stage 1 pickup setting.

**GEN UNBAL STG2 PKP DELAY**

The minimum operate time of the stage 2 element. This is set to prevent nuisance alarms during system faults.



830714A2.cdr

**Figure 282: Generator unbalance inverse time curves**




Figure 283: Generator unbalance logic

### 8.7.8 SPLIT PHASE PROTECTION (ANSI 50SP)


#### SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > SPLIT PHASE

|                                       |   |                                   |                                            |
|---------------------------------------|---|-----------------------------------|--------------------------------------------|
| <div>■ SPLIT PHASE</div> <div>■</div> | ⇔ | SPLIT PHASE<br>FUNCTION: Disabled | Range: Disabled, Enabled                   |
|                                       | ⇕ | SPLIT PHASE SOURCE:<br>SRC 1      | Range: SRC <n><br>n = 1 to 4               |
|                                       | ⇕ | SPLIT PHASE LOAD<br>SOURCE: SRC 2 | Range: SRC <n><br>n = 1 to 4               |
|                                       | ⇕ | SPLIT PHASE A<br>PICKUP: 0.200 pu | Range: 0.020 to 1.500 pu in steps of 0.001 |
|                                       | ⇕ | SPLIT PHASE A<br>OFFSET: 0.000 pu | Range: 0.000 to 1.000 pu in steps of 0.001 |
|                                       | ⇕ | SPLIT PHASE A SLOPE:<br>0.0%      | Range: 0.0 to 100% in steps of 0.1         |
|                                       | ⇕ | SPLIT PHASE B<br>PICKUP: 0.200 pu | Range: 0.020 to 1.500 pu in steps of 0.001 |
|                                       | ⇕ | SPLIT PHASE B<br>OFFSET: 0.000 pu | Range: 0.000 to 1.000 pu in steps of 0.001 |
|                                       | ⇕ | SPLIT PHASE B SLOPE:<br>0.0%      | Range: 0.0 to 100% in steps of 0.1         |
|                                       | ⇕ | SPLIT PHASE C<br>PICKUP: 0.200 pu | Range: 0.020 to 1.500 pu in steps of 0.001 |
|                                       | ⇕ | SPLIT PHASE C<br>OFFSET: 0.000 pu | Range: 0.000 to 1.000 pu in steps of 0.001 |

|   |                                   |                                            |
|---|-----------------------------------|--------------------------------------------|
| ⇅ | SPLIT PHASE C SLOPE:<br>0.0%      | Range: 0.0 to 100% in steps of 0.1         |
| ⇅ | SPLIT PHASE MIN<br>LOAD: 0.00 pu  | Range: 0.00 to 1.00 pu in steps of 0.01    |
| ⇅ | SPLIT PHASE MODE:<br>Over         | Range: Over, Over-Under                    |
| ⇅ | SPLIT PHASE DELAY:<br>0.000 s     | Range: 0.000 to 65.535 s in steps of 0.001 |
| ⇅ | SPLIT PHASE BLK:<br>Off           | Range: FlexLogic operand                   |
| ⇅ | SPLIT PHASE TARGET:<br>Self-Reset | Range: Self-reset, Latched, Disabled       |
| ↑ | SPLIT PHASE EVENTS:<br>Disabled   | Range: Disabled, Enabled                   |


Some generators, due to physical construction, have windings that consist of multiple adjacent turns. It is therefore possible for faults to develop between turns on the same phase (inter-turn faults). These faults are not detected by the stator differential protection, as there is no difference between the neutral and at-terminal currents. Split phase protection can be applied to detect inter-turn faults when the generator is wound with two three-phase windings, each brought separately out of the machine and connected in parallel. The currents in the two windings are compared, any difference indicating an inter-turn fault.

The split phase element allows a separate pickup setting to be applied for each phase. Additionally, the pickup can be biased by the load current (slope characteristic). Two modes of operation are supported (over and over-under).



830728A1.CDR

**Figure 284: Split phase protection for two CTs**



**Figure 285: Split phase protection for one CT**

The split phase element principle of operation is as follows. First, define the following parameters:

- $I_{split}$  = split-phase current
- $I_{load}$  = load current
- pickup = pickup setting

$min\_load$  = minimum load supervision setting

Then, the expected value of the steady state unbalance (defined as bias current) is expressed as follows:

$$I_{bias} = slope \times I_{load} + offset$$

where:


$$slope = (I_{load}/I_{split}) \times (Load\ CT\ Primary/Load\ CT\ Secondary) \times (Split\ Phase\ CT\ Secondary)/(Split\ Phase\ CT\ Primary)$$

and offset is the split phase current at no-load. In “Over” mode, the element picks up if

$$(I_{split} - I_{bias} > pickup) \text{ and } (I_{load} \geq min\_load)$$

In “Over-under” mode, the element picks up if

$$(|I_{split} - I_{bias}| > pickup) \text{ and } (I_{load} \geq min\_load)$$



830729A1.CDR

**Figure 286: Split phase protection operating characteristics**

The settings are as follows.

### SPLIT PHASE FUNCTION

This setting enables and disables the function.

### SPLIT PHASE SOURCE

Specifies a signal source used to provide current from the split phase CT to the split phase protection.

### **SPLIT PHASE LOAD SOURCE**

Specifies a signal source used to provide current from the load CT to the split phase protection.

### **SPLIT PHASE A(C) PICKUP**

Specifies a pickup level for each phase. Set it less than the minimum expected unbalance (split phase) current due to an inter-turn fault.

### **SPLIT PHASE A(C) OFFSET**

Specifies the steady-state split phase current at no-load for the each phase. Set it equal to the split phase current during normal (unfaulted) operation. Assign the split phase current and the load current (positive sequence) to the data logger to identify the optimum value for this setting.

### **SPLIT PHASE A(C) SLOPE**

Specifies the slope of split phase characteristic for each phase. This setting is used to bias the pickup of the element due to variations in generator loading. The slope is defined as the ratio of the per-unit split phase current over the per-unit load current. Assign the split phase current and the load current (positive sequence) to the data logger to identify the optimum value for this setting.

### **SPLIT PHASE MIN LOAD**

Specifies the minimum load (positive-sequence current) supervision level.

### **SPLIT PHASE MODE**

Specifies the mode of operation. If the “Over” mode is chosen, the element picks up when the split phase current rises above the biased offset current plus the pickup setting. If “Over-under” mode is chosen, the element also picks up if the split phase current falls below the biased offset current minus the pickup setting. See the earlier description for details.

### **SPLIT PHASE DELAY**

Specifies a time delay required to operate after the pickup condition is established. During an external disturbance the CTs can saturate. CT saturation can cause a spurious split phase current, especially in the case where the split phase current is derived from the external summation of two split phase CTs (first figure presented). In this instance, a time delay can be used to ride through the saturation event. Alternately, the CT saturation flag also can be used to supervise the function.



|                              |   |                                 |                                                                |
|------------------------------|---|---------------------------------|----------------------------------------------------------------|
| <b>VOLTAGE ELEMENTS</b><br>■ | ⇔ | ■ PHASE<br>■ UNDERVOLTAGE<n>    | All models except C30, T35                                     |
|                              | ⇕ | ■ PHASE<br>■ OVERVOLTAGE<n>     | All models except C30, T35                                     |
|                              | ⇕ | ■ NEUTRAL OV<n><br>■            | All models except C30, B90, N60, T35                           |
|                              | ⇕ | ■ NEG SEQ OV <n><br>■           | All models except B30, B90, C30, C60, C95, F35, L90, N60, T35, |
|                              | ⇕ | ■ AUXILIARY UV<n><br>■          | All models except B90, C30, C70, N60, T35                      |
|                              | ⇕ | ■ AUXILIARY OV<n><br>■          | All models except B90, C30, N60, T35                           |
|                              | ⇕ | ■ VOLTS/HZ <n><br>■             | G30, G60, L90, T60                                             |
|                              | ⇕ | ■ COMPENSATED><br>■ OVERVOLTAGE | D60, L60, L90,                                                 |



|   |                                                                            |     |
|---|----------------------------------------------------------------------------|-----|
| ⇅ | <div> <div>■ VOLTAGE</div> <div>■ DIFFERENTIAL &lt;n&gt;</div> </div>      | C70 |
| ⇅ | <div> <div>■ BANK</div> <div>■ OVERVOLTAGE</div> </div>                    | C70 |
| ↑ | <div> <div>■ NEUTRAL VOLTAGE</div> <div>■ UNBALANCE &lt;n&gt;</div> </div> | C70 |

These protection elements can be used for a variety of applications, such as

- Undervoltage protection — For voltage sensitive loads, such as induction motors, a drop in voltage increases the drawn current, which can cause dangerous overheating in the motor. The undervoltage protection feature can be used to either cause a trip or generate an alarm when the voltage drops below a specified voltage setting for a specified time delay.
- Overvoltage protection — Overvoltage elements can be used to protect voltage sensitive loads and system components against sustained overvoltage conditions
- Permissive functions — The undervoltage/overvoltage features can be used to block the functioning of external devices by operating an output relay when the voltage falls below/exceeds the specified voltage setting. The undervoltage/overvoltage features can also be used to block the functioning of other elements through the block feature of those elements.
- Source transfer schemes — In the event of undervoltage/overvoltage, a transfer signal can be generated to transfer a load from its normal source to a standby or emergency power source

### 8.7.9.2 UNDERVOLTAGE INVERSE TIME CURVES


The undervoltage elements can be programmed to have an inverse time delay characteristic. If in the respective element the CURVE setting is set to Inverse Time, the undervoltage delay setting establishes the operating curve of the element as follows:

$$T = \frac{D}{\left(1 - \frac{V}{V_{\text{pickup}}}\right)}$$

where

- T = operating time
- D = undervoltage delay setting (D = 0.00 operates instantaneously)
- V = secondary voltage applied to the relay
- $V_{\text{pickup}}$  = pickup level

For reset time, see the settings section of the applicable element.



**Figure 288: Inverse time undervoltage curves**

At 0% of pickup, the operating time equals the corresponding undervoltage element **DELAY** setting.

### 8.7.9.3 OVERVOLTAGE INVERSE TIME CURVES

The overvoltage elements can be programmed to have an inverse time delay characteristic. If in the respective element the CURVE setting is set to Inverse Time, the overvoltage pickup delay setting establishes the operating curve of the element as follows:

$$T = D / (V / V_{\text{pickup}} - 1)$$

where:

- T = operating time
- D = undervoltage delay setting (D = 0.00 operates instantaneously)
- V = secondary voltage applied to the relay
- $V_{\text{pickup}}$  = pickup level

For reset time, see the settings section of the applicable element.




Figure 289: Inverse time overvoltage curves

#### 8.7.9.4 PHASE UNDERVOLTAGE (ANSI 27P, IEC PTUV)

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > VOLTAGE ELEMENTS > PHASE UNDERVOLTAGE<n>**

*Note:*  
Only Phase undervoltage 1 is shown

|                                                |   |                                        |                                                            |
|------------------------------------------------|---|----------------------------------------|------------------------------------------------------------|
| <div>■ PHASE</div> <div>■ UNDERVOLTAGE 1</div> | ⇔ | PHASE UV1<br>FUNCTION: Disabled        | Range: Disabled, Enabled                                   |
|                                                | ⇕ | PHASE UV1 SIGNAL<br>SOURCE: SRC 1      | Range: SRC <n>                                             |
|                                                | ⇕ | PHASE UV1 MODE:<br>Phase to Ground     | Range: Phase to Ground, Phase to Phase                     |
|                                                | ⇕ | PHASE UV1<br>PICKUP: 1.000 pu          | Range: 0.004 to 3.000 pu in steps of 0.001                 |
|                                                | ⇕ | PHASE UV1<br>CURVE: Definite Time      | Range: Definite Time, Inverse Time, FlexCurves A through D |
|                                                | ⇕ | PHASE UV1<br>DELAY: 1.00 s             | Range: 0.00 to 600.00 s in steps of 0.01                   |
|                                                | ⇕ | PHASE UV1 RESET<br>DELAY: 1.00 s       | Range: 0.00 to 600.00 s in steps of 0.01                   |
|                                                | ⇕ | PHASE UV1 MINIMUM<br>VOLTAGE: 0.100 pu | Range: 0.000 to 3.000 pu in steps of 0.001                 |
|                                                | ⇕ | PHASE UV1 BLOCK:<br>Off                | Range: FlexLogic operand                                   |

|   |                                 |                                      |
|---|---------------------------------|--------------------------------------|
| ⇅ | PHASE UV1<br>TARGET: Self-reset | Range: Self-reset, Latched, Disabled |
| ↑ | PHASE UV1<br>EVENTS: Disabled   | Range: Disabled, Enabled             |

### PHASE UV1 SIGNAL SOURCE

Selects the signal source for the phase undervoltage protection element.

### PHASE UV1 MODE

This setting defines the mode of operation that can be Phase-to-Phase or Phase-to-Ground voltage. Phase-to-ground or phase-to-phase voltages can be applied for wye VT connection, while phase-to-phase voltages can be applied for delta VT connections only.

### PHASE UV1 PICKUP

This setting specifies the phase undervoltage protection element pickup level.

### PHASE UV1 CURVE

This setting defines the timing characteristic of the element, which can be Definite Time, Inverse Time (per the curves described earlier in the Voltage Elements > Undervoltage Inverse Time Curves section), or FlexCurves A through D. The timing characteristic depends on this setting and the Delay setting that follows.

### PHASE UV1 DELAY

This setting defines the operation time of the element.

- When the PHASE UV1 CURVE setting is set to Definite Time, the PHASE UV1 DELAY setting defines definite time delay for element operation.
- When the PHASE UV1 CURVE setting is set to Inverse Time, the PHASE UV1 DELAY setting defines the inverse curve time delay multiplier (D) that is used in the curve equation explained in the Voltage Elements > Undervoltage Inverse Time Curves section.
- When the PHASE UV1 CURVE setting is set to one of the FlexCurves, the PHASE UV1 DELAY setting defines the FlexCurve time delay multiplier (D) that is used in the following curve equation:

$$T = D \times \text{FlexCurve time at } (V_{pkp}/V)$$

For FlexCurves configuration instructions, see the **System Setup > FlexCurves** section.

### PHASE UV1 RESET DELAY


When the Curve setting is set to Definite Time or Inverse Time, the element resets when applied voltage exceeds the dropout voltage for the duration of the selected **RESET DELAY** setting.

When the Curve setting is set to one of the FlexCurves, the element reset is based on the equation and not the **PHASE UV1 RESET DELAY** setting.

As shown in the equation, because the element is supposed to operate in undervoltage condition, the multiple of pickup value that defines the point on the FlexCurve characteristic is derived from the ratio of the set pickup value to the measured voltage (and not the reverse). For example, if Pickup is set to 0.9 pu, when measured voltage is 0.82 pu, the ratio is  $0.9/0.82 = 1.1$ . Therefore, in FlexCurve, the corresponding operate time is at 1.1 x PKP (not at 0.82 x PKP). On the other hand, when measured voltage is 1 pu, the ratio is  $0.9/1 = 0.9$ . Therefore, in FlexCurve, the corresponding reset time is at 0.9 x PKP.

### PHASE UV1 MINIMUM VOLTAGE

This setting selects the operating voltage below which the element is blocked (a setting of "0" allows a dead source to be considered a fault condition).



85 98 24A1.vsd

Figure 290: Phase undervoltage1 logic

### 8.7.9.5 PHASE OVERVOLTAGE (ANSI 59P, IEC PTOV)

SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > VOLTAGE ELEMENTS > PHASE OVERVOLTAGE<n>

**Note:**  
Only Phase overvoltage 1 is shown

|                                               |   |                                                         |                                                            |
|-----------------------------------------------|---|---------------------------------------------------------|------------------------------------------------------------|
| <div> <div>■ PHASE OVERVOLTAGE 1</div> </div> | ↔ | <div> <div>PHASE OV1 FUNCTION: Disabled</div> </div>    | Range: Disabled, Enabled                                   |
|                                               | ⇕ | <div> <div>PHASE OV1 SIGNAL SOURCE: SRC 1</div> </div>  | Range: SRC <n>                                             |
|                                               | ⇕ | <div> <div>PHASE OV1 MODE: Phase to Ground</div> </div> | Range: Phase to Ground, Phase to Phase                     |
|                                               | ⇕ | <div> <div>PHASE OV1 PICKUP: 1.000 pu</div> </div>      | Range: 0.004 to 3.000 pu in steps of 0.001                 |
|                                               | ⇕ | <div> <div>PHASE OV1 CURVE: Definite Time</div> </div>  | Range: Definite Time, Inverse Time, FlexCurves A through D |
|                                               | ⇕ | <div> <div>PHASE OV1 DELAY: 1.00 s</div> </div>         | Range: 0.00 to 600.00 s in steps of 0.01                   |
|                                               | ⇕ | <div> <div>PHASE OV1 RESET DELAY: 1.00 s</div> </div>   | Range: 0.00 to 600.00 s in steps of 0.01                   |
|                                               | ⇕ | <div> <div>PHASE OV1 BLOCK: Off</div> </div>            | Range: FlexLogic operand                                   |
|                                               | ⇕ | <div> <div>PHASE OV1 TARGET: Self-reset</div> </div>    | Range: Self-reset, Latched, Disabled                       |
|                                               | ↑ | <div> <div>PHASE OV1 EVENTS: Disabled</div> </div>      | Range: Disabled, Enabled                                   |

This element gives a time-delay operating characteristic versus the applied fundamental voltage.

## PHASE OV1 SIGNAL SOURCE

Selects the signal source for the phase overvoltage protection element.

## PHASE OV1 MODE

This setting defines the mode of operation, which can be Phase-to-Phase or Phase-to-Ground voltage. Phase-to-ground or phase-to-phase voltages can be applied for wye VT connection, while phase-to-phase voltages can be applied for delta VT connections only.

## PHASE OV1 PICKUP

This setting specifies phase overvoltage protection element pickup level.

## PHASE OV1 CURVE

This setting defines the timing characteristic of the element, which can be: Definite Time, Inverse Time (per the curves described in the Voltage Elements > Overvoltage Inverse Time Curves section), FlexCurves A through D. The timing characteristic depends on this setting and the Pickup Delay setting that follows.

## PHASE OV1 PICKUP DELAY

This setting defines the operation time of the element.

- When the PHASE OV1 CURVE setting is set to Definite Time, the **PHASE OV1 PICKUP DELAY** setting defines definite time delay for element operation.
- When the PHASE OV1 CURVE setting is set to Inverse Time, the **PHASE OV1 PICKUP DELAY** setting defines the inverse curve time delay multiplier (D) that is used in the Voltage Elements > Overvoltage Inverse Time Curves section.
- When the PHASE OV1 CURVE setting is set to one of the FlexCurves, the **PHASE OV1 PICKUP DELAY** setting defines the FlexCurve time delay multiplier (D) that is used in the following curve equation:

$$T = D \times \text{FlexCurve time at } (V/V_{pkp})$$


For FlexCurves configuration instructions, see the **System Setup > FlexCurves** section.

## PHASE OV1 RESET DELAY

When the Curve setting is set to Definite Time or Inverse Time, the element resets when applied voltage goes below the dropout voltage for the duration of the selected **RESET DELAY** setting.

When the Curve setting is set to one of the FlexCurves, the element reset is based on the equation and not the **PHASE OV1 RESET DELAY** setting.

As shown in the equation, the multiple of pickup value that defines the point on the FlexCurve characteristic is derived from the ratio of the measured voltage to the set pickup. For example, if Pickup is set to 1.1 pu when the measured voltage is 1.3 pu, the ratio is  $1.3/1.1 = 1.2$ . Therefore, in FlexCurve, the corresponding operate time is at  $1.2 \times \text{PKP}$  (not at  $1.3 \times \text{PKP}$ ). On the other hand, when measured voltage is 1 pu, the ratio is  $1/1.1 = 0.9$ . Therefore, in FlexCurve, the corresponding reset time is at  $0.9 \times \text{PKP}$ .



859823A1.vsd

Figure 291: Phase overvoltage logic

### 8.7.9.6 NEUTRAL OVERVOLTAGE (ANSI 59N, IEC PTOV)

SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > VOLTAGE ELEMENTS > NEUTRAL OVERVOLTAGE<n>

Note:  
Only Neutral overvoltage 1 is shown


|                                       |   |                                                         |                                                             |
|---------------------------------------|---|---------------------------------------------------------|-------------------------------------------------------------|
| <div>■ NEUTRAL OV1</div> <div>■</div> | ↔ | <div>NEUTRAL OV1</div> <div>FUNCTION: Disabled</div>    | Range: Disabled, Enabled                                    |
|                                       | ⇅ | <div>NEUTRAL OV1 SIGNAL</div> <div>SOURCE: SRC 1</div>  | Range: SRC <n>                                              |
|                                       | ⇅ | <div>NEUTRAL OV1 PICKUP:</div> <div>0.300 pu</div>      | Range: 0.004 to 3.000 pu in steps of 0.001                  |
|                                       | ⇅ | <div>NEUTRAL OV1 CURVE:</div> <div>Definite Time</div>  | Range: Definite Time, FlexCurve A, FlexCurve B, FlexCurve C |
|                                       | ⇅ | <div>NEUTRAL OV1 PICKUP:</div> <div>DELAY: 1.00 s</div> | Range: 0.00 to 600.00 s in steps of 0.01                    |
|                                       | ⇅ | <div>NEUTRAL OV1 RESET:</div> <div>DELAY: 1.00 s</div>  | Range: 0.00 to 600.00 s in steps of 0.01                    |
|                                       | ⇅ | <div>NEUTRAL OV1 BLOCK:</div> <div>Off</div>            | Range: FlexLogic operand                                    |
|                                       | ⇅ | <div>NEUTRAL OV1 TARGET:</div> <div>Self-reset</div>    | Range: Self-reset, Latched, Disabled                        |
|                                       | ⇅ | <div>NEUTRAL OV1 EVENTS:</div> <div>Disabled</div>      | Range: Disabled, Enabled                                    |

The neutral overvoltage element is used to detect asymmetrical system voltage condition due to a ground fault or to the loss of one or two phases of the source. The element responds to the system neutral voltage (3V\_0), calculated

from the phase voltages. The nominal secondary voltage of the phase voltage channels entered under **SETTINGS > SYSTEM SETUP > AC INPUTS > VOLTAGE BANK > PHASE VT SECONDARY** is the p.u. base used when setting the pickup level.

The neutral overvoltage element can provide a time-delayed operating characteristic versus the applied voltage (initialized from FlexCurves A, B, or C) or be used as a definite time element. The **NEUTRAL OV1 PICKUP DELAY** setting applies only if the **NEUTRAL OV1 CURVE** setting is *Definite Time*. The source assigned to this element must be configured for a phase VT.

VT errors and normal voltage unbalance must be considered when setting this element. This function requires the VTs to be wye-connected.



827848A3.CDR

Figure 292: Neutral overvoltage1 logic

### 8.7.9.7 NEGATIVE-SEQUENCE OVERVOLTAGE (ANSI 59Q, IEC PTOV)

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > VOLTAGE ELEMENTS > NEG SEQ OV<n>**

**Note:**  
Only Neg Seq OV 1 is shown

|                                       |   |                                                         |                                           |
|---------------------------------------|---|---------------------------------------------------------|-------------------------------------------|
| <div>■ NEG SEQ OV1</div> <div>■</div> | ↔ | <div>NEG SEQ OV1</div> <div>FUNCTION: Disabled</div>    | Range: Disabled, Enabled                  |
|                                       | ⇕ | <div>NEG SEQ OV 1 SIGNAL</div> <div>SOURCE: SRC 1</div> | Range: SRC <n>                            |
|                                       | ⇕ | <div>NEG SEQ OV 1 PICKUP:</div> <div>0.300 pu</div>     | Range: 0.004 to 1.250 pu in steps of 0.00 |
|                                       | ⇕ | <div>NEG SEQ OV 1 PICKUP</div> <div>DELAY: 0.50 s</div> | Range: 0.00 to 600.00 s in steps of 0.01  |
|                                       | ⇕ | <div>NEG SEQ OV 1 RESET</div> <div>DELAY: 0.50 s</div>  | Range: 0.00 to 600.00 s in steps of 0.01  |
|                                       | ⇕ | <div>NEG SEQ OV 1 BLOCK:</div> <div>Off</div>           | Range: FlexLogic operand                  |
|                                       | ⇕ | <div>NEG SEQ OV 1 TARGET:</div> <div>Self-reset</div>   | Range: Self-reset, Latched, Disabled      |
|                                       | ↑ | <div>NEG SEQ OV 1 EVENTS:</div> <div>Disabled</div>     | Range: Disabled, Enabled                  |



Use the negative-sequence overvoltage element to detect loss of one or two phases of the source, a reversed phase sequence of voltage, or a non-symmetrical system voltage condition.




Figure 293: Negative-sequence overvoltage logic

### 8.7.9.8 AUXILIARY UNDERVOLTAGE (ANSI 27X, IEC PTUV)

SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > VOLTAGE ELEMENTS > AUXILIARY UNDERVOLTAGE<n>

**Note:**  
Only Auxiliary undervoltage 1 is shown

|                                         |   |                                      |                                                            |
|-----------------------------------------|---|--------------------------------------|------------------------------------------------------------|
| <div>■ AUXILIARY UV1</div> <div>■</div> | ⇔ | AUX UV1<br>FUNCTION: Disabled        | Range: Disabled, Enabled                                   |
|                                         | ⇕ | AUX UV1 SIGNAL<br>SOURCE: SRC 1      | Range: SRC <n>                                             |
|                                         | ⇕ | AUX UV1<br>PICKUP: 0.700 pu          | Range: 0.004 to 3.000 pu in steps of 0.001                 |
|                                         | ⇕ | AUX UV1 CURVE:<br>Definite Time      | Range: Definite Time, Inverse Time, FlexCurves A through D |
|                                         | ⇕ | AUX UV1 DELAY:<br>1.00 s             | Range: 0.00 to 600.00 s in steps of 0.01                   |
|                                         | ⇕ | AUX UV1 RESET DELAY:<br>1.00 s       | Range: 0.00 to 600.00 s in steps of 0.01                   |
|                                         | ⇕ | AUX UV1 MINIMUM<br>VOLTAGE: 0.100 pu | Range: 0.000 to 3.000 pu in steps of 0.001                 |
|                                         | ⇕ | AUX UV1 BLOCK:<br>Off                | Range: FlexLogic operand                                   |
|                                         | ⇕ | AUX UV1 TARGET:<br>Self-reset        | Range: Self-reset, Latched, Disabled                       |
|                                         | ⇕ | AUX UV1 EVENTS:<br>Disabled          | Range: Disabled, Enabled                                   |

This element monitors undervoltage conditions of the auxiliary voltage.

## AUX UV1 SIGNAL SOURCE

Selects the signal source for the auxiliary undervoltage protection element.

## AUX UV1 PICKUP

This setting specifies auxiliary undervoltage protection element pickup level in per unit values. The nominal secondary voltage of the auxiliary voltage channel entered under **SETTINGS > SYSTEM SETUP > AC INPUTS > VOLTAGE BANK X5 > AUXILIARY VT X5 SECONDARY** is the per-unit base used when setting the pickup level.

## AUX UV1 CURVE

This setting defines the timing characteristic of the element, which can be: Definite Time, Inverse Time (per the curves described in the **Voltage Elements > Undervoltage Inverse Time Curves** section), FlexCurves A through D. The timing characteristic depends on this setting and the Delay setting that follows.

## AUX UV1 DELAY

This setting defines the operation time of the element.

- When the **AUX UV1 CURVE** setting is set to Definite Time, the **AUX UV1 DELAY** setting defines definite time delay for element operation.
- When the **AUX UV1 CURVE** setting is set to Inverse Time curve, the **AUX UV1 DELAY** setting defines the inverse curve time delay multiplier (D) that is used in the curve equation explained in the **Voltage Elements > Undervoltage Inverse Time Curves** section.
- When the **AUX UV1 CURVE** setting is set to one of the FlexCurves, the **AUX UV1 DELAY** setting defines FlexCurve time delay multiplier (D), that is used in the following curve equation:

$$T = D \times \text{FlexCurve time at } (V_{pk} / V)$$

For FlexCurves configuration instructions, see the **System Setup > FlexCurves** section.

## AUX UV1 RESET DELAY

When the Curve setting is set to Definite Time or Inverse Time, the element resets when applied voltage exceeds the dropout voltage for the duration of the selected RESET DELAY setting.

When the Curve setting is set to one of the FlexCurves, the element reset is based on the equation and not the **AUX UV1 RESET DELAY** setting.

As shown in the equation, because the element is supposed to operate in undervoltage condition, the multiple of pickup value that defines the point on the FlexCurve characteristic is derived from the ratio of the set pickup value to the measured voltage (and not the reverse). For example, if the Pickup is set to 0.9 pu, when the measured voltage is 0.82 pu, the ratio is  $0.9/0.82 = 1.1$ . Therefore, in the FlexCurve, the corresponding operate time is at  $1.1 \times PKP$  (not at  $0.82 \times PKP$ ). On the other hand, when measured voltage is 1 pu, the ratio is  $0.9/1 = 0.9$ . Therefore, in the FlexCurve, the corresponding reset time is at  $0.9 \times PKP$ .

## AUX UV1 DELAY

Selects the minimum operating time of the auxiliary undervoltage element.

## AUX UV1 RESET DELAY

The element resets if the applied voltage exceeds the dropout voltage for the duration of the selected RESET DELAY setting.

## AUX UV1 MINIMUM VOLTAGE

Selects the operating voltage below which the element is blocked.




Figure 294: Auxiliary undervoltage logic

### 8.7.9.9 AUXILIARY OVERVOLTAGE (ANSI 59X, IEC PTOV)

SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > VOLTAGE ELEMENTS > AUXILIARY OVERVOLTAGE<n>

Note:  
Only Auxiliary overvoltage 1 is shown

|                                             |   |                                   |                                                            |
|---------------------------------------------|---|-----------------------------------|------------------------------------------------------------|
| <div><div>■ AUX OV1</div><div>■</div></div> | ⇔ | AUX OV1<br>FUNCTION: Disabled     | Range: Disabled, Enabled                                   |
|                                             | ⇕ | PHASE OV1 SIGNAL<br>SOURCE: SRC 1 | Range: SRC <n>                                             |
|                                             | ⇕ | AUX OV1 PICKUP:<br>0.300 pu       | Range: 0.004 to 3.000 pu in steps of 0.001                 |
|                                             | ⇕ | AUX OV1 CURVE:<br>Definite Time   | Range: Definite Time, Inverse Time, FlexCurves A through D |
|                                             | ⇕ | AUX OV1 PICKUP<br>DELAY: 1.00 s   | Range: 0.00 to 600.00 s in steps of 0.01                   |
|                                             | ⇕ | AUX OV1 RESET<br>DELAY: 1.00 s    | Range: 0.00 to 600.00 s in steps of 0.01                   |
|                                             | ⇕ | AUX OV1 BLOCK:<br>Off             | Range: FlexLogic operand                                   |
|                                             | ⇕ | AUX OV1 TARGET:<br>Self-reset     | Range: Self-reset, Latched, Disabled                       |
|                                             | ↑ | AUX OV1 EVENTS:<br>Disabled       | Range: Disabled, Enabled                                   |

This element is intended for monitoring overvoltage conditions of the auxiliary voltage. Monitoring the neutral voltage supplied from an open-delta VT connection is a typical application for this element.

#### AUX OV1 SIGNAL SOURCE

Selects the signal source for the auxiliary overvoltage protection element.

#### AUX OV1 PICKUP

This setting specifies auxiliary overvoltage protection element pickup level in per-unit values.

The nominal secondary voltage of the auxiliary voltage channel entered under **SYSTEM SETUP > AC INPUTS > VOLTAGE BANK X5 > AUXILIARY VT SECONDARY** is the per-unit base used when setting the pickup level.

### AUX OV1 CURVE

This setting defines the timing characteristic of the element, which can be: Definite Time, Inverse Time (per the curves described in the **Voltage Elements > Overvoltage Inverse Time Curves** section), FlexCurves A through D. The timing characteristic depends on this setting and the Pickup Delay setting that follows.

### AUX OV1 PICKUP DELAY

This setting defines the operation time of the element.

- When the **AUX OV1 CURVE** setting is set to Definite Time, the **AUX OV1 PICKUP DELAY** setting defines definite time delay for element operation.
- When the **AUX OV1 CURVE** setting is set to Inverse Time, the **AUX OV1 PICKUP DELAY** setting defines inverse curve time delay multiplier (D), that is used in the Voltage Elements > Overvoltage Inverse Time Curves section.
- When the **AUX OV1 CURVE** setting is set to one of the FlexCurves, the **AUX OV1 PICKUP DELAY** setting defines the FlexCurve time delay multiplier (D) that is used in the following equation:

$$T = D \times \text{FlexCurve time at } (V/V_{pkp})$$

For FlexCurves configuration instructions, see the **System Setup > FlexCurves** section.

### AUX OV1 RESET DELAY

- When the Curve setting is set to Definite Time or Inverse Time, the element resets when applied voltage goes below the dropout voltage for the duration of the selected **RESET DELAY** setting.
- When the Curve setting is set to one of the FlexCurves, the elements reset is based on the equation and not the **AUX OV1 RESET DELAY** setting.

As shown in the equation, the multiple of pickup value that defines the point on the FlexCurve characteristic is derived from the ratio of the measured voltage to the set pickup. For example, if Pickup is set to 1.1 pu, when measured voltage is 1.3 pu, the ratio is  $1.3/1.1 = 1.2$ . Therefore, in the FlexCurve, the corresponding operate time is at  $1.2 \times PKP$  (not at  $1.3 \times PKP$ ). On the other hand, when measured voltage is 1 pu, the ratio is  $1/1.1 = 0.9$ . Therefore, in the FlexCurve, the corresponding reset time is at  $0.9 \times PKP$ .




Figure 295: Auxiliary overvoltage logic

#### 8.7.9.10 VOLTS PER HERTZ (ANSI 24, IEC PVPH)


**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > VOLTAGE ELEMENTS > VOLTS/HZ<n>**

Note:  
Only Volts/Hz 1 is shown

|                                      |   |                                             |                                                                                                           |
|--------------------------------------|---|---------------------------------------------|-----------------------------------------------------------------------------------------------------------|
| <div>■ VOLTS/HZ 1</div> <div>■</div> | ⇔ | VOLTS/HZ 1 FUNCTION:<br>Disabled            | Range: Disabled, Enabled                                                                                  |
|                                      | ⇕ | VOLTS/HZ 1 SOURCE:<br>SRC 1                 | Range: SRC <n>                                                                                            |
|                                      | ⇕ | VOLTS/HZ 1 VOLTAGE<br>MODE: Phase to Ground | Range: Phase to Ground, Phase to Phase                                                                    |
|                                      | ⇕ | VOLTS/HZ 1 PICKUP:<br>0.80 pu               | Range: 0.80 to 4.00 pu in steps of 0.01                                                                   |
|                                      | ⇕ | VOLTS/HZ 1 CURVE:<br>Definite Time          | Range: Definite Time, Inverse A, Inverse B, Inverse C, FlexCurve A, FlexCurve B, FlexCurve C, FlexCurve D |
|                                      | ⇕ | VOLTS/HZ 1 TD<br>MULTIPLIER: 1.00           | Range: 0.05 to 600.00 in steps of 0.01                                                                    |
|                                      |   | VOLTS/HZ 1<br>T-RESET: 1.0 s                | Range: 0.0 to 1000.0 s in steps of 0.1                                                                    |
|                                      | ⇕ | VOLTS/HZ 1 BLOCK:<br>Off                    | Range: FlexLogic operand                                                                                  |
|                                      | ⇕ | VOLTS/HZ 1 TARGET:<br>Self-reset            | Range: Self-reset, Latched, Disabled                                                                      |
|                                      | ↑ | VOLTS/HZ 1 EVENTS:<br>Disabled              | Range: Disabled, Enabled                                                                                  |

The per-unit volts-per-hertz (V/Hz) value is calculated using the maximum of the three-phase voltage inputs or the auxiliary voltage channel Vx input, if the source is not configured with phase voltages. To use the V/Hz element with auxiliary voltage, set **SYSTEM SETUP > SIGNAL SOURCES > SOURCE 1(6) > SOURCE 1(6) PHASE VT** to *None* and **SOURCE 1(6) AUX VT** to the corresponding voltage input bank. If there is no voltage on the relay terminals in either case, the per-unit V/Hz value is automatically set to “0”. The per unit value is established as per voltage and nominal frequency power system settings as follows:

- If the phase voltage inputs defined in the source menu are used for V/Hz operation, then *1 pu* is the selected **SYSTEM SETUP > AC INPUTS > VOLTAGE BANK N > PHASE VT N SECONDARY** setting, divided by the divided by the **SYSTEM SETUP > POWER SYSTEM > NOMINAL FREQUENCY** setting.
- If the voltage bank connection value is selected as *Delta*, then the phase-to-phase nominal voltage is used to define the per-unit value. If the voltage bank connection value is selected as *Wye*, then the **VOLTS/HZ 1 VOLTAGE MODE** setting further defines the operating quantity and per-unit value for this element. If the voltage mode is set as *Phase to Phase*, then the operating quantity for this element is the phase-to-phase nominal voltage. Likewise, if the voltage mode is set to *Phase to Ground*, then the operating quantity for this element is the phase-to-ground nominal voltage. It is beneficial to use the phase-to-phase voltage mode for this element when the Product device is applied on an isolated or resistance-grounded system.
- When the auxiliary voltage Vx is used (regarding the condition for *None* phase voltage setting mentioned above), then the 1 pu value is the **SYSTEM SETUP > AC INPUTS > VOLTAGE BANK N > AUXILIARY VT N SECONDARY** setting divided by the **SYSTEM SETUP > POWER SYSTEM > NOMINAL FREQUENCY** setting.
- If V/Hz source is configured with both phase and auxiliary voltages, the maximum phase among the three voltage channels at any given point in time is the input voltage signal for element operation, and therefore the per-unit value is calculated as described in Step 1. If the measured voltage of all three phase voltages is 0, then the per-unit value becomes automatically 0 regardless of the presence of auxiliary voltage.



828003A8.cdr

**Figure 296: Volts per hertz logic**

The element has a linear reset characteristic. The reset time can be programmed to match the cooling characteristics of the protected equipment. The element fully resets from the trip threshold in **VOLTS/HZ T-RESET** seconds. The V/Hz element can be used as an instantaneous element with no intentional time delay or as a Definite or Inverse timed element.

The characteristics of the inverse curves are as follows.

### Definite time

For the definite time curve,  $T(\text{sec.}) = \text{TD multiplier}$ . For example, setting the TD multiplier to 20 results a time delay of 20 seconds to operate when above the **Volts/Hz pickup** setting. Instantaneous operation can be obtained the same way by setting the TD multiplier to 0.

### Inverse curve A


The curve for the volts/hertz inverse curve A shape is derived from the formula:

$$T = \frac{\text{TDM}}{\left[\left(\frac{V}{F}\right) / \text{Pickup}\right]^2 - 1} \text{ when } \frac{V}{F} > \text{Pickup}$$

where:

- T = Operating Time
- TDM = Time Delay Multiplier (delay in seconds)
- V = fundamental RMS value of voltage (pu)
- F = frequency of voltage signal (pu)
- Pickup = volts-per-hertz pickup setpoint (pu)

The figure shows the volts/hertz inverse A curves.



**Figure 297: Volts-per-hertz curves, inverse curve A**

#### Inverse curve B


The curve for the Volts/Hertz Inverse Curve B shape is derived from the formula:

$$T = \frac{TDM}{\left[\left(\frac{V}{F}\right) / \text{Pickup}\right] - 1} \quad \text{when } \frac{V}{F} > \text{Pickup}$$

where:

- T = Operating Time
- TDM = Time Delay Multiplier (delay in sec.)
- V = fundamental RMS value of voltage (pu)
- F = frequency of voltage signal (pu)
- Pickup = volts-per-hertz pickup setpoint (pu)

The figure shows the volts/hertz inverse B curves.



830739A1.CDR

**Figure 298: Volts-per-hertz curves, inverse curve B**

### Inverse curve C

The curve for the Volts/Hertz Inverse Curve C shape is derived from the formula:

$$T = \frac{TDM}{\left[\left(\frac{V}{F}\right)/\text{Pickup}\right]^{0.5} - 1} \quad \text{when } \frac{V}{F} > \text{Pickup}$$

where:

- T = Operating Time
- TDM = Time Delay Multiplier (delay in sec.)
- V = fundamental RMS value of voltage (pu)
- F = frequency of voltage signal (pu)
- Pickup = volts-per-hertz pickup setpoint (pu)

The figure shows the volts/hertz inverse C curves.







Figure 299: Volts-per-hertz curves, inverse curve C

### 8.7.10 LOSS OF EXCITATION (ANSI 40)

**SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > LOSS OF EXCITATION**

|                                              |   |                                           |                                             |
|----------------------------------------------|---|-------------------------------------------|---------------------------------------------|
| <div>■ LOSS OF</div> <div>■ EXCITATION</div> | ⇔ | LOSS OF EXCITATION<br>FUNCTION: Disabled  | Range: Disabled, Enabled                    |
|                                              | ⇕ | LOSS OF EXCITATION<br>SOURCE: SRC 1       | Range: SRC <n>                              |
|                                              | ⇕ | LOSS OF EXCITATION<br>CENTER 1: 10.00 ohm | Range: 0.10 to 300.00 ohms in steps of 0.01 |
|                                              | ⇕ | LOSS OF EXCITATION<br>RADIUS 1: 8.00 ohm  | Range: 0.10 to 300.00 ohms in steps of 0.01 |
|                                              | ⇕ | LOSS OF EXCITATION<br>ANGLE 1: 0°         | Range: -75° to +75° in steps of 1°          |
|                                              | ⇕ | EXCITATION V SUPV 1:<br>Enabled           | Range: Disabled, Enabled                    |
|                                              | ⇕ | LOSS OF EXCITATION<br>PKP DELAY1: 0.050 s | Range: 0.000 to 65.535 s in steps of 0.01   |
|                                              | ⇕ | LOSS OF EXCITATION<br>CENTER 2: 12.00 ohm | Range: 0.10 to 300.00 ohms in steps of 0.01 |
|                                              | ⇕ | LOSS OF EXCITATION<br>RADIUS 2: 10.00 ohm | Range: 0.10 to 300.00 ohms in steps of 0.01 |
|                                              | ⇕ | LOSS OF EXCITATION<br>ANGLE 2: 0°         | Range: -75° to +75° in steps of 1°          |
|                                              | ⇕ | LOSS OF EXCITATION<br>V SUPV 2: Enabled   | Range: Disabled, Enabled                    |
|                                              | ⇕ | LOSS OF EXCITATION<br>PKP DELAY2: 0.500 s | Range: 0.000 to 65.535 s in steps of 0.01   |



830711A2

**Figure 300: Loss of excitation operating characteristics**

The G60 relay supports all 3 schemes for the loss of excitation described in the IEEE Std C37.102-2023 “IEEE Guide for AC Generator Protection”. The above figure shows each scheme in the R-X plane. The first two impedance schemes are supported directly in the R-X plane and the third admittance scheme is supported via conversion from the G-B or P-Q planes into R-X plane.

The following settings calculations are shown for Scheme 1. Refer to IEEE Std C37.102-2023 for details for other characteristics.

### Stage 1 settings

The stage 1 characteristic is typically set to detect a loss of excitation for load conditions of 30% of the nominal or higher. This is achieved with a mho element with a diameter equal to the base impedance of the machine and an offset equal to half the machine transient reactance ( $X'd$ ).

$$\text{CENTER 1} = (Z_b + X'd)/2$$

$$\text{RADIUS 1} = (Z_b)/2$$

The stage 1 element should be time delayed to allow for blocking by the VT fuse failure element (50 ms).

### Stage 2 settings

The stage 2 characteristic is typically set to detect a loss of excitation for all load conditions. This is achieved with a mho element with a diameter equal to the synchronous reactance of the machine and an offset equal to half the machine transient reactance ( $X'd$ ).

$$\text{CENTER } 2 = (X_d + X'_d)/2$$

$$\text{RADIUS } 1 = (X_d)/2$$

During stable power swing conditions, the positive-sequence impedance can momentarily enter the stage 2 characteristic. For security of the function under such conditions, it is recommended to delay stage 2 by a minimum of 0.5 seconds.


### LOSS OF EXCIT BLK

The **LOSS OF EXCIT BLK** setting specifies a FlexLogic operand for blocking the feature based on user-programmable conditions. When the blocking input is asserted, the element resets its timers, de-asserts the PKP and OP operands (if asserted), clears self-reset targets, logs a 'blocked' event if events are enabled, and becomes inactive. When unblocked, the element starts functioning instantly. If exposed to pickup conditions for an extended period of time and unblocked, the element picks up and starts timing out at the moment of unblocking.

#### Note:

For the G30, if the VTs are located on the HV side of the transformer, then the source should be configured using CTs that are also on the HV side. Correspondingly, if the VTs are located on the LV side of the transformer, then the source should be configured using CTs that are also on the LV side. In both cases, the CT polarity should produce a positive power measurement when the machine is generating.

The element responds to the positive sequence impedance as shown in the logic diagram.




830001AC

Figure 301: Loss of excitation logic

### 8.7.11 ACCIDENTAL ENERGIZATION (ANSI 50/27)

SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > ACCIDENTAL ENERGIZATION



|   |                                            |                                            |
|---|--------------------------------------------|--------------------------------------------|
| ⇅ | ACCDNT ENRG SOURCE:<br>SRC 1               | Range: SRC <n>                             |
| ⇅ | ACCDNT ENRG ARMING<br>MODE: UV and Offline | Range: UV and Offline, UV or Offline       |
| ⇅ | ACCDNT ENRG OC<br>PICKUP: 0.300 pu         | Range: 0.020 to 3.000 pu in steps of 0.001 |
| ⇅ | ACCDNT ENRG UV<br>PICKUP: 0.500 pu         | Range: 0.004 to 3.000 pu in steps of 0.001 |
| ⇅ | ACCDNT ENRG OFFLINE:<br>Off                | Range: FlexLogic operand                   |
| ⇅ | ACCDNT ENRG BLOCK:<br>Off                  | Range: FlexLogic operand                   |
| ⇅ | ACCDNT ENRG TARGET:<br>Self-reset          | Range: Self-reset, Latched, Disabled       |
| ↑ | ACCDNT ENRG EVENTS:<br>Disabled            | Range: Disabled, Enabled                   |

This element provides protection against energization while the generator is at standstill or reduced speed. The feature is armed using either the AND or OR combination of the undervoltage and machine offline conditions, selected with the **ACCDNT ENRG ARMING MODE** setting (see below). The undervoltage condition is determined from the measured voltages. The machine offline status is indicated by a dedicated FlexLogic operand. Once armed, the accidental energization feature operates upon detecting an overcurrent condition in any of the stator phases.

This feature can also provide protection against poor synchronization.

### ACCDNT ENRG ARMING MODE

This setting specifies whether the feature gets armed by either of the undervoltage or machine offline conditions (*UV or Offline* value), or by both the conditions (*UV and Offline* value). In both cases, the element is armed after five seconds of the appropriate condition and de-armed 250 ms after the arming condition (UV and/or Offline) ceases.

Select *UV or Offline* when the VTs are on the power system side of the disconnecting device. If this is the case, the measured voltages can be normal regardless of the status of the protected machine, thus the need for an OR condition. The *UV or Offline* value provides protection against poor synchronization. During normal synchronization, there should be relatively low current measured. If however, synchronization is attempted when conditions are not appropriate, a large current is measured shortly after closing the breaker. Since this feature does not de-arm immediately, but after a 250 ms time delay, this results in operation under imprecise synchronization. The **ACCDNT ENRG OC PICKUP** setting can control the required precision of synchronization.

Select the *UV and Offline* value when the VTs are on the generator side of the disconnecting device. If this is the case, both the undervoltage and machine offline conditions are required to indicate that the protected generator is not energized.

### ACCDNT ENRG OC PICKUP

This setting specifies the current level required to operate the armed Accidental Energization element. If any of the phase current is above the **ACCDNT ENRG OC PICKUP** level, the feature operates.

### ACCDNT ENRG UV PICKUP

This setting specifies the voltage level required to arm the Accidental Energization element. All of the line-to-line voltages must drop below the **ACCDNT ENRG UV PICKUP** level in order to detect the undervoltage condition. The setting is entered in voltage pu values. As the element always responds to the line-to-line voltages, care must be applied in picking up the value depending on the VT connection.

### ACCDNT ENRG OFFLINE

This setting specifies the FlexLogic operand indicating that the protected generator is offline.




Figure 302: Accidental energization logic

### 8.7.12 POWER

SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > POWER

|                    |   |                     |                                             |
|--------------------|---|---------------------|---------------------------------------------|
| <div>■ POWER</div> | ⇔ | ■ SENSITIVE         | C60, C95, D60, F60, G30, G60, L90, N60, T60 |
|                    |   | ■ DIRECTIONAL POWER |                                             |
| ■                  | ↑ | ■ UNDERPOWER        | M60 only                                    |
|                    |   | ■                   |                                             |

#### 8.7.12.1 SENSITIVE DIRECTIONAL POWER (ANSI 32)

SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > VOLTAGE ELEMENTS > POWER > SENSITIVE DIRECTIONAL POWER > DIRECTIONAL POWER 1(2)

Note:  
Only Directional power 1 is shown

|                                               |   |                                   |                                |
|-----------------------------------------------|---|-----------------------------------|--------------------------------|
| <div>■ DIRECTIONAL</div> <div>■ POWER 1</div> | ⇔ | DIR POWER 1<br>FUNCTION: Disabled | Range: Disabled, Enabled       |
|                                               |   | DIR POWER 1<br>SOURCE: SRC 1      | Range: SRC <n>                 |
|                                               |   | DIR POWER 1<br>RCA: 0°            | Range: 0 to 359° in steps of 1 |

|   |                                    |                                             |
|---|------------------------------------|---------------------------------------------|
| ⇅ | DIR POWER 1<br>CALIBRATION: 0.00°  | 0 to 0.95° in steps of 0.05                 |
| ⇅ | DIR POWER 1 STG1<br>SMIN: 0.100 pu | Range: -3.300 to 3.300 pu in steps of 0.001 |
| ⇅ | DIR POWER 1 STG1<br>DELAY: 0.50 s  | Range: 0.00 to 600.00 s in steps of 0.01    |
| ⇅ | DIR POWER 1 STG2<br>SMIN: 0.100 pu | Range: -3.300 to 3.300 pu in steps of 0.001 |
| ⇅ | DIR POWER 1 STG2<br>DELAY: 20.00 s | Range: 0.00 to 600.00 s in steps of 0.01    |
| ⇅ | DIR POWER 1 BLK:<br>Off            | Range: FlexLogic operand                    |
| ⇅ | DIR POWER 1<br>TARGET: Self-reset  | Range: Self-reset, Latched, Disabled        |
| ↑ | DIR POWER 1<br>EVENTS: Disabled    | Range: Disabled, Enabled                    |

The sensitive directional power element responds to three-phase directional power and is designed for reverse power and low forward power applications for synchronous machines or interconnections involving co-generation. The relay measures the three-phase power from either a full set of wye-connected VTs or a full set of delta-connected VTs. In the latter case, the two-wattmeter method is used. See the UR-series Metering Conventions section in chapter 6 for details regarding the active and reactive powers used by the sensitive directional power element.


The element has an adjustable characteristic angle and minimum operating power as shown in the Directional Power Characteristic diagram that follows. The element responds to the following condition:

$$P \cos \theta + Q \sin \theta > \text{SMIN}$$

where:


- P and Q are active and reactive powers as measured per the UR metering convention
- $\theta$  is a sum of the element characteristic (**DIR POWER 1 RCA**) and calibration (**DIR POWER 1 CALIBRATION**) angles
- SMIN is the minimum operating power

The operating quantity is displayed in the **ACTUAL VALUES > METERING > SENSITIVE DIRECTIONAL POWER 1(2)** actual value. The element has two independent (as to the pickup and delay settings) stages for alarm and trip, respectively.



**Figure 303: Directional power characteristic**

By making the characteristic angle adjustable and providing for both negative and positive values of the minimum operating power, a variety of operating characteristics can be achieved as presented in the following figure. For example, section (a) in the figure shows settings for reverse power, while section (b) shows settings for low forward power applications.



**Figure 304: Directional power element sample applications**

### DIR POWER 1 RCA

Specifies the relay characteristic angle (RCA) for the sensitive directional power function. Application of this setting is threefold:

- It allows the element to respond to active or reactive power in any direction (active overpower/underpower, and so on)
- Together with a precise calibration angle, it allows compensation for any CT and VT angular errors to permit more sensitive settings
- It allows for required direction in situations when the voltage signal is taken from behind a delta-wye connected power transformer and the phase angle compensation is required

For example, the active overpower characteristic is achieved by setting **DIR POWER 1 RCA** to  $0^\circ$ , reactive overpower by setting **DIR POWER 1 RCA** to  $90^\circ$ , active underpower by setting **DIR POWER 1 RCA** to  $180^\circ$ , and reactive underpower by setting **DIR POWER 1 RCA** to  $270^\circ$ .

### DIR POWER 1 CALIBRATION

This setting allows the relay characteristic angle to change in steps of  $0.05^\circ$ . This is useful when a small difference in VT and CT angular errors is to be compensated to permit more sensitive settings. This setting virtually enables calibration of the directional power function in terms of the angular error of applied VTs and CTs. The element responds to the sum of the **DIR POWER 1 RCA** and **DIR POWER 1 CALIBRATION** settings.

### DIR POWER 1 STG1 SMIN

This setting specifies the minimum power as defined along the relay characteristic angle (RCA) for the stage 1 of the element. The positive values imply a shift towards the operate region along the RCA line; the negative values imply a shift towards the restrain region along the RCA line. See the Directional Power Sample Applications figure for details. Together with the RCA, this setting enables a wide range of operating characteristics. This setting applies to three-phase power and is entered in per-unit (pu) values. The base quantity is  $3 \times \text{VT pu base} \times \text{CT pu base}$  for wye connected VTs, and  $\sqrt{3} \times \text{VT pu base} \times \text{CT pu base}$  for delta connected VTs.

For example, a setting of 2% for a 200 MW machine is  $0.02 \times 200 \text{ MW} = 4 \text{ MW}$ . If 13.8kV is line voltage and 10 kA is a primary CT current, the source pu quantity is 239 MVA, and thus, SMIN needs to be set at  $4 \text{ MW} / 239 \text{ MVA} = 0.0167 \text{ pu} \approx 0.017 \text{ pu}$ . If the reverse power application is considered,  $\text{RCA} = 180^\circ$  and  $\text{SMIN} = 0.017 \text{ pu}$ .

The element drops out if the magnitude of the positive-sequence current becomes virtually zero, that is, it drops below the cutoff level.


### DIR POWER 1 STG1 DELAY

This setting specifies a time delay for stage 1. For reverse power or low forward power applications for a synchronous machine, stage 1 is typically applied for alarming and stage 2 for tripping.

**Note:**

*If the VTs are located on the high-voltage (HV) side of the transformer, then the source should be configured using CTs that are also on the HV side. Correspondingly, if the VTs are located on the low-voltage (LV) side of the transformer, then the source should be configured using CTs that are also on the LV side. In both cases, the CT polarity should produce a positive power measurement when the machine is generating.*






842003A3.CDR

Figure 305: Sensitive directional power logic

### 8.7.13 STATOR GROUND

#### SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > STATOR GROUND




Third harmonic neutral undervoltage protection that responds to the third harmonic in the voltage at the machine neutral point is provided as a means of stator ground protection.

This element is configured through its individual setting menu. The STATOR GROUND SOURCE setting specifies a signal source used to provide current and voltage signals for stator ground fault protection. The third harmonic neutral undervoltage function is configured as follows:

- Configure phase voltages measured at the terminal of the machine as phase VT banks. The element uses the voltages to measure the power at the machine terminals for power supervision.
- Configure phase currents measured at the terminal of the machine as phase CT banks. The element uses the currents to measures the power at the machine terminals for power supervision.
- Configure voltage measured at the neutral of the machine as the auxiliary VT bank. The element extracts the third harmonic of the auxiliary voltage from the source in order to operate.

#### 8.7.13.1 THIRD HARMONIC NEUTRAL UNDERVOLTAGE (ANSI 27TN)

##### SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1(6) > STATOR GROUND > 3RD HARM NTRL UNDERVOLTAGE



|   |                                         |                                            |
|---|-----------------------------------------|--------------------------------------------|
| ⇅ | 3RD HARM NTRL UV PKP<br>DELAY: 0.00 s   | Range: 0.00 to 600.00 s in steps of 0.01   |
| ⇅ | 3RD HARM NTRL UV MAX<br>POWER: 0.200 pu | Range: 0.000 to 1.250 pu in steps of 0.001 |
| ⇅ | 3RD HARM NTRL UV MIN<br>POWER: 0.200 pu | Range: 0.000 to 1.250 pu in steps of 0.001 |
| ⇅ | 3RD HARM NTRL UV<br>VOLT SUPV: 0.500 pu | Range: 0.000 to 1.250 pu in steps of 0.001 |
| ⇅ | 3RD HARM NTRL UV BLK:<br>Off            | Range: FlexLogic operand                   |
| ⇅ | 3RD HARM NTRL UV<br>TARGET: Self-reset  | Range: Self-reset, Latched, Disabled       |
| ↑ | 3RD HARM NTRL UV<br>EVENTS: Disabled    | Range: Disabled, Enabled                   |

The third harmonic neutral undervoltage function detects a loss of third harmonic voltage at the generator neutral. The percentage of stator winding covered by this function depends on the pickup setting and the amount of third harmonic generated by the machine at the time of the fault. A settable window of forward power can supervise this element for enhanced security. The element is also supervised by positive-sequence voltage measured at the generator output terminals. This element can be used with either wye or delta connected VTs on the terminal side and requires the machine neutral voltage to be connected via an auxiliary voltage channel of a relay VT bank.

### 3RD HARM NTRL UV PICKUP

This setting specifies the pickup level for the magnitude of the third harmonic of the neutral voltage. This setting is entered in pu of the nominal auxiliary voltage. Use the **ACTUAL VALUES > METERING > STATOR GROUND** menu to monitor the magnitude of the third harmonic voltage at the neutral point. Measuring the actual value of the operating quantity for a specific machine under variety of load conditions can be helpful when selecting the pickup threshold for this feature.

### 3RD HARM NTRL UV MAX POWER

This setting specifies the maximum active power that inhibits this protection function. If the measured power is below this setting but above the **3RD HARM NTRL UV MIN POWER** setting, the element does not operate. This setting applies to three-phase power and is entered in pu. The base quantity is three-phase power on the primary side, which is calculated as  $\sqrt{3} \times \text{Phase CT Primary} \times \text{Phase VT Ratio} \times \text{Phase VT Secondary}$  in case of delta connected VTs and as  $3 \times \text{Phase CT Primary} \times \text{Phase VT Ratio} \times \text{Phase VT Secondary}$  in case of wye connected VTs.

For example, a setting of 20% for a 200 MW machine, is:

$$0.20 \times 200 \text{ MW} = 40 \text{ MW.}$$

If 7.967 kV is a primary VT voltage and 10 kA is a primary CT current, the source pu quantity is 239 MVA, and thus, the pu power setting is:

$$40 \text{ MW} / 239 \text{ MVA} = 0.167 \text{ pu.}$$

### 3RD HARM NTRL UV MIN POWER

This setting specifies the minimum active power that inhibits this protection function. If the measured power is above this setting but below the **3RD HARM NTRL UV MAX POWER** setting, the element does not operate. If the **3RD HARMONIC NTRL UV MIN POWER** is set to  $0.00 \text{ pu}$ , then the element does not operate for all power values less than the **3RD HARM NTRL UV MAX POWER** setting.

This setting applies to three-phase power and is entered in pu. The base quantity is three-phase power on the primary side, which is calculated as  $\sqrt{3} \times \text{Phase CT Primary} \times \text{Phase VT Ratio} \times \text{Phase VT Secondary}$  in case of

delta connected VTs and as 3 x Phase CT Primary x Phase VT Ratio x Phase VT Secondary in case of wye connected VTs.

For the G30, if the VTs are located on the high-voltage (HV) side of the transformer, then configure the source using CTs that are also on the HV side. Correspondingly, if the VTs are located on the low-voltage (LV) side of the transformer, then configure the source using CTs that are also on the LV side. In both cases, the CT polarity produces a positive power measurement when the machine is generating.




Figure 306: Third harmonic neutral undervoltage logic

## 8.8 CONTROL ELEMENTS

Control elements are used for control rather than protection. See the Introduction to Elements section at the beginning of this chapter for information.


### 8.8.1 TRIP BUS

Setting path: **SETTINGS > CONTROL ELEMENTS > TRIP BUS > TRIP BUS 1(6)**

|                                                   |   |                                    |                                          |
|---------------------------------------------------|---|------------------------------------|------------------------------------------|
| <div> <div>■ TRIP BUS 1</div> <div>■</div> </div> | ⇔ | TRIP BUS 1<br>FUNCTION: Disabled   | Range: Enabled, Disabled                 |
|                                                   | ⇕ | TRIP BUS 1 BLOCK:<br>Off           | Range: FlexLogic operand                 |
|                                                   | ⇕ | TRIP BUS 1 PICKUP<br>DELAY: 0.00 s | Range: 0.00 to 600.00 s in steps of 0.01 |
|                                                   | ⇕ | TRIP BUS 1 RESET<br>DELAY: 0.00 s  | Range: 0.00 to 600.00 s in steps of 0.01 |
|                                                   | ⇕ | TRIP BUS 1 INPUT 1(16):<br>Off     | Range: FlexLogic operand                 |
|                                                   | ⇕ | TRIP BUS 1<br>LATCHING: Disabled   | Range: Enabled, Disabled                 |
|                                                   | ⇕ | TRIP BUS 1 RESET:<br>Off           | Range: FlexLogic operand                 |
|                                                   | ⇕ | TRIP BUS 1:<br>TARGET: Self-reset  | Range: Self-reset, Latched, Disabled     |
|                                                   | ↑ | TRIP BUS 1<br>EVENTS: Disabled     | Range: Enabled, Disabled                 |

The trip bus element allows aggregating outputs of protection and control elements without using FlexLogic and assigning them a simple and effective manner. Each trip bus can be assigned for either trip or alarm actions. Simple trip conditioning such as latch, delay, and seal-in delay are available.

The easiest way to assign element outputs to a trip bus is through the EnerVista software under **Settings > Protection Summary**. Navigate to a specific protection or control protection element and check the bus box by hovering over the blank check box and selecting an option that displays. Once the required element is selected for a specific bus, a list of element operate-type operands are displayed and can be assigned to a trip bus. If more than one operate-type operand is required, it can be assigned directly from the trip bus menu.



**Figure 307: Trip bus fields in the protection summary**

The following settings are available.

### TRIP BUS 1 BLOCK

The trip bus output is blocked when the operand assigned to this setting is asserted.

### TRIP BUS 1 PICKUP DELAY

This setting specifies a time delay to produce an output depending on how output is used.

### TRIP BUS 1 RESET DELAY

This setting specifies a time delay to reset an output command. Set the time delay long enough to allow the breaker or contactor to perform a required action.

### TRIP BUS 1 INPUT 1 to TRIP BUS 1 INPUT 16

These settings select a FlexLogic operand to be assigned as an input to the trip bus.

### TRIP BUS 1 LATCHING

This setting enables or disables latching of the trip bus output. This is typically used when lockout is required or user acknowledgement of the relay response is required.

### TRIP BUS 1 RESET

The trip bus output is reset when the operand assigned to this setting is asserted. Note that the RESET OP operand is pre-wired to the reset gate of the latch. As such, a reset command from the front panel interface or via communications resets the trip bus output.




Figure 308: Trip bus logic

### 8.8.2 SETTING GROUPS

Setting path: **SETTINGS > CONTROL ELEMENTS > TRIP BUS > SETTING GROUPS**

|                  |   |                                      |                                         |
|------------------|---|--------------------------------------|-----------------------------------------|
| ■ SETTING GROUPS | ↔ | SETTING GROUPS<br>FUNCTION: Disabled | Range: Enabled, Disabled                |
| ■                | ↕ | Control Mode:<br>Local               | Range: Local, IEC61850 Client           |
|                  | ↕ | SETTING GROUPS BLK:<br>Off           | Range: FlexLogic operand                |
|                  | ↕ | GROUP 2(6) ACTIVATE ON:<br>Off       | Range: FlexLogic operand                |
|                  | ↕ | GROUP 1(6) NAME:                     | Range: up to 16 alphanumeric characters |
|                  | ↑ | SETTING GROUP<br>EVENTS: Disabled    | Range: Enabled, Disabled                |

The setting groups menu controls the activation and deactivation of up to six groups of settings in the **GROUPED ELEMENTS** settings menu. The active setting group can be indicated on the front display of the Product by configuring User-Programmable LEDs to display the state of the SETTING GROUP ACT FlexLogic operands.

On a setting group change, protection elements are blocked temporarily to allow the relay to re-initialize with the new settings. The duration of the block depends on relay configuration and can last up to four cycles. The actual block duration on the group switching can be verified by the PROTSUPV operand.

#### SETTING GROUPS FUNCTION

When Enabled, allows setting groups other than group 1 (the default active group) to be activated. When Disabled, the default setting group is forced active. When changed from Disabled to Enabled, it resets the active setting group to 1 independent of the **Control Mode** setting.

#### Control Mode

This setting displays when IEC 61850 is used. It selects the active setting group selection control mode. When set to *Local*, active setting group selection is based on the FlexLogic operand states selected by **GROUP ACTIVATE ON** settings and the *SelectActiveSG* request from an IEC 61850 client generates a negative response. When set


to *IEC61850 Client*, the `SelectActiveSG` request from an IEC 61850 client selects the active setting group and the FlexLogic operand states of the **GROUP ACTIVATE ON** settings are ignored/not used.

The logic diagram shows the active setting group selection behavior based on the **Control Mode** setting.

When the Control Mode is *Local*, the priority scheme makes active the highest numbered group selected by the **GROUP ACTIVATE ON** settings. The most recent active group selection is preserved while the Product is powered down or reset.

When the Control Mode is *IEC61850 Client*, the `SelectActiveSG` selection has an initial value that can be set on a CID file download by the IEC 61850 setting Initial Setting Group. The most recent `SelectActiveSG` selection is preserved while the Product is powered down or reset. If it becomes necessary to cancel the `SelectActiveSG` selection without using a `SelectActiveSG` service request, disable the **SETTING GROUPS FUNCTION**. This resets the `SelectActiveSG` selection to 1.

When the Control Mode is changed, the current active setting group selection is preserved.



**Figure 309: Logic diagram for Control Mode setting**

**Note:**

Active setting group selection can be made either by IEC 61850 MMS `SelectActiveSG` service or Local by the FlexLogic operand states selected by **GROUP # ACTIVATE ON** settings. Simultaneous setting group control is not permissible.

## SETTING GROUPS BLK

Prevents the active setting group from changing when the selected FlexLogic operand is *On*. This can be useful in applications where it is undesirable to change the settings under certain conditions, such as during a control sequence.

## GROUP 2 ACTIVATE ON to GROUP 6 ACTIVATE ON

Selects a FlexLogic operand which, when set, makes the particular setting group active for use by any grouped element. A priority scheme ensures that only one group is active at a given time — the highest-numbered group that is activated by its **ACTIVATE ON** parameter takes priority over the lower-numbered groups. There is no activate on setting for group 1 (the default active group), because group 1 automatically becomes active if no other group is active.

The settings are read-only with default values when the **Control Mode** setting is set to *IEC61850 Client*.


A setting group selection can also be made by the IEC 61850 MMS service SelectActiveSG to the control block @Master/LLN0.SGCB. An active group selection can be done either by SelectActiveSG service from a IEC 61850 client or by **GROUP ACTIVATE ON** settings, but mixed operation is not allowed.

An initial setting group value is initialized to the **GROUP ACTIVATE ON** setting value on Product reboot immediately following the receipt of a valid CID file.

### SETTING GROUP 1 NAME to SETTING GROUP 6 NAME

Allows the user to assign a name to each of the six settings groups. Once programmed, this name appears on the second line of the **GROUPED ELEMENTS > SETTING GROUP 1(6)** menu display.

The relay can be set up via a FlexLogic equation to receive requests to activate or de-activate a particular non-default settings group. The following FlexLogic equation (see the following figure) illustrates requests via remote communications (for example, VIRTUAL INPUT 1 ON) or from a local contact input (for example, CONTACT IP 1 ON) to initiate the use of a particular settings group, and requests from several overcurrent pickup measuring elements to inhibit the use of the particular settings group. The assigned VIRTUAL OUTPUT 1 operand is used to control the *On* state of a particular settings group.



842789A1.CDR

Figure 310: Example of FlexLogic control of a setting group

### 8.8.3 SELECTOR SWITCH

Setting path: **SETTINGS > CONTROL ELEMENTS > SELECTOR SWITCH > SELECTOR SWITCH 1(2)**

*Note:*  
Only selector switch 1 is shown

|                                             |   |                                      |                                      |
|---------------------------------------------|---|--------------------------------------|--------------------------------------|
| <div>■ SELECTOR SWITCH 1</div> <div>■</div> | ⇔ | SELECTOR 1 FUNCTION:<br>Disabled     | Range: Disabled, Enabled             |
|                                             | ⇕ | SELECTOR 1 FULL<br>RANGE: 7          | Range: 1 to 7 in steps of 1          |
|                                             | ⇕ | SELECTOR 1 TIME-OUT:<br>5.0 s        | Range: 3.0 to 60.0 s in steps of 0.1 |
|                                             | ⇕ | SELECTOR 1 STEP-UP:<br>Off           | Range: FlexLogic operand             |
|                                             | ⇕ | SELECTOR 1 STEP-UP<br>MODE: Time-out | Range: Time-out, Acknowledge         |



|   |                                      |                                           |
|---|--------------------------------------|-------------------------------------------|
| ⇅ | SELECTOR 1 ACK:<br>Off               | Range: FlexLogic operand                  |
| ⇅ | SELECTOR 1 3BIT A0:<br>Off           | Range: FlexLogic operand                  |
| ⇅ | SELECTOR 1 3BIT A1:<br>Off           | Range: FlexLogic operand                  |
| ⇅ | SELECTOR 1 3BIT A2:<br>Off           | Range: FlexLogic operand                  |
| ⇅ | SELECTOR 1 3BIT<br>MODE: Time-out    | Range: Time-out, Acknowledge              |
| ⇅ | SELECTOR 1 3BIT ACK:<br>Off          | Range: FlexLogic operand                  |
| ⇅ | SELECTOR 1 POWER-UP<br>MODE: Restore | Range: Restore, Synchronize, Sync/Restore |
| ⇅ | SELECTOR 1 TARGETS:<br>Self-reset    | Range: Self-reset, Latched, Disabled      |
| ↑ | SELECTOR 1 EVENTS:<br>Disabled       | Range: Disabled, Enabled                  |

The selector switch element is intended to replace a mechanical selector switch. Typical applications include setting group control or control of multiple logic sub-circuits in user-programmable logic.

The element provides for two control inputs. The step-up control allows stepping through selector position one step at a time with each pulse of the control input, such as a user-programmable pushbutton. The three-bit control input allows setting the selector to the position defined by a three-bit word.

The element allows pre-selecting a new position without applying it. The pre-selected position gets applied either after time-out or upon acknowledgement via separate inputs (user setting). The selector position is stored in non-volatile memory. Upon power-up, either the previous position is restored or the relay synchronizes to the current three-bit word (user setting). Basic alarm functionality alerts the user under abnormal conditions; for example, the three-bit control input being out of range.

A selector switch runs every two power cycles.

### SELECTOR 1 FULL RANGE

This setting defines the upper position of the selector. When stepping up through available positions of the selector, the upper position wraps up to the lower position (position 1). When using a direct three-bit control word for programming the selector to a desired position, the change would take place only if the control word is within the range of 1 to the **SELECTOR FULL RANGE**. If the control word is outside the range, an alarm is established by setting the SELECTOR ALARM FlexLogic operand for three seconds.

### SELECTOR 1 TIME-OUT

This setting defines the time-out period for the selector. This value is used by the relay in the following two ways. When the **SELECTOR STEP-UP MODE** is *Time-out*, the setting specifies the required period of inactivity of the control input after which the pre-selected position is automatically applied. When the **SELECTOR STEP-UP MODE** is *Acknowledge*, the setting specifies the period of time for the acknowledging input to appear. The timer is re-started by any activity of the control input. The acknowledging input must come before the **SELECTOR 1 TIME-OUT** timer expires; otherwise, the change does not take place and an alarm is set.

### SELECTOR 1 STEP-UP

This setting specifies a control input for the selector switch. The switch is shifted to a new position at each rising edge of this signal. The position changes incrementally, wrapping up from the last (**SELECTOR 1 FULL RANGE**) to

the first (position 1). Consecutive pulses of this control operand must not occur faster than every 50 ms. After each rising edge of the assigned operand, the time-out timer is restarted and the `SELECTOR SWITCH 1: POS Z CHNG INITIATED` target message is displayed, where Z the pre-selected position. The message is displayed for the time specified by the **FLASH MESSAGE TIME** setting. The pre-selected position is applied after the selector times out (*Time-out* mode), or when the acknowledging signal appears before the element times out (*Acknowledge* mode). When the new position is applied, the relay displays the `SELECTOR SWITCH 1: POSITION Z IN USE` message. Typically, a user-programmable pushbutton is configured as the stepping up control input.

### SELECTOR 1 STEP-UP MODE

This setting defines the selector mode of operation. When set to *Time-out*, the selector changes its position after a pre-defined period of inactivity at the control input. The change is automatic and does not require any explicit confirmation of the intent to change the selector's position. When set to *Acknowledge*, the selector changes its position only after the intent is confirmed through a separate acknowledging signal. If the acknowledging signal does not appear within a pre-defined period of time, the selector does not accept the change and an alarm is established by setting the `SELECTOR STP ALARM` output FlexLogic operand for three seconds.

### SELECTOR 1 ACK

This setting specifies an acknowledging input for the stepping up control input. The pre-selected position is applied on the rising edge of the assigned operand. This setting is active only under *Acknowledge* mode of operation. The acknowledging signal must appear within the time defined by the **SELECTOR 1 TIME-OUT** setting after the last activity of the control input. A user-programmable pushbutton is typically configured as the acknowledging input.

### SELECTOR 1 3BIT A0, A1, and A2

These settings specify a three-bit control input of the selector. The three-bit control word pre-selects the position using the following encoding convention:

| A2 | A1 | A0 | Position |
|----|----|----|----------|
| 0  | 0  | 0  | rest     |
| 0  | 0  | 1  | 1        |
| 0  | 1  | 0  | 2        |
| 0  | 1  | 1  | 3        |
| 1  | 0  | 0  | 4        |
| 1  | 0  | 1  | 5        |
| 1  | 1  | 0  | 6        |
| 1  | 1  | 1  | 7        |

The *rest* position (0, 0, 0) does not generate an action and is intended for situations when the device generating the three-bit control word is having a problem. When **SELECTOR 1 3BIT MODE** is *Time-out*, the pre-selected position is applied in **SELECTOR 1 TIME-OUT** seconds after the last activity of the three-bit input. When **SELECTOR 1 3BIT MODE** is *Acknowledge*, the pre-selected position is applied on the rising edge of the **SELECTOR 1 3BIT ACK** acknowledging input.

The stepping up control input (**SELECTOR 1 STEP-UP**) and the three-bit control inputs (**SELECTOR 1 3BIT A0** through **A2**) lock-out mutually: once the stepping up sequence is initiated, the three-bit control input is inactive; once the three-bit control sequence is initiated, the stepping up input is inactive.

### SELECTOR 1 3BIT MODE

This setting defines the selector mode of operation. When set to *Time-out*, the selector changes its position after a pre-defined period of inactivity at the control input. The change is automatic and does not require explicit confirmation to change the selector position. When set to *Acknowledge*, the selector changes its position only after confirmation via a separate acknowledging signal. If the acknowledging signal does not appear within a pre-defined

period of time, the selector rejects the change and an alarm established by invoking the **SELECTOR BIT ALARM** FlexLogic operand for three seconds.

### SELECTOR 1 3BIT ACK

This setting specifies an acknowledging input for the three-bit control input. The pre-selected position is applied on the rising edge of the assigned FlexLogic operand. This setting is active only under the *Acknowledge* mode of operation. The acknowledging signal must appear within the time defined by the **SELECTOR TIME-OUT** setting after the last activity of the three-bit control inputs. Note that the stepping up control input and three-bit control input have independent acknowledging signals (**SELECTOR 1 ACK** and **SELECTOR 1 3BIT ACK**, accordingly).

### SELECTOR 1 POWER-UP MODE

This setting specifies the element behavior on power up of the relay.

When set to *Restore*, the last position of the selector (stored in the non-volatile memory) is restored after powering up the relay. If the position restored from memory is out of range, position 0 (no output operand selected) is applied and an alarm is set (**SELECTOR 1 PWR ALARM**).

When set to *Synchronize*, the selector switch acts as follows. For two power cycles, the selector applies position 0 to the switch and activates **SELECTOR 1 PWR ALARM**. After two power cycles expire, the selector synchronizes to the position dictated by the three-bit control input. This operation does not wait for time-out or the acknowledging input. When the synchronization attempt is unsuccessful (that is, the three-bit input is not available (0,0,0) or out of range), then the selector switch output is set to position 0 (no output operand selected) and an alarm is established (**SELECTOR 1 PWR ALARM**).


The operation of *Synch/Restore* mode is similar to the *Synchronize* mode. The only difference is that after an unsuccessful synchronization attempt, the switch attempts to restore the position stored in the relay memory. The *Synch/Restore* mode is useful for applications where the selector switch is employed to change the setting group in redundant (two relay) protection schemes.

### SELECTOR 1 EVENTS


If enabled, the following events are logged:

| Event name           | Description                                                                                                     |
|----------------------|-----------------------------------------------------------------------------------------------------------------|
| SELECTOR 1 POS Z     | Selector 1 changed its position to Z                                                                            |
| SELECTOR 1 STP ALARM | The selector position pre-selected via the stepping up control input has not been confirmed before the time out |
| SELECTOR 1 BIT ALARM | The selector position pre-selected via the three-bit control input has not been confirmed before the time out   |

The following figures illustrate the operation of the selector switch. In these diagrams, “T” represents a time-out setting:



**Figure 311: Time-out mode**



**Figure 312: Acknowledge mode**

**Application example**

Consider an application where the selector switch is used to control setting groups 1 through 4 in the relay. The setting groups are to be controlled from both user-programmable pushbutton 1 and from an external device via contact inputs 1 through 3. The active setting group is to be available as an encoded three-bit word to the external device and SCADA via output contacts 1 through 3. The pre-selected setting group is to be applied automatically after five seconds of inactivity of the control inputs. When the relay powers up, it is to synchronize the setting group to the three-bit control input.

Make the following changes to setting group control in the **SETTINGS > CONTROL ELEMENTS > SETTING GROUPS** menu:

- **FUNCTION:** *Enabled*
- **Block:** *Off*
- **GROUP 2 ACTIVATE ON:** *SELECTOR 1 POS 2*
- **GROUP 3 ACTIVATE ON:** *SELECTOR 1 POS 3*
- **GROUP 4 ACTIVATE ON:** *SELECTOR 1 POS 4*
- **GROUP 5 ACTIVATE ON:** *Off*
- **GROUP 6 ACTIVATE ON:** *Off*

Make the following changes to selector switch element in the **SETTINGS > CONTROL ELEMENTS > SELECTOR SWITCH > SELECTOR SWITCH 1** menu to assign control to user programmable pushbutton 1 and contact inputs 1 through 3:

- **SELECTOR 1 FUNCTION:** *Enabled*
- **SELECTOR 1 FULL-RANGE:** *4*
- **SELECTOR 1 STEP-UP MODE:** *Time-out*
- **SELECTOR 1 TIME-OUT:** *5.0 s*
- **SELECTOR 1 STEP-UP:** *PUSHBUTTON 1 ON*
- **SELECTOR 1 ACK:** *Off*
- **SELECTOR 1 3BIT A0:** *CONT IP 1 ON*
- **SELECTOR 1 3BIT A1:** *CONT IP 2 ON*
- **SELECTOR 1 3BIT A2:** *CONT IP 3 ON*
- **SELECTOR 1 3BIT MODE:** *Time-out*
- **SELECTOR 1 3BIT ACK:** *Off*
- **SELECTOR 1 POWER-UP MODE:** *Synchronize*

Now, assign the contact output operation (assume the H6E module) to the selector switch element by making the following changes in the **SETTINGS > INPUTS/OUTPUTS > CONTACT OUTPUTS** menu:

- **OUTPUT H1 OPERATE:** *SELECTOR 1 BIT 0*
- **OUTPUT H2 OPERATE:** *SELECTOR 1 BIT 1*
- **OUTPUT H3 OPERATE:** *SELECTOR 1 BIT 2*

Finally, assign configure user-programmable pushbutton 1 by making the following changes in the **SETTINGS > PRODUCT SETUP > USER-PROGRAMMABLE PUSHBUTTONS > USER PUSHBUTTON 1** menu:

- **PUSHBUTTON 1 FUNCTION:** *Self-reset*
- **PUSHBUTTON 1 DROP-OUT TIME:** *0.10 s*

The figure shows the logic for the selector switch.




Figure 313: Selector switch logic

### 8.8.4 UNDERFREQUENCY (ANSI 81U)

Setting path: **SETTINGS > CONTROL ELEMENTS > UNDERFREQUENCY > UNDERFREQUENCY <n>**

*Note:*  
Only Underfrequency 1 is shown

|                               |   |                                    |                                            |
|-------------------------------|---|------------------------------------|--------------------------------------------|
| <div>■ UNDERFREQUENCY 1</div> | ⇔ | UNDFREQ 1 FUNCTION:<br>Disabled    | Range: Disabled, Enabled                   |
|                               | ⇕ | UNDFREQ 1 BLOCK:<br>Off            | Range: FlexLogic operand                   |
|                               | ⇕ | UNDFREQ 1 SOURCE:<br>SRC 1         | Range: SRC <n>                             |
|                               | ⇕ | UNDFREQ 1 MIN<br>VOLT/AMP: 0.10 pu | Range: 0.10 to 1.25 pu in steps of 0.01    |
|                               | ⇕ | UNDFREQ 1 PICKUP:<br>59.50 Hz      | Range: 20.00 to 70.00 Hz in steps of 0.01  |
|                               | ⇕ | UNDFREQ 1 PICKUP<br>DELAY: 2.000 s | Range: 0.000 to 65.535 s in steps of 0.001 |
|                               | ⇕ | UNDFREQ 1 RESET<br>DELAY: 2.000 s  | Range: 0.000 to 65.535 s in steps of 0.001 |
|                               | ⇕ | UNDFREQ 1 TARGET:<br>Self-reset    | Range: Self-reset, Latched, Disabled       |

↑

UNDERFREQ 1 EVENTS:  
Disabled

Range: Disabled, Enabled

The steady-state frequency of a power system is a certain indicator of the existing balance between the generated power and the load. Whenever this balance is disrupted through the loss of an important generating unit or the isolation of part of the system from the rest of the system, the effect is a reduction in frequency. If the control systems of the system generators do not respond fast enough, the system can collapse. A reliable method to quickly restore the balance between load and generation is to automatically disconnect selected loads, based on the actual system frequency. This technique, called load-shedding, maintains system integrity and minimize widespread outages. After the frequency returns to normal, the load can be restored automatically or manually.

UNDERFREQ 1 SOURCE

This setting is used to select the source for the signal to be measured. The element first checks for a live phase voltage available from the selected source. If voltage is not available, the element attempts to use a phase current. If neither voltage nor current is available, the element does not operate, as it does not measure a parameter below the minimum voltage/current setting.

UNDERFREQ 1 MIN VOLT/AMP

Selects the minimum per unit voltage or current level required to allow the underfrequency element to operate. This threshold is used to prevent an incorrect operation because there is no signal to measure.

UNDERFREQ 1 PICKUP

Selects the level at which the underfrequency element is to pickup. For example, if the system frequency is 60 Hz and the load shedding is required at 59.5 Hz, the setting is 59.5 Hz.




Figure 314: Underfrequency logic

8.8.5 OVERFREQUENCY (ANSI 81O)

Setting path: **SETTINGS > CONTROL ELEMENTS > OVERFREQUENCY > OVERFREQUENCY 1(4)**

*Note:*  
Only Overfrequency 1 is shown

■ OVERFREQUENCY 1

⇔

OVERFREQ 1 FUNCTION:  
Disabled

OVERFREQ 1 BLOCK:  
Off

OVERFREQ 1 SOURCE:  
SRC 1

Range: Disabled, Enabled

Range: FlexLogic operand

Range: SRC <n>



|   |                                     |                                            |
|---|-------------------------------------|--------------------------------------------|
| ⇅ | OVERFREQ 1 PICKUP:<br>60.50 Hzz     | Range: 20.00 to 70.00 Hz in steps of 0.01  |
| ⇅ | OVERFREQ 1 PICKUP<br>DELAY: 0.500 s | Range: 0.000 to 65.535 s in steps of 0.001 |
| ⇅ | OVERFREQ 1 RESET<br>DELAY : 0.500 s | Range: 0.000 to 65.535 s in steps of 0.001 |
| ⇅ | OVERFREQ 1 TARGET:<br>Self-reset    | Range: Self-reset, Latched, Disabled       |
| ↑ | OVERFREQ 1 EVENTS:<br>Disabled      | Range: Disabled, Enabled                   |

There are four overfrequency elements, numbered 1 through 4.

A frequency calculation for a given source is made on the input of a voltage or current channel, depending on which is available. The channels are searched for the signal input in the following order: voltage channel A, auxiliary voltage channel, current channel A, and ground current channel. The first available signal is used for frequency calculation.

The steady-state frequency of a power system is an indicator of the existing balance between the generated power and the load. Whenever this balance is disrupted through the disconnection of significant load or the isolation of a part of the system that has a surplus of generation, the effect is an increase in frequency. If the control systems of the generators do not respond fast enough, to quickly ramp the turbine speed back to normal, the overspeed can lead to the turbine trip. The overfrequency element can be used to control the turbine frequency ramp down at a generating location. This element can also be used for feeder reclosing as part of the after load shedding restoration.

The **OVERFREQ 1 SOURCE** setting selects the source for the signal to be measured.

The **OVERFREQ 1 PICKUP** setting selects the level at which the overfrequency element is to pickup.




Figure 315: Overfrequency logic

### 8.8.6 FREQUENCY RATE OF CHANGE (ANSI 81R)

Setting path: **SETTINGS > CONTROL ELEMENTS > FREQUENCY RATE OF CHANGE > FREQUENCY RATE OF CHANGE <n>**

**Note:**  
Only Frequency rate of change 1 is shown

|                                                                   |   |                                         |                                               |
|-------------------------------------------------------------------|---|-----------------------------------------|-----------------------------------------------|
| <div> <div>■ FREQUENCY RATE</div> <div>■ OF CHANGE 1</div> </div> | ⇔ | FREQ RATE 1<br>FUNCTION: Disabled       | Range: Disabled, Enabled                      |
|                                                                   | ⇕ | FREQ RATE 1 SOURCE:<br>SRC 1            | Range: SRC <n>                                |
|                                                                   | ⇕ | FREQ RATE 1 TREND:<br>Increasing        | Range: Increasing, Decreasing, Bi-directional |
|                                                                   | ⇕ | FREQ RATE 1 PICKUP:<br>0.50 Hz/sec      | Range: 0.10 to 15.00 Hz/sec in steps of 0.01  |
|                                                                   | ⇕ | FREQ RATE 1 OV SUPV<br>PICKUP: 0.700 pu | Range: 0.100 to 3.000 pu in steps of 0.001    |
|                                                                   | ⇕ | FREQ RATE 1 OC SUPV<br>PICKUP: 0.200 pu | Range: 0.020 to 30.000 pu in steps of 0.001   |
|                                                                   | ⇕ | FREQ RATE 1 MIN<br>FREQUENCY: 45.00 Hz  | Range: 20.00 to 80.00 Hz in steps of 0.01     |
|                                                                   | ⇕ | FREQ RATE 1 MAX<br>FREQUENCY: 65.00 Hz  | Range: 20.00 to 80.00 Hz in steps of 0.01     |
|                                                                   | ⇕ | FREQ RATE 1 PICKUP<br>DELAY: 0.000 s    | Range: 0 to 65.535 s in steps of 0.001        |
|                                                                   | ⇕ | FREQ RATE 1 RESET<br>DELAY: 0.000 s     | Range: 0 to 65.535 s in steps of 0.001        |
|                                                                   | ⇕ | FREQ RATE 1 BLOCK:<br>Off               | Range: FlexLogic operand                      |
|                                                                   | ⇕ | FREQ RATE 1 TARGET:<br>Self-reset       | Range: Self-reset, Latched, Disabled          |
|                                                                   | ↑ | FREQ RATE 1 EVENTS:<br>Disabled         | Range: Disabled, Enabled                      |

The element responds to rate of change of frequency with voltage, current and frequency supervision.

### FREQ RATE 1 TREND

This setting configures the element to respond to increasing or decreasing frequency, or to frequency change in either direction.

### FREQ RATE 1 PICKUP

This setting specifies an intended df/dt pickup threshold. For applications monitoring a decreasing trend, set **FREQ RATE 1 TREND** to *Decreasing* and specify the pickup threshold accordingly. The operating condition is  $-df/dt > \text{Pickup}$ .

For applications monitoring an increasing trend, set **FREQ RATE 1 TREND** to *Increasing* and specify the pickup threshold accordingly. The operating condition is:  $df/dt > \text{Pickup}$ .

For applications monitoring rate of change of frequency in any direction set **FREQ RATE 1 TREND** to “Bi-Directional” and specify the pickup threshold accordingly. The operating condition is  $\text{abs}(df/dt) > \text{Pickup}$ .

### FREQ RATE 1 OV SUPV PICKUP

This setting defines the minimum voltage level required for operation of the element. The supervising function responds to the positive-sequence voltage. Use overvoltage supervision to prevent operation under specific system conditions, such as faults.

### FREQ RATE 1 OC SUPV PICKUP

This setting defines minimum current level required for operation of the element. The supervising function responds to the positive-sequence current. Typical application includes load shedding. Set the pickup threshold to 0.020 if no overcurrent supervision is required.

### FREQ RATE 1 MIN FREQUENCY

This setting defines the minimum frequency level required for operation of the element. The setting can be used to effectively block the feature based on frequency. For example, if the intent is to monitor an increasing trend but only if the frequency is already above certain level, set this setting to the required frequency level.

### FREQ RATE 1 MAX FREQUENCY

This setting defines the maximum frequency level required for operation of the element. The setting can be used to effectively block the feature based on frequency. For example, if the intent is to monitor a decreasing trend but only if the frequency is already below a certain level (such as for load shedding), set this setting to the required frequency level.

**Note:**  
If the signal source assigned to the frequency rate of change element is only set to auxiliary VT, then the minimum voltage supervision is 3 V.




Figure 316: Frequency rate of change logic

## 8.8.7 FREQUENCY OUT-OF-BAND ACCUMULATION

Setting path: **SETTINGS > CONTROL ELEMENTS > FREQUENCY OOB ACCUMULATION**

|                  |   |                    |                                         |
|------------------|---|--------------------|-----------------------------------------|
| ■ FREQ OOB ACCUM | ⇔ | FREQ OOB ACCUM     |                                         |
| ■ ACCUMULATION   | ⇔ | SOURCE: SRC 1      | Range: SRC <n>                          |
|                  | ⇕ | FREQ OOB ACCUM MIN |                                         |
|                  | ⇕ | VOLT/AMP: 0.10 pu  | Range: 0.10 to 1.25 pu in steps of 0.01 |
|                  | ⇕ | FREQ ACCUM BLOCK:  |                                         |
|                  | ⇕ | Off                | Range: FlexLogic operand                |
|                  | ⇕ | FREQ OOB ACCUM     |                                         |
|                  | ⇕ | TARGET: Self-reset | Range: Self-reset, Latched, Disabled    |

|   |                                      |                          |
|---|--------------------------------------|--------------------------|
| ⇅ | FREQ OOB ACCUM<br>EVENTS: Disabled   | Range: Enabled, Disabled |
| ↑ | ■ FREQUENCY OOB<br>■ ACCUMULATOR <n> | n = 1 to 7               |

The turbine portion of a generator is designed to operate in a narrow frequency range around the nominal, typically  $\pm 5\%$ . As the turbine overspeeds (typically due to load rejection) or coasts down, the turbine passes through operating frequencies where the turbine blades find stimulus at their natural frequencies. Blade vibrations at these natural frequencies result in stress on the blades that is accumulated and can result in cracking in some parts of the blade structure, most likely the tie wires or blade covers. Though typically not catastrophic, the stress can change the vibration behavior of the blade so that they can have natural resonances closer to the normal operating frequency.

This element provides diagnostic information and alarms based on the accumulated off-nominal frequency operation time of a turbine over several frequency bands, that can then be used to schedule maintenance or other action.

The available setting of an upper and lower frequency for each band enables the user to overlap bands of frequencies in the accumulation function. The accumulation function in any band can be blocked as wanted. For example, accumulation can be blocked during an out-of-service condition as set via an input to the relay.

Settings are described as follows and apply to all accumulators.

### FREQ OOB ACCUM SOURCE

Selects the source for the signal to be measured. The element first checks for a live phase voltage available from the selected source. If voltage is not available, the element attempts to use a phase current. If neither voltage nor current is available, the element does not operate, as it does not measure a parameter below the minimum voltage/current setting.

### FREQ OOB ACCUM MIN VOLT/AMP

This setting specifies the minimum per-unit positive-sequence voltage or current level required to allow the frequency out-of-band accumulators to operate. This threshold is used to prevent an incorrect accumulation when operating quantity is too low.

### FREQ ACCUM BLOCK

This setting selects a FlexLogic operand to block out-of-band frequency accumulation in all bands. This is typically required to avoid unnecessary accumulation when relay testing is being performed.

### Accumulators 1 to 7

Setting path: **SETTINGS > CONTROL ELEMENTS > FREQUENCY OOB ACCUMULATION > FREQUENCY OOB ACCUMULATOR 1(7)**

*Note:*  
Only Accumulator 1 is shown

|                                    |   |                                     |                                           |
|------------------------------------|---|-------------------------------------|-------------------------------------------|
| ■ FREQUENCY OOB<br>■ ACCUMULATOR 1 | ⇅ | FREQ ACCUM 1<br>FUNCTION: Disabled  | Range: Enabled, Disabled: SRC <n>         |
|                                    | ⇅ | FREQ ACCUM 1 UPPER<br>FREQ 60.00 Hz | Range: 20.00 to 70.00 Hz in steps of 0.01 |
|                                    | ⇅ | FREQ ACCUM 1 LOWER<br>FREQ 60.00 Hz | Range: 20.00 to 70.00 Hz in steps of 0.01 |

|   |                                   |                                   |
|---|-----------------------------------|-----------------------------------|
| ⇅ | FREQ ACCUM 1 TIME<br>LIMIT: 200 s | Range: 1 to 65535 s in steps of 1 |
| ↑ | FREQ ACCUM 1 TIME<br>PRESET: 0 s  | Range: 0 to 65535 s in steps of 1 |

Seven frequency out-of-band accumulators are available. The following settings are available for each accumulator.

### FREQ ACCUM 1 FUNCTION

Enables and disables a particular frequency band.

### FREQ ACCUM 1 UPPER FREQ

Specifies the upper frequency value, in Hz, below which band 1 values start to accumulate. This upper frequency value must be greater than the lower frequency value.

### FREQ ACCUM 1 LOWER FREQ


Specifies the lower frequency value, in Hz, above which band 1 values start to accumulate. This lower frequency value must be less than the upper frequency value.

### FREQ ACCUM 1 TIME LIMIT

Specifies the accumulation time, in seconds, at which the overfrequency accumulation band exceeds the overfrequency accumulation limit and operates.

### FREQ ACCUM 1 TIME PRESET

Allows the transfer of accumulated frequency time of operation values from a previous hardware platform to a new platform, or, given that some knowledge of the operation of the turbine is known, starts accumulation at a user-specified value.



830008A1.CDR

Figure 317: Frequency out-of-band accumulation logic

## 8.8.8 SYNCHROCHECK (ANSI 25)

Setting path: **SETTINGS > CONTROL ELEMENTS > SYNCHROCHECK > SYNCHROCHECK <n>**

*Note:*  
Only Synchrocheck 1 is shown

|                                                       |   |                                            |                                                                             |
|-------------------------------------------------------|---|--------------------------------------------|-----------------------------------------------------------------------------|
| <div> <div>■ SYNCHROCHECK 1</div> <div>■</div> </div> | ⇔ | SYNCHK1 FUNCTION:<br>Disabled              | Range: Disabled, Enabled                                                    |
|                                                       | ⇕ | SYNCHK1 BLOCK:<br>Off                      | Range: FlexLogic operand                                                    |
|                                                       | ⇕ | SYNCHK1 V1 SOURCE:<br>SRC 1                | Range: SRC <n>                                                              |
|                                                       | ⇕ | SYNCHK1 V2 SOURCE:<br>SRC 2                | Range: SRC <n>                                                              |
|                                                       | ⇕ | SYNCHK1 PHASE<br>SELECT: Auto              | Range: Auto, Vag, Vbg, Vcg, Vab, Vbc, Vca                                   |
|                                                       | ⇕ | SYNCHK1 MAX VOLT<br>DIFF: 10000 V          | Range: 0 to 400000 V in steps of 1                                          |
|                                                       | ⇕ | SYNCHK1 MAX ANGLE<br>DIFF: 30              | Range: 0 to 100° in steps of 1                                              |
|                                                       | ⇕ | SYNCHK1 MAX FREQ<br>DIFF: 0.100 Hz         | Range: 0.005 to 2.000 Hz in steps of 0.001                                  |
|                                                       | ⇕ | SYNCHK1 MAX FREQ<br>HYSTERESIS: 0.060 Hz   | Range: 0.000 to 0.100 Hz in steps of 0.001                                  |
|                                                       | ⇕ | SYNCHK1 SYNC CLOSE:<br>Off                 | Range: FlexLogic operand                                                    |
|                                                       | ⇕ | SYNCHK1 S-CLS MAX<br>dF: 0.500 Hz          | Range: 0.100 to 10.000 Hz in steps of 0.001                                 |
|                                                       | ⇕ | SYNCHK1 S-CLS MIN<br>dF: 0.100 Hz          | Range: 0.005 to 1.000 Hz in steps of 0.001                                  |
|                                                       | ⇕ | SYNCHK1 S-CLS ANG:<br>1                    | Range: 0 to 100° in steps of 1                                              |
|                                                       | ⇕ | SYNCHK1 S-CLS BRK<br>TIME: 0.035 s         | Range: 0.010 to 0.500 s in steps of 0.001                                   |
|                                                       | ⇕ | SYNCHK1 V2 MAG CORR<br>FACTOR: 1.00        | Range: 0.10 to 10.00 in steps of 0.01                                       |
|                                                       | ⇕ | SYNCHK1 V2 ANGLE<br>SHIFT: 0               | Range: -180 to +180 degrees in steps of 1                                   |
|                                                       | ⇕ | SYNCHK1 DEAD SOURCE<br>SELECT: LV1 and DV2 | Range: None, LV1 and DV2, DV1 and LV2, DV1 or DV2, DV1 Xor DV2, DV1 and DV2 |
|                                                       | ⇕ | SYNCHK1 DEAD V1<br>MAX VOLT: 0.30 pu       | Range: 0.04 to 1.25 pu in steps of 0.01                                     |
|                                                       | ⇕ | SYNCHK1 DEAD V2<br>MAX VOLT: 0.30 pu       | Range: 0.04 to 1.25 pu in steps of 0.01                                     |
|                                                       | ⇕ | SYNCHK1 LIVE V1<br>MIN VOLT: 0.70 pu       | Range: 0.04 to 1.25 pu in steps of 0.01                                     |
|                                                       | ⇕ | SYNCHK1 LIVE V2<br>MIN VOLT: 0.70 pu       | Range: 0.04 to 1.25 pu in steps of 0.01                                     |
|                                                       | ⇕ | SYNCHK1 TARGET:<br>Self-reset              | Range: Self-reset, Latched, Disabled                                        |



SYNCHK1 EVENTS:  
Disabled

Range: Disabled, Enabled

The synchronism check function supervises the paralleling of two parts of a system that are to be joined by the closure of a circuit breaker. The synchrocheck elements are typically used at locations where the two parts of the system are interconnected through at least one other point in the system.

Synchrocheck verifies that the voltages (V1 and V2) on the two sides of the supervised circuit breaker are within set limits of magnitude, angle, and frequency differences. The time that the two voltages remain within the admissible angle difference is determined by the setting of the phase angle difference DF and the frequency difference DF (slip frequency). It can be defined as the time it takes the voltage phasor V1 or V2 to traverse an angle equal to  $2 \times DF$  at a frequency equal to the frequency difference DF. This time is calculated by:

$$T = (\Delta F \times 360^\circ / 2\Delta\Phi)^{-1}$$

where:

- $\Delta\Phi$  = phase angle difference in degrees
- $\Delta F$  = frequency difference in Hz

If one or both sources are de-energized, the synchrocheck programming can allow for closing of the circuit breaker using undervoltage control to bypass the synchrocheck measurements (dead source function).

### SYNCHK1 V1 SOURCE

This setting selects the source for voltage V1 (see the Notes section that follows).

### SYNCHK1 V2 SOURCE

Selects the source for voltage V2. V1 and V2 can have different sources or they can be the same (see the table in the next section).

If V1 and V2 are assigned to SRC 1, for example, then in **Settings > System Setup > Power System**, the below settings should have the following values:

- **FREQUENCY AND PHASE REFERENCE:** SRC 1
- **ALTERNATE FREQ AND PHS REFERENCE:** SRC 1
- **SIGNAL TO TRACK:** Auto or 3PH\_VT
- **ALT SIGNAL TO TRACK:** 1PH\_VT

Also, in **Settings > System Setup > Signal Sources**, both **PHASE VT** and **AUX VT** should be configured.

If the above settings are not configured as suggested, the following target message will appear: SYNCHK 1 : CHECK SETTINGS. This message self-resets when the element is either disabled or configured as above.

#### Note:

The same source feature is not supported in the L60

### SYNCHK1 PHASE SELECT

This setting selects the source voltage (see the table in the next section) used by the synchrocheck element and is applicable when

- Both V1 and V2 assigned signal sources differ, and
- Both V1 and V2 assigned signal sources both have three-phase VT banks configured

### SYNCHK1 MAX VOLT DIFF

Selects the maximum primary voltage difference in volts between the two sources. A primary voltage magnitude difference between the two input voltages below this value is within the permissible limit for synchronism.

**SYNCHK1 MAX ANGLE DIFF**

Selects the maximum angular difference in degrees between the two sources. An angular difference between the two input voltage phasors below this value is within the permissible limit for synchronism.

**SYNCHK1 MAX FREQ HYSTERESIS**

This setting specifies the required hysteresis for frequency difference condition.

**SYNCHK1 MAX FREQ DIFF**

The condition becomes satisfied when the frequency difference becomes lower than **SYNCHK1 MAX FREQ DIFF**. Once the condition is satisfied, the frequency difference must increase to more than the sum of **SYNCHK1 MAX FREQ DIFF + SYNCHK1 MAX FREQ HYSTERESIS** to drop out.

**SYNCHK1 S-CLS MAX dF**


The condition becomes satisfied when the frequency difference becomes lower than **SYNCHK1 S-CLS MAX dF**. Once the condition is satisfied, the frequency difference must increase to more than the sum of **SYNCHK1 S-CLS MAX dF + SYNCHK1 MAX FREQ HYSTERESIS** to drop out.

**SYNCHK1 S-CLS MIN dF**


The condition becomes satisfied when the frequency difference becomes higher than **SYNCHK1 S-CLS MIN dF**. Once the condition is satisfied, the frequency difference must decrease to less than **SYNCHK1 S-CLS MIN dF - SYNCHK1 MAX FREQ HYSTERESIS** to drop out.

**SYNCHK1 SYNC CLOSE**

Enables the dynamic mode of synchrocheck. When it is enabled, the location of where the present V2 vector will be arriving to synchronize (shown as V2' in the figures here) with breaker close time being taken into account will be predicted based on the measured slip frequency so that breaker close command can be issued in advance to ensure the synchronism at the time when the breaker is actually closed.



**Figure 318: Synchrocheck plot for slip > 0 (slip = F2-F1)**



**Figure 319: Synchrocheck plot for slip < 0 (slip = F2-F1)**



### **SYNCHK1 S-CLS MAX dF**

Specifies the maximum slip frequency allowed in Hz in the dynamic mode. The dynamic mode is disarmed when the slip frequency exceeds this setting. Setting more than 2 Hz is not recommended as it is expected to have significant errors in phasor estimation, so apply them with caution.

### **SYNCHK1 S-CLS MIN dF**

Specifies the minimum slip frequency allowed in Hz in the dynamic mode. The dynamic mode is disarmed when the slip frequency drops below this setting.

### **SYNCHK1 S-CLS ANG**

This setting specifies the maximum angular difference in degrees between the two voltage phasors V1 and projected V2, that is, V2'.

### **SYNCHK1 S-CLS BRK TIME**

Specifies the breaker closing time in seconds.

### **SYNCHK1 V2 MAG CORR FACTOR**

Specifies the magnitude correction factor of source V2. This setting is used for V2 magnitude compensation so that V2 magnitude can be directly compared with V1 magnitude. For example, when V1 and V2 are taken from 2 different windings of the transformer and at different voltage levels, the magnitude compensation must be performed before starting magnitude comparison in synchrocheck element.

### **SYNCHK1 V2 ANGLE SHIFT**

Specifies the angle of source V2 that needs to be shifted so that V2 angle can be directly compared with V1 angle. For example, when V1 and V2 are taken from two different windings of the transformer and with different angle shift due to winding connections, the angle shift compensation must be performed before starting angle comparison in synchrocheck element.

### **SYNCHK1 DEAD SOURCE SELECT**

Selects the combination of dead and live sources that bypass the synchronism check function and permit the breaker to be closed when one or both of the two voltages (V1 or/and V2) are below the maximum voltage threshold. A dead or live source is declared by monitoring the voltage level. Six options are available:

None — Dead Source function is disabled

- LV1 and DV2 — Live V1 and Dead V2
- DV1 and LV2 — Dead V1 and Live V2
- DV1 or DV2 — Dead V1 or Dead V2
- DV1 Xor DV2 — Dead V1 exclusive-or Dead V2 (one source is Dead and the other is Live)
- DV1 and DV2 — Dead V1 and Dead V2

### **SYNCHK1 DEAD V1 MAX VOLT**

Establishes a maximum voltage magnitude for V1 in 1 pu. Below this magnitude, the V1 voltage input used for synchrocheck is considered “Dead” or de-energized.

### **SYNCHK1 DEAD V2 MAX VOLT**

Establishes a maximum voltage magnitude for V2 in pu. Below this magnitude, the V2 voltage input used for synchrocheck is considered “Dead” or de-energized.

**SYNCHK1 LIVE V1 MIN VOLT**

Establishes a minimum voltage magnitude for V1 in pu. Above this magnitude, the V1 voltage input used for synchrocheck is considered “Live” or energized.

**SYNCHK1 LIVE V2 MIN VOLT**

This setting establishes a minimum voltage magnitude for V2 in pu. Above this magnitude, the V2 voltage input used for synchrocheck is considered “Live” or energized.

**8.8.8.1 NOTES ON THE SYNCHROCHECK FUNCTION**

Note the following:

1) The selected sources for synchrocheck inputs V1 and V2 can include both a three-phase and an auxiliary voltage. The relay automatically selects the specific voltages to be used by the synchrocheck element in accordance with the following tables.

**V1 and V2 assigned with different signal source**

| No. | V1 or V2 (source Y)                          | V1 or V2 (source Z)                          | Auto-selected combination |                 | SYNCHK PHASE SELECT                    | Selected Voltage for comparison           |
|-----|----------------------------------------------|----------------------------------------------|---------------------------|-----------------|----------------------------------------|-------------------------------------------|
|     |                                              |                                              | Source Y                  | Source Z        |                                        |                                           |
| 1   | 3 Phase VT bank with or without Auxiliary VT | 3 Phase VT bank with or without Auxiliary VT | 3 Phase VT bank           | 3 Phase VT bank | Auto                                   | Vab                                       |
| 2   | 3 Phase VT bank with or without Auxiliary VT | 3 Phase VT bank with or without Auxiliary VT | 3 Phase VT bank           | 3 Phase VT bank | Vag or Vbg or Vcg or Vab or Vbc or Vca | As set for SYNCHK PHASE SELECT            |
| 3   | 3 Phase VT bank with or without Auxiliary VT | Auxiliary VT                                 | 3 Phase VT bank           | Auxiliary VT    | Not applicable                         | V auxiliary (as set for Source Z)         |
| 4   | Auxiliary VT                                 | Auxiliary VT                                 | Auxiliary VT              | Auxiliary VT    | Not applicable                         | V auxiliary (as set for selected sources) |

The voltages V1 and V2 are matched automatically so that the corresponding voltages from the two sources are used to measure conditions. A phase to phase voltage is used if available in both sources; if one or both of the Sources have only an auxiliary voltage, this voltage is used. For example, if an auxiliary voltage is programmed to VAG, the synchrocheck element automatically selects VAG from the other source. If the comparison is required on a specific voltage, the user has the following two options:

Select the preferred phase to ground or phase to phase voltage using the **SYNCHK PHASE SELECT** setting when both Source 1 and Source 2 have phase VTs

Externally connect that specific voltage to auxiliary voltage terminals and then use this “Auxiliary Voltage” to check the synchronism conditions. If using a single CT/VT module with both phase voltages and an auxiliary voltage, ensure that only the auxiliary voltage is programmed in one of the sources to be used for synchrocheck. An exception is that synchronism cannot be checked between Delta connected phase VTs and a Wye connected auxiliary voltage.

**V1 and V2 assigned with same signal source**

| No. | V1 or V2 (source Y)               | Required combination |              | Selected Voltage for comparison   |
|-----|-----------------------------------|----------------------|--------------|-----------------------------------|
|     |                                   | V1                   | V2           |                                   |
| 1   | 3 Phase VT bank with Auxiliary VT | 3 Phase VT bank      | Auxiliary VT | V auxiliary (as set for Source Y) |


When both V1 and V2 are assigned with the same source, the relay assigns the three Phase VT bank to V1 and Auxiliary VT to V2 and as programmed per setting “Auxiliary VT connection” used for Synchrocheck. For example, if “Auxiliary VT connection” is programmed to VAG, the synchrocheck element automatically selects VAG from the 3 Phase VT bank of the same source.

**Note:**

*Refer to the SYNCHK1 V2 SOURCE setting description for further information.*

Exception: Synchronism cannot be checked between Delta-connected phase VTs and a Wye-connected auxiliary voltage.

2) The relay measures frequency and Volts/Hz from an input on a given source with priorities as established by the configuration of input channels to the source. The relay uses the phase channel of a three-phase set of voltages if programmed as part of that source. The relay uses the auxiliary voltage channel only if that channel is programmed as part of the Source and a three-phase set is not.



827.197.AZ.c.dtl

Figure 320: Synchrocheck logic

## 8.8.9 DIGITAL ELEMENTS

Setting path: **SETTINGS > CONTROL ELEMENTS > DIGITAL ELEMENTS > DIGITAL ELEMENTS 1(96)**

*Note:*  
Only Digital Element 1 is shown

|                                          |   |                                          |                                                |
|------------------------------------------|---|------------------------------------------|------------------------------------------------|
| <div>DIGITAL ELEMENT 1</div> <div></div> | ↔ | DIGITAL ELEMENT 1<br>FUNCTION: Disabled  | Range: Disabled, Enabled                       |
|                                          | ↕ | DIG ELEM 1 NAME:<br>Dig Element 1        | Range: up to 16 alphanumeric characters        |
|                                          | ↕ | DIG ELEM 1 INPUT:<br>Off                 | Range: FlexLogic operand                       |
|                                          | ↕ | DIG ELEM 1 PICKUP<br>DELAY: 0.000 s      | Range: 0.000 to 999999.999 s in steps of 0.001 |
|                                          | ↕ | DIG ELEM 1 RESET<br>DELAY: 0.000 s       | Range: 0.000 to 999999.999 s in steps of 0.001 |
|                                          | ↕ | DIGITAL ELEMENT 1<br>PICKUP LED: Enabled | Range: Disabled, Enabled                       |
|                                          | ↕ | DIG ELEM 1 BLOCK:<br>Off                 | Range: FlexLogic operand                       |
|                                          | ↕ | DIGITAL ELEMENT 1<br>TARGET: Self-reset  | Range: Self-reset, Latched, Disabled           |
|                                          | ↑ | DIGITAL ELEMENT 1<br>EVENTS: Disabled    | Range: Disabled, Enabled                       |

*Note:*  
Digital elements run once per power system cycle. As such they can easily fail to react to an input signal or a block signal with a duration less than one power system cycle. This also means that digital element output can react up to one power system cycle later than the pickup and reset delay settings indicate.

*Note:*  
Do not use digital elements with transient signals, such as communications commands. Do not use digital elements where random delays of up to one cycle cannot be tolerated, such as in high speed protection.

There are 96 identical digital elements available, numbered 1 to 96. A digital element can monitor any FlexLogic operand and present a target message and/or enable events recording depending on the output operand state. The digital element settings include a name to be referenced in any target message, a blocking input from any selected FlexLogic operand, and a timer for pickup and reset delays for the output operand.

DIGITAL ELEMENT 1 INPUT

Selects a FlexLogic operand to be monitored by the digital element.

DIGITAL ELEMENT 1 PICKUP DELAY

Sets the required time delay from element pickup to element operation. If a pickup delay is not required, set it to 0. To avoid nuisance alarms, set the delay greater than the operating time of the breaker.

DIGITAL ELEMENT 1 RESET DELAY

Sets the time delay to reset. If a reset delay is not required, set to 0.

### DIGITAL ELEMENT 1 PICKUP LED

This setting enables or disabled the digital element pickup LED. When disabled, the operation of the pickup LED is blocked.




Figure 321: Digital element logic

### Circuit monitoring applications

Some versions of the digital input modules include an active voltage monitor circuit connected across form-A contacts. The voltage monitor circuit limits the trickle current through the output circuit (see technical specifications for form-A).

As long as the current through the voltage monitor is above a threshold (see technical specifications for form-A), the Cont Op 1 VOn FlexLogic operand is set (for contact input 1—corresponding operands exist for each contact output). If the output circuit has a high resistance or the DC current is interrupted, the trickle current drops below the threshold and the Cont Op 1 VOff FlexLogic operand is set. Consequently, the state of these operands can be used as indicators of the integrity of the circuits in which form-A contacts are inserted.

### Example 1: Breaker trip circuit integrity monitoring

In many applications it is desired to monitor the breaker trip circuit integrity so that problems can be detected before a trip operation is required. The circuit is considered to be healthy when the voltage monitor connected across the trip output contact detects a low level of current, well below the operating current of the breaker trip coil. If the circuit presents a high resistance, the trickle current falls below the monitor threshold, and an alarm is declared.

In most breaker control circuits, the trip coil is connected in series with a breaker auxiliary contact that is open when the breaker is open (see figure). To prevent unwanted alarms in this situation, the trip circuit monitoring logic must include the breaker position.




Figure 322: Trip circuit example 1

Assume the output contact H1 is a trip contact. Using the contact output settings, this output is given an ID name; for example, *Cont Op 1*. Assume a 52a breaker auxiliary contact is connected to contact input H5a to monitor breaker status. Using the contact input settings, this input is given an ID name, for example, *Cont Ip 1*, and is set *On* when the breaker is closed. The settings to use digital element 1 to monitor the breaker trip circuit are indicated (EnerVista example shown).

| PARAMETER              | DIGITAL ELEMENT 1   |
|------------------------|---------------------|
| Function               | Enabled             |
| Digital Element 1 Name | Bkr Trip Cct Out    |
| Input                  | Cont Op 1 VOff (H1) |
| Pickup Delay           | 0.200 s             |
| Reset Delay            | 0.100 s             |
| Pickup Led             | Enabled             |
| Block                  | Cont Ip 1 Off(H5a)  |
| Target                 | Self-reset          |
| Events                 | Enabled             |

D60\_500.urs Control Elements

Figure 323: Digital Element 1 parameters for Example 1

#### Example 2: Breaker trip circuit integrity monitoring

If it is required to monitor the trip circuit continuously, independent of the breaker position (open or closed), a method to maintain the monitoring current flow through the trip circuit when the breaker is open must be provided (as shown in the following figure). This can be achieved by connecting a suitable resistor (see figure) across the auxiliary contact in the trip circuit. In this case, it is not required to supervise the monitoring circuit with the breaker position – the **BLOCK** setting is selected to *OFF*. In this case, the settings are as follows (EnerVista example shown)

| PARAMETER              | DIGITAL ELEMENT 1   |
|------------------------|---------------------|
| Function               | Enabled             |
| Digital Element 1 Name | Bkr Trip Cct Out    |
| Input                  | Cont Op 1 VOff (H1) |
| Pickup Delay           | 0.200 s             |
| Reset Delay            | 0.100 s             |
| Pickup Led             | Enabled             |
| Block                  | OFF                 |
| Target                 | Self-reset          |
| Events                 | Enabled             |

D60\_500.urs Control Elements

Figure 324: Digital Element 1 parameters for Example 2




Figure 325: Trip circuit example 2

**Note:**  
The wiring connection for two examples above is applicable to both form-A contacts with voltage monitoring and solid-state contact with voltage monitoring.

### 8.8.10 DIGITAL COUNTERS

Setting path: **SETTINGS > CONTROL ELEMENTS > DIGITAL COUNTERS > COUNTER 1(8)**

**Note:**  
Only Counter 1 is shown

■ COUNTER 1  
■

|   |                                 |                                         |
|---|---------------------------------|-----------------------------------------|
| ⇔ | COUNTER 1<br>FUNCTION: Disabled | Range: Disabled, Enabled                |
| ⇕ | COUNTER 1 NAME:<br>Counter 1    | Range: up to 12 alphanumeric characters |
| ⇕ | COUNTER 1 UNITS:                | Range: up to 6 alphanumeric characters  |
| ⇕ | COUNTER 1 PRESET:<br>0          | Range: -2,147,483,648 to +2,147,483,647 |
| ⇕ | COUNTER 1 COMPARE:<br>0         | Range: -2,147,483,648 to +2,147,483,647 |
| ⇕ | COUNTER 1 UP:<br>Off            | Range: FlexLogic operand                |
| ⇕ | COUNTER 1 DOWN:<br>Off          | Range: FlexLogic operand                |
| ⇕ | COUNTER 1 BLOCK:<br>Off         | Range: FlexLogic operand                |
| ⇕ | CNT1 SET TO PRESET:<br>Off      | Range: FlexLogic operand                |
| ⇕ | COUNTER 1 RESET:<br>Off         | Range: FlexLogic operand                |
| ⇕ | COUNT1 FREEZE/RESET:<br>Off     | Range: FlexLogic operand                |
| ↑ | COUNT1 FREEZE/COUNT:<br>Off     | Range: FlexLogic operand                |



There are eight identical digital counters, numbered from 1 to 8. A digital counter counts the number of state transitions from Logic 0 to Logic 1. The counter is used to count operations such as the pickups of an element, the changes of state of an external contact (for example, breaker auxiliary switch), or pulses from a watt-hour meter.

### COUNTER 1 UNITS

Assigns a label to identify the unit of measure pertaining to the digital transitions to be counted. The units label appears in the corresponding actual values status.

### COUNTER 1 PRESET

Sets the count to a required preset value before counting operations begin, as in the case where a substitute relay is to be installed in place of an in-service relay, or while the counter is running.

### COUNTER 1 COMPARE

Sets the value to which the accumulated count value is compared. Three FlexLogic output operands are provided to indicate if the present value is 'more than (HI)', 'equal to (EQL)', or 'less than (LO)' the set value.

### COUNTER 1 UP

Selects the FlexLogic operand for incrementing the counter. If an enabled UP input is received when the accumulated value is at the limit of +2,147,483,647 counts, the counter rolls over to -2,147,483,648.

### COUNTER 1 DOWN

Selects the FlexLogic operand for decrementing the counter. If an enabled DOWN input is received when the accumulated value is at the limit of -2,147,483,648 counts, the counter rolls over to +2,147,483,647.

### COUNTER 1 BLOCK

Selects the FlexLogic operand for blocking the counting operation. All counter operands are blocked.

### CNT1 SET TO PRESET

Selects the FlexLogic operand used to set the count to the preset value. The counter sets to the preset value in the following situations:

- When the counter is enabled and the CNT1 SET TO PRESET operand has the value 1 (when the counter is enabled and CNT1 SET TO PRESET operand is 0, the counter sets to 0)
- When the counter is running and the CNT1 SET TO PRESET operand changes the state from 0 to 1 (CNT1 SET TO PRESET changing from 1 to 0 while the counter is running has no effect on the count)
- When a reset or reset/freeze command is sent to the counter and the CNT1 SET TO PRESET operand has the value 1 (when a reset or reset/freeze command is sent to the counter and the CNT1 SET TO PRESET operand has the value 0, the counter sets to 0)

### COUNTER 1 RESET


Selects the FlexLogic operand for setting the count to either "0" or the preset value depending on the state of the CNT1 SET TO PRESET operand.

### COUNTER 1 FREEZE/RESET

Selects the FlexLogic operand for capturing (freezing) the accumulated count value into a separate register with the date and time of the operation, and resetting the count to 0.

COUNTER 1 FREEZE/COUNT

Selects the FlexLogic operand for capturing (freezing) the accumulated count value into a separate register with the date and time of the operation, and continuing counting. The present accumulated value and captured frozen value with the associated date/time stamp are available as actual values. If control power is interrupted, the accumulated and frozen values are saved into non-volatile memory during the power-down operation.



827065A4.VSD

Figure 326: Digital counter logic

8.8.11 MULTI-RANGE SIGNAL OSCILLATION DETECTOR (MSOD)

Setting path: **SETTINGS > CONTROL ELEMENTS > MULTI-RANGE SIGNAL OSCILL DETECTOR > MUTLI-RANGE SIGNAL OSCILLATOR <n>**

**Note:**  
Only Multi-range signal oscillation detector 1 is shown

|                      |   |                              |                                               |
|----------------------|---|------------------------------|-----------------------------------------------|
| ■ MULTI-RANGE SIGNAL | ⇔ | MSOD 1 FUNCTION:<br>Disabled | Range: Disabled, Enabled                      |
| ■ OSCILL DETECTOR 1  | ⇕ | MSOD 1 FREQ BAND:<br>BAND 4  | Range: BAND 0, BAND 1, BAND 2, BAND 3, BAND 4 |
|                      | ⇕ | MSOD 1 SOURCE:<br>SRC1       | Range: SRC <n>                                |
|                      | ⇕ | MSOD 1 INPUT SIGNAL:<br>Va   | Range: See table                              |
|                      | ⇕ | MSOD 1 LOW FREQ:<br>35 Hz    | Range: See table                              |

|   |                                |                                                |
|---|--------------------------------|------------------------------------------------|
| ⇅ | MSOD 1 HIGH FREQ:<br>45 Hz     | Range: See table                               |
| ⇅ | MSOD 1 ALARM PKP:<br>0.100 pu  | Range: 0.02 to 10.00 pu in steps of 0.01       |
| ⇅ | MSOD 1 TRIP PKP:<br>0.200 pu   | Range: 0.05 to 10.00 pu in steps of 0.01       |
| ⇅ | MSOD 1 DEADBAND:<br>0.02 pu    | Range: 0.01 to 0.20 pu in steps of 0.01        |
| ⇅ | MSOD 1 ALARM DELAY:<br>0.10 s  | Range: See table                               |
| ⇅ | MSOD 1 TRIP DELAY:<br>0.20 s   | Range: See table                               |
| ⇅ | MSOD 1 DAMP R SUPV:<br>Enabled | Range: Enabled, Disabled                       |
| ⇅ | MSOD 1 DAMP R LEVEL:<br>2 %    | Range: 0% to 30.0% in steps of 0.1             |
| ⇅ | MSOD 1 OSC PHASE<br>OFFSET:    | Range: -180.0 to 180.0 degrees in steps of 0.1 |
| ⇅ | MSOD 1 AVG CYCLES:<br>5        | Range: 1 to 20 cycles in steps of 1            |
| ⇅ | MSOD 1 BLOCK:<br>Off           | Range: FlexLogic operand                       |
| ⇅ | MSOD 1 EVENTS:<br>Disabled     | Range: Enabled, Disabled                       |
| ↑ | MSOD 1 TARGET:<br>Disabled     | Range: Self-reset, Latched, Disabled           |

The Multi-Range Signal Oscillation Detector (MSOD) is important for wind and solar farms because of oscillation in the system.

The settings ranges and default values vary by band selected, as outlined in the following table.

#### Parameters for oscillation frequency detection bands

|              | Band 0         |         | Band I                                                                                     |         | Band II                                                                                    |         | Band III                                                                                   |         | Band IV                                          |         |
|--------------|----------------|---------|--------------------------------------------------------------------------------------------|---------|--------------------------------------------------------------------------------------------|---------|--------------------------------------------------------------------------------------------|---------|--------------------------------------------------|---------|
|              | Range          | Default | Range                                                                                      | Default | Range                                                                                      | Default | Range                                                                                      | Default | Range                                            | Default |
| Input signal | Ia, Ib, Ic, Ig | Ia      | Va Mag, Vb Mag, Vc Mag, V1 Mag, Vx Mag, Ia Mag, Ib Mag, Ic Mag, I1 Mag, IG Mag, P3, Q3, S3 | V1 Mag  | Va Mag, Vb Mag, Vc Mag, V1 Mag, Vx Mag, Ia Mag, Ib Mag, Ic Mag, I1 Mag, IG Mag, P3, Q3, S3 | V1 Mag  | Va Mag, Vb Mag, Vc Mag, V1 Mag, Vx Mag, Ia Mag, Ib Mag, Ic Mag, I1 Mag, IG Mag, P3, Q3, S3 | V1 Mag  | Va, Vb, Vc, Vx, Ia, Ib, Ic, Ig, Vclarke, Iclarke | Va      |
| Low freq     | ---            | ---     | 0.01 to 0.10                                                                               | 0.03    | 0.10 to 1.00                                                                               | 0.30    | 1.00 to 10.00                                                                              | 3.00    | 10.0 to ffrom-5                                  | 35.0    |
| High freq    | ---            | ---     | 0.01 to 0.10                                                                               | 0.06    | 0.10 to 1.00                                                                               | 0.60    | 1.00 to 10.00                                                                              | 6.00    | 10.0 to ffrom-5                                  | 45.0    |
| Alarm delay  | 0.00 to 600.00 | 1.00    | 0.00 to 600.00                                                                             | 50.00   | 0.00 to 600.00                                                                             | 5       | 0.00 to 600.00                                                                             | 0.5     | 0.00 to 600.00                                   | 0.1     |

|                                               | Band 0                         |         | Band I                       |         | Band II                      |         | Band III       |         | Band IV                        |         |
|-----------------------------------------------|--------------------------------|---------|------------------------------|---------|------------------------------|---------|----------------|---------|--------------------------------|---------|
|                                               | Range                          | Default | Range                        | Default | Range                        | Default | Range          | Default | Range                          | Default |
| Trip delay                                    | 0.00 to 600.00                 | 2.00    | 0.00 to 600.00               | 100.00  | 0.00 to 600.00               | 10      | 0.00 to 600.00 | 1       | 0.00 to 600.00                 | 0.2     |
| Averaging cycles                              | 1 to 20                        | 5       | ---                          | ---     | ---                          | ---     | ---            | ---     | ---                            | ---     |
| Sample rate and execution rate (60 Hz system) | 3840 Hz down sampled to 480 Hz |         | 480 Hz down sampled to 60 Hz |         | 480 Hz down sampled to 60 Hz |         | 480 Hz         |         | 3840 Hz down sampled to 480 Hz |         |
| Sample rate and execution rate (50 Hz system) | 3200 Hz down sampled to 400 Hz |         | 400 Hz down sampled to 50 Hz |         | 400 Hz down sampled to 50 Hz |         | 400 Hz         |         | 3200 Hz down sampled to 400 Hz |         |

### MSOD 1 FREQ BAND

This setting selects the oscillation frequency band to be detected, BAND 0 (DC quantity), BAND I (0.01 to 0.1Hz), BAND II (0.1 to 1Hz), BAND III (1 to 10Hz), and BAND IV (10 to from-5 Hz).

Band 0 is designed to detect geomagnetic induced currents. It is only applicable if DC-coupled non-conventional instrument transformers (NCITs) are used (otherwise DC component cannot be measured as it does not pass through the line CTs or the internal CTs). Due to the nature of the DC signal, the only measurement provided for Band 0 is the magnitude; all other measurements are fixed to zero. Band 0 is applicable if process bus inputs are used.

### MSOD 1 SOURCE

This setting identifies the signal source for the MSOD element.

### MSOD 1 INPUT SIGNAL

This setting identifies the input signal to the MSOD element collected from the source specified.

### MSOD 1 LOW FREQ

This setting selects the value of the lower frequency of frequency band of interest. If measured frequency is outside the frequency band of interest, neither the alarm output nor the trip output are given.

### MSOD 1 HIGH FREQ

Same as for low frequency but for value of the higher frequency.

### MSOD 1 ALARM PKP


This setting defines the pickup level for the alarm stage of the element. The oscillation magnitude is the oscillating signal magnitude in per unit that is calculated by full cycle Fourier based on the calculated oscillation frequency.

### MSOD 1 TRIP PKP

Same as for alarm pickup but for trip stage of the element.

### MSOD 1 DEADBAND

This setting defines the deadband of the measured analog signal. If signal is inside the deadband, then oscillation is not considered to be happening. When the signal is outside the deadband, then frequency of the oscillation signal is measured and the oscillation magnitude is calculated based on the measured oscillation frequency. A typical setting is at 0.25 of the alarm stage pickup setting.



**Figure 327: Deadband**

### **MSOD 1 ALARM DELAY**

This setting specifies the pickup time delay of the alarm stage of the element.

### **MSOD 1 TRIP DELAY**

This setting specifies the pickup time delay of the trip stage of the element.

### **MSOD 1 DAMP R SUPV**

This setting enables or disables the damping ratio supervision.

### **MSOD 1 DAMP R LEVEL**


This setting defines the oscillation damping ratio supervision level. A positive damping ratio means a damped oscillation (oscillation with decreasing amplitude), and a negative damping ratio causes a power oscillation with increasing amplitude (unstable oscillation). When the damping ratio supervision is enabled, MSOD is not permitted to operate if the calculated damping ratio is greater than this setting (DAMP R LEVEL) because such oscillation is considered a well-damped, stable oscillation. Operating time needs to be graded with the damping ratio setting to prevent maloperation due to the time it takes to calculate the actual damping ratio. When the MSOD 1 DAMP R SUPV setting is disabled, the MSOD 1 DAMP R LEVEL setting is inactive.

### **MSOD 1 OSC PHASE OFFSET**

This setting defines the offset to oscillation phase angle (Phase\_osc), which allows the user to calibrate the input source to offset the phase errors introduced by VTs, CTs, cabling or connections (such as polarity or vector group configurations). The setting value is added directly to the measured angles. Therefore, enter a positive correction when the secondary signal lags the true signal and a negative value when the secondary signal leads the true signal.


### **MSOD 1 AVG CYCLES**

This setting defines the number of averaging cycles to be used in case of Band 0. The setting is visible/enabled if MSOD is configured as Band 0.



859816A1.vsdX

Figure 328: MSOD bands I to IV logic



859817A1.vsdX

Figure 329: MSOD band 0 logic

## 8.9 MONITORING ELEMENTS

### 8.9.1 MONITORING ELEMENTS MENU

Setting path: **SETTINGS > CONTROL ELEMENTS > MONITORING ELEMENTS**

|                                               |   |                                                            |            |
|-----------------------------------------------|---|------------------------------------------------------------|------------|
| <div>■ MONITORING</div> <div>■ ELEMENTS</div> | ⇔ | <div>■ BREAKER &lt;n&gt;</div> <div>■ ARCING CURRENT</div> | n = 1 to 2 |
|                                               | ⇕ | <div>■ CT FAILURE</div> <div>■ DETECTOR &lt;n&gt;</div>    | n = 1 to 4 |
|                                               | ⇕ | <div>■ VT FUSE FAILURE &lt;n&gt;</div> <div>■</div>        | n = 1 to 4 |
|                                               | ⇕ | <div>■ THERMAL OVERLOAD</div> <div>■ PROTECTION</div>      |            |
|                                               | ⇕ | <div>■ HARMONIC</div> <div>■ DETECTION</div>               |            |

### 8.9.2 BREAKER ARCING CURRENT

Setting path: **SETTINGS > CONTROL ELEMENTS > MONITORING ELEMENTS > BREAKER <n> ARCING CURRENT**

*Note:*  
Only Breaker 1 arcing current is shown

|                                                    |   |                                                   |                                                        |
|----------------------------------------------------|---|---------------------------------------------------|--------------------------------------------------------|
| <div>■ BREAKER 1</div> <div>■ ARCING CURRENT</div> | ⇔ | BKR 1 ARC AMP<br>FUNCTION: Disabled               | Range: Disabled, Enabled                               |
|                                                    | ⇕ | BKR 1 ARC AMP<br>SOURCE: SRC 1                    | Range: SRC <n>                                         |
|                                                    | ⇕ | BKR 1 ARC AMP INT-A:<br>Off                       | Range: FlexLogic operand                               |
|                                                    | ⇕ | BKR 1 ARC AMP INT-B:<br>Off                       | Range: FlexLogic operand                               |
|                                                    | ⇕ | BKR 1 ARC AMP INT-C:<br>Off                       | Range: FlexLogic operand                               |
|                                                    | ⇕ | BKR 1 ARC AMP<br>DELAY: 0.000 s                   | Range: 0.000 to 65.535 s in steps of 0.001             |
|                                                    | ⇕ | BKR 1 ARC AMP LIMIT:<br>1000 kA <sup>2</sup> -cyc | Range: 0 to 50000 kA <sup>2</sup> -cycle in steps of 1 |
|                                                    | ⇕ | BKR 1 INTERRUPTION<br>RATING: 31.5 kA             | Range: 0.0 to 100.0 kA in steps of 0.1                 |
|                                                    | ⇕ | BKR 1 CLR ARC AMPS:<br>Off                        | Range: FlexLogic operand                               |
|                                                    | ⇕ | BKR 1 ARC AMP BLOCK:<br>Off                       | Range: FlexLogic operand                               |
|                                                    | ⇕ | BKR 1 ARC AMP<br>TARGET: Self-reset               | Range: Self-reset, Latched, Disabled                   |



BKR 1 ARC AMP  
EVENTS: Disabled

Range: Disabled, Enabled

**Note:**

*There are no breaker arcing current elements with 9-2LE hardware and software options*

There is one breaker arcing current element available per CT bank, with a minimum of two elements.

This element calculates an estimate of the per-phase wear on the breaker contacts by measuring and integrating the current squared passing through the breaker contacts as an arc. These per-phase values are added to accumulated totals for each phase and compared to a programmed threshold value. When the threshold is exceeded in any phase, the relay can set an output operand to “1.” The accumulated value for each phase can be displayed as an actual value.

The operation of the scheme is shown in the following logic diagram. The same output operand that is selected to operate the output relay used to trip the breaker, indicating a tripping sequence has begun, is used to initiate this feature. A time delay is introduced between initiation and the starting of integration to prevent integration of current flow through the breaker before the contacts have parted. This interval includes the operating time of the output relay, any other auxiliary relays, and the breaker mechanism. For maximum measurement accuracy, measure the interval between change-of-state of the operand (from 0 to 1) and contact separation for the specific installation. Integration of the measured current continues for 100 ms, which is expected to include the total arcing period.

The feature is programmed to perform fault duration calculations. Fault duration is defined as a time between operation of the disturbance detector occurring before initiation of this feature, and reset of an internal low-set overcurrent function. Correction is implemented to account for a non-zero reset time of the overcurrent function.

Breaker arcing currents and fault duration values are available under the **ACTUAL VALUES > RECORDS > MAINTENANCE < BREAKER <n>** menus.

### BKR 1 ARC AMP INT-A(C)

Select the same output operands that are configured to operate the output relays used to trip the breaker. In three-pole tripping applications, configure the same operand to initiate arcing current calculations for poles A, B, and C of the breaker. In single-pole tripping applications, configure per-pole tripping operands to initiate the calculations for the poles that are actually tripped.

### BKR 1 ARC AMP DELAY

This setting is used to program the delay interval between the time the tripping sequence is initiated and the time the breaker contacts are expected to part, starting the integration of the measured current.

### BKR 1 ARC AMP LIMIT

Selects the threshold value above which the output operand is set.

### BKR 1 CLR ARC AMPS

Selects a FlexLogic Operand to clear the accumulated I2t values (kA2-cycle), reset fault duration items (breaker operating time), clear ARCING AMPS (kA2-cycle) and AMP MAX (kA) values of the last event.

### BKR 1 INTERRUPTION RATING

This setting specifies the maximum symmetrical interruption rating of the circuit breaker.






Figure 330: Arcing current measurement




Figure 331: Breaker arcing current logic

### 8.9.3 VT FUSE FAILURE

Setting path: **SETTINGS > CONTROL ELEMENTS > MONITORING ELEMENTS > VT FUSE FAILURE <n>**

*Note:*  
Only VT Fuse Failure 1 is shown

|                                                          |   |                                             |                                            |
|----------------------------------------------------------|---|---------------------------------------------|--------------------------------------------|
| <div> <div>■ VT FUSE FAILURE 1</div> <div>■</div> </div> | ↔ | VT FUSE FAILURE 1<br>FUNCTION: Disabled     | Range: Disabled, Enabled                   |
|                                                          | ⇅ | VT FUSE FAILURE 1<br>CT SOURCE: SRC 1       | Range: SRC <n><br>B30 only                 |
|                                                          | ⇅ | VT FUSE FAILURE 1<br>ALARM DELAY: 1.000 s   | Range: 0.000 to 65.535 s in steps of 0.001 |
|                                                          | ⇅ | NEUTRAL WIRE OPEN 1<br>DETECTION: Disabled  | Range: Disabled, Enabled                   |
|                                                          | ↑ | NEUTRAL WIRE OPEN 1<br>3 HARM PKP: 0.100 pu | Range: 0.004 to 3.000 pu in steps of 0.001 |

Every signal source includes a fuse failure scheme. A signal source must have a three-phase VT bank and a three-phase CT bank assigned to it, in order for the fuse failure scheme to operate.

The VT fuse failure detector is used to raise an alarm and/or block elements that operate incorrectly for a full or partial loss of AC potential caused by one or more blown fuses. Some elements that can be blocked (via the BLOCK input) are distance, voltage restrained overcurrent, and directional current.

There are two classes of fuse failure that occur:

- Class A — Loss of one or two phases
- Class B — Loss of all three phases

Different means of detection are required for each class. An indication of class A failures is a significant level of negative-sequence voltage, whereas an indication of class B failures is when positive sequence current is present and there is an insignificant amount of positive sequence voltage. Also, a rapid decrease in the phase voltages magnitude from a healthy voltage level without disturbance in current can indicate VT fuse fail conditions. These noted indications of fuse failure can also be present when faults are present on the system, so a means of detecting faults and inhibiting fuse failure declarations during these events is provided.

Once the fuse failure condition is declared, it is sealed-in until the cause that generated it disappears.

An additional condition is introduced to inhibit a fuse failure declaration when the monitored circuit is de-energized; positive-sequence voltage and current are both below threshold levels.

#### VT FUSE FAILURE 1 FUNCTION

Enables and disables the fuse failure feature for Source 1 VT Fuse Fail.


#### NEUTRAL WIRE OPEN 1 DETECTION

Enables and disables the VT neutral wire open detection function. When the VT is connected in Delta, do not enable this function because there is no neutral wire for Delta connected VT.

#### NEUTRAL WIRE OPEN 1 3 HARM PKP

Specifies the pickup level of 3rd harmonic of 3V0 signal for the NEUTRAL WIRE OPEN DETECTION logic to pick up.

Base voltage for this element is **PHASE VT SECONDARY** setting in the case of WYE VTs and (PHASE VT SECONDARY)/ $\sqrt{3}$  in case of DELTA VTs. The setting is found under **SETTINGS > SYSTEM SETUP > AC INPUTS > VOLTAGE BANK > PHASE VT SECONDARY**.



859 808A2.vsd

Figure 332: VT fuse fail logic

### 8.9.4 THERMAL OVERLOAD PROTECTION (ANSI 49)

Setting path: **SETTINGS > CONTROL ELEMENTS > MONITORING ELEMENTS > THERMAL OVERLOAD PROTECTION > THERMAL PROTECTION <n>**

**Note:**  
Only Thermal Protection 1 is shown

|                                                |   |                                                                                                                                                                                                                  |                                                                                                                                                           |
|------------------------------------------------|---|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div>■ THERMAL</div> <div>■ PROTECTION 1</div> | ↔ | <div>THERMAL PROTECTION 1<br/>FUNCTION: Disabled</div> <div>THERMAL PROTECTION 1<br/>SOURCE: SRC1</div> <div>THERMAL PROTECTION 1<br/>MODE: 3-PHASE</div> <div>THERMAL PROTECTION 1<br/>BASE CURR: 0.80 pu</div> | <div>Range: Disabled, Enabled</div> <div>Range: SRC &lt;n&gt;</div> <div>Range: 3-Phase, 1-Phase</div> <div>Range: 0.20 to 3.00 pu in steps of 0.01</div> |
|------------------------------------------------|---|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|

|   |                                             |                                             |
|---|---------------------------------------------|---------------------------------------------|
| ⇅ | THERMAL PROTECTION 1<br>k FACTOR: 1.10      | Range: 0.20 to 4.00 in steps of 0.05        |
| ⇅ | THERMAL PROTECTION 1<br>ALARM LEVEL: 0.5 pu | Range: 0.2 to 1.0 pu in steps of 0.1        |
| ⇅ | THERM PROT 1 TRIP<br>TIME CONST: 45.0 min   | Range: 0.0 to 999.0 minutes in steps of 0.1 |
| ⇅ | THERM PROT 1 RESET<br>TIME CONST: 45.0 min  | Range: 0.0 to 999.0 minutes in steps of 0.1 |
| ⇅ | THERM PROT 1 MINIM<br>RESET TIME: 20.0 min  | Range: 0.0 to 999.0 minutes in steps of 0.1 |
| ⇅ | THERM PROT 1 RESET:<br>Off                  | Range: FlexLogic operand                    |
| ⇅ | THERM PROT 1 BLOCK:<br>Off                  | Range: FlexLogic operand                    |
| ⇅ | THERMAL PROTECTION 1<br>TARGET: Self-reset  | Range: Self-reset, Latched, Disabled        |
| ↑ | THERMAL PROTECTION 1<br>EVENTS: Disabled    | Range: Disabled, Enabled                    |

The thermal overload protection element corresponds to the IEC 255-8 standard and is used to detect thermal overload conditions in protected power system elements. Choosing an appropriate time constant element can be used to protect different elements of the power system.

The cold curve characteristic is applied when the estimated  $I_p$  current is less than 10% of the base current. If  $I_p$  current is greater or equal than 10% than the base current, then the hot curve characteristic is applied. The  $I_p$  current is estimated with a fixed time constant for both cooling and heating that reaches to the final value in two seconds on a step change (either step up or step down) signal.

The IEC255-8 cold curve trip time is defined as follows:

$$t_{op} = \tau_{op} \times \ln [ I^2 / (I^2 - (kI_b)^2) ]$$

The IEC255-8 hot curve trip time is defined as follows:

$$t_{op} = \tau_{op} \times \ln [ (I^2 - I_p^2) / (I^2 - (kI_b)^2) ]$$

where:

- $t$  = time to operate
- $\tau$  = thermal protection trip time constant
- $I$  = measured overload RMS current
- $I_p$  = measured load RMS current before overload occurs
- $k$  = IEC 255-8 k-factor applied to  $I_b$ , defining maximum permissible current above nominal current. A typical value range for this  $k$  factor is 1.0 to 1.5 per the standard
- $I_b$  = protected element base (nominal) current


To ensure element accuracy for high overcurrent conditions, the maximum value of  $I/(k \times I_b)$  is limited to 8, even when realistically it is exceeding this value.

The reset time of the thermal overload protection element is also time delayed using following formula:

$$t_{rst} = \tau_{rst} \times \ln [ (kI_b)^2 / (I^2 - (kI_b)^2) ] + T_{min}$$

where:

- $\tau_{rst}$  = thermal protection trip time constant
- $T_{min}$  = a minimum reset time setting



**Figure 333: IEC 255-8 sample operate and reset curves**

The thermal overload protection element estimates accumulated thermal energy  $E$  using the following equations calculated each power cycle. When current is greater than the pickup level,  $I_n > k \times I_b$ , element starts increasing the thermal energy:

$$E_n = E_{n-1} + \Delta t / t_{op}(I_n)$$

When current is less than the dropout level,  $I_n > 0.97 \times k \times I_b$ , the element starts decreasing the thermal energy:

$$E_{rst} = E_{n-1} + \Delta t / t_{rst}(I_n)$$

where

- $\Delta t$  is the power cycle duration
- $n$  is the power cycle index
- $t_{op}(I_n)$  is the trip time calculated at index  $n$  as per the IEC255-8 cold curve or hot curve equations
- $t_{rst}(I_n)$  is the reset time calculated at index  $n$  as per the reset time equation

- $I_n$  is the measured overload RMS current at index n
- $E_n$  is the accumulated energy at index n
- $E_{n-1}$  is the accumulated energy at index n – 1

The thermal overload protection element removes the THERMAL PROT 1 OP and THERMAL PROT 1 ALARM output operand when  $E < 0.05$ . In case of emergency, the thermal memory and as a result THERMAL PROT 1 OP and THERMAL PROT 1 ALARM output operands can be reset using **THERM PROT 1 RESET** setting.


The calculations are performed per the selected mode (three-phase or single-phase). For three-phase, calculations are performed per phase. If the accumulated energy reaches value 1 pu in any phase, the thermal overload protection element operates and only resets when energy is less than 0.05 in all three phases. The THERMAL PROT 1 ALARM operand asserts if accumulated energy reaches the selected **THERMAL PROTECTION 1 ALARM LEVEL** setting in any phase and resets only when energy is below 0.05 in all three phases.

In single-phase mode, the thermal energy of only the ground channel IG of the assigned source is accumulated.

### Typical time constants

| Protected equipment | Time constant    | Minimum reset time |
|---------------------|------------------|--------------------|
| Capacitor bank      | 10 minutes       | 30 minutes         |
| Overhead line       | 10 minutes       | 20 minutes         |
| Air-core reactor    | 40 minutes       | 30 minutes         |
| Busbar              | 60 minutes       | 20 minutes         |
| Underground cable   | 20 to 60 minutes | 60 minutes         |

The figure shows the logic for the thermal overload protection element




827014A1.vsd

Figure 334: Thermal overload protection logic

# 8.10 INPUTS/OUTPUTS

## 8.10.1 CONTACT INPUTS

Setting path: **SETTINGS > INPUTS / OUTPUTS > CONTACT INPUTS**



Contact inputs and outputs are digital signals associated with connections to hard-wired contacts. Wet and dry contacts are supported.

The contact inputs menu contains configuration settings for each contact input as well as voltage thresholds for each group of two, four and five contact inputs. Upon startup, the relay processor determines (from an assessment of the installed modules) which contact inputs are available and then display settings for only those inputs.

An alphanumeric ID can be assigned to a contact input for diagnostic, setting, and event recording purposes. The CONTACT IP X On (Logic 1) FlexLogic operand corresponds to contact input X being closed, while CONTACT IP X Off corresponds to contact input “X” being open. The **CONTACT INPUT DEBNCE TIME** setting defines the time required for the contact to overcome ‘contact bouncing’ conditions. As this time differs for different contact types and manufacturers, set it as a maximum contact debounce time (per manufacturer specifications) plus some margin to ensure proper operation. If **CONTACT INPUT EVENTS** is enabled, every change in the contact input state triggers an event.

A raw status is scanned for all Contact Inputs synchronously at the constant rate of 0.5 ms as shown in the following figure. The DC input voltage is compared to a user-settable threshold. A new contact input state must be maintained for a user-settable debounce time in order for the Product to validate the new contact state. In the following figure, the debounce time is set at 2.5 ms; thus the 6th sample in a row validates the change of state (mark no. 1 in the diagram). Once validated (de-bounced), the contact input asserts a corresponding FlexLogic operand and logs an event as per user setting.

A time stamp of the first sample in the sequence that validates the new state is used when logging the change of the contact input into the Event Recorder (mark no. 2 in the figure).


Protection and control elements, as well as FlexLogic equations and timers, are executed eight times in a power system cycle. The protection pass duration is controlled by the frequency tracking mechanism. The FlexLogic operand reflecting the debounced state of the contact is updated at the protection pass following the validation (marks no. 3 and 4 on the figure that follows). The update is performed at the beginning of the protection pass so all protection and control functions, as well as FlexLogic equations, are fed with the updated states of the contact inputs.

The FlexLogic operand response time to the contact input change is equal to the debounce time setting plus up to one protection pass (variable and depending on system frequency if frequency tracking enabled). If the change of state occurs just after a protection pass, the recognition is delayed until the subsequent protection pass; that is, by the entire duration of the protection pass. If the change occurs just prior to a protection pass, the state is recognized immediately. Statistically a delay of half the protection pass is expected. Owing to the 0.5 ms scan rate, the time resolution for the input contact is below 1 ms.

For example, eight protection passes per cycle on a 60 Hz system correspond to a protection pass every 2.1 ms. With a contact debounce time setting of 3.0 ms, the FlexLogic operand-assert time limits are:  $3.0 + 0.0 = 3.0$  ms and  $3.0 + 2.1 = 5.1$  ms. These time limits depend on how soon the protection pass runs after the debouncing time.

Regardless of the contact debounce time setting, the contact input event is time-stamped with a 1 ms accuracy using the time of the first scan corresponding to the new state (mark no. 2 shown). Therefore, the time stamp reflects a change in the DC voltage across the contact input terminals that was not accidental as it was subsequently validated using the debounce timer. Keep in mind that the associated FlexLogic operand is asserted/de-asserted later, after validating the change.

The debounce algorithm is symmetrical: the same procedure and debounce time are used to filter the LOW-HIGH (marks no. 1, 2, 3, and 4 in the figure) and HIGH-LOW (marks no. 5, 6, 7, and 8) transitions.



842709A1.cdr

**Figure 335: Input contact debouncing mechanism and time stamp sample timing**

The contact inputs are grouped with a common return. They are isolated in groups of four to allow connection of wet contacts from different voltage sources for each group.

The **CONTACT INPUT THRESHOLDS** determine the minimum voltage required to detect a closed contact input. This value is selected according to the following criteria: 17 for 24 V sources, 33 for 48 V sources, 84 for 110 to 125 V sources and 166 for 250 V sources.



For example, to use contact input H5a as a status input from the breaker 52b contact to seal-in the trip relay and record it in the Event Records menu, make the following settings changes:

- **CONTACT INPUT H5a ID:** *Breaker Closed (52b)*
- **CONTACT INPUT H5a EVENTS:** *Enabled*

**Note:**

The 52b contact is closed when the breaker is open and open when the breaker is closed.

The setting **STATION BATTERY NOM VOLTAGE** is applicable to 6Y cards only. A 6Y card provides an additional function for station battery voltage measurement through contact inputs 9 (x13a) and 11 (x16a). To measure this DC battery voltage, you:

1. set the **STATION BATTERY NOM VOLTAGE** setting to the nominal voltage of the station battery
2. connect the positive terminal of the station battery directly to the Contact Input 9 or 11
3. connect the negative terminal to the common return.

The measured DC voltage is available as the Flexanalog Battery DC Volt1 / Battery DC Volt2.

Logic for monitoring the station battery voltage can be designed using Flexelements which use a per unit value of the measured voltage. The setting **STATION BATTERY NOM VOLTAGE** is used as base for converting the measured DC voltage to a per unit value. If the setting **STATION BATTERY NOM VOLTAGE** is set to 0 Vdc, then the station battery DC voltage measurement functionality is not available and the Contact Inputs work as regular contact inputs. The Flexanalog Battery DC Volt1 / Battery DC Volt2 would read 0.

The **BATTERY VOLTAGE I/O MODULE** setting is applicable only to the 6Y card. It uses the contacts inputs 9 and 11 for the station battery DC voltage measurement.

It should be noted that when contact inputs 9 (x13a) and 11 (x16a) are used for DC voltage measurement, the contact inputs 10 (x15a) and 12 (x18a) could still be used as regular contact inputs, but the **CONTACT INPUT THRESHOLD** settings for contact inputs 10 (x15a) and 12 (x18a) are forced to a certain value (out of 17, 33, 84, 166 Vdc) as shown in the table below. For example, if **STATION BATTERY NOM VOLTAGE** is set as 250 Vdc and **BATTERY VOLTAGE I/O MODULE** is set to H, then the settings **Ips H13a,H15a THRESHOLD** and **Ips H16a,H18a THRESHOLD** automatically become 166Vdc.

The following table shows the **CI THRESHOLD** setting for Contact Inputs 9-10 and 11-12 of 6Y card based on the setting **STATION BATTERY NOM VOLTAGE** (when using the voltage monitoring functionality)

| Range of the setting STATION BATTERY NOM VOLTAGE | Applicable CI THRESHOLD setting for Contact Inputs 9-10 and 11-12 of 6Y card |
|--------------------------------------------------|------------------------------------------------------------------------------|
| Below 30V                                        | 17V                                                                          |
| 30V to 60V                                       | 33V                                                                          |
| 60V to 150V                                      | 84V                                                                          |
| 150V to 300V                                     | 166V                                                                         |

## 8.10.2 VIRTUAL INPUTS

Setting path: **SETTINGS > INPUTS/OUTPUTS > VIRTUAL INPUTS > VIRTUAL INPUT 1(128)**

**Note:**

Only Virtual input 1 is shown

■ VIRTUAL INPUT 1

■

⇔

VIRTUAL INPUT 1

FUNCTION: Disabled

Range: Disabled, Enabled

|   |                                     |                                         |
|---|-------------------------------------|-----------------------------------------|
| ⇅ | VIRTUAL INPUT 1 ID:<br>Virt Ip 1    | Range: up to 20 alphanumeric characters |
| ⇅ | VIRTUAL INPUT 1<br>TYPE: Latched    | Range: Self-Reset, Latched              |
| ↑ | VIRTUAL INPUT 1<br>EVENTS: Disabled | Range: Disabled, Enabled                |

The virtual inputs and outputs are digital signals associated with UR-series internal logic signals. Virtual inputs include signals generated by the local user interface. The virtual outputs are outputs of FlexLogic equations used to customize the device. Virtual outputs can also serve as virtual inputs to FlexLogic equations.

The virtual inputs can be individually programmed to respond to input signals from the keypad (via the **COMMANDS** menu) and communications protocols. All virtual input operands are defaulted to *Off* (logic 0) unless the appropriate input signal is received.

If the **VIRTUAL INPUT x FUNCTION** is to *Disabled*, the input is forced to off (logic 0) regardless of any attempt to alter the input. If enabled, the input operates as shown on the logic diagram and generates output FlexLogic operands in response to received input signals and the applied settings.

There are two types of operation: self-reset and latched. If **VIRTUAL INPUT x TYPE** is *Self-Reset*, when the input signal transits from off to on, the output operand is set to on for only one evaluation of the FlexLogic equations and then return to off. If set to *Latched*, the virtual input sets the state of the output operand to the same state as the most recent received input.

The self-reset operating mode generates the output operand for a single evaluation of the FlexLogic equations. If the operand is to be used anywhere other than internally in a FlexLogic equation, it likely needs to be lengthened in time. A FlexLogic timer with a delayed reset can perform this function.




Figure 336: Virtual inputs logic

## 8.10.3 CONTACT OUTPUTS

### 8.10.3.1 NON-LATCHING CONTACT OUTPUTS (H)

Setting path: **SETTINGS > INPUTS/OUTPUTS > CONTACT OUTPUTS > CONTACT OUTPUT H1(H72)**

**Note:**  
Only Contact output H1 is shown

|                          |   |                                   |                                                            |
|--------------------------|---|-----------------------------------|------------------------------------------------------------|
| ■ CONTACT OUTPUT H1<br>■ | ⇅ | CONTACT OUTPUT H1 ID<br>Cont Op 1 | Range: up to 20 alphanumeric characters: Disabled, Enabled |
|--------------------------|---|-----------------------------------|------------------------------------------------------------|

|   |                                      |                          |
|---|--------------------------------------|--------------------------|
| ⇅ | OUTPUT H1 OPERATE:<br>Off            | Range: FlexLogic operand |
| ⇅ | OUTPUT H1 SEAL-IN:<br>Off            | Range: FlexLogic operand |
| ↑ | CONTACT OUTPUT H1<br>EVENTS: Enabled | Range: FlexLogic operand |

A contact output is a digital signals associated with connections to hard-wired contacts. Wet and dry contacts are supported.

Upon startup of the relay, the main processor determines from an assessment of the modules installed in the chassis which contact outputs are available and then presents the settings for only these outputs. Where the contact input is non-latching, the settings are as shown.


An ID can be assigned to each contact output. The signal that can OPERATE a contact output can be any FlexLogic operand (virtual output, element state, contact input, or virtual input). An additional FlexLogic operand can be used to SEAL-IN the relay. Any change of state of a contact output can be logged as an Event if programmed to do so.

For example, the trip circuit current is monitored by providing a current threshold detector in series with some Form-A contacts (see the trip circuit example in the Digital Elements section). The monitor sets a flag (see the specifications for Form-A). The name of the FlexLogic operand set by the monitor, consists of the output relay designation, followed by the name of the flag; for example, Cont OP 1 IOn.

In most breaker control circuits, the trip coil is connected in series with a breaker auxiliary contact used to interrupt current flow after the breaker has tripped, to prevent damage to the less robust initiating contact. This can be done by monitoring an auxiliary contact on the breaker which opens when the breaker has tripped, but this scheme is subject to incorrect operation caused by differences in timing between breaker auxiliary contact change-of-state and interruption of current in the trip circuit. The most dependable protection of the initiating contact is provided by directly measuring current in the tripping circuit, and using this parameter to control resetting of the initiating relay. This scheme is often called trip seal-in.

This can be realized using the Cont OP 1 IOn FlexLogic operand to seal-in the contact output as follows:

- **CONTACT OUTPUT H1 ID:** Cont Op 1
- **OUTPUT H1 OPERATE:** any suitable FlexLogic operand
- **OUTPUT H1 SEAL-IN:** Cont Op 1 IOn
- **CONTACT OUTPUT H1 EVENTS:** *Enabled*



**Figure 337: Contact input/output module type 6A contact 1 logic**

### 8.10.3.2 LATCHING CONTACT OUTPUTS

Setting path: **SETTINGS > INPUTS/OUTPUTS > CONTACT OUTPUTS > CONTACT OUTPUT H1a**

*Note:*  
Only Contact output H1a is shown

|                                                           |   |                                       |                                                            |
|-----------------------------------------------------------|---|---------------------------------------|------------------------------------------------------------|
| <div> <div>■ CONTACT OUTPUT H1a</div> <div>■</div> </div> | ⇔ | CONTACT OUTPUT H1a ID<br>Cont Op 1    | Range: up to 20 alphanumeric characters: Disabled, Enabled |
|                                                           | ⇕ | OUTPUT H1a OPERATE:<br>Off            | Range: FlexLogic operand                                   |
|                                                           | ⇕ | OUTPUT H1a RESET:<br>Off              | Range: FlexLogic operand                                   |
|                                                           | ⇕ | OUTPUT H1a SEAL-IN:<br>Off            | Range: FlexLogic operand                                   |
|                                                           | ⇕ | OUTPUT H1a TYPE:<br>Operate-dominant  | Range: Operate-dominant, Reset-dominant                    |
|                                                           | ↑ | CONTACT OUTPUT H1a<br>EVENTS: Enabled | Range: FlexLogic operand                                   |

The latching output contacts are mechanically bi-stable and controlled by two separate (open and close) coils. As such they retain their position even if the relay is not powered up. The relay recognizes all latching output contact cards and populates the setting menu accordingly. On power up, the relay reads positions of the latching contacts from the hardware before executing any other functions of the relay (such as protection and control features or FlexLogic).

The latching output modules, either as part of the relay or as individual modules, are shipped from the factory with all latching contacts open. It is highly recommended to double-check the programming and positions of the latching contacts when replacing a module.

Since the relay asserts the output contact and reads back its position, it is possible to incorporate self-monitoring capabilities for the latching outputs. If any latching outputs exhibits a discrepancy, the **LATCHING OUTPUT ERROR** self-test error is declared. The error is signaled by the **LATCHING OUT ERROR** FlexLogic operand, event, and target message.

The settings shown use H1a as an example. The menu varies; not all fields shown display.

#### OUTPUT H1a OPERATE


This setting specifies a FlexLogic operand to operate the *Close Coil* of the contact. The relay seals-in this input to safely close the contact. Once the contact is closed and the **RESET** input is logic 0 (off), any activity of the **OPERATE** input, such as subsequent chattering, does not have any effect. With both the **OPERATE** and **RESET** inputs active (logic 1), the response of the latching contact is specified by the **OUTPUT H1a TYPE** setting.

#### OUTPUT H1a RESET or SEAL-IN

This setting specifies a FlexLogic operand to operate the *Trip Coil* of the contact. The relay seals-in this input to safely open the contact. Once the contact is opened and the **OPERATE** input is logic 0 (off), any activity of the **RESET** input, such as subsequent chattering, does not have any effect. With both the **OPERATE** and **RESET** inputs active (logic 1), the response of the latching contact is specified by the **OUTPUT H1a TYPE** setting.

## OUTPUT H1a TYPE

This setting specifies the contact response under conflicting control inputs; that is, when both the **OPERATE** and **RESET** signals are applied. With both control inputs applied simultaneously, the contact closes if set to *Operate-dominant* and opens if set to *Reset-dominant*.



**Figure 338: Contact input/output module type 4L contact 1 logic**

### Application example 1

A latching output contact H1a is to be controlled from two user-programmable pushbuttons (buttons number 1 and 2). The following settings are applied.

Program the Latching Outputs by making the following changes in the **SETTINGS > INPUTS/OUTPUTS > CONTACT OUTPUTS > CONTACT OUTPUT H1a** menu (assuming an H4L module):

- **OUTPUT H1a OPERATE:** *PUSHBUTTON 1 ON*
- **OUTPUT H1a RESET:** *PUSHBUTTON 2 ON*

Program the pushbuttons by making the following changes in the **PRODUCT SETUP > USER-PROGRAMMABLE PUSHBUTTONS > USER PUSHBUTTON 1** and **USER PUSHBUTTON 2** menus:

- **PUSHBUTTON 1 FUNCTION:** *Self-reset*
- **PUSHBTN 1 DROP-OUT TIME:** *0.00 s*
- **PUSHBUTTON 2 FUNCTION:** *Self-reset*
- **PUSHBTN 2 DROP-OUT TIME:** *0.00 s*

### Application example 2

A relay, having two latching contacts H1a and H1c, is to be programmed. The H1a contact is to be a Type-a contact, while the H1c contact is to be a Type-b contact (Type-a means closed after exercising the operate input; Type-b means closed after exercising the reset input). The relay is to be controlled from virtual outputs: VO1 to operate and VO2 to reset.

Program the Latching Outputs by making the following changes in the **SETTINGS > INPUTS/OUTPUTS > CONTACT OUTPUTS > CONTACT OUTPUT H1a** and **CONTACT OUTPUT H1c** menus (assuming an H4L module):

- **OUTPUT H1a OPERATE:** *VO1*
- **OUTPUT H1a RESET:** *VO2*
- **OUTPUT H1c OPERATE:** *VO2*
- **OUTPUT H1c RESET:** *VO1*

Since the two physical contacts in this example are mechanically separated and have individual control inputs, they do not operate at exactly the same time. A discrepancy in the range of a fraction of a maximum operating time can occur. Therefore, a pair of contacts programmed to be a multi-contact relay do not guarantee any specific sequence

of operation (such as make before break). If required, the sequence of operation must be programmed explicitly by delaying some of the control inputs as shown in the next application example.

### Application example 3

A make before break functionality must be added to the preceding example. An overlap of 20 ms is required to implement this functionality.

Write the following FlexLogic equation (EnerVista example shown)

| FLEXLOGIC ENTRY   | TYPE                  | SYNTAX             |
|-------------------|-----------------------|--------------------|
| View Graphic      | View                  | View               |
| FlexLogic Entry 1 | Virtual Outputs On    | Virt Op 1 On (VO1) |
| FlexLogic Entry 2 | TIMER                 | Timer 1            |
| FlexLogic Entry 3 | Assign Virtual Output | = Virt Op 3 (VO3)  |
| FlexLogic Entry 4 | Virtual Outputs On    | Virt Op 2 On (VO2) |
| FlexLogic Entry 5 | TIMER                 | Timer 2            |
| FlexLogic Entry 6 | Assign Virtual Output | = Virt Op 4 (VO4)  |
| FlexLogic Entry 7 | End of List           |                    |

Figure 339: Flexlogic settings for Application example 3

Set both timers (Timer 1 and Timer 2) to 20 ms pickup and 0 ms dropout.

Program the Latching Outputs by making the following changes in the **SETTINGS > INPUTS/OUTPUTS > CONTACT OUTPUTS > CONTACT OUTPUT H1a** and **CONTACT OUTPUT H1c** menus (assuming an H4L module):

- **OUTPUT H1a OPERATE:** VO1
- **OUTPUT H1a RESET:** VO4
- **OUTPUT H1c OPERATE:** VO2
- **OUTPUT H1c RESET:** VO3

### Application example 4

A latching contact H1a is to be controlled from a single virtual output VO1. The contact is to remain closed as long as VO1 is high, and is to remain opened when VO1 is low. Program the relay as follows.

Write the following FlexLogic equation (EnerVista example shown).

| FLEXLOGIC ENTRY   | TYPE                  | SYNTAX             |
|-------------------|-----------------------|--------------------|
| View Graphic      | View                  | View               |
| FlexLogic Entry 1 | Virtual Outputs On    | Virt Op 1 On (VO1) |
| FlexLogic Entry 2 | NOT                   | 1 Input            |
| FlexLogic Entry 3 | Assign Virtual Output | = Virt Op 2 (VO2)  |
| FlexLogic Entry 4 | End of List           |                    |

Figure 340: Flexlogic settings for Application example 4

Program the Latching Outputs by making the following changes in the **SETTINGS > INPUTS/OUTPUTS > CONTACT OUTPUTS > CONTACT OUTPUT H1a** menu (assuming an H4L module):

- **OUTPUT H1a OPERATE:** *VO1*
- **OUTPUT H1a RESET:** *VO2*

### 8.10.4 VIRTUAL OUTPUTS

Setting path: **SETTINGS > INPUTS/OUTPUTS > VIRTUAL OUTPUTS > VIRTUAL OUTPUT 1(256)**

*Note:  
Only Virtual output 1 is shown*

|                         |   |                                      |                                         |
|-------------------------|---|--------------------------------------|-----------------------------------------|
| ■ VIRTUAL OUTPUT 1<br>■ | ↔ | VIRTUAL OUTPUT 1 ID:<br>Virt Op 1    | Range: up to 20 alphanumeric characters |
|                         | ↑ | VIRTUAL OUTPUT 1<br>EVENTS: Disabled | Range: Disabled, Enabled                |

The virtual inputs and outputs are digital signals associated with UR-series internal logic signals. Virtual inputs include signals generated by the local user interface. The virtual outputs are outputs of FlexLogic equations used to customize the device. Virtual outputs can also serve as virtual inputs to FlexLogic equations.

The virtual outputs can be assigned using FlexLogic. If not assigned, the output is forced to 'OFF' (Logic 0). An ID also can be assigned to each virtual output. Virtual outputs are resolved in each pass through the evaluation of the FlexLogic equations. Any change of state of a virtual output can be logged as an event if programmed to do so.

For example, if Virtual Output 1 is the trip signal from FlexLogic and the trip relay is used to signal events, the settings is programmed as follows:

- **VIRTUAL OUTPUT 1 ID:** *Trip*
- **VIRTUAL OUTPUT 1 EVENTS:** *Disabled*

### 8.10.5 RESETTING

#### Enhanced and basic front panels

**SETTINGS > INPUTS/OUTPUTS > RESETTING**

|                  |   |                       |                          |
|------------------|---|-----------------------|--------------------------|
| ■ RESETTING<br>■ | ↔ | RESET OPERAND:<br>Off | Range: FlexLogic operand |
|------------------|---|-----------------------|--------------------------|

#### Graphical front panel

**SETTINGS > INPUTS/OUTPUTS > RESETTING**

|                  |   |                           |                          |
|------------------|---|---------------------------|--------------------------|
| ■ RESETTING<br>■ | ↔ | RESET OPERAND:<br>Off     | Range: FlexLogic operand |
|                  | ↕ | RESET ANNUNCIATOR:<br>Off | Range: FlexLogic operand |

Some events can be programmed to latch the front panel LED event indicators, target messages, and/or graphical front panel annunciator windows. Once set, the latching mechanism holds the latched indicators, messages, or

windows in the set state after the initiating condition has cleared until a **RESET** command is received to return these latches (not including FlexLogic latches) to the reset state where the initiating condition has cleared. The **RESET** command can be sent from the front panel **RESET** button, a remote device via a communications channel, or any selected operand. The Modbus execute function 05h with operation code 1 command is also available to perform the same function as the front panel **RESET** key.

### RESET OPERAND

The three sources of **RESET** commands each activates the RESET OP FlexLogic operand. Each individual source of a **RESET** command also activates its individual operand RESET OP (PUSHBUTTON), RESET OP (COMMS), or RESET OP (OPERAND) to identify the source of the command. Each of these three operands generates an event in the event record when activated. The **RESET OPERAND** setting here selects the operand that activates the RESET OP (OPERAND) operand.

### RESET ANNUNCIATOR

Used to select a FlexLogic operand that when activated acknowledges/resets all annunciator windows on the graphical front panel. The other methods to acknowledge/reset annunciator windows include:

- On the displayed page, press the **RESET** pushbutton with none of the annunciator windows selected to acknowledge/reset all annunciator windows on that page
- To acknowledge/reset a specific annunciator window, use the Up, Down, Left and Right pushbuttons to select the window, and press the **RESET** or **ENTER** pushbutton
- All annunciator windows can be reset remotely by programming a Virtual Input (for example Virtual Input 1) as the input to the RESET ANNUNCIATOR setting. Then the Modbus execute function 05h with operation code 1000h command (or function 10h with address 400h) is used to set the state of Virtual Input 1.

For the **RESET ANNUNCIATOR** setting, the RESET ANCTR OP FlexLogic operand is activated by the two sources of **RESET** command, operand source and manual source. Each individual source of a **RESET ANNUNCIATOR** command also activates its individual operand RESET OP (OPRD) or RESET ANCTR OP (MNUL) to identify the source of the command. Each of these two operands generates an event in the event record when activated. The setting here selects the operand that activates the RESET ANCTR OP (OPRD) operand. The **RESET** pushbutton on the front panel or the reset command from the software activates the RESET ANCTR OP (MNUL) operand.

## 8.10.6 DIRECT INPUTS AND OUTPUTS

### 8.10.6.1 DIRECT INPUTS

Setting path: **SETTINGS > INPUTS/OUTPUTS > DIRECT INPUTS > DIRECT INPUT <n>**

|                                          |   |                                    |                                                                      |
|------------------------------------------|---|------------------------------------|----------------------------------------------------------------------|
| <div>■ DIRECT INPUT 1</div> <div>■</div> | ⇔ | DIRECT INPUT 1<br>NAME: Dir Ip 1   | Range: up to 12 alphanumeric characters                              |
|                                          | ⇕ | DIRECT INPUT 1<br>DEVICE ID: 0     | Range: 0 to 16                                                       |
|                                          | ⇕ | DIRECT INPUT 1<br>BIT NUMBER: 0    | Range: 0 to 32<br>Range: 0 to 96 (C30, N60)<br>Range: 0 to 256 (B90) |
|                                          | ⇕ | DIRECT INPUT 1<br>DEFAULT: Off     | Range: On, Off, Latest/On, Latest/Off                                |
|                                          | ↑ | DIRECT INPUT 1<br>EVENTS: Disabled | Range: Enabled, Disabled                                             |

These settings specify how the direct input information is processed.



### DIRECT INPUT 1 NAME

This setting allows the user to assign a descriptive name to the direct input.

### DIRECT INPUT 1 DEVICE ID

Represents the source of direct input 1. The specified direct input is driven by the device identified here.

### DIRECT INPUT 1 BIT NUMBER

The bit number to extract the state for direct input 1. Direct Input 1 is driven by the bit identified as ***DIRECT INPUT 1 BIT NUMBER***. This corresponds to the direct output number of the sending device.

### DIRECT INPUT 1 DEFAULT STATE

Represents the state of the direct input when the associated direct device is offline. The following choices are available:

- On — Defaults the input to Logic 1
- Off — Defaults the input to Logic 0
- Latest/On — Freezes the input in case of lost communications. When the latest state is not known, such as after relay power-up but before the first communication exchange, the input defaults to Logic 1. When communication resumes, the input becomes fully operational.
- Latest/Off — Freezes the input in case of lost communications. When the latest state is not known, such as after relay power-up but before the first communication exchange, the input defaults to Logic 0. When communication resumes, the input becomes fully operational.

### 8.10.6.2 DIRECT OUTPUTS

Setting path: **SETTINGS > INPUTS/OUTPUTS > DIRECT OUTPUTS > DIRECT OUTPUT <n>**

|                        |   |                                     |                                         |
|------------------------|---|-------------------------------------|-----------------------------------------|
| ■ DIRECT OUTPUT 1<br>■ | ↔ | DIR OUT 1 NAME:<br>Dir Out 1        | Range: up to 12 alphanumeric characters |
|                        | ↕ | DIR OUT 1 OPERAND:<br>Off           | Range: FlexLogic operand                |
|                        | ↑ | DIRECT OUTPUT 1<br>EVENTS: Disabled | Range: Enabled, Disabled                |

### DIR OUT 1 NAME

This setting allows the user to assign a descriptive name to the direct output.

### DIR OUT 1 OPERAND

This sets the FlexLogic operand that determines the state of this direct output.


These settings specify how the direct input information is processed.

### 8.10.6.3 APPLICATION EXAMPLES

The examples introduced in the earlier Direct Inputs and Outputs section (part of the Product Setup section) are continued here to illustrate usage of the direct inputs and outputs.

#### Example 1: Extending input/output capabilities of a UR relay

Consider an application that requires additional quantities of contact inputs or output contacts or lines of programmable logic that exceed the capabilities of a single UR-series chassis. The problem is solved by adding an extra UR-series IED, such as the C30, to satisfy the additional inputs/outputs and programmable logic requirements. The figure shows that two IEDs are connected via single-channel digital communication cards.



**Figure 341: Input and output extension via direct inputs and outputs**

Assume that contact input 1 from UR IED 2 is to be used by UR IED 1. The following settings are applied (Direct Input 5 and bit number 12 are used, as an example).

UR IED 1:

- **DIRECT INPUT 5 DEVICE ID** = 2
- **DIRECT INPUT 5 BIT NUMBER** = 12


UR IED 2:

- **DIRECT OUT 12 OPERAND** = Cont Ip 1 On

The Cont Ip 1 On operand of UR IED 2 is now available in UR IED 1 as DIRECT INPUT 5 ON.

### Example 2: Interlocking busbar protection

A simple interlocking busbar protection scheme can be accomplished by sending a blocking signal from downstream devices, say 2, 3 and 4, to the upstream device that monitors a single incomer of the busbar, as shown in the figure.



**Figure 342: Sample interlocking busbar protection scheme**

Assume that Phase Instantaneous Overcurrent 1 is used by Devices 2, 3, and 4 to block Device 1. If not blocked, Device 1 trips the bus upon detecting a fault and applying a short coordination time delay.

The following settings are applied (assume Bit 3 is used by all 3 devices to send the blocking signal and Direct Inputs 7, 8, and 9 are used by the receiving device to monitor the three blocking signals).

UR IED 2:

- **DIRECT OUT 3 OPERAND**: PHASE IOC1 OP

UR IED 3:

- **DIRECT OUT 3 OPERAND**: PHASE IOC1 OP

UR IED 4:

- **DIRECT OUT 3 OPERAND:** PHASE IOC1 OP


UR IED 1:

- **DIRECT INPUT 7 DEVICE ID:** 2
- **DIRECT INPUT 7 BIT NUMBER:** 3
- **DIRECT INPUT 7 DEFAULT STATE:** select *On* for security, select *Off* for dependability
- **DIRECT INPUT 8 DEVICE ID:** 3
- **DIRECT INPUT 8 BIT NUMBER:** 3
- **DIRECT INPUT 8 DEFAULT STATE:** select *On* for security, select *Off* for dependability
- **DIRECT INPUT 9 DEVICE ID:** 4
- **DIRECT INPUT 9 BIT NUMBER:** 3
- **DIRECT INPUT 9 DEFAULT STATE:** select *On* for security, select *Off* for dependability

Now the three blocking signals are available in UR IED 1 as DIRECT INPUT 7 ON, DIRECT INPUT 8 ON, and DIRECT INPUT 9 ON. Upon losing communications or a device, the scheme is inclined to block (if any default state is set to *On*), or to trip the bus on any overcurrent condition (all default states set to *Off*).


### Example 3: Pilot-aided schemes

Consider a three-terminal line protection application shown in the following figure:



**Figure 343: Three-terminal line application**

Assume the Hybrid Permissive Overreaching Transfer Trip (Hybrid POTT) scheme is applied using the architecture shown as follows. The scheme output operand HYB POTT TX1 is used to key the permission.



**Figure 344: Single-channel open-loop configuration**

In this architecture, Devices 1 and 3 do not communicate directly. Therefore, Device 2 must act as a "bridge." The following settings are applied:

UR IEC 1:

- **DIRECT OUT 2 OPERAND:** HYB POTT TX1
- **DIRECT INPUT 5 DEVICE ID:** 2
- **DIRECT INPUT 5 BIT NUMBER:** 2 (this is a message from IED 2)
- **DIRECT INPUT 6 DEVICE ID:** 2
- **DIRECT INPUT 6 BIT NUMBER:** 4 (effectively, this is a message from IED 3)

UR IED 3:

- **DIRECT OUT 2 OPERAND:** HYB POTT TX1
- **DIRECT INPUT 5 DEVICE ID:** 2
- **DIRECT INPUT 5 BIT NUMBER:** 2 (this is a message from IED 2)
- **DIRECT INPUT 6 DEVICE ID:** 2
- **DIRECT INPUT 6 BIT NUMBER:** 3 (effectively, this is a message from IED 1)

UR IED 2:

- **DIRECT INPUT 5 DEVICE ID:** 1
- **DIRECT INPUT 5 BIT NUMBER:** 2
- **DIRECT INPUT 6 DEVICE ID:** 3
- **DIRECT INPUT 6 BIT NUMBER:** 2
- **DIRECT OUT 2 OPERAND:** HYB POTT TX1
- **DIRECT OUT 3 OPERAND:** DIRECT INPUT 5 (forward a message from 1 to 3)
- **DIRECT OUT 4 OPERAND:** DIRECT INPUT 6 (forward a message from 3 to 1)

The figure shows the signal flow among the three IEDs.




Figure 345: Signal flow for direct input and output


In three-terminal applications, both the remote terminals must grant permission to trip. Therefore, at each terminal, direct inputs 5 and 6 are ANDed in FlexLogic and the resulting operand configured as the permission to trip (**HYB POTT RX1** setting).

## 8.10.7 TELEPROTECTION

The relay provides 16 teleprotection inputs on communications channel 1 (numbered 1-1 through 1-16) and 16 teleprotection inputs on communications channel 2 (on two-terminals two-channel and three-terminal systems only, numbered 2-1 through 2-16). The remote relay connected to channels 1 and 2 of the local relay is programmed by assigning FlexLogic operands to be sent via the selected communications channel. This allows the user to create distributed protection and control schemes via dedicated communications channels. Some examples are directional comparison pilot schemes and direct transfer tripping. Note that failures of communications channels affect teleprotection functionality. The teleprotection function must be enabled to utilize the inputs.

### 8.10.7.1 TELEPROTECTION INPUTS

Setting path: **SETTINGS > INPUTS/OUTPUTS > TELEPROTECTION > TELEPROT INPUTS**




Setting the **TELEPROT INPUT <n> DEFAULT** settings to *On* defaults the input to logic 1 when the channel fails. A value of *Off* defaults the input to logic 0 when the channel fails.

The *Latest/On* and *Latest/Off* values freeze the input in case of lost communications. If the latest state is not known, such as after relay power-up but before the first communication exchange, then the input defaults to logic 1 for *Latest/On* and logic 0 for *Latest/Off*.


### 8.10.7.2 TELEPROTECTION OUTPUTS

Setting path: **SETTINGS > INPUTS/OUTPUTS > TELEPROTECTION > TELEPROT OUTPUTS**



### 8.10.7.3 TELEPROTECTION INPUT/OUTPUT PROCESSING

As the following figure demonstrates, processing of the teleprotection inputs/outputs is dependent on the number of communication channels and terminals. On two-terminal two-channel systems, they are processed continuously on each channel and mapped separately per channel. Therefore, to achieve redundancy, the user must assign the same operand on both channels (teleprotection outputs at the sending end or corresponding teleprotection inputs at the receiving end). On three-terminal two-channel systems, redundancy is achieved by programming signal re-transmittal in the case of channel failure between any pair of relays.



842750A2.CDR

Figure 346: Teleprotection input/output processing

## 8.11 TRANSDUCER INPUTS/OUTPUTS

### 8.11.1 DCMA INPUTS

Different slots are used, depending on the model, as shown in the following table:

| Slot | Models                                                               |
|------|----------------------------------------------------------------------|
| F1   | B90, C30, C70, G30, N60, T35, T60                                    |
| H1   | B30, C60, C95, D30, D60, F35, F60, G60, L30, L60, L90, M60           |
| U8   | B30, B90, C70, L30, L90                                              |
| W8   | C30, C60, C95, D30, D60, F35, F60, G30, G60, L60, M60, N60, T35, T60 |

#### SETTINGS > TRANSDUCER I/O > DCMA INPUTS > DCMA INPUT <slot>

|                     |   |                                         |                                                                                        |
|---------------------|---|-----------------------------------------|----------------------------------------------------------------------------------------|
| ■ DCMA INPUT <slot> | ↔ | DCMA INPUT <slot><br>FUNCTION: Disabled | Range: Disabled, Enabled                                                               |
| ■                   | ↕ | DCMA INPUT H1 ID:<br>DCMA Ip 1          | Range: up to 20 alphanumeric characters                                                |
|                     | ↕ | DCMA INPUT H1<br>UNITS: $\mu$ A         | Range: six alphanumeric characters                                                     |
|                     | ↕ | DCMA INPUT H1<br>RANGE: 0 to -1 mA      | Range: 0 to -1 mA, 0 to +1 mA, -1 to +1 mA, 0 to 5mA, 0 to 10mA, 0 to 20 mA, 4 to 20 m |
|                     | ↕ | DCMA INPUT H1 MIN<br>VALUE: 0.000       | Range: -9999.999 to +9999.999 in steps of 0.001                                        |
|                     | ↕ | DCMA INPUT H1 MAX<br>VALUE: 0.000       | Range: -9999.999 to +9999.999 in steps of 0.001                                        |

Hardware and software are provided to receive signals from external transducers and to convert these signals into a digital format for use as required. The relay accepts inputs in the range of -1 to +20 mA DC, suitable for use with most common transducer output ranges; all inputs are assumed to be linear over the complete range.

Before the DCmA input signal can be used, the value of the signal measured by the relay must be converted to the range and quantity of the external transducer primary input parameter, such as DC voltage or temperature. The relay simplifies this process by internally scaling the output from the external transducer and displaying the actual primary parameter.

DCmA input channels are arranged in a manner similar to CT and VT channels. Configure the individual channels with the settings shown here.

The channels are arranged in sub-modules of two channels, numbered from 1 through 8 from top to bottom. On power-up, the relay automatically generates configuration settings for every channel, based on the order code, in the same general manner that is used for CTs and VTs. Each channel is assigned a slot letter followed by the row number, 1 through 8 inclusive, which is used as the channel number. The relay generates an actual value for each available input channel.

Settings are generated automatically for every channel available in the specific relay as shown above for the first channel of an installed type 5F transducer module.

The function of the channel can be enabled or disabled. If disabled, no actual values are created for the channel. An alphanumeric ID is assigned to each channel; this ID is included in the channel actual value, along with the programmed units associated with the parameter measured by the transducer, such as volts, °C, megawatts, and so on. This ID is also used to reference the channel as the input parameter to features designed to measure this type of parameter.

The **DCMA INPUT <slot> RANGE** setting specifies the mA DC range of the transducer connected to the input channel.

The **DCMA INPUT <slot> MIN VALUE** and **DCMA INPUT <slot> MAX VALUE** settings are used to program the span of the transducer in primary units. For example, a temperature transducer might have a span from 0 to 250 °C; in this case the **DCMA INPUT <slot> MIN VALUE** value is 0 and the **DCMA INPUT <slot> MAX VALUE** value is 250. Another example is a watts transducer with a span from –20 to +180 MW; in this case the **DCMA INPUT <slot> MIN VALUE** value is –20 and the **DCMA INPUT <slot> MAX VALUE** value is 180. Intermediate values between the minimum and maximum values are scaled linearly.

## 8.11.2 DCMA OUTPUTS

Different slots are used, depending on the model, as shown in the following table:

| Slot | Models                                                               |
|------|----------------------------------------------------------------------|
| F1   | B90, C30, C70, G30, N60, T35, T60                                    |
| H1   | B30, C60, C95, D30, D60, F35, F60, G60, L30, L60, L90, M60           |
| U8   | B30, B90, C70, L30, L90                                              |
| W8   | C30, C60, C95, D30, D60, F35, F60, G30, G60, L60, M60, N60, T35, T60 |

### SETTINGS > TRANSDUCER I/O > DCMA OUTPUTS > DCMA OUTPUT <slot>

|                      |   |                                         |                                               |
|----------------------|---|-----------------------------------------|-----------------------------------------------|
| ■ DCMA OUTPUT <slot> | ⇔ | DCMA OUTPUT <slot><br>SOURCE: Off       | Range: Off, any analog actual value parameter |
| ■                    | ⇕ | DCMA OUTPUT <slot><br>RANGE: –1 to 1 mA | Range: –1 to 1 mA, 0 to 1 mA, 4 to 20 mA      |
|                      | ⇕ | DCMA OUTPUT <slot><br>MIN VAL: 0.000 pu | Range: –90.000 to 90.000 pu in steps of 0.001 |
|                      | ⇕ | DCMA OUTPUT <slot><br>MAX VAL: 1.000 pu | Range: –90.000 to 90.000 pu in steps of 0.001 |

Hardware and software is provided to generate DCmA signals that allow interfacing with external equipment. The DCmA output channels are arranged in a manner similar to transducer input or CT and VT channels. The user configures individual channels with the settings as follows.

The channels are arranged in sub-modules of two channels, numbered 1 through 8 from top to bottom. On power-up, the relay automatically generates configuration settings for every channel, based on the order code, in the same manner used for CTs and VTs. Each channel is assigned a slot letter followed by the row number, 1 through 8 inclusive, which is used as the channel number.

Both the output range and a signal driving a given output are user-programmable via the following settings menu (an example for channel M5 is shown).

The relay checks the driving signal ( $x$  in equations below) for the minimum and maximum limits, and subsequently re-scales so the limits defined as **MIN VAL** and **MAX VAL** match the output range of the hardware defined as **RANGE**. The following equation is applied:

$$I_{\text{out}} = \begin{cases} I_{\text{min}} & \text{if } x < \text{MIN VAL} \\ I_{\text{max}} & \text{if } x > \text{MAX VAL} \\ k(x - \text{MIN VAL}) + I_{\text{min}} & \text{otherwise} \end{cases}$$



where:

- $x$  is a driving signal specified by the **SOURCE** setting
- $I_{\min}$  and  $I_{\max}$  are defined by the **RANGE** setting
- $k$  is a scaling constant calculated as:

$$k = \frac{I_{\max} - I_{\min}}{\text{MAX VAL} - \text{MIN VAL}}$$

The feature is intentionally inhibited if the **MAX VAL** and **MIN VAL** settings are entered incorrectly, for example when **MAX VAL** – **MIN VAL** < 0.1 pu. The resulting characteristic is illustrated in the following figure.




Figure 347: DCmA output characteristic

## Settings

### DCMA OUTPUT <slot> SOURCE

This setting specifies an internal analog value to drive the analog output. Actual values (FlexAnalog parameters) such as power, current amplitude, voltage amplitude, power factor, etc. can be configured as sources driving DCmA outputs. See Appendix A for a list of FlexAnalog parameters.

### DCMA OUTPUT <slot> RANGE

This setting allows selection of the output range. Each DCmA channel can be set independently to work with different ranges. The three most commonly used output ranges are available.

### DCMA OUTPUT <slot> MIN VAL

This setting allows setting the minimum limit for the signal that drives the output. This setting is used to control the mapping between an internal analog value and the output current. The setting is entered in per-unit values. The base units are defined in the same manner as the FlexElement base units.

### DCMA OUTPUT <slot> MAX VAL

This setting allows setting the maximum limit for the signal that drives the output. This setting is used to control the mapping between an internal analog value and the output current. The setting is entered in per-unit values. The base units are defined in the same manner as the FlexElement base units.

**Note:**

The DCMA OUTPUT <slot> MIN VAL and DCMA OUTPUT <slot> MAX VAL settings are ignored for power factor base units (that is, if the DCMA OUTPUT <slot> SOURCE is set to FlexAnalog value based on power factor measurement).

### 8.11.3 DCMA APPLICATION EXAMPLES

#### Example: Power monitoring (not applicable to B30, B90, C30)

A three phase active power on a 13.8 kV system measured via UR-series relay source 1 is to be monitored by the DCmA H1 output of the range of -1 to 1 mA. The following settings are applied on the relay: CT ratio = 1200:5, VT secondary 115, VT connection is delta, and VT ratio = 120. The nominal current is 800 A primary and the nominal power factor is 0.90. The power is to be monitored in both importing and exporting directions and allow for 20% overload compared to the nominal.

The nominal three-phase power is:

$$P = \sqrt{3} \times 13.8\text{kV} \times 0.8\text{kA} \times 0.9 = 17.21\text{MW}$$

The three-phase power with 20% overload margin is:

$$P_{\text{max}} = 1.2 \times 17.21\text{MW} = 20.65\text{MW}$$

The base unit for power (refer to the FlexElements section in this chapter for additional details) is:

$$P_{\text{BASE}} = 115\text{V} \times 120 \times 1.2\text{kA} = 16.56\text{MW}$$

The minimum and maximum power values to be monitored (in pu) are:

$$\text{Minimum power} = -20.65\text{MW}/16.56\text{MW} = -1.247 \text{ pu}$$

$$\text{Maximum power} = 20.65\text{MW}/16.56\text{MW} = 1.247 \text{ pu}$$

The following settings are entered:

- **DCMA OUTPUT H1 SOURCE:** *SRC 1 P*
- **DCMA OUTPUT H1 RANGE:** *-1 to 1 mA*
- **DCMA OUTPUT H1 MIN VAL:** *-1.247 pu*
- **DCMA OUTPUT H1 MAX VAL:** *1.247 pu*

With the above settings, the output will represent the power with the scale of 1 mA per 20.65 MW. The worst-case error for this application can be calculated by superimposing the following two sources of error:

- $\pm 0.5\%$  of the full scale for the analog output module, or  $\pm 0.005 \times (1 - (-1)) \times 20.65 \text{ MW} = \pm 0.207 \text{ MW}$
- $\pm 1\%$  of reading error for the active power at power factor of 0.9

For example at the reading of 20 MW, the worst-case error is  $0.01 \times 20 \text{ MW} + 0.207 \text{ MW} = 0.407 \text{ MW}$ .

#### Example: Current monitoring (not applicable to C30)

The phase A current (true RMS value) is to be monitored via the H2 current output working with the range from 4 to 20 mA. The CT ratio is 5000:5 and the maximum load current is 4200 A. The current is to be monitored from 0 A upwards, allowing for 50% overload.

The phase current with the 50% overload margin is:

$$I_{\text{max}} = 1.5 \times 4.2\text{kA} = 6.3\text{kA}$$

The base unit for current (see the FlexElements section in this chapter for additional details) is:

$$I_{\text{BASE}} = 5\text{kA}$$

The minimum and maximum power values to be monitored (in pu) are:

$$\text{Minimum current} = 0\text{kA}/5\text{kA} = 0 \text{ pu}$$

$$\text{Maximum current} = 6.3\text{kA}/5\text{kA} = 1.26 \text{ pu}$$

The following settings are entered:

- **DCMA OUTPUT H2 SOURCE:** *SRC 1 Ia RMS*
- **DCMA OUTPUT H2 RANGE:** *4 to 20 mA*
- **DCMA OUTPUT H2 MIN VAL:** *0.000 pu*
- **DCMA OUTPUT H2 MAX VAL:** *1.260 pu*

The worst-case error for this application can be calculated by superimposing the following two sources of error:

- $\pm 0.5\%$  of the full scale for the analog output module, or  $\pm 0.005 \times (20 - 4) \times 6.3 \text{ kA} = \pm 0.504 \text{ kA}$
- $\pm 0.25\%$  of reading or  $\pm 0.1\%$  of rated (whichever is greater) for currents between 0.1 and 2.0 of nominal

For example, at the reading of 4.2 kA, the worst-case error is  $\max(0.0025 \times 4.2 \text{ kA}, 0.001 \times 5 \text{ kA}) + 0.504 \text{ kA} = 0.515 \text{ kA}$ .

#### Example: Voltage monitoring (not applicable to C30)

A positive-sequence voltage on a 400 kV system measured via source 2 is to be monitored by the DCmA H3 output with a range of 0 to 1 mA. The VT secondary setting is 66.4 V, the VT ratio setting is 6024, and the VT connection setting is "Delta." The voltage is to be monitored in the range from 70% to 110% of nominal.

The minimum and maximum positive-sequence voltages to be monitored are:

$$V_{\min} = 0.7 \times 400\text{kV}/\sqrt{3} = 161.66\text{kV}$$

$$V_{\max} = 1.1 \times 400\text{kV}/\sqrt{3} = 254.03 \text{ kV}$$

The base unit for voltage (see the FlexElements section in this chapter for additional details) is:

$$V_{\text{BASE}} = 0.0664\text{kV} \times 6024 = 400\text{kV}$$

The minimum and maximum voltage values to be monitored (in pu) are:

$$\text{Minimum voltage} = 161.66\text{kV}/400\text{kV} = 0.404 \text{ pu}$$

$$\text{Maximum voltage} = 254.03\text{kV}/400\text{kV} = 0.635 \text{ pu}$$

The following settings are entered:

- **DCMA OUTPUT H3 SOURCE:** *SRC 2 V\_1 mag*
- **DCMA OUTPUT H3 RANGE:** *0 to 1 mA*
- **DCMA OUTPUT H3 MIN VAL:** *0.404 pu*
- **DCMA OUTPUT H3 MAX VAL:** *0.635 pu*

The limit settings differ from the expected 0.7 pu and 1.1 pu because the relay calculates the positive-sequence quantities scaled to the phase-to-ground voltages, even if the VTs are connected in "Delta" (see the Metering Conventions section in chapter 6), while at the same time the VT nominal voltage is 1 pu for the settings. Consequently the settings required in this example differ from naturally expected by the factor of  $\sqrt{3}$ .

The worst-case error for this application could be calculated by superimposing the following two sources of error:

- $\pm 0.5\%$  of the full scale for the analog output module, or  $\pm 0.005 \times (1-0) \times 254.03 \text{ kV} = \pm 1.27 \text{ kV}$
- $\pm 0.5\%$  of reading

For example, under nominal conditions, the positive-sequence reads 230.94 kV and the worst-case error is  $0.005 \times 230.94 \text{ kV} + 1.27 \text{ kV} = 2.42 \text{ kV}$ .

#### 8.11.4 RTD INPUTS

Different slots are used, depending on the model, as shown in the following table:

| Slot | Models                            |
|------|-----------------------------------|
| F1   | B90, C30, C70, G30, N60, T35, T60 |

| Slot | Models                                                               |
|------|----------------------------------------------------------------------|
| H1   | B30, C60, C95, D30, D60, F35, F60, G60, L30, L60, L90, M60           |
| U8   | B30, B90, C70, L30, L90                                              |
| W8   | C30, C60, C95, D30, D60, F35, F60, G30, G60, L60, M60, N60, T35, T60 |

### SETTINGS > TRANSDUCER I/O > RTD INPUTS > RTD INPUT <slot>

|                                                  |   |                                         |                                                            |
|--------------------------------------------------|---|-----------------------------------------|------------------------------------------------------------|
| <div>■ RTD INPUT &lt;slot&gt;</div> <div>■</div> | ↔ | RTDINPUT <slot><br>FUNCTION: Disabled   | Range: Disabled, Enabled                                   |
|                                                  | ↕ | RTD INPUT <slot> ID:<br>RTD Ip 1        | Range: up to 20 alphanumeric characters                    |
|                                                  | ↑ | RTD INPUT <slot> TYPE:<br>100Ω Platinum | Range: 100Ω Nickel, 10Ω Copper, 100Ω Platinum, 120Ω Nickel |

Hardware and software is provided to receive signals from external resistance temperature detectors and convert these signals into a digital format for use as required. These channels are intended to be connected to any of the RTD types in common use. Specific hardware details are contained in chapter 3.

RTD input channels are arranged in a manner similar to CT and VT channels. The user configures individual channels with the settings shown here.

The channels are arranged in sub-modules of two channels, numbered from 1 through 8 from top to bottom. On power-up, the relay automatically generates configuration settings for every channel, based on the order code, in the same general manner that is used for CTs and VTs. Each channel is assigned a slot letter followed by the row number, 1 through 8 inclusive, which is used as the channel number. The relay generates an actual value for each available input channel.

Settings are automatically generated for every channel available in the specific relay as shown above for the first channel of a type 5C transducer module installed in the first available slot.

The function of the channel can be either enabled or disabled. If disabled, there is not an actual value created for the channel. An alphanumeric ID is assigned to the channel; this ID is included in the channel actual values. It is also used to reference the channel as the input parameter to features designed to measure this type of parameter. Selecting the type of RTD connected to the channel configures the channel.

Actions based on RTD overtemperature, such as trips or alarms, are done in conjunction with the FlexElements feature. In FlexElements, the operate level is scaled to a base of 100°C. For example, a trip level of 150°C is achieved by setting the operate level at 1.5 pu. FlexElement operands are available to FlexLogic for further interlocking or to operate an output contact directly.

See the following table for reference temperature values for each RTD type.

| Temperature |     | Resistance (in ohms)    |          |          |         |
|-------------|-----|-------------------------|----------|----------|---------|
| °C          | °F  | 100 Ω Pt<br>(DIN 43760) | 120 Ω Ni | 100 Ω Ni | 10 Ω Cu |
| −50         | −58 | 80.31                   | 86.17    | 71.81    | 7.10    |
| −40         | −40 | 84.27                   | 92.76    | 77.30    | 7.49    |
| −30         | −22 | 88.22                   | 99.41    | 82.84    | 7.88    |
| −20         | −4  | 92.16                   | 106.15   | 88.45    | 8.26    |
| −10         | 14  | 96.09                   | 113.00   | 94.17    | 8.65    |
| 0           | 32  | 100.00                  | 120.00   | 100.00   | 9.04    |
| 10          | 50  | 103.90                  | 127.17   | 105.97   | 9.42    |
| 20          | 68  | 107.79                  | 134.52   | 112.10   | 9.81    |

| Temperature |     | Resistance (in ohms)    |          |          |         |
|-------------|-----|-------------------------|----------|----------|---------|
| °C          | °F  | 100 Ω Pt<br>(DIN 43760) | 120 Ω Ni | 100 Ω Ni | 10 Ω Cu |
| 30          | 86  | 111.67                  | 142.06   | 118.38   | 10.19   |
| 40          | 104 | 115.54                  | 149.79   | 124.82   | 10.58   |
| 50          | 122 | 119.39                  | 157.74   | 131.45   | 10.97   |
| 60          | 140 | 123.24                  | 165.90   | 138.25   | 11.35   |
| 70          | 158 | 127.07                  | 174.25   | 145.20   | 11.74   |
| 80          | 176 | 130.89                  | 182.84   | 152.37   | 12.12   |
| 90          | 194 | 134.70                  | 191.64   | 159.70   | 12.51   |
| 100         | 212 | 138.50                  | 200.64   | 167.20   | 12.90   |
| 110         | 230 | 142.29                  | 209.85   | 174.87   | 13.28   |
| 120         | 248 | 146.06                  | 219.29   | 182.75   | 13.67   |
| 130         | 266 | 149.82                  | 228.96   | 190.80   | 14.06   |
| 140         | 284 | 153.58                  | 238.85   | 199.04   | 14.44   |
| 150         | 302 | 157.32                  | 248.95   | 207.45   | 14.83   |
| 160         | 320 | 161.04                  | 259.30   | 216.08   | 15.22   |
| 170         | 338 | 164.76                  | 269.91   | 224.92   | 15.61   |
| 180         | 356 | 168.47                  | 280.77   | 233.97   | 16.00   |
| 190         | 374 | 172.46                  | 291.96   | 243.30   | 16.39   |
| 200         | 392 | 175.84                  | 303.46   | 252.88   | 16.78   |
| 210         | 410 | 179.51                  | 315.31   | 262.76   | 17.17   |
| 220         | 428 | 183.17                  | 327.54   | 272.94   | 17.56   |
| 230         | 446 | 186.82                  | 340.14   | 283.45   | 17.95   |
| 240         | 464 | 190.45                  | 353.14   | 294.28   | 18.34   |
| 250         | 482 | 194.08                  | 366.53   | 305.44   | 18.73   |

## 8.12 TESTING

### 8.12.1 IED MODE CONFIG

#### SETTINGS > TESTING > IED MODE CONFIG

|                                                        |   |                                     |                                                    |
|--------------------------------------------------------|---|-------------------------------------|----------------------------------------------------|
| <div> <div>■ IED MODE CONFIG</div> <div>■</div> </div> | ↔ | IED MODE:<br>On                     | Range: On, Test, Test Blocked                      |
|                                                        | ⇅ | TEST MODE INPUT:<br>Off             | Range: FlexLogic operand                           |
|                                                        | ⇅ | TEST-BLK MODE INPUT:<br>Off         | Range: FlexLogic operand                           |
|                                                        | ⇅ | MODE CTRL VIA MMS:<br>On            | Range: FlexLogic operand (displays with IEC 61850) |
|                                                        | ⇅ | CONTACT I/O FORCING:<br>On          | Range: FlexLogic operand                           |
|                                                        | ⇅ | IED MODE TARGET:<br>ENABLED         | Range: Enabled, Disabled                           |
|                                                        | ⇅ | IED BEHAVIOR:<br>On                 | Range: On, Test, Test Blocked                      |
|                                                        | ↑ | IED MODE TRIP SECURITY:<br>Disabled | Range: Enabled, Disabled                           |

The Product provides a test facility to verify the functionality of contact inputs and outputs, some communication functions and the Phasor Measurement Unit (PMU, where applicable), using simulated conditions. It is accessible in the software and graphical front panel.

#### IED MODE

Can be in one of three states: On, Test, or Test Blocked. In UR 7.7 and later, as outlined in the Simulation section that follows, the UR test mode and GOOSE simulation mode are isolated, and they no longer depend on the mode setting here.

The *On* mode is for normal in service operation; the relay protection, control, and communication function is normal. Test features are disabled, except channel tests and PMU tests remain usable when provided. In On mode, the front panel Test Mode LED is off.

The *Test Blocked* mode is implemented per IEC61850-7-4 standard. This allows the relay to be isolated quickly so that it cannot negatively affect the power system or other parts of the substation automation system. This is primarily used for testing purposes, but can also be used for loading new firmware, changing hardware modules, and changing communication connections etc., providing all local or regional safety/testing guidelines are adhered to.

As far as practical, all relay output signals are blocked, contact outputs are de-energized, and latching outputs are frozen. Commands to HardFiber Bricks are blocked. The test bit of quality attribute of values that can be output via IEC 61850 services is set to *TRUE*. The validity bit of the quality attribute of the data sent via IEC 61850 services is set to "GOOD" if no major error is active. Direct I/O, 87L channel and PMU tests are operational on applicable models. In *Test Blocked* mode, the front panel Test Mode LED is on.

The Test mode is for testing involving forcing relay operation by test signal injection and verifying correct relay output. This mode is also for tests to verify the relay outputs (both contact and communications) have the intended impact on specific power system devices or on specific other substation automation devices. Contact outputs can be selectively enabled or forced as described in the Force Contact Inputs and Force Contact Outputs sections that

follow. Shared outputs to Bricks have their test mode flag raised, which results in their value only being accepted by relays also in forcible Test mode. The test bit and validity bit of the quality attribute of data sent via IEC 61850 services are set as *TRUE* and *GOOD* respectively. In Test mode, the front panel Test Mode LED flashes.

Otherwise, the UR remains fully operational while in the Test mode, allowing for various testing procedures. In particular, the protection and control elements, and FlexLogic function normally. Other than the IEC 61850 protocol, communications based inputs and outputs remain fully operational. The test procedure must take this into account. Direct I/O channel tests and PMU tests are usable on applicable models.

When set to Test mode and the operand selected by the **CONTACT I/O FORCING** setting is On.

- If the **FORCE Cont Ip #** setting is set to Open or Closed, the respective quality attribute of the data sent via IEC 61850 services is set to q.source = *substituted*
- If the **FORCE Cont Op #** setting is set to Energized, De-energized, or Freeze, the respective quality attribute of the data sent via IEC 61850 services is set to q.source = *substituted*

When the Breaker Status is substituted manually from a graphical front panel, the respective quality attribute of the breaker position data sett via IEC 61850 services is set to q.source = *substituted*.

The **IED MODE** setting can be selected through

- Front panel
- EnerVista UR Setup software
- FlexLogic operands
- IEC 61850 control to LLN0.Mod
- **INITIATE TEST MODE ON SIM** setting (under **SIMULATION > SUBSCRIBE TO SIMULATED VALUES** menu)

**Note:**

*It is important to note that following the writing of a new setting file to the relay, IED behavior will change according to the IED MODE CONFIG settings in the new file. The user must ensure that IED MODE CONFIG settings in the new file are set according to the expected behavior following the writing of the new setting file.*

## TEST MODE INPUT

This setting selects a FlexLogic operand that can put the UR into Test mode as per the logic diagram. Any FlexLogic operand can be assigned to enable forcible Test mode, that is driven by any remote inputs, logic outputs, front panel (user-programmable push buttons), and so on.

## TEST-BLK MODE INPUT

This setting selects a FlexLogic operand that can put the UR into Test Blocked mode as per the logic diagram. Any FlexLogic operand can be assigned to enable test isolated mode, that is driven by any remote inputs, logic outputs, front panel (user-programmable push buttons) and so on.

## MODE CTRL VIA MMS

This setting selects a FlexLogic operand for an IEC 61850 client to control the IED mode. When the operand is low/off, IED mode control from the IEC 61850 client is disabled, and the control request to LLN0.Mod.ctIVal returns a negative response. When high/on, IED mode control by an IEC 61850 client is accepted.

## CONTACT I/O FORCING

When in Test mode, the operand selected by this setting dictates further response of the UR to testing conditions, as described in the Force Contact Inputs and Force Contact Outputs sections that follow. When no operand is specified in this setting, forcing of inputs and outputs during Test mode are not available.

The test mode state is indicated on the relay front panel by a combination of the Test Mode LED indicator, the In-Service LED indicator, and by the critical fail relay, as shown in the table.

## IED MODE TARGET

When this setting is Enabled, the corresponding target message of IED Mode Config is displayed on the front panel when the relay behavior is either TEST or TEST BLOCKED. The target message gets self-reset when the relay behavior is ON.

When this setting is Disabled, target message is not displayed when the relay behavior is either *TEST* or *TEST BLOCKED*.

| IED MODE setting | In-Service LED | Test Mode LED | Critical fail relay | CONTACT I/O FORCING setting | Contact input and output behavior |
|------------------|----------------|---------------|---------------------|-----------------------------|-----------------------------------|
| On               | Unaffected     | Off           | Normal              | No effect                   | Normal                            |
| Test Blocked     | Off            | On            | De-energized        | No effect                   | Contact outputs disabled          |
| Test             | Off            | Flashing      | De-energized        | Off                         | Normal                            |
|                  |                |               |                     | On                          | Controlled by forcing features    |

**Note:**

Following a restart or power-up, the CONTACT I/O FORCING setting remains at the last value before restart, but force contact input and force contact output settings revert to Normal state.

**Note:**

Before uploading settings to the Online Window from the Offline Window of the software, ensure that the settings in this panel in the Offline Window have been set to required values. Otherwise, undesired relay operation can occur.

## IED BEHAVIOR

Displays the actual behavior of the IED based on different inputs to control the IED MODE. Note that the test mode can be changed through the front panel, EnerVista software, FlexLogic operands, IEC 61850 control to LLN0.Mod, and **INITIATE TEST MODE ON SIM** setting, with the following behavior.

### TEST MODE TRIP SECURITY

This setting is used to govern both IOC Trip Security and Differential Trip Security functions. It is in effect only when the IED is not in the normal in-service operation mode (i.e., IED Mode is set to a value other than On).

| Change to IED MODE                      | Behavior                                                                          |
|-----------------------------------------|-----------------------------------------------------------------------------------|
| Using front panel                       | IED MODE and IED BEHAVIOR change in software                                      |
| Using software                          | IED MODE and IED BEHAVIOR change on front panel                                   |
| Using operand                           | IED MODE does not change in software or front panel, IED BEHAVIOR reflects change |
| Using INITIATE TEST MODE ON SIM setting | IED MODE and IED BEHAVIOR do not change in software or front panel                |

## 8.12.2 IED MODE PROCESS

The **IED MODE** setting is changed to Test or Test Blocked (depending upon the selected setting value for *INITIATE TEST MODE ON SIM*) when the relay is put into simulation mode. After this, the **IED MODE** is controlled by the **TESTING > IED MODE CONFIG** menu.

The **IED MODE** selection is illustrated in the logic diagram.



The SR Latch that drives the UR into *Test mode* or *On mode* are reset-dominant, which means that *Test Blocked* mode has the highest priority over Test and On modes, when simultaneous commands are active. For example, if both the FlexLogic operands assigned to the TEST MODE INPUT and TEST-BLK MODE INPUT settings are ON, then the **IED MODE** is Test Blocked.

If Any Major error FlexLogic operand is set, then **IED MODE** is set to *Test Blocked*.

Following UR restart or power-up, the **IED MODE** remains latched at the last value, until change is triggered by another input/command.

When the relay simulation mode is enabled (LPHD.Sim.stVal = TRUE), the *INITIATE TEST MODE ON SIM* setting triggers respective test mode. If the relay is already in *Test* or *Test Blocked* mode, the priority scheme defined in the **IED MODE** processing logic decides the resulting IED mode.

In summary, enabling the Test or Test Blocked mode in the **TESTING > IED MODE CONFIG** menu has no impact on the simulation mode. However, enabling the simulation mode triggers the respective test mode selected by the *INITIATE TEST MODE ON SIM* setting and the resulting IED mode is decided by the **IED MODE** process logic diagram. Once the simulation mode is enabled, the user can switch independently among IED modes using the **IED MODE CONFIG** settings while the simulation mode continues.

As shown in the logic diagram, the *INITIATE TEST MODE ON SIM* setting triggers the respective IED mode only when the relay is entering into simulation mode (meaning on the positive edge trigger of RLY IN SIM MODE FlexLogic operand) or there is a change in the *INITIATE TEST MODE ON SIM* setting value. Once simulation mode is enabled, any command to change the IED Mode triggers the respective IED mode. When the simulation mode is disabled, the test mode initiated by *INITIATE TEST MODE ON SIM* setting resets.





Figure 348: IED mode processing logic

### 8.12.3 FORCE CONTACT INPUTS

Setting path: **SETTINGS > INPUTS/OUTPUTS > DIRECT OUTPUTS > DIRECT OUTPUTS**



The force contact inputs feature provides a method of performing checks on the function of all contact inputs.

While in Test mode, the relay contact inputs can be pre-programmed to respond in the following ways:

- If set to *Normal*, the input remains fully operational. It is controlled by the voltage across its input terminals and can be turned on and off by external circuitry. Select this value if a given input must be operational during the test. This includes, for example, an input initiating the test, or being a part of a user pre-programmed test sequence.
- If set to *Open*, the input is forced to report as opened (Logic 0) while the operand selected by **CONTACT I/O FORCING** setting is On, regardless of the voltage across the input terminals. While the selected operand is Off, the input behaves as it does when in service.
- If set to *Closed*, the input is forced to report as closed (Logic 1) while the operand selected by **CONTACT I/O FORCING** setting is On regardless of the voltage across the input terminals. While the selected operand is Off, the input behaves as it does when in service.

**Note:**

Following a restart or power-up, the **CONTACT I/O FORCING** setting remains at the last value before restart, but force contact input and force contact output settings revert to Normal state.

## 8.12.4 FORCE CONTACT OUTPUTS

Setting path: **SETTINGS > INPUTS/OUTPUTS > DIRECT OUTPUTS > DIRECT OUTPUTS**

|                                                                                      |   |                             |                                                |
|--------------------------------------------------------------------------------------|---|-----------------------------|------------------------------------------------|
| <ul style="list-style-type: none"> <li>■ FORCE CONTACT</li> <li>■ OUTPUTS</li> </ul> | ⇔ | FORCE Cont op <n><br>Normal | Range: Normal, Energized, De-energized, Freeze |
|--------------------------------------------------------------------------------------|---|-----------------------------|------------------------------------------------|

The force contact outputs feature provides a method of performing checks on the function of all contact outputs.

While in Test mode, the relay contact outputs can be pre-programmed to respond in the following ways:


- If set to *Normal*, the contact output remains fully operational. It operates when its control operand is logic 1 and resets when its control operand is logic 0.
- If set to *Energized*, the output closes and remains closed while the operand selected by the **CONTACT I/O FORCING** setting is On, regardless of the status of the operand configured to control the output contact. While the selected operand is Off, the output behaves as it does when in service.
- If set to *De-energized*, the output opens and remains opened while the operand selected by the **CONTACT I/O FORCING** setting is On, regardless of the status of the operand configured to control the output contact. While the selected operand is Off, the output behaves as it does when in service.
- If set to *Freeze*, the output retains its position at the instant before the **IED MODE** was *Test* and the operand selected by the **CONTACT I/O FORCING** setting was On, regardless of later changes in the status of the operand configured to control the output contact. While the selected operand is Off, the output behaves as it does when in service.

**Note:**

Following a restart or power-up, the **CONTACT I/O FORCING** setting remains at the last value before restart, but force contact input and force contact output settings revert to Normal state.

# 8.13 SIMULATION

Setting path: **SETTINGS > SIMULATION**



## 8.13.1 SUBSCRIBE TO SIMULATED VALUES

Setting path: **SETTINGS > SIMULATION > SUBSCRIBE TO SIMULATED VALUES**

|                                                                      |   |                                            |                                     |
|----------------------------------------------------------------------|---|--------------------------------------------|-------------------------------------|
| <div> <div>■ SUBSCRIBE TO</div> <div>■ SIMULATED VALUES</div> </div> | ⇔ | SIMULATION MODE:<br>Disabled               | Range: Disabled, Enabled            |
|                                                                      | ⇕ | SIM MODE INPUT:<br>Off                     | Range: FlexLogic operand            |
|                                                                      | ⇕ | SIM CTRL VIA MMS:<br>On                    | Range: FlexLogic operand            |
|                                                                      | ⇕ | INITIATE TEST MODE<br>ON SIM: Test-Blocked | Range: Disabled, Test, Test-Blocked |
|                                                                      | ⇕ | SIM MODE TARGET:<br>Enabled                | Range: Enabled, Disabled            |
|                                                                      | ⇕ | SIM MODE EVENTS:<br>Disabled               | Range: Enabled, Disabled            |
|                                                                      | ↑ | SIMULATION MODE<br>STATUS: Disabled        | Range: Enabled, Disabled            |

**Note:**  
 The relay is provided with optional IEC 61850 communications that include simulation. The option is specified at the time of ordering. The field reads *Unavailable* when IEC 61850 is not present.

Prior to UR 7.7, when the **UR TEST MODE FUNCTION** is set to *Test Blocked* or *Test*, the sim bit in the header of all transmitted GOOSE messages is set to TRUE, so that the UR plays the simulator role during the testing and commissioning phases. The **Sim** data attribute in the relay is set (<MasterLD>/LPHD1.Sim.stVal = TRUE), so that if GOOSE messages are received with the *simulation* flag set, these are used in place of the normal messages. The quality attribute values that are transmitted via GOOSE services are set to *valid + test*.

In UR 7.7 and later, the UR test mode and GOOSE simulation mode are isolated. The sim bit in the transmitted GOOSE messages and the relay *Sim* attribute (<MasterLD>/LPHD1.Sim.stVal) are controlled via new Modbus settings and MMS control requests. They no longer depend on the **UR TEST MODE FUNCTION** or **IED MODE**.

The settings also display in the software when the Product is set to IEC 61850 Edition 2. When using IEC 61850 Edition 1, the settings are read-only.

### SIMULATION MODE

When set to Disabled, the relay *Sim* attribute (<MasterLD>/LPHD1.Sim.stVal) is set to False and the GOOSE/SV messages received with simulation flag/bit set are ignored.

When set to Enabled, the relay *Sim* attribute (<MasterLD>/LPHD1.Sim.stVal) is set to True, so that if GOOSE/SV messages are received with the simulation flag/bit set, these are used in place of the normal messages.

SV messages has a simulation bit in the Reserved 1 field.

### SIM MODE INPUT

This setting selects a FlexLogic operand. When set, the relay Simulation mode is enabled and, if the messages (either GOOSE or SV) are received with the simulation bit true, messages from simulation devices are used in place of actual messages. Any FlexLogic operand can be assigned to enable simulation mode, that is, driven by any remote inputs, logic outputs, front panel (user-programmable pushbuttons), and so on.

### SIM CTRL VIA MMS

This setting selects a FlexLogic operand for the IEC 61850 client to control the simulation mode.

When set to Off, simulation mode selection via IEC 61850 client is disabled and control request to LPHD.SimctlVal returns return negative response.

When set to On, simulation mode selection via IEC 61850 client is accepted.

This setting can be set from the front panel, EnerVista UR Setup software, FlexLogic operand, and IEC61850 control to LPHD.SimctlVal.

### INITIATE TEST MODE ON SIM

This setting initiates the selected test mode when simulation mode is enabled.

When set to Disabled, any command (from an IEC 61850 client, front panel, or Flex Operand) to set the simulation mode enables the Sim mode irrespective of the current IED mode.

When set to Test or Test-Blocked, any command to set the simulation mode selects respective test mode, if the relay is not already in Test or Test-Blocked mode. If the relay is already in Test or Test-Blocked mode by any user command (from IEC 61850 client, front panel, or Flex Operand), the respective priority defined in test mode processing decides the resultant test mode.

In summary, enabling the Test or Test-Blocked mode via the **IED MODE** setting (from front panel or EnerVista), via a IEC61850 client command to LLN0.ModctlVal, or via **TEST MODE INPUT** and **TEST-BLK MODE INPUT** settings (FlexLogic operands) has no impact on the simulation mode. However, enabling the simulation mode using the **SIMULATION MODE** setting (from front panel or EnerVista), via an IEC61850 client command to LPHD.SimctlVal, or via **SIM MODE INPUT** setting (FlexLogic operand) enables the selected test mode by the **INITIATE TEST MODE ON SIM** setting. A user can independently disable the test or test-blocked mode by any specified command type, but the relay simulation mode continues and accepts the simulated values in place of actual values until the simulation mode is disabled.

### SIM MODE TARGET

When this setting is Enabled, a target message **IED IN SIM MODE** is displayed on the front panel when the relay is in Simulation mode. The target message gets self-reset when the relay exits the Simulation mode.


When this setting is Disabled, target message is not displayed when the relay is in Simulation mode.

### SIM MODE EVENT

This setting is used to control whether the change in Simulation mode of relay is recorded in the event recorder. When this setting is Enabled, the event showing the change in the status of Simulation is recorded. If this setting is Disabled, the events related to Simulation mode are not recorded.

### SIMULATION MODE STATUS

This is an actual value that indicates the present simulation mode of the relay.



### Figure 349: Simulation mode logic

### 8.13.2 PUBLISH SIMULATED VALUES

Setting path: **SETTINGS > SIMULATION > PUBLISH SIMULATED VALUES**

|                                                                 |   |                                                  |                                          |
|-----------------------------------------------------------------|---|--------------------------------------------------|------------------------------------------|
| <div> <div>■ PUBLISH</div> <div>■ SIMULATED VALUES</div> </div> | ↕ | <div>TxGOOSE SIM MODE:</div> <div>Disabled</div> | Range: Disabled, Enabled                 |
|                                                                 | ↕ | <div>SIM Q.VALIDITY:</div> <div>NONE</div>       | Range: NONE, GOOD, INVALID, QUESTIONABLE |
|                                                                 | ↑ | <div>SIM Q.TEST:</div> <div>NONE</div>           | Range: NONE, TRUE, FALSE                 |

## TxGOOSE SIM MODE

When set to Disabled, the sim bits in all transmitted GOOSE messages are set to FALSE.

When set to Enabled, the sim bits in all transmitted GOOSE messages are set to TRUE.

This setting can be modified through the front panel, EnerVista UR Setup software, IEC 61850 client control to <MasterLD>/LPHD1.TxGoSim.

## SIM Q.VALIDITY

This setting simulates the validity bits of the quality attribute values included in all transmitted GOOSE messages. When set to NONE, the q.Validity bits are set based on the logical node behavior value. When set to any other value, the q.Validity bits of quality attributes included in all transmitted GOOSE messages are set to the selected value.

This setting is used when ***TxGOOSE SIM MODE*** is enabled. It can be modified through the front panel and EnerVista UR Setup software.

## SIM Q.TEST

This setting simulates the Test bit of the quality attribute values included in all transmitted GOOSE messages. When set to NONE, the q.Test bit is set based on the relay **TEST MODE FUNCTION / IED** MODE. When set to any other value, the q.Test bit of quality attributes included in all transmitted GOOSE messages is set to the selected value.

This setting is used when ***TxGOOSE SIM MODE*** is set to Enabled. It can be modified through the front panel and EnerVista UR Setup software.

## 8.14 PROCESS BUS SETTINGS

Setting path: **SETTINGS > PROCESS BUS MODULE > GENERAL**

|                                                |   |                                                   |                                                                                                     |
|------------------------------------------------|---|---------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| <div> <div>■ GENERAL</div> <div>■</div> </div> | ⇔ | NETWORK CONFIG:<br>INDEPENDENT                    | Range: INDEPENDENT, PRP, HSR, Dual HSR                                                              |
|                                                | ⇕ | PRP SUPV MCST ADDR:<br>01154E000100               | Range: 01 15 4E 00 01 00 to 01 15 4E 00 01 FF                                                       |
|                                                | ⇕ | HSR-1 SUPV MCST ADDR:<br>01154E000100             | Range: 01 15 4E 00 01 00 to 01 15 4E 00 01 FF                                                       |
|                                                | ⇕ | HSR-2 SUPV MCST ADDR:<br>01154E000101             | Range: 01 15 4E 00 01 00 to 01 15 4E 00 01 FF                                                       |
|                                                | ⇕ | PORT 1a FUNCTION:<br>Enabled                      | Range: Disabled, Enabled                                                                            |
|                                                | ⇕ | ↓                                                 |                                                                                                     |
|                                                | ⇕ | PORT 4b FUNCTION:<br>Enabled                      | Range: Disabled, Enabled                                                                            |
|                                                | ⇕ | SV TRBL PRT BLOCK:<br>Global                      | Range: Global, Partial                                                                              |
|                                                | ⇕ | SV TRBL CONT OP BLK:<br>Off                       | Range: FlexLogic operand                                                                            |
|                                                | ⇕ | SV DELAY ALARM:<br>6.0 ms                         | Range: 1.0 ms to 10.0 ms in steps of 0.1 ms                                                         |
|                                                | ⇕ | QUALITY CHECK:<br>Reject Questionable             | Range: Reject Questionable, Accept Questionable                                                     |
|                                                | ⇕ | ANTI-ALIASING FILTER:<br>Disabled                 | Range: Disabled, Enabled                                                                            |
|                                                | ⇕ | SMPSYNCH CHECK:<br>Global                         | Range: Global, Local, Local-87L, Any                                                                |
|                                                | ⇕ | Fallback GmID:<br>00 00 00 00 00 00 00 00         | Range: 8 Octet string                                                                               |
|                                                | ⇕ | TARGET: Click to view or<br>edit selected Targets | Range: List of available Targets. Access in EnerVista.                                              |
|                                                | ⇕ | EVENTS: Click to view or<br>edit selected Events  | Range: List of available FlexLogic operand types<br>from SV Stream Processing. Access in EnerVista. |

### NETWORK CONFIG

This setting specifies the network configuration and redundancy for the Process Bus Module. If set to *INDEPENDENT*, all ports on the Process Bus Module are enabled, and the Process Bus Module can be connected directly to merging units (MUs) or to a switch without redundancy. To enable and disable individual ports on the Process Bus Module in a point-to-point (PPP) network, use the **PORT x FUNCTION** settings. If set to *PRP* or *HSR*, ports 1a and 1b are enabled. The **PORT 1a FUNCTION** and **PORT 1b FUNCTION** settings change, depending on usage. If set to *Dual HSR*, ports 1a and 1b are enabled for one HSR ring. When using a Process Bus Module, ports 3a and 3b are enabled for another HSR ring.



### PRP SUPV MCST ADDR

This setting changes the multicast address used by the Parallel Redundancy Protocol (PRP) supervision frames. Configure all DANP devices in the PRP network with the same multicast address for the network supervision to operate properly. You can edit this setting when the **NETWORK CONFIG** setting is set to *PRP*.

### HSR-1 SUPV MCST ADDR

This setting changes the multicast address used by High-Availability Seamless Redundancy ring one (HSR-1 ports 1a and 1b) supervision frames, for single HSR configuration. Configure all DANH devices in the HSR network with the same multicast address for the network supervision to operate properly. This setting is editable when the **NETWORK CONFIG** setting is set to *HSR* or *Dual HSR*.

### HSR-2 SUPV MCST ADDR

This setting changes the multicast address used by the HSR-2 (ports 3a and 3b) supervision frames for the second DANH in a Dual HSR configuration. Configure all DANH devices in the HSR network with the same multicast address for the network supervision to operate properly. You can edit this setting when the **NETWORK CONFIG** setting is set to *Dual HSR*.

### PORT 1a to 4b FUNCTION

These settings manually enable and disable Process Bus Module Ethernet ports. Typically, Process Bus Module ports are order-code dependent, and the *INDEPENDENT* network configuration enables all the ports by default. These settings allow individual ports to be enabled and disabled individually. To connect only a few of the ports, other ports can be disabled to avoid a *PBEthPort-# Offline* self-test error. The fields active depend on order code and **NETWORK CONFIG** setting. For order code 85, ports 1a, 1b, 3a, and 3b are available to be turned on or off. For order codes 86 and 87, all eight ports can be available to be turned on or off.

When a port is disabled, all transmitting and receiving traffic on the port is blocked. Relay restart is not required when changing these port function fields.

### SV TRBL PRT BLOCK

In case of loss of any subscribed SV streams or due to bad quality of any subscribed SV frames, the relay's protection functions need to be blocked to avoid undesired operation. This setting specifies the type of blocking applied. When set to *Global*, all the protection functions that utilize the sampled values are blocked. Communications, data logging, and oscillography remain functional. Availability of switchgear control is determined by the SV TRBL CONT OP BLK operand. When set to *Partial*, only those protection functions are blocked that utilize the sampled values from the affected SV stream. All other protection functions remain operational.

### SV TRBL CONT OP BLK

This setting selects a FlexLogic operand that determines whether the contact outputs are blocked or not. When the state of the operand is low, the contact outputs are not blocked when there is a loss of any SV stream or received SV frames have bad quality. You can enable switchgear control through contact outputs during SV stream trouble. When the operand is high, the contact outputs are blocked when there is a loss of any SV stream or received SV frames have bad quality and the switchgear control is not available through contact outputs during SV stream trouble.

### SV DELAY ALARM

The sampled value (SV) frames may arrive with a delay from the MUs, which can be due to the MU performance or different network path delays. This setting specifies the maximum delay expected between the time a sample is taken at the MU and the time of arrival of that SV message. Sampling time is estimated based on the UR Process Bus Module clock and the sampling rate. If the calculated frame delay is more than this setting value, the RxSV# Delay Alm On FlexLogic operand asserts. The setting value needs to be calibrated and set at the commissioning time for the given network topology. An alarm in runtime indicates the network performance is degrading over the time. In short, this setting specifies how long the relay waits to declare that a sample is delayed. Protection is not blocked by this setting.

## QUALITY CHECK

Flags are used to assess the quality of sampled value data to ensure protection. This setting specifies how the sampled values are processed by the relay when the associated **q.validity** is set to *Questionable*. Quality is checked per AC bank, not per SV stream. When set to *Reject Questionable*, the questionable data is considered invalid and the frame is rejected. Only Good quality data is accepted. Set it to *Accept Questionable* only if it is absolutely known that questionable quality from a MU is not compromising the quality of the data for various applications. When set to *Accept Questionable*, both the *Good* and *Questionable* quality data are accepted.

## ANTI-ALIASING FILTER

This setting activates or deactivates the anti-aliasing filter that conditions the sampled values from the Process Bus network. If the Merging Unit providing sampled values is applies an anti-aliasing filter, this setting must be disabled. Otherwise, this setting can be enabled to apply filtering of the received sampled values. When enabled, the device applies a low-pass-filter, which attenuates all the harmonics above the 15th order.

## SMPSYNCH CHECK

This setting is a time synchronization check. It specifies the time synchronization source of an SV stream expected by the Process Bus Module.

When set to *Global*, only the SV streams with **SmpSynch** indicating a *Global (2)* value are accepted. A stream with a **SmpSynch** value other than *Global (2)* is rejected.

When set to *Local*, all SV streams with **SmpSynch** indicating a *Local (1)* or *Global (2)* area clock are accepted.

When set to *Any*, any **SmpSynch** value in the range of 0 to 254 is acceptable. Streams outside the range are rejected.

When all the subscribed MU streams support IEC61850 Ed 2.1, an additional acceptance criterion as outlined in the description of setting Fallback GmID, has been added from UR version 8.5 and onwards

## Fallback GmID

In the RxSV streams supporting IEC61850 Ed 2.1, the *SynchSrcID* attribute is used as acceptance criteria for the RxSV streams, which are used by the Protection elements. In the absence of Global Clock, this setting indicates the GmID of the local clock to which all subscribed MUs have to be synchronized for RxSV streams to be accepted. The effect of the **Fallback GmID** is explained as below:

When **SMPSYNCH CHECK** is set to *Global*, only the RxSV streams with SmpSynch attribute indicating a *Global (2)* value are accepted. SynchSrcID(GmID) Check is not done as all the streams accepted are Globally synchronized.




Figure 350: SmpSynchCheck with GmID Flowchart

Effect of SMPSYNCH CHECK setting and attribute

| MU Smpsynchron Attribute | UR Setting: SMPSYNCH CHECK      |                                                 |                                       |
|--------------------------|---------------------------------|-------------------------------------------------|---------------------------------------|
|                          | Global                          | Local                                           | Any                                   |
| Global                   | Protection elements operational | Protection elements operational                 | Protection elements operational       |
| Local                    | Protection elements blocked     | Protection elements operational if GmID=GmIDRef | Protection elements operational       |
| Any                      | Protection elements blocked     | Protection elements blocked                     | Other protection elements operational |

## TARGET

With this setting, you can select the target messages of the affected SV stream(s) to be displayed on the front panel. The target resets itself once the issue with the SV stream is resolved. Note that a selected target message applies to all the configured SV streams. For example, if target message **RxSV DELAY ALM ON** is selected, then a target displays when any of the configured SV streams has an active SV Delay Alarm. When disabled, no target message displays on the front panel.




Figure 351: FlexLogic operand target selection

## EVENTS

With this setting, you can select the flexlogic operands, which will generate the events of the affected SV stream(s), to be recorded in the event recorder. Note that a selected event from the menu applies to all the configured SV streams. When disabled, no event is recorded in the event recorder.




Figure 352: FlexLogic operand event selection

**Note:**  
Choose carefully the events to be recorded in the event recorder. If an SV stream is noisy, there is risk of event recorder overflow. Apart from testing, select a minimal number of events following relay commissioning

**Important!**

**Note:**  
The assertion of the **Delayed Processing On** operand can be observed only in the event recorder because the oscillography is not running when the SV samples are delayed enough to trigger the assertion of this operand.

## 8.15 SV STREAM SETTINGS

The following settings are available.

### RxSV Format

*Range: IEC 61850-9-2LE r2-1, IEC 61869-9 ed1.0*

*Default: IEC 61850-9-2LE r2-1*

This setting selects the SV frame format, or protocol.

When set to *IEC 61850-9-2LE r2-1*, the relay assumes that the received SV frame references datasets that comply with IEC 61850-9-2LE, Table 6: Dataset (PhsMeas1). The IED must be configured with a system frequency of 50 or 60 Hz for correct operation.

When set to *IEC 61869-9 ed1.0*, the relay assumes that the dataset rules comply with IEC 61869-9 ed1.0 and that the number of Application-layer Service Data Units (ASDUs) are user-configurable.

**Note:**

When a file using a single SV stream (either IEC 61850-9-2LE r2-1 or IEC 61869-9 ed1.0) is converted from firmware version 8.2x and below to firmware versions 8.3x and above, the conversion will complete with no errors and the RxSV Format setting will have the same value as the original file. If there is a mix of SV streams in the original file, then the user will be notified of this error and all configured SV streams will be set to the SV Stream default; "Disabled". The RxSV Format setting will also default to "IEC 61850-9-2LE r2-1"

### SV Stream

- *Range: Disabled, Enabled*
- *Default: Disabled*

This setting enables an SV stream. When disabled, all other **RxSV** settings are not editable and set to default.

### svID

- *Range: 1 up to 129 Visible String characters*
- *Default: empty string*

svID refers to the name of the sampled value packet. The svID field of incoming SV messages must exactly match this value for the message to be accepted as a valid RxSV# message. The svID field of the sampled value frame must be unique within the system/substation.

### Dst MAC

- *Range: any valid multicast MAC (12-digit hexadecimal number)*
- *Default: 01-0C-CD-04-00-00*

Only received SV messages having a destination Media Access Control (MAC) address equal to this value are accepted as valid RxSV# messages. Each address must be unique. The destination MAC increases the overall performance of multicast message reception by filtering only the configured messages for processing. For a received SV message, the Dst MAC is validated if it matches with any of the configured RxSV# Dst MAC. If validation is successful, the message is forwarded for further checks. There is no explicit check for the configured Dst MAC versus the SvID for a received SV message.

### ConfRev

- *Range: 0 to 2147483647 in steps of 1*
- *Default: 0*


ConfRev refers to configuration revision, which is a count of configuration changes in the SV control block. If the value entered here is non-zero, the ConfRev field of incoming SV messages must match this value for the message

to be accepted as a valid RxSV# message. If the setting is zero, RxSV# does not check the value received in the ConfRev field.

### Force MU Out of Service

- *Range: FlexLogic operand*
- *Default: Off*

This setting is intended specifically for forcing a faulty Merging Unit (MU) out of service in applications where a circuit can be energized from more than one side, such as breaker and a half application, and the redundancy at MU level is not available. For such application current from both sides are summed up using UR source mechanism and if one MU fails, it will block all protection functions from using this source.



**Figure 353: Forcing MU1 out of service for a Breaker-and-a-half configuration**

For example, in the above figure it is possible to open Breaker1 and still keep the system energized through Breaker 2. The setting **FORCE MU OUT OF SERVICE** allows MU1 to be taken out of service while keeping the protection and control elements operational by using the RxSV stream from MU2 only. If redundancy is available at MU level, then the protection can be kept operational without using setting FORCE MU OUT OF SERVICE, through the Cross-checking functionality. Please refer to the description of settings CROSS-CHECKING, PHASE ORIGIN 1, 2 and NEUTRAL ORIGIN 1, 2 for more details.

To put an MU out of service, the corresponding breaker has to be opened before asserting the FlexLogic selected in the setting **FORCE MU OUT OF SERVICE** to the *ON* state. The MU can now be disconnected for troubleshooting purposes. The current channels from the affected MU will be treated as online with sampled current values forced to ZEROs. The protection using respective source remains operational based on the current values sent by the other MU which is located on the closed breaker side.

Note that:

- Keeping RxSV online (with current substituted as ZEROs) is applicable to current channels only. The status of voltage channels will become Offline, and the protection elements will get blocked according to the setting **SV TRBL PRT BLOCK**.
- The FlexLogic operands on the SV Config logic show the actual state of the affected the RxSV stream (i.e., RxSV# Off/On), irrespective of setting **FORCE MU OUT OF SERVICE** being Off or On.

You must ensure that the primary circuit to which the affected MU is connected remains de-energized for the entire duration of forcing MU out of service, otherwise the protection elements will mal-operate. The circuit should be de-



energized before changing the setting **FORCE MU OUT OF SERVICE** to *On*. The circuit should be energized only after the setting **FORCE MU OUT OF SERVICE** is set to *Off*.

SV stream processing FlexLogic operands must not be used to automate **FORCE MU OUT OF SERVICE**. We strongly recommend that **FORCE MU OUT OF SERVICE** is manually controlled (for example, through a pushbutton, contact input, virtual input, or GOOSE).

The setting **FORCE MU OUT OF SERVICE** is intended for applications where a breaker can be opened, and the corresponding MU can be taken out of service while the circuit is energized through another breaker such as in breaker-and-a-half application. For any other application, the use of this setting should be carefully evaluated.

We do not recommend using the setting **FORCE MU OUT OF SERVICE** together with the cross-checking function.

### Stream Status

This is an LED status indicator for the reception of an SV stream (RxSV#). A green LED reflects the RxSV# On FlexLogic operand, meaning that the SV stream is online. A red LED reflects the RxSV# Off FlexLogic operand, meaning that the SV stream is offline. When the EnerVista UR Setup software is not online or the stream is disabled, the LED is grayed-out with Not Available, or “-NA-” status.


### Advanced Configuration

Click the button to display or hide the fields.

These are settings to import an MU CID file and/or support IEC 61869-9 based SV streams, as per Table 902 on Standard sample rates. IEC 61869-9 allows flexibility on numbers of current and voltage channels. It can be in one of these sequences: A, B, C, N or A, AB, B, BC, C, CA, N. The UR supports up to eight CT channels and up to eight VT channels and one or two ASDUs for protection applications. The following settings are active when the SV Stream field is set to IEC 61869-9, and they also depend on the MU Variant Code.

### MU SCL Import

Use this feature to configure SV streams by importing an MU CID file. The setting file comparison with IEC 61869-9-2LE configuration is not available. The IEC 61850 Merge feature with IEC 61869-9-2LE is not available. Upon clicking the Import button and selecting a .cid file, a window appears from which to select the stream to import.



**Figure 354: Selecting a stream to import from a merging unit CID file**

Rules for accepting a CID file include:

- The same remote channel cannot be mapped to more than one AC bank channel
- An AC bank channel cannot be mapped to more than one remote channel



- For each AC bank, there are three phase inputs from the same SV control block and all three inputs are configured
- Phase 1 and Phase 2 inputs are not from the same SV control block
- Phase 1 and Phase 2 aux inputs are not from the same SV control block
- A configured Phase consumes three analog channels and Aux consumes one analog channel, with a maximum of 24 channels

### SvCBRef

- *Range: 0 up to 129 alphanumeric, underscore, slash, and period characters, beginning with an alpha character*
- *Default: empty string*

This field is read-only. When imported, the MU SCL file populates this field. The value is an ObjectReference to the publishing control block in the format:

- `<LDName>/LLN0.<SvCBName>`

where `<LDName>` is the function-related name, if any, of the logical device containing the publishing control block, otherwise the product-related name of that logical device, and `<SvCBName>` is the name of the publishing control block.

When `RxSV#` is configured manually, the field is empty.

### CT Channels

- *Range: 0 to 8*
- *Default: 4*

This setting specifies the number of CT channels available in the subscribed `RxSV#` message from the publisher MU. The CT-1 fields reflect the number selected here. The number of current quantities matches the number specified by the Variant Code of the MU.

Typically, a CT channel includes four current channels (three phase-ground currents and one ground/neutral/earth current). A current channel is the combination of the current sample value attribute (`AmpSv.instMag.i`) and the subsequent quality attribute (`AmpSv.q`).

If CT Channels is 4, CT1-A/B/C/N are supported for the stream.

If CT Channels is 8, CT2-A/B/C/N also are supported for the stream.

If CT Channels is 0, no CT channels display for AC input selection.

This setting is read-only and fixed at 4 when an **SV Stream** is set to IEC 61850-9-2LE.

If a message displays that *the number of channels being selected for CT inputs...exceeds the total allowable 4 CT channels*, this means that the CT Channels field is set at 4 and there are entries in the CT2-A/B/C/N fields. Set the latter fields to None or increase the number of channels.

### VT Channels

- *Range: 0 to 8*
- *Default: 4*

This setting specifies the number of VT channels in the subscribed `RxSV#` message from the publisher MU. Typically, VT channels include four voltage channels (three phase-ground voltages and auxiliary voltage). This setting specifies the number of voltage channels in the subscribed `RxSV#` message. The voltage channel is the combination of voltage sample value attribute (`VolSv.instMag.i`) and the corresponding quality attribute (`VolSv.q`). The VT-1 fields reflect the number selected here. The number of voltage quantities matches the number specified by the Variant Code of the dataset.

If VT Channels is 4, VT1-A/B/C/N are supported for the stream.

If VT Channels is 8, VT2-A/B/C/ also are supported for the stream.

If VT Channels is 0, no VT channels display for AC input selection.

This setting is read-only and fixed at 4 when an **SV Stream** is set to IEC 61850-9-2LE.

If a message displays that "*the number of channels being selected for CT inputs...exceeds the total allowable 2 VT*", this means that the VT Channels field is set at 2 and there are more than two entries in the VT1-A/B/C/N fields. The number of configured VT1 fields needs to match the VT Channels field.

### ASDUs

- *Range: 1, 2*
- *Default: 1*

This setting specifies the number of Application-layer Service Data Units (ASDUs) concatenated in one Application Protocol Data Unit (APDU) in the subscribed RxSV# message. When concatenating several ASDUs into one frame, the ASDU with the oldest samples is the first one in the frame. This setting is read-only and set at the default when an SV Stream is set to IEC 61850-9-2LE.

Recycle power to the relay when changing this setting.

### Variant Code

The EnerVista software auto-populates the Variant Code for the RxSV# message based on the settings Sample Rate, the number of ASDUs, the number of CT Channels, and the number of VT Channels configured.

For example, F4800S2I8U0 describes sampled values with 4800 samples per second, two ASDU (samples) per message, 8 currents, and no voltages.

As another example, F4800S1I8U4 means sampled values with 4800 samples per second, 1 ASDU per message, 8 CT channels, and 4 VT channels.

This field is read-only as per IEC 61869-9: 2016, Clause-6.903.2.

The number of samples (sample rate) in the variant code is set based on the **SETTINGS > SYSTEM SETUP > POWER SYSTEM > NOMINAL FREQUENCY** setting. This value displays *4000 Hz* for 50 Hz nominal frequency. This value displays *4800 Hz* for 60 Hz nominal frequency or any other nominal frequency except 50 Hz. IEC 61869-9 suggests the 4800 Hz sample rate for general measuring and protective applications, regardless of the power system frequency.

### CT1-A/B/C

- *Range: None, AC1 to AC16*
- *Default: AC1/AC2/AC3*

This setting specifies the sequence of Analog Channel (per phase) that is mapped to the CT-1 of the corresponding stream. An origin to CT Phase input defines the physical measurement input to the CT bank by mapping specific AC inputs from that merging unit (or SV message).

The fields are active when the **SV Stream** field is set to IEC 61869-9. The CT1 phases are available if the number of **CT Channels** is 4 or below. CT2 is added if **CT Channels** is 5 or higher.

The fields are set to the defaults and are read-only when the **SV Stream** field is set to IEC 61850-9-2LE.

### CT1- N

- *Range: None, AC1 to AC16*
- *Default: AC4*

This setting specifies the Analog Channel that is mapped to the CT ground/neutral input. An origin to CT1-N input defines the physical measurement input to the CT bank by mapping specific AC inputs from that MU (or SV message). If the MU does not publish any CT1-N inputs, configure the setting as None.

In the EnerVista software, the CT Aux input setting only populates the current channels of that RxSV#.

This CT Aux input setting is active when the **SV Stream** field is set to IEC 61869-9.

This CT Aux input setting is set to AC4 and is read-only when the **SV Stream** is set to IEC 61850-9-2LE.

### VT1-A/B/C

- *Range: None, AC1 to AC16*
- *Default: AC5/AC6/AC7*

This setting specifies the Analog Channel (per phase) that is mapped to the VT1- phase inputs. An origin to VT Phase input defines the physical measurement input to the VT bank by mapping specific AC inputs from that MU (or SV message). If the MU does not publish any VT channels, configure the setting as None.

The VT1 phase fields are active when the **SV Stream** field is set to IEC 61869-9. The VT1 phases are available if the number of **VT Channels** is 4 or below. VT2 is added if **VT Channels** is 5 or higher.

The fields are set to the defaults and are read-only when the **SV Stream** field is set to IEC 61850-9-2LE.

### VT1-N

- *Range: None, AC1 to AC16*
- *Default: AC8*

This setting specifies the Analog Channel that is mapped to the VT Aux/neutral input. An origin to VT input defines the physical measurement input to the VT bank by mapping specific AC inputs from that MU (or SV message). If the MU does not publish any VT1-N inputs, configure the setting as None.

In the EnerVista software, the VT Aux input setting only populates the voltage channels of that RxSV#.

The VT1-N input setting is active when the **SV Stream** field is set to IEC 61869-9.

The VT1-N input setting is set to the default and is read-only when the SV Stream field is set to IEC 61850-9-2LE.

## AC BANKS

The UR platform supports up to six AC Banks. They can be CT or VT banks (similar to **SETTINGS > SYSTEM SETUP > AC INPUTS > CURRENT/VOLTAGE BANK**). That is, each AC Bank can be configured either as current or voltage (not both). If configured as current, inapplicable voltage settings (such as VT ratio, VT secondary) are inactive. Similarly, if a bank is configured as voltage, current settings (such as CT primary, CT secondary) are inactive. In addition, bank level redundancy (that is, Origin-1 and Origin-2) is supported using crosschecking of each channel signal received from two different SV streams that are connected to the same electrical point on the primary power system. A maximum 24 channels can be configured to the AC Banks.

Click the button to display or hide the fields.

The following settings are available for each AC bank.

Each Phase Origin setting consumes three phase channels Ia/Va, Ib/Vb, or Ic/Vc, and a Neutral Origin setting consumes one ground or Aux Channel In/Vn, which means that

- An AC Bank with Phase Origin1 and Neutral Origin1 settings configured consumes four channels
- An AC Bank with both Phase Origin 1 and Phase Origin 2 and both Neutral Origin 1 and Neutral Origin 2 settings configured consumes eight channels

A maximum of 24 channels can be configured to the AC Banks.

For changes in this section, restart the relay, for example using **Maintenance > Reboot Relay Command**.

### Phase Origin 1, 2

- *Range: None, RxSV1-CT1/PHS, RxSV1-VT1/PHS to RxSV8-CT1/PHS, RxSV8-VT1/PHS*
- *Default: None*

An origin to an AC bank defines the physical measurement input to the bank by mapping specific AC inputs from a specific MU to the bank.

The UR Process Bus Module provides for the reliability of AC values for protection, metering, and oscillography by allowing duplicate origins of AC data. An origin is considered unavailable when set to None. If origin 1 is available,

the relay uses the values from origin 1 for protection, metering, and oscillography. Otherwise if origin 2 is available, the relay uses the values from origin 2. If both origins are unavailable, then the bank AC values are forced to zero to prevent ambiguity of measurement.

With crosschecking, the relay can use different origins. See the **Crosschecking** setting for information regarding automatic protection blocking possibilities on loss of one or both origins.

The two-phase origins in an AC bank must be of the same type and connected to the same electrical point in the primary power system. The two origins must be two currents with the same CT settings, or two voltages with the same VT settings. The current/voltage type of the phase and auxiliary origins must also match on each AC bank. It is intended that the origin AC inputs measure the same primary quantity with the same ratio. The same ratio and connection settings are applied to both origins.

### Neutral Origin 1, 2

- *Range: None, RxSV1-CT1/NTR, RxSV1-VT1/ NTR to RxSV8-CT1/NTR, RxSV8-VT1/ NTR*
- *Default: None*

These settings specify the field units that are the origins of the auxiliary input IN or VN. Duplicate auxiliary origins are supported in the same way as phase origins.

The two auxiliary origins in an AC bank must be of the same type. The two origins must be two currents with the same CT secondary setting, or two voltages. The current/voltage type of the phase and auxiliary origins also must match on each AC bank. It is intended that the origin AC inputs measure the same primary quantity with the same ratio. The same ratio and connection settings are applied to both origins.

### Crosschecking

- *Range: None, Depend Origin-1 Pref, Depend Origin-2 Pref*
- *Default: None*

The crosschecking feature allows application-level redundancy by checking between two independent SV streams from the same electrical connection of the instrument transformers. In addition to the network redundancy provided by PRP/HSR, the UR Process Bus Module allows the relay to communicate with redundant merging units.

When set to None, crosschecking is disabled. Use this on a non-protection-critical AC bank, such as one used for a synchrocheck voltage. GE strongly recommends setting it to None when redundancy is not supported at the merging unit level; otherwise the "ACBank# Orig1(2) In Use" operand status is inaccurate.

Origin preference is supported in case of discrepancy in dependability mode. This allows testing (secondary injection) or replacement of an MU that is configured to non-preferred origin without affecting protection functions since these functions are using a preferred origin stream when online. As such, dependability with Origin-1 preference allows continued use of Origin-1 in case of discrepancy between both online origin stream sampled values. Similarly, dependability with Origin-2 preference allows continued use of Origin-2 in case of discrepancy between both online origin stream sampled values.

The table shows how the Crosschecking setting, the availability of AC bank origins, and discrepancy checks determine whether protection is blocked. Blocked here means only protection elements. It does not inhibit metering, actual values, oscillography, or other functions.

When set to Depend Origin-1 Pref, protection is blocked if there is no good signal from both the Origin-1 and Origin-2 sources. When both the merging unit sources are good, the preference is given always for Origin-1. When the preferred MU sources fails, the alternate MU source is used for protection and measurement.

When set to Depend Origin-2 Pref, protection is blocked if there is no good signal from both the Origin-1 and Origin-2 sources. When both the merging unit sources are good, the preference is given always for Origin-2. When the preferred MU sources fails, the alternate MU source is used for protection and measurement.

#### Note:

While switching from a preferred to non-preferred channel, the protection functions are delayed for two cycles. While switching back to a preferred channel, the protection functions are delayed for one cycle.

**Crosschecking and protection behavior**

| Crosschecking setting | Origin-1 RxSV stream status | Origin-2 RxSV stream status | Discrepancy check | Protection operation         |
|-----------------------|-----------------------------|-----------------------------|-------------------|------------------------------|
| None                  | Not relevant                | Not relevant                | No check          | Normal                       |
| Depend Origin-1 Pref  | Not mapped                  | Not mapped                  | No check          | Normal                       |
|                       | Online                      | Online                      | OK / discrepant   | Normal using Origin-1 stream |
|                       | Online                      | Offline                     | No check          | Normal using Origin-1 stream |
|                       | Offline                     | Online                      | No check          | Normal using Origin-2 stream |
|                       | Offline                     | Offline                     | No check          | Blocked                      |
| Depend Origin-2 Pref  | Not mapped                  | Not mapped                  | No check          | Normal                       |
|                       | Online                      | Online                      | OK / discrepant   | Normal using Origin-2 stream |
|                       | Online                      | Offline                     | No check          | Normal using Origin-1 stream |
|                       | Offline                     | Online                      | No check          | Normal using Origin-2 stream |
|                       | Offline                     | Offline                     | No check          | Blocked                      |

Origin1 becomes offline and switches to Origin2 for the following reasons:

- When more than three of five frame samples received are invalid or a frame with sequence number is received after three consecutive missed frames for any channel of origin. The reason for invalid frames can be any of the following reasons:
  - If one or more AmpSv.q or VolSv.q attribute(s) are invalid from the assigned SV frame channels to the AC bank origin
  - When “Quality Check” is set to ‘Reject questionable’ data, the data with q.validity = questionable is processed as invalid
  - When the relay is in-service or the test function is Disabled, the SV data with q.test set to TRUE is processed invalid
  - When received SV frames with Sim Bit TRUE, the frame is invalid unless the value of @Master/LPHD1.Sim.stVal is true (that is Settings > Simulation > GOOSE/SV > Accept Sim GOOSE&SV or Settings > Simulation > Subscribe to Simulated Values > Simulation Mode is set to Enabled)
  - If the value of @Master/LPHD1.Sim.stVal is TRUE, once a subscribed SV messages with simulation bit TRUE are received, subscribed SV messages with simulation bit FALSE are invalid until @Master/LPHD1.Sim.stVal is set to FALSE
  - SV streams with “SmpSync” value out of the following specified ranges are rejected:
    - i. When the “SmpSynch Check” is set to “Global” (2), SV streams with “SmpSynch” value set to Global (2) are accepted
    - ii. When the “SmpSynch Check” is set to “Local” (1), SV streams with “SmpSynch” value set to Global (2) or Local (1) are accepted
    - iii. When the “SmpSynch Check” is set to “Any” (0 to 254), SV streams with “SmpSynch” value set in the range of 0 to 254 are accepted. For 7.80 version, the accepted range is 0 to 127.
- SV frames are delayed/not received for more than 1.9 power system cycles

The selected Origin quality will be the quality of the AC Bank.

If both Origins have invalid quality, then the AC Bank data is marked as invalid and does not participate in protection.

**Phase/Ground CT Primary**

- *Range: 1 to 65000 A insteps of 1*
- *Default: 1*

Enter the rated CT primary current value in Amperes. For 1000:5 and 1000:1 CTs, enter 1000.

### Phase/Ground CT Secondary

- *Range: 1A, 5A*
- *Default: 1A*

Enter the rated CT secondary current value in Amperes. For correct operation, the CT secondary rating must match the setting (that must also correspond to the specific CT connections used).

### Phase CT Polarity

- *Range: Standard, Inverted-3ph, Inverted Ph-A, Inverted Ph-B, Inverted Ph-C*
- *Default: Standard*

If CTs are wired with the correct polarity in all phases, i.e. CT polarity reversal is not required, "Standard" should be selected. If CT polarity is incorrect in just one phase, then select "Inverted Ph-A (B or C)"; choosing the affected phase. If CT polarities of all three phases are incorrect, select "Inverted-3Ph" to correct the CT polarities for all three phases. It should be noted that the oscillography record will capture the CTs current signal as applied to the relay terminal irrespective of this setting. This ensures correct relay behavior when recorded oscillography is played back to the relay.

### Ground CT Polarity

Range: Standard, Inverted

Default: Standard

If the ground CT is wired with the correct polarity, select "Standard" for this setting. If the Ground CT polarity is incorrect, then select "Inverted" to correct it. It should be noted that the oscillography record will capture ground CT current signal as applied to the relay terminal irrespective of this setting. This ensures the correct relay behavior when recorded oscillography is played back to the relay.

It is important that the settings **PHASE CT POLARITY** and **GROUND CT POLARITY** are set to the correct values before putting the relay into operation. Selecting the wrong value or changing this setting whilst relay is in operation would result in undesirable operation of the protection and control functions.

If you intend to use the crosschecking functionality (redundancy at MU level), then this setting should be used carefully to ensure that CT Polarity is the same on both MUs on each phase/neutral channel.

### SIGNAL SOURCES

Click the button to display or hide the fields. The first six Sources are the platform sources and can accept both current banks and voltage banks and are associated with AC bank 1 to 6. The first six sources allow current summation for phase and auxiliary CTs.

Recycle power to the relay when changing a source.

### Name

- *Range: up to 20 alphanumeric characters*
- *Default: SRC 1*

This setting specifies an alphanumeric name for the source.

### Phase CT

- *Range: None, B1, B2, B3, B4, B5, B6, B1+B2, ... B1+B2+B3+B4+B5+B6 or B7...B28*
- *Default: None*

This setting selects the phase CTs of an AC bank or the sum of the phase CTs of multiple AC banks to be the phase current of the source. That is, it select the AC Banks section above in the window.

If you see the message "the AC Bank x assigned...is not configured..," it means that you need to configure the AC Banks section in the software window before setting this field. The AC Bank selected can match the Origins fields

and Sources, such as a Phase CT set at B1 with Phase Origin 1 RxSV1-CT1/PHS and source SRC1. Another example is to use Phase CT set at B2 with Phase Origin 1 RxSV2-CT1/PHS and source SRC2.

### Ground CT

- *Range: None, B1, B2, B3, B4, B5, B6, B1+B2, ... B1+B2+B3+B4+B5+B6 or B7...B28*
- *Default: None*

This setting selects the ground CTs of an AC bank or the sum of the ground CTs of multiple AC banks to be the ground current of the source. That is, it selects the AC Banks section above in the window.

### Phase VT

- *Range: None, B1, B2, B3, B4, B5, B6*
- *Default: None*

This setting selects the phase VTs of an AC bank to be the phase voltages of the source.

### Alt Phase CT

- *Range: None, B1, B2, B3, B4, B5, B6, B1+B2, ... B1+B2+B3+B4+B5+B6 or B7...B28*
- *Default: None*

This setting is for switching between main and alternate sources. It selects the alternate phase CTs of an AC bank or the sum of the phase CTs of multiple AC banks to be the phase current of the source.

### Alt Ground CT

- *Range: None, B1, B2, B3, B4, B5, B6, B1+B2, ... B1+B2+B3+B4+B5+B6 or B7...B28*
- *Default: None*

This setting is for switching between main and alternate sources. It selects the ground CTs of an AC bank or the sum of the ground CTs of multiple AC banks to be the ground current of the source.

### Switch Alt CT

- *Range: FlexLogic operand*
- *Default: Off*

This setting is for switching the alternate source on or off.

### Alt Phase VT

- *Range: None, B1, B2, B3, B4, B5, B6*
- *Default: None*

This setting is for switching between main and alternate sources. It selects the phase VTs of an AC bank to be the phase voltages of the source.

### Alt Aux VT

- *Range: None, B1, B2, B3, B4, B5, B6*
- *Default: None*

This setting is for switching between main and alternate sources. It selects the auxiliary VT input of an AC bank to be the auxiliary voltage of the source.

### Switch Alt VT

- *Range: FlexLogic operand*
- *Default: Off*

This setting is for switching the alternate source on or off.

## CHAPTER 9

# ACTUAL VALUES



---

# 9.1      CHAPTER OVERVIEW

---

This chapter contains the following sections:

|                     |     |
|---------------------|-----|
| Chapter Overview    | 677 |
| Actual Values Menu  | 678 |
| Front panel         | 679 |
| Status              | 681 |
| Metering            | 694 |
| Remote resources    | 713 |
| Process Bus Module  | 714 |
| Records             | 721 |
| Product information | 726 |

## 9.2 ACTUAL VALUES MENU

|                   |
|-------------------|
| ■ ■ ACTUAL VALUES |
| ■ ■               |



|                                           |
|-------------------------------------------|
| ■ ■ ACTUAL VALUES<br>■ ■ FRONT PANEL      |
| ■ ■ ACTUAL VALUES<br>■ ■ STATUS           |
| ■ ■ ACTUAL VALUES<br>■ ■ METERING         |
| ■ ■ ACTUAL VALUES<br>■ ■ REMOTE RESOURCES |
| ■ ■ ACTUAL VALUES<br>■ ■ PB MODULE        |
| ■ ■ ACTUAL VALUES<br>■ ■ RECORDS          |
| ■ ■ ACTUAL VALUES<br>■ ■ PRODUCT INFO     |

Not L60

Not B90, C30, L60

## 9.3 FRONT PANEL

### Basic and Enhanced

You can view the front panel using the EnerVista software (for example to view an error message displayed on the front panel). You cannot however, change the settings using this view.

To view the front panel in EnerVista software:

1. Click **Actual Values > Front Panel**.
2. Click the pushbutton or LCD area to enlarge it.




Figure 355: Front panel use in the software

### Graphical front panel


**Note:**

The graphical front panel is a hardware option.

Using the graphical front panel, You can acknowledge and reset Annunciator alarms, as well as view LEDs and pushbuttons.

To view alarms for the graphical front panel in EnerVista:

1. Access **Actual Values > Graphical Panel > Annunciator Panel**. Alarms are listed, allowing remote acknowledgement/reset.
2. Click the **Acknowledge** or **Reset** button for an alarm.



The screenshot shows a software window titled "Annunciator Panel // New Site 1: C90P\_E: Actual Values: Local HMI". Below the title bar are four buttons: "Save", "Restore", "Default", and "Reset". The main area contains a table with three columns: "PARAMETER", "ALARM", and "ACTION".

| PARAMETER   | ALARM              | ACTION      |
|-------------|--------------------|-------------|
| Indicator 1 | NewTransientRecord | Acknowledge |
| Indicator 2 | 0.000              | Acknowledge |
| Indicator 3 | 0.000              | Acknowledge |
| Indicator 6 | hiTest             | Reset       |

**Figure 356: Annunciator alarms displayed in the software**


To view LEDs and pushbuttons on the graphical front panel in EnerVista:

1. **Access Actual Values > Graphical Panel > LEDs or Pushbuttons.**

## 9.4 STATUS

### 9.4.1 IED

**ACTUAL VALUES > STATUS > IED**



#### IED BEHAVIOUR


Displays the **SETTINGS > TESTING > IED MODE CONFIG > IED MODE** value.

#### SIMULATION MODE STATUS

Displays the **SETTINGS > SIMULATION > SUBSCRIBE TO SIMULATED VALUES > SIMULATION MODE** value, meaning if simulation mode is enabled or disabled on a device.

### 9.4.2 CONTACT INPUTS


**ACTUAL VALUES > STATUS > CONTACT INPUTS**



The present status of the contact inputs is shown here. The first line of a message display indicates the ID of the contact input. For example, *Cont Ip 1* refers to the contact input in terms of the default name-array index. The second line of the display indicates the logic state of the contact input.

### 9.4.3 VIRTUAL INPUTS

**ACTUAL VALUES > STATUS > CONTACT INPUTS**



The present status of the 128 virtual inputs is shown here. The first line of a message display indicates the ID of the virtual input. For example, *Virt Ip 1* refers to the virtual input in terms of the default name. The second line of the display indicates the logic state of the virtual input.

### 9.4.4 RXGOOSE BOOLEAN INPUTS

**ACTUAL VALUES > STATUS > RxGOOSE BOOLEANS**



This menu displays when the product includes an IEC 61850 software option.

### 9.4.5 RXGOOSE DPS INPUTS


#### ACTUAL VALUES > STATUS > RxGOOSE DPS



This menu displays when the product includes an IEC 61850 software option.

### 9.4.6 TELEPROTECTION INPUTS


#### ACTUAL VALUES > STATUS TELEPROTECTION INPUTS



The present state of teleprotection inputs from communication channels 1 and 2 are shown here. The state displayed is that of corresponding remote output unless the channel is declared failed.

### 9.4.7 CONTACT OUTPUTS

#### ACTUAL VALUES > STATUS > CONTACT OUTPUTS



The present state of the contact outputs is shown here. The first line of a message display indicates the ID of the contact output. For example, *Cont Op 1* refers to the contact output in terms of the default name-array index. The second line of the display indicates the logic state of the contact output.

For form-A contact outputs, the state of the voltage and current detectors is displayed as Off, VOff, IOff, On, IOn, and VOn. For form-C contact outputs, the state is displayed as Off or On.

### 9.4.8 VIRTUAL OUTPUTS

#### ACTUAL VALUES > STATUS > CONTACT OUTPUTS



The present state of each virtual output displays here. The first line of a message display indicates the ID of the virtual output. For example, *Virt Op 1* refers to the virtual output in terms of the default name-array index. The second line of the display indicates the logic state of the virtual output, as calculated by the FlexLogic equation for that output.

### 9.4.9 RXGOOSE STATUS

#### ACTUAL VALUES > STATUS > RxGOOSE DPS

|                                                |   |                                |                                       |
|------------------------------------------------|---|--------------------------------|---------------------------------------|
| <div><div>RxGOOSE</div><div>STATUS</div></div> | ⇔ | All RxGOOSE Online:<br>Yes     | Range: Yes, No                        |
|                                                | ↑ | RxGOOSE <n> Status:<br>Offline | Range: Online, Offline<br>n = 1 to 64 |

This menu displays when the product includes an IEC 61850 software option.

The **All RxGOOSE Online** actual value does not consider RxGOOSE that are not configured or are not used by any RxGOOSE Input.

If fixed GOOSE is configured, the **All RxGOOSE Online** actual value reflects the status of both the configurable GOOSE subscriptions and the fixed GOOSE subscriptions. For **All RxGOOSE Online** status to have the value "Yes", all **RxGOOSE x Status** actual values must be *Online* and the fixed GOOSE All Remote Devices Online status must have the value *Yes*.

### 9.4.10 RXGOOSE STATISTICS

**ACTUAL VALUES > STATUS > RxGOOSE STATISTICS > RxGOOSE 1(64)**

*Note:*  
Only RxGOOSE 1 is shown

|                                            |   |                      |                                               |
|--------------------------------------------|---|----------------------|-----------------------------------------------|
| <div><div>RxGOOSE 1</div><div></div></div> | ⇔ | RxGOOSE 1<br>stNum 0 | Range: 0 up to 4,294,967,295                  |
|                                            | ↑ | RxGOOSE 1<br>sqNum 0 | Range: 0 up to 4,294,967,295: Online, Offline |

This menu displays when the product includes an IEC 61850 software option.

#### stNum

State number. The most recently received value in GOOSE message field stNum. The publisher increments stNum each time that the state of one or more of the GOOSE message members is sent with a revised value.

#### sqNum

Sequence number. The most recently received value in GOOSE message field sqNum. The publisher sets sqNum to zero each time the state of one or more of the GOOSE message members is sent with a new value, and it increments it whenever a GOOSE message is resent without any member value change.

### 9.4.11 FIXED GOOSE

#### Remote Devices

**ACTUAL VALUES > STATUS > FIXED GOOSE > REMOTE DEVICES STATUS**

|                                                      |   |                                   |                               |
|------------------------------------------------------|---|-----------------------------------|-------------------------------|
| <div><div>REMOTE DEVICE</div><div>STATUS</div></div> | ⇔ | ALL REMOTE DEVICES ONLINE:<br>Yes | Range: Yes, No                |
|                                                      | ↑ | REMOTE DEVICE <n> STATUS:<br>Off  | Range: On, Off<br>n = 1 to 16 |

Displays the present state of the programmed remote devices.

**ALL REMOTE DEVICES ONLINE**

Indicates whether all programmed devices are online or not. If the state is *No*, then at least one required remote device is not online.

**ACTUAL VALUES > STATUS > FIXED GOOSE > REMOTE DEVICES STATISTICS > REMOTE DEVICE 1(16)**

*Note:*  
Only REMOTE DEVICE 1 is shown.

|                                           |   |                             |                           |
|-------------------------------------------|---|-----------------------------|---------------------------|
| <div>■ REMOTE DEVICE 1</div> <div>■</div> | ↔ | REMOTE DEVICE 1 stNum:<br>0 | Range: 0 to 4,294,967,295 |
|                                           | ↑ | REMOTE DEVICE 1 sqNum:<br>0 | Range: 0 to 4,294,967,295 |

**REMOTE DEVICES 1 stNum**

This indicates the most recently received value in the received Fixed GOOSE message field stNum (state number). The publisher increments stNum each time that the state of one or more of the Fixed GOOSE message members is sent with a revised value.

**REMOTE DEVICES 1 sqNum**

This indicates the most recently received value in the received Fixed GOOSE message field sqNum (sequence number). The publisher sets sqNum to zero each time the state of one or more of the GOOSE message members is sent with a new value, and it increments it whenever a Fixed GOOSE message is resent without any member value change. This number rolls over to zero when the maximum count of 4,294,967,295 is reached.

**Remote inputs**

**ACTUAL VALUES > STATUS > FIXED GOOSE > REMOTE INPUTS > REMOTE INPUT 1(32)**

*Note:*  
Only REMOTE INPUT 1 is shown

|                                         |   |                              |                |
|-----------------------------------------|---|------------------------------|----------------|
| <div>■ REMOTE INPUTS</div> <div>■</div> | ↔ | REMOTE INPUT 1 STATUS<br>Off | Range: On, Off |
|-----------------------------------------|---|------------------------------|----------------|

**9.4.12 DIGITAL COUNTERS**

**ACTUAL VALUES > STATUS > DIGITAL COUNTERS > DIGITAL COUNTERS Counter <n>**

*Note:*  
Only Counter 1 is shown



|                                                      |   |                                          |                                      |
|------------------------------------------------------|---|------------------------------------------|--------------------------------------|
| <div>■ DIGITAL COUNTERS</div> <div>■ Counter 1</div> | ↔ | Counter 1 ACCUM:<br>0                    |                                      |
|                                                      | ↕ | Counter 1 FROZEN:<br>0                   |                                      |
|                                                      | ↕ | Counter 1 FROZEN:<br>1970/01/01 00:00:00 | Range: YYYY/MM/DD HH:MM:SS           |
|                                                      | ↑ | Counter 1 MICROS:<br>0                   | Range: 0 to 4294967295 in steps of 1 |

The present status of the digital counters displays here. The status of each counter, with the user-defined counter name, includes the accumulated and frozen counts (the count units label also appears). Also included, is the date and time stamp for the frozen count. The **COUNTER 1 MICROS** value refers to the microsecond portion of the time stamp.

### 9.4.13 BREAKER STATUS

**ACTUAL VALUES > STATUS > BREAKERS**

|                                    |   |                                 |                                   |
|------------------------------------|---|---------------------------------|-----------------------------------|
| <div>■ BREAKERS</div> <div>■</div> | ↔ | BREAKER <n> ΦA/3P STATE:<br>N/A | Range: N/A, Opened, Closed, Alert |
|                                    | ↕ | BREAKER <n> ΦB/3P STATE:<br>N/A | Range: N/A, Opened, Closed, Alert |
|                                    | ↑ | BREAKER <n> ΦC/3P STATE:<br>N/A | Range: N/A, Opened, Closed, Alert |

N/A is shown when **BREAKER 1 FUNCTION** is disabled.

*Closed* is shown when the breaker is closed.

*Opened* is shown when the breaker is opened.

*Alert* is the state that represents one of the following breaker conditions:

- Bad
- Intermediate
- Racked-out
- Out of Service
- Pole Discrepancy
- Trouble

### 9.4.14 SELECTOR SWITCHES

**ACTUAL VALUES > STATUS > SELECTOR SWITCHES**

|                                             |   |                                    |                             |
|---------------------------------------------|---|------------------------------------|-----------------------------|
| <div>■ SELECTOR SWITCHES</div> <div>■</div> | ↔ | SELECTOR SWITCH 1<br>POSITION: 0/7 | Range: Current Position / 7 |
|---------------------------------------------|---|------------------------------------|-----------------------------|

|   |                                    |                             |
|---|------------------------------------|-----------------------------|
| ↑ | SELECTOR SWITCH 2<br>POSITION: 0/7 | Range: Current Position / 7 |
|---|------------------------------------|-----------------------------|

The display shows both the current position and the full range. The current position only (an integer from 0 through 7) is the actual value.

### 9.4.15 FLEX STATES

#### ACTUAL VALUES > STATUS > FLEX STATES

|                    |   |                       |                               |
|--------------------|---|-----------------------|-------------------------------|
| ■ FLEX STATES<br>■ | ⇔ | PARAM <n>: Off<br>Off | Range: On,Off<br>n = 1 to 256 |
|--------------------|---|-----------------------|-------------------------------|

There are 256 FlexState bits available. The second line value indicates the state of the given FlexState bit.

### 9.4.16 ETHERNET

#### ACTUAL VALUES > STATUS > ETHERNET

|                 |   |                                   |                 |
|-----------------|---|-----------------------------------|-----------------|
| ■ ETHERNET<br>■ | ⇔ | ETHERNET PRI LINK<br>STATUS: Fail | Range: Fail, OK |
|                 | ⇕ | ETHERNET SEC LINK<br>STATUS: OK   | Range: Fail, OK |
|                 | ↑ | ETHERNET TER LINK<br>STATUS: Fail | Range: Fail, OK |

These values indicate the status of the first, second, and third Ethernet ports.

### 9.4.17 REAL TIME CLOCK SYNCHRONIZING

#### ACTUAL VALUES > STATUS > TIME SYNC

|                                      |   |                                     |                                                                                                                               |
|--------------------------------------|---|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| ■ REAL TIME CLOCK<br>■ SYNCHRONIZING | ⇔ | RTC SYNC SOURCE:<br>None            | Range: None, Port 1(3) PTP Clock, IRIG-B, Other,<br>Process Bus Module Clock, SNTP1, SNTP2: On, Off                           |
|                                      | ⇕ | GRANDMASTER ID:<br>0000000000000000 | Range: any 8 octet value                                                                                                      |
|                                      | ⇕ | ACCURACY:<br>999999999 ns           | Range: 0 to 999,999,999 ns                                                                                                    |
|                                      | ⇕ | PBM SW1 PTP State:<br>DISABLED      | Range: Disabled, No Signal, Calibrating,<br>Synchronized, Qualifying, Idea, Master                                            |
|                                      | ⇕ | PBM SW2 PTP State:<br>DISABLED      | Range: Disabled, No Signal, Calibrating,<br>Synchronized, Qualifying, Idea, Master                                            |
|                                      | ⇕ | PORT 1 PTP STATE:<br>No Signal      | Range: Disabled, No Signal, Calibrating, Synch'd (No<br>Pdelay), Synchronized, Synch'd (Inv UTCoff), Synch'd<br>(Nopd INVoff) |

|   |                                     |                                                                                                                         |
|---|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| ⇅ | PORT 2 PTP STATE:<br>No Signal      | Range: Disabled, No Signal, Calibrating, Synch'd (No Pdelay), Synchronized, Synch'd (Inv UTCoff), Synch'd (Nopd INVoff) |
| ⇅ | PORT 3 PTP STATE:<br>No Signal      | Range: Disabled, No Signal, Calibrating, Synch'd (No Pdelay), Synchronized, Synch'd (Inv UTCoff), Synch'd (Nopd INVoff) |
| ⇅ | PTP - IRIG-B DELTA:<br>500000000 ns | Range: -500,000,000 to +500,000,000 ns                                                                                  |
| ⇅ | Last LeapSec Dir<br>None            | None, Positive, Negative                                                                                                |
| ↑ | Last LeapSec Date<br>1970/01/01     | Date: YYYY/MM/DD                                                                                                        |

**Note:**

This menu displays when the product includes an IEEE 1588 software option.

**RTC SYNC SOURCE**

This is the time synchronizing source the relay is using at present. Possible sources include Port 1 PTP Clock to Port 3 PTP Clock. A value of Other means a less precise source (IEC 103, IEC 104, Modbus, DNP). An actual value displays when the relay includes the IEEE 1588 software option.

**Note:**

When the **SYNCHRONIZING SOURCE** setting in **Settings > Product Setup > Real Time Clock** is set to *PBM Clock*, the **RTC SYNC SOURCE** should also be set to *Process Bus Module Clock*.

**GRANDMASTER ID**

This is the grandmaster identity code being received from the present PTP grandmaster, if any. When the relay is not using any PTP grandmaster, this actual value is zero. The grandmaster identity code is specified by PTP to be globally unique, so one can always know which clock is grandmaster in a system with multiple grandmaster-capable clocks.

**ACCURACY**

This is the estimated maximum time error at present in the RTC, considering the quality information embedded in the received time signal. The value 999,999,999 indicates that the magnitude of the estimated error is one second or more, or that the error cannot be estimated.

**PORT 1...3 PTP STATE**

This is the present state of the port's PTP clock. The PTP clock state is:

- *DISABLED*: The PTP function setting is disabled. With all other values, the PTP function is enabled.
- *NO SIGNAL*: No signal from an active master has been found.
- *CALIBRATING*: An active master has been selected but is not yet locked in.
- *Synch'd (No Pdelay)*: This value is shown if the port is synchronized, but the peer delay mechanism is non-operational

- *SYNCH'D (INV UTCOff)*: This value is shown if the signal is synchronized to the PTP master but with **currentUtcOffsetValid** = False
- *Synch'd (Nopd INVOff)*: This value is shown if the port is synchronized, but the peer delay mechanism is non-operational and PTP master has **currentUtcOffsetValid** = False
- *SYNCHRONIZED*: The signal is synchronized.

PTP - IRIG-B DELTA

This is the time difference, measured in nanoseconds, between the fractional seconds portion of the time being received via PTP and that being received via IRIG-B. A positive value indicates that PTP time is fast compared to IRIG-B time.

Last LeapSec Dir

This shows the direction of the last leap second.

- *None*: No leap second history
- *Positive*: Last leap second is positive and leap second is added
- *Negative*: Last leap second is negative and leap second is removed

Last LeapSec Date

This shows the date on which the last leap second was adjusted

Note:  
Note: These actual values are non-volatile and persisted across reboots.

9.4.18 DIRECT INPUTS

ACTUAL VALUES > STATUS > DIRECT INPUTS

|                                         |   |                                      |                     |
|-----------------------------------------|---|--------------------------------------|---------------------|
| <div>■ DIRECT INPUTS</div> <div>■</div> | ⇔ | AVERAGE MSG RETURN<br>TIME CH1: 0 ms | n = model dependent |
|                                         | ⇕ | UNRETURNED MSG<br>COUNT CH1: 0       |                     |
|                                         | ⇕ | CRC FAIL COUNT<br>CH1: 0             |                     |
|                                         | ⇕ | AVERAGE MSG RETURN<br>TIME CH2: 0 ms |                     |
|                                         | ⇕ | UNRETURNED MSG<br>COUNT CH2: 0       |                     |
|                                         | ⇕ | CRC FAIL COUNT<br>CH2: 0             |                     |
|                                         | ↑ | DIRECT INPUT <n><br>On               |                     |

### AVERAGE MSG RETURN TIME

This is the time taken for direct output messages to return to the sender in a direct input/output ring configuration (this value is not applicable for non-ring configurations). This is a rolling average calculated for the last ten messages. There are two return times for dual-channel communications modules.

### UNRETURNED MSG COUNT

These values (one per communications channel) count the direct output messages that do not make the trip around the communications ring.

### CRC FAIL COUNT

These values (one per communications channel) count the direct output messages that have been received but fail the CRC check. High values for either of these counts can indicate a problem with wiring, the communication channel, or one or more relays. The **UNRETURNED MSG COUNT** and **CRC FAIL COUNT** values can be cleared using the **CLEAR DIRECT I/O COUNTERS** command.


### DIRECT INPUT <n>

These values represent the state of each direct input.

---

## 9.4.19 DIRECT DEVICES STATUS

### ACTUAL VALUES > STATUS > DIRECT DEVICES STATUS




These actual values represent the state of direct devices 1 through 16

---

## 9.4.20 EGD PROTOCOL STATUS

### Fast Exchange

### ACTUAL VALUES > STATUS > EGD PROTOCOL STATUS > PRODUCER STATUS > FAST EXCHANGE 1



These values provide information for debugging an Ethernet Global Data (EGD) network. The EGD signature and packet size for the fast EGD exchange display.

### Slow Exchange

### ACTUAL VALUES > STATUS > EGD PROTOCOL STATUS > PRODUCER STATUS > SLOW EXCHANGE 1(2)

Note:  
Only SLOW EXCHANGE 1 is shown

|                        |   |                                   |
|------------------------|---|-----------------------------------|
| ■ FAST EXCHANGE 1<br>■ | ⇔ | SLOW EXCHANGE 1<br>SIGNATURE: 0   |
|                        | ↑ | SLOW EXCHANGE 1<br>DATA LENGTH: 0 |

These values provide information for debugging an EGD network. The EGD signature and packet size for the slow EGD exchanges display.

### 9.4.21 TELEPROTECTION CHANNEL TESTS

**ACTUAL VALUES > STATUS > TIME SYNC**

|                          |   |                                            |                                 |
|--------------------------|---|--------------------------------------------|---------------------------------|
| ■ TELEPROT CH TESTS<br>■ | ⇔ | CHANNEL 1<br>STATUS: n/a                   | Range: n/a, FAIL, OK            |
|                          | ⇕ | CHANNEL 1 LOST<br>PACKETS: 1               | Range: 1 to 65535 in steps of 1 |
|                          | ⇕ | CHANNEL 2<br>STATUS: n/a                   | Range: n/a, FAIL, OK            |
|                          | ⇕ | CHANNEL 2 LOST<br>PACKETS: 1               | Range: 1 to 65535 in steps of 1 |
|                          | ↑ | VALIDITY OF CHANNEL<br>CONFIGURATION: FAIL | Range: n/a, FAIL, OK            |

The status information for two channels is shown here.

#### CHANNEL 1 STATUS

This represents the receiver status of each channel. If the value is *OK*, teleprotection is enabled and data is being received from the remote terminal; If the value is *FAIL*, teleprotection enabled and data is not being received from the remote terminal. If *n/a*, teleprotection is disabled.

#### CHANNEL 1 LOST PACKETS

Data is transmitted to the remote terminals in data packets at a rate of two packets per cycle.

The number of lost packets represents data packets lost in transmission; this count can be reset to 0 through the **COMMANDS > CLEAR RECORDS** menu.

#### VALIDITY OF CHANNEL CONFIGURATION

This value displays the current state of the communications channel identification check, and hence validity. If a remote relay ID does not match the programmed ID at the local relay, the *FAIL* message displays. The *N/A* value appears if the local relay ID is set to a default value of 0, the channel is failed, or if the teleprotection inputs/outputs are not enabled.

### 9.4.22 REMAINING CONNECTION STATUS

**ACTUAL VALUES > STATUS > CHANNEL TESTS**

|                                                                      |   |                          |                                              |
|----------------------------------------------------------------------|---|--------------------------|----------------------------------------------|
| <div> <div>■ COMM STATUS</div> <div>■ REMAINING CONNECT</div> </div> | ↔ | MMS TCP (max 6)<br>6     | Range: 0 to 6                                |
|                                                                      | ↕ | Modbus TCP (max 4)<br>4  | Range: 0 to 4                                |
|                                                                      | ↕ | DNP TCP (max 2)<br>2     | Range: 0 to 2                                |
|                                                                      | ↕ | IEC-104 TCP (max 2)<br>2 | Range: 0 to 2                                |
|                                                                      | ↕ | PMU TCP<br>1             | Range: 1 to 4<br>Relays with PMU option only |
|                                                                      | ↑ | SFTP (max 4)<br>4        | Range: 0 to 4                                |

These values specify the remaining number of TCP connections still available for each protocol. The display depends on the options applicable to your device. Each time a connection is used, the remaining number of connections decrements. When released, the remaining number of connections increments. If no connection is made over the specific protocol, the number equals the maximum number available for the specific protocol.

For example, the maximum number of Modbus TCP connections is 4. Once an EnerVista session is opened on a computer connected to the UR over Ethernet, the Modbus TCP status shows 3. If the EnerVista application is closed, the Modbus TCP status shows 4.

For the graphical front panel, the remaining connections refer to TCP connections only.

### MMS TCP

The number of IEC 61850 connections remaining.

### PMU TCP (relays with PMU only)

The maximum number of PMU TCP connections matches the number of aggregators. The maximum number of aggregators for the N60 is 4. The maximum number for the C60 is 2. The maximum number is 1 for other products with a PMU. The remaining number of aggregators displays here.

## 9.4.23 PARALLEL REDUNDANCY PROTOCOL (PRP)

### ACTUAL VALUES > STATUS > CHANNEL TESTS

|                                                   |   |                           |                                       |
|---------------------------------------------------|---|---------------------------|---------------------------------------|
| <div> <div>■ PRP STATUS</div> <div>■</div> </div> | ↔ | Total Rx Port A:<br>0     | Range: 0 to 4G, blank if PRP disabled |
|                                                   | ↕ | Total Rx Port B:<br>0     | Range: 0 to 4G, blank if PRP disabled |
|                                                   | ↕ | Total Errors Port A:<br>0 | Range: 0 to 4G, blank if PRP disabled |
|                                                   | ↕ | Total Errors Port B:<br>0 | Range: 0 to 4G, blank if PRP disabled |

|   |                           |                                       |
|---|---------------------------|---------------------------------------|
| ⇅ | Mismatches Port A:<br>0   | Range: 0 to 4G, blank if PRP disabled |
| ⇅ | Mismatches Port B:<br>0   | Range: 0 to 4G, blank if PRP disabled |
| ⇅ | FER Port A:<br>0          | Range: 0 to 4G                        |
| ⇅ | FER Port B:<br>0          | Range: 0 to 4G                        |
| ⇅ | Link Active Port A:<br>No | Range: Yes, No                        |
| ⇅ | Link Active Port B:<br>No | Range: Yes, No                        |

**Note:**

*This menu displays when the product includes a PRP software option.*

**Total Rx Port A**

This is a counter for total messages received (either from DANPs or from SANs) on port A.

**Total Rx Port B**

This is a counter for total messages received (either from DANPs or from SANs) on port B.

**Total Errors Port A**

This is a counter for total messages received with an error (bad port code, frame length too short) on port A.

**Total Errors Port B**

This is a counter for total messages received with an error (bad port code, frame length too short) on port B.

**Mismatches Port A**

This is a counter for total messages received with an error on Port A (PRP frame, but port received through and LAN ID in the frame do not match).

**Mismatches Port B**

This is a counter for total messages received with an error on Port B (PRP frame, but port received through and LAN ID in the frame do not match).

**Link Active Port A**

This shows whether the link on port A is active or not.

**Link Active Port B**

This shows whether the link on port B is active or not.



### 9.4.24 TXGOOSE STATUS

#### ACTUAL VALUES > STATUS > TxGOOSE STATUS

|                       |   |                           |                               |
|-----------------------|---|---------------------------|-------------------------------|
| ■ TxGOOSE<br>■ STATUS | ⇔ | R-TxGOOSE <n><br>ARP: Off | Range: On, Off<br>n = 1 to 16 |
|-----------------------|---|---------------------------|-------------------------------|

**Note:**

*This menu displays when the product includes an IEC 61850 software option.*

This status is relevant to R-GOOSE reception when configured for SSM or ASM reception modes. It is not relevant for GOOSE or for R-GOOSE in unicast reception mode.

#### ARP

The unicast mode of R-GOOSE transmission requires Address Resolution Protocol (ARP) for the resolution of the network layer address into the MAC layer address. R-TxGOOSE <n> ARP status On indicates that ARP responses are being received and the destination MAC address for R-GOOSE transmissions has been obtained. This status remains Off if TxGOOSE <n> is not configured for R-GOOSE. It also remains Off if setting R-TxGOOSE1 DST IP is set to a multicast address. In the case where setting R-TxGOOSE1 DST IP is configured with a unicast address and this status indicates Off, TxGOOSE <n> transmission will be off, and therefore communication network diagnosis needs to be carried out.

This status is only applicable for R-GOOSE transmission with setting R-TxGOOSE1 DST IP set to a unicast IP address. It is not applicable for GOOSE or for R-GOOSE when setting R-TxGOOSE1 DST IP is multicast.

### 9.4.25 PROTOCOL

#### ACTUAL VALUES > STATUS > PROTOCOL

|                 |   |                               |                           |
|-----------------|---|-------------------------------|---------------------------|
| ■ PROTOCOL<br>■ | ⇔ | IEC61850 EDITION:<br>Edition2 | Range: Edition1, Edition2 |
|-----------------|---|-------------------------------|---------------------------|

**Note:**


*This menu displays when the product includes an IEC 61850 software option.*

This displays the IEC 61850 edition currently being used, as set under **Settings > Product Setup > Communications > Protocol > IEC61850 Edition**.

## 9.5 METERING

### 9.5.1 METERING CONVENTIONS

#### UR convention for measuring power and energy




**Figure 357: Flow direction of signed values for watts and VARs****UR convention for measuring phase angles**

All phasors calculated by URs and used for protection, control and metering functions are rotating phasors that maintain the correct phase angle relationships with each other at all times.

For display and oscillography purposes, all phasor angles in a given relay are referred to an AC input channel pre-selected by the **SETTINGS > SYSTEM SETUP > POWER SYSTEM > FREQUENCY AND PHASE REFERENCE** setting. This setting defines a particular AC signal source to be used as the reference.

The relay first determines if any Phase VT bank is indicated in the source. If it is, voltage channel VA of that bank is used as the angle reference. Otherwise, the relay determines if any Aux VT bank is indicated; if it is, the auxiliary voltage channel of that bank is used as the angle reference. If neither of the two conditions is satisfied, then two more steps of this hierarchical procedure to determine the reference signal include Phase CT bank and Ground CT bank.

If the AC signal pre-selected by the relay upon configuration is not measurable, the phase angles are not referenced. The phase angles are assigned as positive in the leading direction, and are presented as negative in the lagging direction, to more closely align with power system metering conventions. The figure illustrates this.



827845A1.CDR

**Figure 358: UR phase angle measurement convention****UR convention for symmetrical components**

The URs calculate voltage symmetrical components for the power system phase A line-to-neutral voltage, and symmetrical components of the currents for the power system phase A current. Owing to the above definition, phase angle relations between the symmetrical currents and voltages stay the same irrespective of the connection of instrument transformers. This is important for setting directional protection elements that use symmetrical voltages.

For display and oscillography purposes the phase angles of symmetrical components are referenced to a common reference as described previously.

**Wye-connected instrument transformers****ABC rotation:**

$$V_0 = (V_{AG} + V_{BG} + V_{CG})/3$$

$$V_1 = (V_{AG} + aV_{BG} + a^2V_{CG})/3$$

$$V_{-2} = (V_{AG} + a^2V_{BG} + aV_{CG})/3$$

**ACB rotation**

$$V_{-0} = (V_{AG} + V_{BG} + V_{CG})/3$$

$$V_{-1} = (V_{AG} + a^2V_{BG} + aV_{CG})/3$$

$$V_{-2} = (V_{AG} + aV_{BG} + a^2V_{CG})/3$$

Swapping out V for I, the above equations also apply to currents.

**Delta-connected instrument transformers****ABC rotation**

$$V_{-0} = N/A$$

$$V_{-1} = 1\angle-30^\circ(V_{AB} + aV_{BC} + a^2V_{CA})/3\sqrt{3}$$

$$V_{-2} = 1\angle30^\circ(V_{AB} + a^2V_{BC} + aV_{CA})/3\sqrt{3}$$

**ACB rotation**

$$V_{-0} = N/A$$

$$V_{-1} = 1\angle30^\circ(V_{AB} + a^2V_{BC} + aV_{CA})/3\sqrt{3}$$

$$V_{-2} = 1\angle-30^\circ(V_{AB} + aV_{BC} + a^2V_{CA})/3\sqrt{3}$$

The zero-sequence voltage is not measurable under the Delta connection of instrument transformers and is defaulted to zero. The table below shows an example of symmetrical components calculations for the ABC phase rotation.

**Symmetrical components calculation example**

| SYSTEM VOLTAGES, sec. V *                     |                 |                 |                |                 |                | VT<br>conn. | relay INPUTS, sec. V |                 |                | SYMM. COMP, sec. V |               |                |
|-----------------------------------------------|-----------------|-----------------|----------------|-----------------|----------------|-------------|----------------------|-----------------|----------------|--------------------|---------------|----------------|
| VAG                                           | VBG             | VCG             | VAB            | VBC             | VCA            |             | F5ac                 | F6ac            | F7ac           | V0                 | V1            | V2             |
| 13.9<br>∠ 0°                                  | 76.2 ∠-<br>125° | 79.7 ∠-<br>250° | 84.9<br>∠-313° | 138.3<br>∠-97°  | 85.4<br>∠-241° | WYE         | 13.9<br>∠0°          | 76.2<br>∠-125°  | 79.7<br>∠-250° | 19.5<br>∠-192°     | 56.5<br>∠-7°  | 23.3<br>∠-187° |
| UNKNOWN (only V1 and<br>V2 can be determined) |                 |                 | 84.9<br>∠0°    | 138.3<br>∠-144° | 85.4<br>∠-288° | DELTA       | 84.9<br>∠0°          | 138.3<br>∠-144° | 85.4<br>∠-288° | N/A                | 56.5<br>∠-54° | 23.3<br>∠-234° |

In this example, the power system voltages are phase-referenced to VAG and VAB, respectively. This, however, is a relative matter. It is important to remember that the Product displays are always referenced as specified under **SETTINGS > SYSTEM SETUP > POWER SYSTEM > FREQUENCY AND PHASE REFERENCE**.

The example above is illustrated in the following figure.




Figure 359: Measurement convention for symmetrical components

## 9.5.2 TRANSFORMER

### Differential and restraint currents

**ACTUAL VALUES > METERING > TRANSFORMER > DIFFERENTIAL AND RESTRAINT**

|                                               |   |                                    |
|-----------------------------------------------|---|------------------------------------|
| <div>■ DIFFERENTIAL AND<br/>■ RESTRAINT</div> | ⇔ | REFERENCE WINDING:<br>Winding 1    |
|                                               | ⇕ | DIFF PHASOR Iad:<br>0.000 pu 0.0°  |
|                                               | ⇕ | REST PHASOR Iar:<br>0.000 pu 0.0°  |
|                                               | ⇕ | DIFF 2ND HARM Iad:<br>0.0% fo 0.0° |
|                                               | ⇕ | DIFF 5TH HARM Iad:<br>0.0% fo 0.0° |
|                                               | ⇕ | DIFF PHASOR Ibd:<br>0.000 pu 0.0°  |
|                                               | ⇕ | REST PHASOR Ibr:<br>0.000 pu 0.0°  |
|                                               | ⇕ | DIFF 2ND HARM Ibd:<br>0.0% fo 0.0° |

|   |                                    |
|---|------------------------------------|
| ⇅ | DIFF 5TH HARM Ibd:<br>0.0% fo 0.0° |
| ⇅ | DIFF PHASOR Icd:<br>0.000 pu 0.0°  |
| ⇅ | REST PHASOR Icr:<br>0.000 pu 0.0°  |
| ⇅ | DIFF 2ND HARM Icd:<br>0.0% fo 0.0° |
| ↑ | DIFF 5TH HARM Icd<br>0% fo 0.0°    |

The metered differential current, restraint current, second harmonic current, and fifth harmonic current are displayed for each phase. See the Percent Differential section in chapter 5 for details on how these values are calculated.

If differential current in any phase is below the hard-coded cutoff of 0.04 pu, then the differential, 2nd harmonic, and 5th harmonic currents are forced to zero.

### Thermal elements

#### ACTUAL VALUES > METERING > TRANSFORMER > THERMAL ELEMENTS

|                         |   |                                |
|-------------------------|---|--------------------------------|
| ■ THERMAL ELEMENTS<br>■ | ⇅ | TOP OIL °C:<br>70°C            |
|                         | ⇅ | HOTTEST-SPOT °C:<br>30°C       |
|                         | ⇅ | AGING FACTOR:<br>1.2 PU        |
|                         | ⇅ | DAILY RATE LOL:<br>0.000 Hours |
|                         | ↑ | XFMR LIFE LOST:<br>0.000 Hours |

The daily rate loss of life is summarized at 00:00 h, and displayed for the next 24 hour period. The transformer accumulated loss of life in hours is also available. It can be reset by either changing the **XFMR INITIAL LOSS OF LIFE** setting or through the **COMMANDS > CLEAR RECORDS > CLEAR LOSS OF LIFE RECORDS** command.

### 9.5.3 SPLIT PHASE

#### ACTUAL VALUES > METERING > SPLIT PHASE

|                    |   |                                    |
|--------------------|---|------------------------------------|
| ■ SPLIT PHASE<br>■ | ⇅ | SPLIT PHASE A<br>CURRENT: 0.000 pu |
|                    | ⇅ | SPLIT PHASE B<br>CURRENT: 0.000 pu |

|   |                                    |
|---|------------------------------------|
| ⇅ | SPLIT PHASE C<br>CURRENT: 0.000 pu |
| ↑ | LOAD CURRENT:<br>0.000 pu          |

## 9.5.4 SOURCES

This menu displays the metered values available for each source.

Metered values presented for each source depend on the phase and auxiliary VTs and phase and ground CTs assignments for this particular source. For example, if no phase VT is assigned to this source, then any voltage, energy, and power values are unavailable.

### 9.5.4.1 PHASE CURRENT METERING

**ACTUAL VALUES > METERING > SOURCE SRC 1 > PHASE CURRENT**

|                            |   |                                             |
|----------------------------|---|---------------------------------------------|
| ■ PHASE CURRENT<br>■ SRC 1 | ⇅ | SRC 1 RMS Ia: 0.000<br>b: 0.000 c: 0.000 kA |
|                            | ⇅ | SRC 1 RMS Ia:<br>0.000 kA                   |
|                            | ⇅ | SRC 1 RMS Ib:<br>0.000 kA                   |
|                            | ⇅ | SRC 1 RMS Ic:<br>0.000 kA                   |
|                            | ⇅ | SRC 1 RMS In:<br>0.000 kA                   |
|                            | ⇅ | SRC 1 PHASOR Ia:<br>0.000 kA 0.0°           |
|                            | ⇅ | SRC 1 PHASOR Ib:<br>0.000 kA 0.0°           |
|                            | ⇅ | SRC 1 PHASOR Ic:<br>0.000 kA 0.0°           |
|                            | ⇅ | SRC 1 PHASOR In:<br>0.000 kA 0.0°           |
|                            | ⇅ | SRC 1 ZERO SEQ I0:<br>0.000 kA 0.0°         |
|                            | ⇅ | SRC 1 POS SEQ I1:<br>0.000 kA 0.0°          |
|                            | ↑ | SRC 1 NEG SEQ I2:<br>0.000 kA 0.0°          |

The metered values are displayed in this menu. The SRC 1 text gets replaced by whatever name was programmed by the user for the associated source (see **SETTINGS > SYSTEM SETUP > SIGNAL SOURCES**).

**9.5.4.2 GROUND CURRENT METERING**

**ACTUAL VALUES > METERING > SOURCE SRC 1 > GROUND CURRENT**

|                                                |   |                                    |
|------------------------------------------------|---|------------------------------------|
| <div>■ GROUND CURRENT</div> <div>■ SRC 1</div> | ⇔ | SRC 1 RMS Ig:<br>0.0 A             |
|                                                | ⇕ | SRC 1 PHASOR Ig:<br>0.0 A 0.0°     |
|                                                | ↑ | SRC 1 PHASOR Igd:<br>0.000 kA 0.0° |

The metered values are displayed in this menu. The SRC 1 text gets replaced by whatever name was programmed by the user for the associated source (see **SETTINGS > SYSTEM SETUP > SIGNAL SOURCES**).

**9.5.4.3 PHASE VOLTAGE METERING**

**ACTUAL VALUES > METERING > SOURCE SRC 1 > PHASE VOLTAGE**

|                                               |   |                                 |
|-----------------------------------------------|---|---------------------------------|
| <div>■ PHASE VOLTAGE</div> <div>■ SRC 1</div> | ⇔ | SRC 1 RMS Vag:<br>0.0 V         |
|                                               | ⇕ | SRC 1 RMS Vbg:<br>0.0 V         |
|                                               | ⇕ | SRC 1 RMS Vcg:<br>0.0 V         |
|                                               | ⇕ | SRC 1 PHASOR Vag:<br>0.0 V 0.0° |
|                                               | ⇕ | SRC 1 PHASOR Vbg:<br>0.0 V 0.0° |
|                                               | ⇕ | SRC 1 PHASOR Vcg:<br>0.0 V 0.0° |
|                                               | ⇕ | SRC 1 RMS Vab:<br>0.0 V         |
|                                               | ⇕ | SRC 1 RMS Vbc:<br>0.0 V         |
|                                               | ⇕ | SRC 1 RMS Vca:<br>0.0 V         |
|                                               | ⇕ | SRC 1 PHASOR Vab:<br>0.0 V 0.0° |



|   |                                  |
|---|----------------------------------|
| ⇅ | SRC 1 PHASOR Vbc:<br>0.0 V 0.0°  |
| ⇅ | SRC 1 PHASOR Vca:<br>0.0 V 0.0°  |
| ⇅ | SRC 1 ZERO SEQ V0:<br>0.0 V 0.0° |
| ⇅ | SRC 1 POS SEQ V1:<br>0.0 V 0.0°  |
| ↑ | SRC 1 NEG SEQ V2:<br>0.0 V 0.0°  |

The metered values are displayed in this menu. The SRC 1 text gets replaced by whatever name was programmed by the user for the associated source (see **SETTINGS > SYSTEM SETUP > SIGNAL SOURCES**).

**9.5.4.4     AUXILIARY VOLTAGE METERING**

**ACTUAL VALUES > METERING > SOURCE SRC 1 > AUXILIARY VOLTAGE**

|                                |   |                         |
|--------------------------------|---|-------------------------|
| ■ AUXILIARY VOLTAGE<br>■ SRC 1 | ⇅ | SRC 1 RMS Vx:<br>0.00 V |
|                                | ↑ | SRC 1 RMS Vx:<br>0.00 V |

The metered values are displayed in this menu. The SRC 1 text gets replaced by whatever name was programmed by the user for the associated source (see **SETTINGS > SYSTEM SETUP > SIGNAL SOURCES**).

**9.5.4.5     POWER METERING**

**ACTUAL VALUES > METERING > SOURCE SRC 1 > POWER**

|                    |   |                                      |
|--------------------|---|--------------------------------------|
| ■ POWER<br>■ SRC 1 | ⇅ | SRC 1 REAL POWER<br>3φ: 0.000 kW     |
|                    | ⇅ | SRC 1 REAL POWER<br>φa: 0.000 kW     |
|                    | ⇅ | SRC 1 REAL POWER<br>φb: 0.000 kW     |
|                    | ⇅ | SRC 1 REAL POWER<br>φc: 0.000 kW     |
|                    | ⇅ | SRC 1 REACTIVE PWR<br>3φ: 0.000 kvar |
|                    | ⇅ | SRC 1 REACTIVE PWR<br>φa: 0.000 kvar |

|   |                                      |
|---|--------------------------------------|
| ⇅ | SRC 1 REACTIVE PWR<br>φb: 0.000 kvar |
| ⇅ | SRC 1 REACTIVE PWR<br>φc: 0.000 kvar |
| ⇅ | SRC 1 APPARENT PWR<br>3φ: 0.000 kVA  |
| ⇅ | SRC 1 APPARENT PWR<br>φa: 0.000 kVA  |
| ⇅ | SRC 1 APPARENT PWR<br>φb: 0.000 kVA  |
| ⇅ | SRC 1 APPARENT PWR<br>φc: 0.000 kVA  |
| ⇅ | SRC 1 POWER FACTOR<br>3φ: 1.000      |
| ⇅ | SRC 1 POWER FACTOR<br>φa: 1.000      |
| ⇅ | SRC 1 POWER FACTOR<br>φb: 1.000      |
| ⇅ | SRC 1 POWER FACTOR<br>φc: 1.000      |

The metered values are displayed in this menu. The SRC 1 text gets replaced by whatever name was programmed by the user for the associated source (see **SETTINGS > SYSTEM SETUP > SIGNAL SOURCES**).

When VTs are configured in wye, the relay calculates power in each phase and three-phase power is measured as:

$$S = V_A \times \hat{I}_A + V_B \times \hat{I}_B + V_C \times \hat{I}_C$$

When VTs are configured in delta, the Product does not calculate power in each phase and three-phase power is measured as:

$$S = V_{AB} \times \hat{I}_A + V_{CB} \times \hat{I}_C$$

where:

- S is the apparent power
- $V_A$ ,  $V_B$ ,  $V_C$ ,  $I_A$ ,  $I_B$ ,  $I_C$  are phase voltage and phase current phasors
- $V_{AB}$  and  $V_{CB}$  are phase-to-phase voltage phasors
- $\hat{I}$  is the conjugate of I

#### 9.5.4.6 ENERGY METERING

**ACTUAL VALUES > METERING > SOURCE SRC 1 > ENERGY**

|                                        |   |                                   |
|----------------------------------------|---|-----------------------------------|
| <div>■ ENERGY</div> <div>■ SRC 1</div> | ⇔ | SRC 1 POS WATTHOUR:<br>0.000 MWh  |
|                                        | ⇕ | SRC 1 NEG WATTHOUR:<br>0.000 Wh   |
|                                        | ⇕ | SRC 1 POS VARHOUR:<br>0.000 varh  |
|                                        | ↑ | SRC 1 NEG VARHOUR:<br>0.000 mvarh |

The metered values are displayed in this menu. The SRC 1 text gets replaced by whatever name was programmed by the user for the associated source (see **SETTINGS > SYSTEM SETUP > SIGNAL SOURCES**).

Because energy values are accumulated, record them and then reset them immediately prior to changing CT or VT characteristics.

9.5.4.7 FREQUENCY METERING

ACTUAL VALUES > METERING > SOURCE SRC 1 > FREQUENCY

|                                           |   |                              |
|-------------------------------------------|---|------------------------------|
| <div>■ FREQUENCY</div> <div>■ SRC 1</div> | ⇔ | SRC 1 FREQUENCY:<br>0.000 Hz |
|-------------------------------------------|---|------------------------------|

The metered values are displayed in this menu. The SRC 1 text gets replaced by whatever name was programmed by the user for the associated source (see **SETTINGS > SYSTEM SETUP > SIGNAL SOURCES**).

**SOURCE FREQUENCY** is measured via software-implemented zero-crossing detection of an AC signal. The signal is either a Clarke transformation of three-phase voltages or currents, auxiliary voltage, or ground current as per source configuration (see the **SYSTEM SETUP > POWER SYSTEM** settings). The signal used for frequency estimation is low-pass filtered. The final frequency measurement is passed through a validation filter that eliminates false readings due to signal distortions and transients.

9.5.4.8 CURRENT HARMONICS AND THD METERING

ACTUAL VALUES > METERING > SOURCE SRC 1 > CURRENT HARMONICS


|                                                   |   |                                        |
|---------------------------------------------------|---|----------------------------------------|
| <div>■ CURRENT HARMONICS</div> <div>■ SRC 1</div> | ⇔ | SRC 1 THD Ia: 0.0<br>Ib: 0.0 Ic: 0.0%  |
|                                                   | ⇕ | SRC 1 2ND Ia: 0.0<br>Ib: 0.0 Ic: 0.0%  |
|                                                   | ⇕ | SRC 1 3RD Ia: 0.0<br>Ib: 0.0 Ic: 0.0%  |
|                                                   | ↓ |                                        |
|                                                   | ↑ | SRC 1 25TH Ia: 0.0<br>Ib: 0.0 Ic: 0.0% |

The metered values are displayed in this menu. The SRC 1 text gets replaced by whatever name was programmed by the user for the associated source (see **SETTINGS > SYSTEM SETUP > SIGNAL SOURCES**).

Current harmonics are measured for each source for the total harmonic distortion (THD) and 2nd to 25th harmonics per phase.

#### 9.5.4.9 VOLTAGE HARMONICS AND THD METERING

##### ACTUAL VALUES > METERING > SOURCE SRC 1 > VOLTAGE HARMONICS



The metered values are displayed in this menu. The SRC 1 text gets replaced by whatever name was programmed by the user for the associated source (see **SETTINGS > SYSTEM SETUP > SIGNAL SOURCES**).

This menu displays metered voltage harmonics values. The “SRC 1” text is replaced by the programmed name for the associated source (see the **SETTINGS ðð SYSTEM SETUP ðð SIGNAL SOURCES** menu).

To extract the 2nd to 25th voltage harmonics, each harmonic is computed on a per-phase basis, where:

- $N = 64$  is the number of samples per cycle
- $\omega_0 = 2\pi f$  is the angular frequency based on the system frequency (50 or 60 Hz)
- $k = 1, 2, \dots, N - 1$  is the index over one cycle for the Fast Fourier Transform (FFT)
- $m$  is the last sample number for the sliding window
- $h = 1, 2, \dots, 25$  is the harmonic number

The short-time Fourier transform is applied to the unfiltered signal:

$$F_{\text{real}}(m, h) = \frac{2}{N} \sum_k (f(m-k) \cdot \cos(h \cdot \omega_0 \cdot t(k)))$$

$$F_{\text{imag}}(m, h) = \frac{2}{N} \sum_k (f(m-k) \cdot \sin(h \cdot \omega_0 \cdot t(k)))$$

$$F_{\text{ampl}}(m, h) = \sqrt{F_{\text{real}}(m, h)^2 + F_{\text{imag}}(m, h)^2}$$

The harmonics are a percentage of the fundamental signal obtained as a ratio of harmonic amplitude to fundamental amplitude multiplied by 100%. The total harmonic distortion (THD) is the ratio of the total harmonic content to the fundamental:

$$\text{THD} = \sqrt{F_2^2 + F_3^2 + \dots + F_{25}^2}$$

Voltage harmonics are not available on Product relays configured with the high-impedance fault detection (Hi-Z) feature.

Voltage harmonics are calculated only for Wye connected phase VTs. Ensure that the **SYSTEM SETUP > AC INPUTS > VOLTAGE BANK F5 > PHASE VT <n> CONNECTION** setting is *Wye* to enable voltage harmonics metering.

### 9.5.5 SYNCHROCHECK

**ACTUAL VALUES > METERING > SOURCE SRC 1 > SYNCHROCHECK<n>**

*Note:*  
Only SYNCHROCHECK 1 is shown

|                                               |   |                                          |
|-----------------------------------------------|---|------------------------------------------|
| <div>■ SYNCHROCHECK1</div> <div>■ SRC 1</div> | ⇔ | SYNCHROCHECK 1 DELTA<br>VOLT: 0.000 kV   |
|                                               | ⇕ | SYNCHROCHECK 1 DELTA<br>FREQ: 0.000 Hz   |
|                                               | ⇕ | SYNCHROCHECK 1 DELTA<br>PHASE: 0.0°      |
|                                               | ⇕ | SYNCHROCHECK 1<br>SYNSCP D_PH: 0.0°      |
|                                               | ⇕ | SYNCHROCHECK 1<br>V1 MAG: 0.0 V          |
|                                               | ⇕ | SYNCHROCHECK 1<br>V1 MAG: 0.0 V          |
|                                               | ⇕ | SYNCHROCHECK 1<br>V2 MAG: 0.0 V          |
|                                               | ⇕ | SYNCHROCHECK 1<br>V2 ANG: 0.0°           |
|                                               | ⇕ | SYNCHROCHECK 1 PROJ<br>V2 MAG: 0.0 V     |
|                                               | ⇕ | SYNCHROCHECK 1 PROJ<br>V2 ANG: 0.0°      |
|                                               | ⇕ | SYNCHROCHECK 1 PROJ<br>DELTA PHASE: 0.0° |
|                                               | ↑ | SYNCHROCHECK 1 PROJ<br>SYNSCP D_PH: 0.0° |

If synchrocheck or a setting is disabled, the corresponding actual values menu item does not display.

### 9.5.6 TRACKING FREQUENCY

**ACTUAL VALUES > METERING > TRACKING FREQUENCY**

|                                                    |   |                                  |
|----------------------------------------------------|---|----------------------------------|
| <div>■ TRACKING FREQUENCY</div> <div>■ SRC 1</div> | ⇔ | TRACKING FREQUENCY:<br>60.00 Hz  |
|                                                    | ⇕ | ACTIVE FREQ AND PHS REF:<br>MAIN |
|                                                    | ⇕ | MAIN REF FREQUENCY:<br>60.00 Hz  |
|                                                    | ↑ | ALT REF FREQUENCY:<br>60.00 Hz   |

The Tracking Frequency and the Active Frequency and Phase Reference are metered as shown here. The tracking frequency is calculated from the signals defined in the Active Frequency and Phase Reference. Note that based on the signal availability and the settings defined in the Main and Alternate Frequency and Phase Reference, the Active Frequency and Phase Reference might be switched between main and alternate frequency reference in runtime.

The frequency calculated in main and alternate reference respectively are also metered as shown here. They will be displayed as 0 if the signal in this reference is lost or it's not configured.

9.5.7 FREQUENCY RATE OF CHANGE

ACTUAL VALUES > METERING > FREQUENCY RATE OF CHANGE <n>

Note:  
Only FREQUENCY RATE OF CHANGE 1 is shown

|                                                      |   |                                         |
|------------------------------------------------------|---|-----------------------------------------|
| <div>■ FREQUENCY RATE</div> <div>■ OF CHANGE 1</div> | ⇔ | FREQUENCY RATE OF<br>CHANGE1: 0.00 Hz/s |
|------------------------------------------------------|---|-----------------------------------------|

The metered frequency rate of change for the frequency rate of change elements is shown here.

9.5.8 FREQUENCY OUT-OF-BAND ACCUMULATION

ACTUAL VALUES > METERING > FREQUENCY OOB ACCUMULATION

|                                                      |   |                                              |            |
|------------------------------------------------------|---|----------------------------------------------|------------|
| <div>■ FREQUENCY OOB</div> <div>■ ACCUMULATION</div> | ⇔ | FREQUENCY OOB BAND <n><br>ACCUMULATION: 0.0% | n = 1 to 7 |
|------------------------------------------------------|---|----------------------------------------------|------------|

The frequency out-of-band accumulation metered values are displayed to the nearest percent as a ratio of the present accumulation to the user-specified limit. Note that this value can be greater than 100%.

9.5.9 FLEXELEMENTS

ACTUAL VALUES > METERING > FLEXELEMENTS □ FLEXELEMENT 1(16)

Note:  
Only FLEXELEMENT 1 is shown

■ DIRECTIONAL  
■ POWER 1



FLEXELEMENT 1  
OpSig: 0.000

The operating signals for the FlexElements are displayed in pu values using the following definitions of the base units.

| Base unit                                                                                                                                        | Description                                                                                                                                                      | Applicable models                           |
|--------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------|
| 87L SIGNALS<br>(Local IA Mag, IB, and IC)<br>(Diff Curr IA Mag, IB, and IC)<br>(Terminal 1 IA Mag, IB, and IC)<br>(Terminal 2 IA Mag, IB and IC) | IBASE = maximum primary RMS value of the +IN and –IN inputs<br>(CT primary for source currents, and 87L source primary current for line differential currents)   | L30, L90                                    |
| 87L SIGNALS<br>(Op Square Curr IA, IB, and IC)<br>(Rest Square Curr IA, IB, and IC)                                                              | BASE = Squared CT secondary of the 87L source                                                                                                                    | L30, L90                                    |
| BREAKER ACC ARCING AMPS<br>(Brk X Acc Arc Amp A, B, and C)                                                                                       | BASE = 2000 kA <sup>2</sup> × cycle                                                                                                                              | All but B90, DC30, N60                      |
| BREAKER ARCING AMPS<br>(Brk X Arc Amp A, B, and C)                                                                                               | BASE = 1 kA <sup>2</sup> × cycle                                                                                                                                 | All but B90, DC30, N60                      |
| BUS DIFFERENTIAL<br>RESTRAINING CURRENT<br>(Bus Diff Mag)                                                                                        | IBASE = maximum primary RMS value of the +IN and –IN inputs<br>(CT primary for source currents, and bus reference primary current for bus differential currents) | B30                                         |
| BUS DIFFERENTIAL<br>RESTRAINING CURRENT<br>(Bus Rest Mag)                                                                                        | IBASE = maximum primary RMS value of the +IN and –IN inputs<br>(CT primary for source currents, and bus reference primary current for bus differential currents) | B30                                         |
| CURRENT UNBALANCE<br>(Amp Unbalance)                                                                                                             | BASE = 100%                                                                                                                                                      | M60                                         |
| DCmA                                                                                                                                             | BASE = maximum value of the DCMA INPUT MAX setting for the two transducers configured under the +IN and –IN inputs.                                              | All models                                  |
| FAULT LOCATION                                                                                                                                   | BASE = Line Length as specified in Fault Report                                                                                                                  | C60, C95, D30, D60, F35, F60, L30, L60, L90 |
| FIELD CURRENT                                                                                                                                    | IBASE = maximum value setting defined for the specific transducer input configured                                                                               | G60                                         |
| FIELD GROUND CURRENT                                                                                                                             | IBASE = 5 mA                                                                                                                                                     | G60                                         |
| FIELD GROUND FAULT<br>LOCATION                                                                                                                   | BASE = 100%                                                                                                                                                      | G60                                         |
| FIELD GROUND INJECTED<br>VOLTAGE                                                                                                                 | VBASE = 15 V                                                                                                                                                     | G60                                         |
| FIELD GROUND RESISTANCE                                                                                                                          | RBASE = 250 KΩ                                                                                                                                                   | G60                                         |
| FIELD VOLTAGE                                                                                                                                    | VBASE = 500 V                                                                                                                                                    | G60                                         |
| FREQUENCY                                                                                                                                        | fBASE = 1 Hz                                                                                                                                                     | All models                                  |
| FREQUENCY RATE OF<br>CHANGE                                                                                                                      | df/dtBASE = 1 Hz/s                                                                                                                                               | D30, D60, F60, G30, G60, L30, L90, N60, T60 |
| PHASE ANGLE                                                                                                                                      | jBASE = 360 degrees (see the UR angle referencing convention)                                                                                                    | All models                                  |
| POWER FACTOR                                                                                                                                     | PFBASE = 1.00                                                                                                                                                    | All models                                  |
| RTDs                                                                                                                                             | BASE = 100°C                                                                                                                                                     | All models                                  |

| Base unit                                                                             | Description                                                                                                                                                                      | Applicable models                                               |
|---------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------|
| SENSITIVE DIR POWER<br>(Sns Dir Power)                                                | PBASE = maximum value of $3 \times VBASE \times IBASE$ for the +IN and –IN inputs of the sources configured for the sensitive power directional element(s).                      | C60, C95, D60, G30, G60, L90, M60, N60, T60                     |
| SOURCE CURRENT                                                                        | IBASE = maximum nominal primary RMS value of the +IN and –IN inputs                                                                                                              | All models                                                      |
| SOURCE ENERGY<br>(Positive and Negative Watthours,<br>Positive and Negative Varhours) | EBASE = 10000 MWh or MVAh, respectively                                                                                                                                          | B30, C60, C95, D60, F35, F60, G30, G60, L90, M60, N60, T60      |
| SOURCE POWER                                                                          | PBASE = maximum value of $VBASE \times IBASE$ for the +IN and –IN inputs                                                                                                         | All models                                                      |
| SOURCE THD & HARMONICS                                                                | BASE = 1%                                                                                                                                                                        | C70, D60, F35, F60, G30, G60, L90, N60, T60                     |
| SOURCE VOLTAGE                                                                        | VBASE = maximum nominal primary RMS value of the +IN and –IN inputs                                                                                                              | All models                                                      |
| STATOR DIFFERENTIAL<br>CURRENT<br>(Stator Diff Iar, Ibr, and Icr)                     | IBASE = maximum primary RMS value of the +IN and –IN inputs<br>(CT primary for source currents, and bus reference primary current for bus differential currents)                 | G60, M60                                                        |
| STATOR GROUND 3RD<br>HARMONIC VOLTAGES<br>(Stator Gnd Vn/V0 3rd)                      | VBASE = Primary auxiliary voltage of the STATOR GROUND SOURCE                                                                                                                    | G30, G60                                                        |
| STATOR GROUND<br>RESISTANCE                                                           | RBASE = 10 K $\Omega$                                                                                                                                                            | G60                                                             |
| STATOR GROUND SUB-<br>HARMONIC VOLTAGE                                                | VBASE = nominal secondary voltage of auxiliary VT for the stator ground source                                                                                                   | G60                                                             |
| STATOR GROUND SUB-<br>HARMONIC CURRENT                                                | IBASE = ground CT primary current of stator ground source                                                                                                                        | G60                                                             |
| STATOR RESTRAINING<br>CURRENT<br>(Stator Diff Iad, Ibd, and Icd)                      | IBASE = maximum primary RMS value of the +IN and –IN inputs<br>(CT primary for source currents, and bus reference primary current for bus differential currents)                 | G60, M60                                                        |
| SYNCHROCHECK<br>(Max Delta Volts)                                                     | VBASE = maximum primary RMS value of all the sources related to the +IN and –IN inputs                                                                                           | B30, C60, C95, D30, D60, F60, G30, G60, L30, L60, L90, N60, T60 |
| THERMAL MODEL<br>(Model Capacity Used)<br>(Model Motor Unbalance)                     | BASE = 100%                                                                                                                                                                      | M60                                                             |
| THERMAL MODEL<br>(Model Lockout Time)                                                 | BASE = 10 minutes                                                                                                                                                                | M60                                                             |
| THERMAL MODEL<br>(Thermal Model Load)<br>(Biased Motor Load)                          | BASE = 1.00 pu of FLA                                                                                                                                                            | M60                                                             |
| THERMAL MODEL<br>(Trip Time on Overload)                                              | BASE = 10 seconds                                                                                                                                                                | M60                                                             |
| VOLTS PER HERTZ                                                                       | BASE = 1.00 pu                                                                                                                                                                   | G30, G60, L90, T60                                              |
| XFMR DIFFERENTIAL<br>CURRENT<br>(Xfmr Iad, Ibd, and Icd Mag)                          | IBASE = maximum primary RMS value of the +IN and –IN inputs<br>(CT primary for source currents, and transformer reference primary current for transformer differential currents) | G30, T35, T60                                                   |



| Base unit                                                                                                      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Applicable models            |
|----------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| XFMR DIFFERENTIAL HARMONIC CONTENT<br>(Xfmr Harm2 Iad, Ibd, and Icd Mag)<br>(Xfmr Harm5 Iad, Ibd, and Icd Mag) | BASE = 100%                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | G30, T35, T60                |
| XFMR RESTRAINING CURRENT<br>(Xfmr Iar, Ibr, and Icr Mag)                                                       | IBASE = maximum primary RMS value of the +IN and -IN inputs<br>(CT primary for source currents, and transformer reference primary current for transformer differential currents)                                                                                                                                                                                                                                                                                                                                                                                                                                                   | G30, T35, T60                |
| ZBASE                                                                                                          | ZBASE = PhaseVTSecondary / PhaseCTSecondary, where PhaseVTSecondary and PhaseCTSecondary are the secondary nominal voltage and the secondary nominal current of the distance source. In case multiple CT inputs are summed as one source current and mapped as the distance source, use the PhaseCTSecondary value from the CT with the highest primary nominal current.<br>Distance source is specified in setting under <b>SETTINGS &gt; GROUPED ELEMENTS &gt; SETTING GROUP 1(6) &gt; DISTANCE</b> .<br>PhaseVTSecondary and PhaseCTSecondary are specified in setting under <b>SETTINGS &gt; SYSTEM SETUP &gt; AC INPUTS</b> . | D30, D60, G60, L60, L90, T60 |

### 9.5.10 RXGOOSE ANALOGS

#### ACTUAL VALUES > METERING > RxGOOSE Analogs

|                                                                            |   |                                   |             |
|----------------------------------------------------------------------------|---|-----------------------------------|-------------|
| <ul style="list-style-type: none"> <li>RxGOOSE</li> <li>Analogs</li> </ul> | ⇔ | RxGOOSE Analog <n><br>0.000LEVEL: | n = 1 to 32 |
|                                                                            | ↑ | RxGOOSE An1 ExpnSt:<br>Off        |             |

*Note:*

*This menu displays when the product includes an IEC 61850 software option.*

The RxGOOSE Analog values display in this menu. The RxGOOSE Analog values are received via IEC 61850 GOOSE messages sent from other devices.

### 9.5.11 SENSITIVE DIRECTIONAL POWER

#### ACTUAL VALUES > METERING > SOURCE SRC 1 > SENSITIVE DIRECTIONAL POWER > DIRECTIONAL POWER 1(2)

*Note:*

*Only DIRECTIONAL POWER 1 is shown*

|                                                                                |   |                                   |
|--------------------------------------------------------------------------------|---|-----------------------------------|
| <ul style="list-style-type: none"> <li>DIRECTIONAL</li> <li>POWER 1</li> </ul> | ⇔ | DIRECTIONAL POWER 1<br>3Φ: 0.0 kW |
|--------------------------------------------------------------------------------|---|-----------------------------------|

The effective operating quantities of the sensitive directional power elements display here. The display is useful to calibrate the feature by compensating the angular errors of the CTs and VTs with the use of the **RCA** and **CALIBRATION** settings.

### 9.5.12 STATOR GROUND

#### ACTUAL VALUES > METERING > STATOR GROUND

|                                                      |   |                                       |
|------------------------------------------------------|---|---------------------------------------|
| <div> <div>■ STATOR GROUND</div> <div>■</div> </div> | ⇔ | STATOR GND 3RD HARM<br>VN: 0.000 V    |
|                                                      | ⇕ | STATOR GND 3RD HARM<br>VN+V0: 0.000 V |
|                                                      | ↑ | STATOR GND 3RD HARM<br>V0: 0.000 V    |

Magnitudes of the third harmonic components of the machine neutral point voltage (VN), the zero-sequence voltage at the machine terminals (V0), and in the vector sum of the neutral point voltage and zero-sequence voltage (VN + V0) in primary volts are available for display. The values are calculated for a signal source specified under the **STATOR GROUND** settings menu.

These readings can be useful when selecting a pickup and supervision setting for the third harmonic neutral undervoltage protection element.

### 9.5.13 VOLTS PER HERTZ

#### ACTUAL VALUES > METERING > VOLTS PER HERTZ 1(4)

*Note:*  
Only VOLTS PER HERTZ 1 is shown

|                                                          |   |                                |
|----------------------------------------------------------|---|--------------------------------|
| <div> <div>■ VOLTS PER HERTZ 1</div> <div>■</div> </div> | ⇔ | VOLTS PER HERTZ 1:<br>0.000 pu |
|----------------------------------------------------------|---|--------------------------------|

This menu displays the data for volts per hertz.

### 9.5.14 RESTRICTED GROUND FAULT

#### ACTUAL VALUES > METERING > RESTRICTED GROUND FAULT CURRENTS > RESTRICTED GROUND FAULT <n>

*Only RGF 1 is shown*

|                                                                  |   |                              |
|------------------------------------------------------------------|---|------------------------------|
| <div> <div>■ RESTRICTED</div> <div>■ GROUND FAULT 1</div> </div> | ⇔ | RGF 1 DIFF Igd:<br>0.000 kA  |
|                                                                  | ↑ | RGF 1 RESTR Igr:<br>0.000 kA |

This menu displays the differential and restraint current values for the restricted ground fault element.

### 9.5.15 TRANSDUCER INPUTS AND OUTPUTS

**ACTUAL VALUES > METERING > TRANSDUCER I/O DCMA INPUTS** □ **DCMA INPUT <n>**

|                       |   |                            |
|-----------------------|---|----------------------------|
| ■ DCMA INPUT <n><br>■ | ⇔ | DCMA INPUT <n><br>0.000 mA |
|-----------------------|---|----------------------------|

Actual values for each DCmA input channel that is enabled are displayed with the top line as the programmed channel ID and the bottom line as the value followed by the programmed units.

**ACTUAL VALUES > METERING > TRANSDUCER I/O RTD INPUTS > RTD INPUT <n>**

|                      |   |                         |
|----------------------|---|-------------------------|
| ■ RTD INPUT <n><br>■ | ⇔ | RTD INPUT <n><br>-50 °C |
|----------------------|---|-------------------------|

Actual values for each RTD input channel that is enabled are displayed with the top line as the programmed channel ID and the bottom line as the value.

### 9.5.16 HARMONIC DETECTION

**ACTUAL VALUES > METERING > HARMONIC DETECTION** □ **HARMONIC DETECTOR <n>**

*Note:*  
Only HARMONIC DETECTOR 1 is shown

|                       |   |                             |
|-----------------------|---|-----------------------------|
| ■ HARMONIC DET 1<br>■ | ⇔ | HARMONIC DET 1<br>A: 0.0%   |
|                       | ⇕ | HARMONIC DET 1<br>B: 0.0%   |
|                       | ⇕ | HARMONIC DET 1<br>C: 0.0%   |
|                       | ⇕ | HARMONIC DET 1<br>AVG: 0.0% |
|                       | ↑ | HARMONIC DET 1<br>G: 0.0%   |

### 9.5.17 STATION BATTERY VOLTAGE

**ACTUAL VALUES > METERING > STATION BATTERY VOLTAGE**

|                                  |   |                              |
|----------------------------------|---|------------------------------|
| ■ STATION BATTERY<br>■ DC VOLTGE | ⇔ | BATTERY DC VOLT1: :<br>0 Vdc |
|                                  | ↑ | BATTERY DC VOLT2:<br>0 Vdc   |

9.5.18      **MULTI-RANGE SIGNAL OSCILLATION DETECTOR (MSOD)**

**ACTUAL VALUES > METERING > MUTLI-RANGE SIGNAL OSCILL DETECTOR 1(2)**

*Note:*  
*Only MSOD 1 is shown*

|                                                                |   |                       |
|----------------------------------------------------------------|---|-----------------------|
| <div>■ MULTI-RANGE SIGNAL</div> <div>■ OSCILL DETECTOR 1</div> | ↔ | Freq_osc:<br>0.00 Hz  |
|                                                                | ⇅ | Mag_osc:<br>0.00 pu   |
|                                                                | ⇅ | Phase_osc:<br>0.0 DEG |
|                                                                | ⇅ | DampR_osc:<br>0.0 %   |

## 9.6 REMOTE RESOURCES

### Field Unit

**ACTUAL VALUES > REMOTE RESOURCES > FIELD UNIT <slot and terminal>**


|                                          |   |                                         |                          |
|------------------------------------------|---|-----------------------------------------|--------------------------|
| <div>■ FIELD UNIT U1<br/>■ ID: U 1</div> | ⇔ | FIELD UNIT STATUS:<br>DISABLED          | Range: Disabled, Enabled |
|                                          | ⇕ | BRICK SERIAL NUMBER:                    |                          |
|                                          | ⇕ | BRICK ORDER CODE:<br>CC-55              |                          |
|                                          | ⇕ | BRICK DIGITAL CORE:<br>0                |                          |
|                                          | ⇕ | LOCAL TRANSCEIVER:<br>TX POWER: 0.0 dBm |                          |
|                                          | ⇕ | BRICK TRANSCEIVER<br>RX POWER: 0.0 dBm  |                          |
|                                          | ⇕ | BRICK TRANSCEIVER<br>TX POWER: 0.0 dBm  |                          |
|                                          | ↑ | LOCAL TRANSCEIVER<br>RX POWER: 0.0 dBm  |                          |

This menu displays when using a Process Bus Module for a HardFiber Brick.

## 9.7 PROCESS BUS MODULE

### 9.7.1 GENERAL STATUS

**ACTUAL VALUES > PB MODULE > GENERAL STATUS**




*Note:*  
These menus display when the product includes a Process Bus Module with order code 85, 86, or 87. The actual values display on the front panel and software. Additional values display in a web browser; enter the IP address of the relay and access the Process Card Menu.

Ports applicable to the Process Bus Module display. The example shows all eight ports.  
The information also displays in a web browser under **Process Card Menu > Process Card Port Information**.


### 9.7.2 RXSV STATUS

**ACTUAL VALUES > PB MODULE > RxSV Status**



**ACTUAL VALUES > PB MODULE > RxSV Status > RxSV<n>**

*Note:*  
Only RxSV 1 is shown



|   |                                      |                          |
|---|--------------------------------------|--------------------------|
| ⇅ | SV 1 SynchSrcID:<br>0000000000000000 | Range: Any 8-octet value |
| ⇅ | SV 1 Sim Flag:<br>Off                | Range: Off, On           |
| ⇅ | SV 1 Delay:<br>0 $\mu$ s             | Range: $\mu$ s           |
| ⇅ | SV 1 Missed Frames:<br>No            | Range: Yes, No           |
| ⇅ | SV 1 Ch 1 Quality:<br>0              | Range: 00000000000000    |
| ↓ |                                      |                          |
| ↑ | SV 1 Ch<n> Quality:<br>0             |                          |

Additional actual values for sampled values display in a web browser. Enter the IP address of the relay and access **Process Card Menu > Process Card Diagnostics**, for which the following fields are explained.

All SV diagnostics are volatile and are cleared when power is cycled.

**Sample Value processing delay...Min Delay**

The minimum time delay in received sample values. The accuracy threshold of this diagnostics is within 1/8 of a power system cycle.

**Sample Value processing delay...Max Delay**

The maximum time delay in received sample values. The accuracy threshold of this diagnostics is within 1/8 of a power system cycle.

**Sample Value processing delay...Avg Delay**

he average time delay for received sample values. A delay up to about 1.5 milliseconds (1500  $\mu$ sec) is normal. The accuracy threshold of this diagnostics is within 1/8 of a power system cycle.

**SV Delay Alarm Counter**

The number of times that sampled values from a configured SV stream are delayed for more than the Settings > Process Bus Module > General > SV Delay Alarm setting. Counters wrap around when they reach 4294967295.

**Sample Estimation Counter**

The number of times that the relay used an internal estimation algorithm to substitute a missing sample value. Counters wrap around when they reach 4294967295.

**Stream Status**

The status of a configured SV stream. If the Settings > Process Bus Module > SV Stream Config > SV Stream setting is set to Disabled, this value is shown as Disabled. If the setting is set to IEC 61850-9-2LE or IEC 61869-9 and received sample values are accepted by the relay, this value is shown as Online. If received sample values are rejected, or sample values are lost (frames not received), stream status changes to Offline.

### Latest Unacceptable Quality

Time stamp of the latest sample value with unacceptable quality, in any data item in a dataset. This time stamp has 1/8 of a power system cycle accuracy threshold.

### Latest Sim Bit Change

The time stamp of latest change in simulation bit status of the received RxSV# messages. This time stamp has 1/8 of a power system cycle accuracy threshold.

### SmpSync Latest Update Time

The time stamp of the latest sample value for which the SmpSync attribute was different from the previous samples. This value determines when the time source that sample value stream is synchronized to has changed. This time stamp has 1/8 of a power system cycle accuracy threshold.

### SmpSync Changes in Past 24hrs

The number of times the SmpSync attribute in the sample value messages from this stream has changed in the past 24 hours. This counter is updated every hour. Counters wrap around when they reach 4294967295. The accuracy of this metric is 1.5 hours over a 24-hour period.

### Sample Estimate Fail-Last 10s

The number of times that three or more out of five consecutive samples has been lost in the last 10 seconds. This counter is updated every second. Counters wrap around when they reach 4294967295.

### Sample Value Trouble Counter

The number of times that the SV Stream Trouble On minor self-test error is detected by the Process Bus Module. Counters wrap around when they reach 4294967295.

## 9.7.3 CLOCK SYNCHRONIZING

### ACTUAL VALUES > PB MODULE > PBM PTP

|                                   |   |                                     |                                                                                                       |
|-----------------------------------|---|-------------------------------------|-------------------------------------------------------------------------------------------------------|
| <div>■ PBM PTP</div> <div>■</div> | ↔ | Clock Sync Source:<br>None          | Range: CPU Clock, PBM PTP Clock, PBM Internal Clock, None                                             |
|                                   | ↕ | Grandmaster ID:<br>0000000000000000 | Range: any 8 octet value                                                                              |
|                                   | ↕ | Accuracy:<br>0 ns                   | Range: 0 to 999,999,999 ns                                                                            |
|                                   | ↕ | PBM SW1 PTP State                   | Range: Disabled, No Signal, Calibrating, Synch'd (INV UTCOFF), Synchronized, Qualifying, idle, master |
|                                   | ↑ | PBM SW2 PTP State                   | Range: Disabled, No Signal, Calibrating, Synch'd (INV UTCOFF), Synchronized, Qualifying, idle, master |

*Note:*  
Additional actual values for time are available under **Actual Values > Status > Real Time Clock Synchronizing**.



## Clock Sync Source

This is the time synchronizing source that the UR Process Bus Module is using at present. It displays CPU Clock when the 1 pulse per second (PPS) signal from the main CPU drives the Process Bus Module clock. It displays None when the Process Bus Module clock free runs. It displays SV Sync Stream when the Process Bus Module clock is synchronized to the configured reference stream. It displays PBM Clock when the Process Bus Module clock is synchronized to a PTP grandmaster clock. The time synchronizing source itself is set using **SETTINGS > PRODUCT SETUP > REAL TIME CLOCK** and **SETTINGS > PROCESS BUS MODULE > PBM PTP > PTP FUNCTION**. If the latter is not set, then the Sync Source displays None even when the **REAL TIME CLOCK** setting is configured.

## Grandmaster ID

This is the grandmaster clock (grandmasterIdentity) of the present PTP network if any. When the UR Process Bus Module is not using any PTP grandmaster, this actual value is set to the ID of that relay and the relay is acting as grandmaster in the network. The ID code is specified by PTP to be globally unique, so one can always know which clock is grandmaster in a system with multiple grandmaster-capable clocks.

## Accuracy

This is the estimated time error based on the clockAccuracy information embedded in the received time signal. This actual value indicates the grandmaster clock accuracy. The clockAccuracy enumeration information received from the grandmaster is translated into nanoseconds as specified in the following table. The value 999,999,999 indicates that the magnitude of the estimated error is one second or more, or that the error cannot be estimated. The value 999,999,999 is used if the clockAccuracy received from grandmaster is in the ranges: 00 - 1F and 2F - FF. If the relay is the grandmaster, the actual value indicates the estimated accuracy of the local clock and the same information is embedded in the transmitted PTP messages. See `defaultDS.clockQuality.clockAccuracy` for more information.

| Value (hex) | Specification                             |
|-------------|-------------------------------------------|
| 00-1F       | Reserved                                  |
| 20          | The time is accurate to within 25 ns      |
| 21          | The time is accurate to within 100 ns     |
| 22          | The time is accurate to within 250 ns     |
| 23          | The time is accurate to within 1 µs       |
| 24          | The time is accurate to within 2.5 µs     |
| 25          | The time is accurate to within 10 µs      |
| 26          | The time is accurate to within 25 µs      |
| 27          | The time is accurate to within 100 µs     |
| 28          | The time is accurate to within 250 µs     |
| 29          | The time is accurate to within 1 ms       |
| 2A          | The time is accurate to within 2.5 ms     |
| 2B          | The time is accurate to within 10 ms      |
| 2C          | The time is accurate to within 25 ms      |
| 2D          | The time is accurate to within 100 ms     |
| 2E          | The time is accurate to within 250 ms     |
| 2F          | The time is accurate to within 1 s        |
| 30          | The time is accurate to within 10 s       |
| 31          | The time is accurate to greater than 10 s |
| 32-7F       | Reserved                                  |
| 80-FD       | For use by alternate PTP profiles         |
| FE          | Unknown                                   |

| Value (hex) | Specification |
|-------------|---------------|
| FF          | Reserved      |

### PBM SW1 PTP State and PBM SW2 PTP State

These are actual values that indicate the PTP clock state at switch level. The possible values are as follows:

- *DISABLED*: The PTP function setting is disabled. With all other values, the PTP function is enabled.
- *NO SIGNAL*: No signal from an active master has been found.
- *CALIBRATING*: An active master has been selected but is not yet locked in.
- *SYNCHRONIZED*: The signal is synchronized.
- *SYNCH'D (INV UTCOff)*: This value is shown if the signal is synchronized to the PTP master but with **currentUtcOffsetValid** = False
- *QUALIFYING*: This value is shown if the local clock is the better clock, but it is waiting for the qualification time to expire
- *IDLE*: The port is neither slave nor master and is in a PASSIVE state.
- *MASTER*: The port is acting as the master.

### Explanation of ports

The UR Process bus module has a total of 8 ports. They are implemented using 2 switches (4 ports on each switch). Switch1 includes port 1a, 1b, 2a and 2b, and Switch 2 includes 3a, 3b, 4a and 4b. The UR process bus module implements a hybrid PTP clock. Both the switches implement a stateless transparent clock between the 4 ports of the switch, and on top an ordinary clock is implemented between the two switches. So, the PTP states are not applicable at port level, but the states are maintained at switch level. Enabled ports on each switch operate in stateless transparent clock mode and PTP messages are forwarded between the ports of that switch.

At switch level, each switch acts as an independent ordinary clock and no messages are forwarded between the switches. A BMCA is run between both the ordinary clocks of the switches, and the selected best master is synchronized to the PBM local clock. If grandmasters are available on both switches, both the switches can be in a SLAVE state. However internally, the PBM runs BMCA on both switches and selects one as the best master. The Grandmaster ID indicates the selected master. In master-slave mode, if the switch state is master, the time is encoded from the PBM local clock, and messages are sent as if the switch is a grandmaster.

The enabled transceiver ports on the PBM module operate in stateless transparent clock mode. For this reason we recommend setting the **Network Config** setting to match the network topology. This will avoid unnecessary data storms. For example, if the PRP network has multiple relays connected on a PRP LAN and if its **Process Bus Module -> General -> Network Config** setting is configured as *Independent*, PTP messages other than the PDelay message are forwarded between the connected ports, which can create PTP Data storm.

## 9.7.4 PRP

### ACTUAL VALUES > PB Module > PBM PRP Status

|                                                       |   |                           |                |
|-------------------------------------------------------|---|---------------------------|----------------|
| <div> <div>■ PBM PRP Status</div> <div>■</div> </div> | ↔ | Total Rx Port A:<br>0     | Range: 0 to 4G |
|                                                       | ⇕ | Total Rx Port B:<br>0     | Range: 0 to 4G |
|                                                       | ⇕ | Total Errors Port A:<br>0 | Range: 0 to 4G |

|   |                           |                |
|---|---------------------------|----------------|
| ⇅ | Total Errors Port B:<br>0 | Range: 0 to 4G |
| ⇅ | Mismatches Port A:<br>0   | Range: 0 to 4G |
| ⇅ | Mismatches Port B:<br>0   | Range: 0 to 4G |
| ⇅ | FER Port A:<br>0          | Range: 0 to 4G |
|   | FER Port B:<br>0          | Range: 0 to 4G |
|   | Link Active Port A:<br>No | Range: Yes, No |
| ↑ | Link Active Port B:<br>No | Range: Yes, No |

**Total Rx Port A**

Counter for total messages received (either from DANPs or from SANs) on Port A

**Total Rx Port B**

Counter for total messages received (either from DANPs or from SANs) on Port B

**Total Errors Port A**

Counter for total messages received with an error (bad port code, frame length too short) on Port A

**Total Errors Port B**

Counter for total messages received with an error (bad port code, frame length too short) on Port B

**Mismatches Port A**

Counter for total messages received with an error on Port A (PRP frame, but port received through and LAN id in the frame don't match)

**Mismatches Port B**

Counter for total messages received with an error on Port B (PRP frame, but port received through and LAN id in the frame don't match),

**FER Port A**

Frame Error Rate is a counter which counts Erroneous messages on channel A for every 1000 messages forwarded to Application.

**FER Port B**

Frame Error Rate is a counter which counts Erroneous messages on channel B for every 1000 messages forwarded to Application.

### Link Active Port A

If true, link is up and channel A is receiving telegrams within a specified time interval (5 s).

### Link Active Port B

If true, link is up and channel B is receiving telegrams within a specified time interval (5 s).

Actual values for the Parallel Redundancy Protocol (PRP) display in a web browser. Enter the IP address of the relay and access the **Process Card Menu > Process Card PRP Statistics**, which displays only when PRP is used.

- PRP Status — PRP is Enabled if Settings > Process Bus Module > General > Network Config is set to PRP, else it is Disabled.
- Total Rx Port A — Counter indicating the number of frames received on port A, for example port 1a.
- Total Rx Port B — Counter indicating the number of frames received on port B, for example port 1b.
- Total Tx Port A — Counter indicating the number of frames sent on port A, for example port 1a.
- Total Tx Port B — Counter indicating the number of frames sent on port B, for example port 1b.
- Mismatches Port A — Counter indicating the number of erroneous frames received on port A, for example port 1a.
- Mismatches Port B — Counter indicating the number of erroneous frames received on port B, for example port 1b.
- Duplicates Removed Port A — Number of PRP duplicate frames received from port A and discarded, for example port 1a.
- Duplicates Removed Port B — Number of PRP duplicate frames received from port B and discarded, for example port 1b.

---

### 9.7.5 HSR

Actual values for High-Availability Seamless Redundancy (HSR) display in a web browser. Enter the IP address of the relay and access the **Process Card Menu > Process Card HSR Statistics**, which displays only when HSR is used.

- HSR1 Status — Status of the first ring, either enabled or disabled. Enabled when redundancy is set to HSR or Dual-HSR.
- HSR2 Status — Status of the second ring, either enabled or disabled. Enabled when redundancy is set to HSR or Dual-HSR.
- Total Rx Port A — Counter indicating the number of frames received on port A, for example port 1a.
- Total Rx Port B — Counter indicating the number of frames received on port B for example port 1b.
- Total Tx Port A — Counter indicating the number of frames sent on port A, for example port 1a.
- Total Tx Port B — Counter indicating the number of frames sent on port B, for example port 1b.
- Duplicates Removed Port A — Number of HSR duplicate frames received from port A and discarded, for example port 1a.
- Duplicates Removed Port B — Number of HSR duplicate frames received from port B and discarded, for example port 1b.

## 9.8 RECORDS

### 9.8.1 USER PROGRAMMABLE FAULT REPORTS

**ACTUAL VALUES > RECORDS > USER PROGRAMMABLE FAULT REPORTS**

|                                                           |   |                                           |
|-----------------------------------------------------------|---|-------------------------------------------|
| <div>■ USER PROGRAMMABLE</div> <div>■ FAULT REPORTS</div> | ⇔ | NEWEST RECORD<br>NUMBER: 0                |
|                                                           | ⇅ | LAST CLEARED DATE:<br>2020/08/11 14:23:57 |
|                                                           | ↑ | LAST REPORT DATE:<br>2020/10/09 08:25:27  |

This menu displays the user-programmable fault report actual values. See the User Programmable Fault Report section for information on this feature.

### 9.8.2 EVENT RECORDS

#### 9.8.2.1 ENHANCED AND BASIC FRONT PANELS

**ACTUAL VALUES > RECORDS > EVENT RECORDS**


|                                         |   |                                               |                                                                                                       |
|-----------------------------------------|---|-----------------------------------------------|-------------------------------------------------------------------------------------------------------|
| <div>■ EVENT RECORDS</div> <div>■</div> | ⇔ | EVENT: <latest event number><br><Event cause> | Click right arrow to replace Event cause with Event date and time stamp. Click left arrow to go back. |
|                                         | ⇅ | ... up to 1024 events                         |                                                                                                       |
|                                         | ↑ | EVENT: <oldest event number><br><Event cause> |                                                                                                       |

The event records menu shows the contextual data associated with up to the last 1024 events, listed in chronological order from most recent to oldest. When all 1024 event records have been filled, the oldest record is removed as a new record is added. Each event record shows the event identifier/sequence number, cause, and date/time stamp associated with the event trigger. See the **COMMANDS > CLEAR RECORDS** menu for clearing event records.

Only major output operands generate events, not every operand. Elements that assert output per phase, for example, log operating phase output only without asserting the common three-phase operand event.

See also the system log (syslog) information in the previous chapter.

The event records are viewable in the software and in a web browser. The figure shows the event records in the software.



**Figure 360: Event records viewed in EnerVista software**

To view events in a web browser, enter the IP address of the device.

To download an oscillography waveform, click the Oscillography icon in the Data column (not shown in the figure).

### 9.8.2.2 GRAPHICAL FRONT PANEL

To display the event records page, press the **Home** pushbutton then the **Event Record** Tab pushbutton.

The newest event is always at the top.

Up and Down pushbuttons move the event selector up and down. When the selector is at the bottom of the display, the Down pushbutton also scrolls the page, and similarly when the active selector is at the top of the display the Up pushbutton scroll the page.

A selected event is highlighted in yellow and becomes active by pressing the Up or Down pushbutton.

There are two event markers, one green, the other cyan. To mark some an event, use the Up and Down pushbuttons to select it (highlight in yellow), then press the green or cyan Mark Event Tab pushbutton. The mark color hides the selector until the selector is moved. A field at the top of the page shows the interval between the two marks.

| \\Event Record           |                           | 29-Jun-17 11:56:33 AM   |                    |
|--------------------------|---------------------------|-------------------------|--------------------|
| Most recent event number |                           | 38                      | Time between marks |
|                          |                           | 0d 0h : 0m : 35.012364s |                    |
| Event ID                 | Date/Time                 | Cause                   |                    |
| 38                       | 29-Jun-17 10:17:56.117582 | WRONG TRANSCEIVER       |                    |
| 37                       | 29-Jun-17 10:17:56.117582 | POWER ON                |                    |
| 36                       | 29-Jun-17 10:17:21.105218 | POWER OFF               |                    |
| 35                       | 29-Jun-17 10:17:21.105218 | REBOOT COMMAND          |                    |
| 34                       | 29-Jun-17 10:01:41.074062 | FLASH PROGRAMMING       |                    |
| 33                       | 29-Jun-17 09:49:33.711569 | RESET ANCTR OP(MNUL)    |                    |
| 32                       | 29-Jun-17 09:49:12.946980 | RESET ANCTR OP(MNUL)    |                    |
| 31                       | 29-Jun-17 09:47:51.344902 | RESET ANCTR OP(MNUL)    |                    |
| 30                       | 29-Jun-17 09:41:34.117044 | WRONG TRANSCEIVER       |                    |
| 29                       | 29-Jun-17 09:41:34.117044 | POWER ON                |                    |
| Mark Event               |                           | Mark Event              | Page Up            |
|                          |                           |                         | Page Down          |

Figure 361: Event record

### 9.8.3 OSCILLOGRAPHY

#### ACTUAL VALUES > RECORDS > OSCILLOGRAPHY

|                                         |   |                                           |                |
|-----------------------------------------|---|-------------------------------------------|----------------|
| <div>■ OSCILLOGRAPHY</div> <div>■</div> | ⇔ | FORCE TRIGGER?<br>No                      | Range: No, Yes |
|                                         | ⇕ | NUMBER OF TRIGGERS:<br>0                  |                |
|                                         | ⇕ | AVAILABLE RECORDS:<br>0                   |                |
|                                         | ⇕ | CYCLES PER RECORD:<br>0                   |                |
|                                         | ↑ | LAST CLEARED DATE:<br>2019/07/14 15:40:16 |                |

This menu allows the user to view the number of triggers involved and number of oscillography traces available. The cycles per record value is calculated to account for the fixed amount of data storage for oscillography. See the Oscillography section of chapter 5 for details.

A trigger can be forced here at any time by setting *Yes* to the **FORCE TRIGGER?** command. See the **COMMANDS > CLEAR RECORDS** menu for information on clearing the oscillography records.

To view a waveform:

1. Access **Actual Values > Records > Oscillography** in the EnerVista software.
2. In the window that opens, select the record number. The highest number is the most recent record (Newest Record Number).
3. Click the **Read** button to get the waveform. When available, waveforms are displayed graphically, and otherwise error messages display.
4. In the waveform window that opens, you can save the file, for example with the CFG extension.

### 9.8.4 DATA LOGGER

#### ACTUAL VALUES > RECORDS > DATA LOGGER

|                                       |   |                                            |
|---------------------------------------|---|--------------------------------------------|
| <div>■ DATA LOGGER</div> <div>■</div> | ⇔ | OLDEST SAMPLE TIME:<br>2020/01/14 13:45:51 |
|                                       |   | NEWEST SAMPLE TIME:<br>2020/01/14 15:21:19 |

The **OLDEST SAMPLE TIME** represents the time at which the oldest available samples were taken. It is static until the log gets full, at which time it starts counting at the defined sampling rate.

The **NEWEST SAMPLE TIME** represents the time the most recent samples were taken. It counts up at the defined sampling rate. If the data logger channels are defined, then both values are static.

See the **COMMANDS > CLEAR RECORDS** menu for clearing data logger records.

### 9.8.5 BREAKER MAINTENANCE

#### ACTUAL VALUES > RECORDS > MAINTENANCE > BREAKER <n>

*Note:*  
Only BREAKER 1 is shown

|                                     |   |                                          |
|-------------------------------------|---|------------------------------------------|
| <div>■ BREAKER 1</div> <div>■</div> | ⇔ | BKR 1 ACC ARCING AMP<br>φA: 0.00 kA2-cyc |
|                                     |   | BKR 1 ACC ARCING AMP<br>φB: 0.00 kA2-cyc |
|                                     |   | BKR 1 ACC ARCING AMP<br>φC: 0.00 kA2-cyc |
|                                     |   | BKR 1 OPERATING TIME<br>φA: 0 ms         |
|                                     |   | BKR 1 OPERATING TIME<br>φB: 0 ms         |
|                                     |   | BKR 1 OPERATING TIME<br>φC: 0 ms         |



|   |                                            |
|---|--------------------------------------------|
| ⇅ | BKR 1 OPERATING<br>TIME: 0 ms              |
| ⇅ | BKR 1 ARCING AMP $\phi$ A:<br>0.00 kA2-cyc |
| ⇅ | BKR 1 ARCING AMP $\phi$ B:<br>0.00 kA2-cyc |
| ⇅ | BKR 1 ARCING AMP $\phi$ C:<br>0.00 kA2-cyc |
| ⇅ | BKR 1 AMP MAX $\phi$ A:<br>0.00 kA         |
| ⇅ | BKR 1 AMP MAX $\phi$ B:<br>0.00 kA         |
| ⇅ | BKR 1 AMP MAX $\phi$ C:<br>0.00 kA         |

There is an identical menu for each of the breakers.

The **BKR 1 ACC ARCING AMP** values are in units of kA2-cycles. See the **COMMANDS > CLEAR RECORDS** menu for clearing breaker arcing current records.

The **BREAKER OPERATING TIME** is defined as the slowest operating time of breaker poles that were initiated to open.

All of the values are stored in non-volatile memory and retained with power cycling.

## 9.9 PRODUCT INFORMATION

### 9.9.1 MODEL INFORMATION

#### ACTUAL VALUES > PRODUCT INFO > MODEL INFORMATION

|                                                          |   |                                                       |                                             |
|----------------------------------------------------------|---|-------------------------------------------------------|---------------------------------------------|
| <div> <div>■ MODEL INFORMATION</div> <div>■</div> </div> | ⇔ | ORDER CODE LINE 1:<br><order code>                    | Range: standard GE order code format        |
|                                                          | ⇕ | ORDER CODE LINE 2:<br><order code continued>          | Range: up to 20 alphanumeric characters     |
|                                                          | ⇕ | ORDER CODE LINE 3:<br><order code continued>          | Range: up to 20 alphanumeric characters     |
|                                                          | ⇕ | ORDER CODE LINE 3:<br><order code continued>          | Range: up to 20 alphanumeric characters     |
|                                                          | ⇕ | SERIAL NUMBER:<br><serial number>                     | Range: standard GE serial number format     |
|                                                          | ⇕ | ETHERNET MAC ADDRESS<br><MAC address>                 | Range: standard Ethernet MAC address format |
|                                                          | ⇕ | MANUFACTURING DATE:<br><Date>                         | Range: YYYY/MM/DD HH:MM:SS                  |
|                                                          | ⇕ | OPERATING TIME:<br><accumulative operating time>      | Range: HH:MM:SS                             |
|                                                          | ⇕ | PMU FEATURE ACTIVE:<br>No                             | Range: Yes, No                              |
|                                                          | ⇕ | CT/ VT ADVANCED DIAG<br>ACTIVE: No                    | Range: Yes, No<br>(not L60)                 |
|                                                          | ⇕ | LAST SETTING CHANGE:<br><Date of last setting change> | Range: YYYY/MM/DD HH:MM:SS                  |
|                                                          | ↑ | PBM MAC ADDRESS:<br><MAC address>                     | Range: YYYY/MM/DD HH:MM:SS                  |

The order code, serial number, Ethernet MAC address, date and time of manufacture, and operating time are shown here. The rear panel on the device contains similar information. The information is read-only in the software and modifiable on the front panel. For example, the order code can be corrected using the front panel.

#### ETHERNET MAC ADDRESS

UR devices with firmware 7.0x and above have three Ethernet ports that can be used on three networks. The MAC address displays for port 1. The MAC address for port 2 is one higher. The MAC address for port 3 is one higher than port 2. In redundant mode, the MAC addresses for ports 2 and 3 are the same as port 2.

**PBM MAC ADDRESS**

The MAC address for the Process Bus Module.

**9.9.2 FIRMWARE REVISIONS****Enhanced and basic front panels****ACTUAL VALUES > PRODUCT INFO > FIRMWARE REVISIONS**

|                                                           |   |                                  |                                                                                          |
|-----------------------------------------------------------|---|----------------------------------|------------------------------------------------------------------------------------------|
| <div> <div>■ FIRMWARE REVISIONS</div> <div>■</div> </div> | ⇔ | G30<br>REVISION: 8.8x            | Range: 0.00 to 655.35<br>Revision number of the application firmware.                    |
|                                                           | ⇕ | MODIFICATION FILE<br>NUMBER: 0   | Range: 0 to 65535 (ID of the MOD FILE)<br>Value is 0 for each standard firmware release. |
|                                                           | ⇕ | BOOT PROGRAM<br>REVISION:        | Range: 0.00 to 655.35<br>Revision number of the boot program firmware.                   |
|                                                           | ⇕ | FRONT PANEL PROGRAM<br>REVISION: | Range: 0.00 to 655.35<br>Revision number of front panel program firmware.                |
|                                                           | ⇕ | COMPILE DATE:                    | Range: YYYY/MM/DD HH:MM:SS<br>Date and time when product firmware was built.             |
|                                                           | ⇕ | BOOT DATE:                       | Range: YYYY/MM/DD HH:MM:SS<br>Date and time when the boot program was built.             |
|                                                           | ⇕ | PROCESS BUS BOOT<br>REVISION:    | Range: 0.00 to 655.35                                                                    |
|                                                           | ⇕ | PB BOOT DATE:                    | Range: YYYY/MM/DD HH:MM:SS                                                               |
|                                                           | ⇕ | PROCESS BUS<br>REVISION:         | Range: 0.00 to 655.35                                                                    |
|                                                           | ⇕ | PROCESS BUS DATE:                | Range: YYYY/MM/DD HH:MM:SS                                                               |
|                                                           | ⇕ | PB CVSOC FPGA<br>REVISION:       | Range: 0.00 to 655.35                                                                    |
|                                                           | ⇕ | PB CVFPGA FPGA<br>REVISION:      | Range: 0.00 to 655.35                                                                    |
|                                                           | ⇕ | PB CVFPGA SIGN:                  |                                                                                          |
|                                                           | ⇕ | FPGA PROGRAM<br>REVISION:        | Range: 0.00 to 655.35<br>Revision number for FPGA.                                       |
|                                                           | ↑ | FPGA DATE:                       | Range: YYYY/MM/DD HH:MM:SS<br>Date and time when the FPGA was built.                     |

The shown data is illustrative only. A modification file number of 0 indicates that, currently, no modifications have been installed. PB and process bus refer to the Process Bus Module.

**Graphical front panel**

With a graphical front panel (GFP), the following additional items display in the software.

|   |                               |                            |
|---|-------------------------------|----------------------------|
| ⇅ | GFP PROGRAM<br>REVISION:      | Range: 0.00 to 655.35      |
| ⇅ | GFP COMPILE DATE:             | Range: YYYY/MM/DD HH:MM:SS |
| ⇅ | GFP BOOT PROGRAM<br>REVISION: | Range: 0.00 to 655.35      |
| ↑ | GFP BOOT COMP. DATE:          | Range: YYYY/MM/DD HH:MM:SS |

## CHAPTER 10

# COMMANDS AND TARGETS

---


# 10.1      CHAPTER OVERVIEW

---

This chapter contains the following sections:

|                  |     |
|------------------|-----|
| Chapter Overview | 730 |
| Commands menu    | 731 |
| Targets menu     | 736 |

## 10.2 COMMANDS MENU




The commands menu contains relay directives intended for operations personnel. All commands can be protected from unauthorized access via the command password; see the Security section of chapter 5 for details. The following flash message appears after successfully command entry.

COMMAND  
EXECUTED


### 10.2.1 VIRTUAL INPUTS

#### COMMANDS > VIRTUAL INPUTS



### 10.2.2 CLEAR RECORDS

#### COMMANDS > CLEAR RECORDS



|   |                                     |                                                                          |
|---|-------------------------------------|--------------------------------------------------------------------------|
| ⇅ | CLEAR OSCILLOGRAPHY?<br>No          | Range: No, Yes                                                           |
| ⇅ | CLEAR DATA LOGGER?<br>No            | Range: No, Yes                                                           |
| ⇅ | CLEAR ENERGY?<br>No                 | Range: No, Yes                                                           |
| ⇅ | CLEAR UNAUTHORIZED<br>ACCESS? No    | Range: No, Yes                                                           |
| ⇅ | CLEAR DIRECT I/O<br>COUNTERS? No    | Range: No, Yes.<br>Valid only for units with Direct Input/Output module. |
| ⇅ | CLEAR TELEPROTECT<br>COUNTERS? No   | Range: No, Yes                                                           |
| ⇅ | CLEAR FREQ OOB<br>ACCUMULATORS? No  | Range: No, Yes                                                           |
| ⇅ | PRESET FREQ OOB<br>ACCUMULATORS? No | Range: No, Yes                                                           |
| ⇅ | ■ CLEAR IEC61850<br>■ XWSI OPCNT    |                                                                          |
| ⇅ | ■ CLEAR IEC61850<br>■ XCBR OPCNT    |                                                                          |
| ⇅ | CLEAR SV<br>DIAGNOSTICS? No         | Range: No, Yes                                                           |
| ↑ | CLEAR ALL RELAY<br>RECORDS? No      | Range: No, Yes                                                           |

The **CLEAR SV DIAGNOSTICS** command clears the sampled value diagnostics information for a non-HardFiber Process Bus Module. All other Process Bus Module diagnostics information is reset up relay power cycling, such as HSR and PTP.

#### COMMANDS > CLEAR RECORDS > CLEAR IEC61850 XWSI OPCNT

|                                  |   |                             |                               |
|----------------------------------|---|-----------------------------|-------------------------------|
| ■ CLEAR IEC61850<br>■ XWSI OPCNT | ⇅ | CLEAR XSWI <n><br>OpCnt? No | Range: No, Yes<br>n = 1 to 24 |
|----------------------------------|---|-----------------------------|-------------------------------|

#### COMMANDS > CLEAR RECORDS > CLEAR IEC61850 XCBR OPCNT

|                                  |   |                             |                              |
|----------------------------------|---|-----------------------------|------------------------------|
| ■ CLEAR IEC61850<br>■ XCBR OPCNT | ⇅ | CLEAR XSWI <n><br>OpCnt? No | Range: No, Yes<br>n = 1 to 8 |
|----------------------------------|---|-----------------------------|------------------------------|

The **Clear XSWI** commands clear the disconnect operation counters for each phase and the three-phase counter. Similarly, the **Clear XCBR** commands clear the circuit breaker operation counters for each phase and the three-phase counter.

## 10.2.3 SET DATE AND TIME

#### COMMANDS > SET DATE AND TIME

|                                       |   |                                             |                            |
|---------------------------------------|---|---------------------------------------------|----------------------------|
| ■ ■ COMMANDS<br>■ ■ SET DATE AND TIME | ⇅ | SET DATE AND TIME:<br><YYYY/MM/DD HH:MM:SS> | Range: YYYY/MM/DD HH:MM:SS |
|---------------------------------------|---|---------------------------------------------|----------------------------|



The date and time can be entered on the front panel keypad. The time setting is based on the 24-hour clock. The complete date, as a minimum, must be entered to allow execution of this command. The new time and date take effect when the **ENTER** key is pressed.

The clock also can be synchronized to the local computer time among several UR devices. Use the **Synchronize Devices** entry in the Online Window area of the EnerVista software. (Click the button at the top of the window that opens.)

When the relay is synchronizing to an external time source such as PTP, IRIG-B, or SNTP, the manually entered time or the manually synchronized time is over-written.

The timescale of the entered time is local time, including daylight savings time where and when applicable.

### 10.2.4 RELAY MAINTENANCE

#### COMMANDS > RELAY MAINTENANCE

|                                                          |   |                                  |                                                                                           |
|----------------------------------------------------------|---|----------------------------------|-------------------------------------------------------------------------------------------|
| <div>■ ■ COMMANDS</div> <div>■ ■ RELAY MAINTENANCE</div> | ⇔ | PERFORM LAMP TEST?<br>No         | Range: No, Yes                                                                            |
|                                                          | ⇕ | PERFORM LCD TEST?<br>Off         | Range: Off, Red, Green, Blue, White & Text Pattern, Black & Text Pattern, TV Test Pattern |
|                                                          | ⇕ | PERFORM PUSHBUTTON TEST? No      | Range: No, Yes                                                                            |
|                                                          | ⇕ | UPDATE ORDER CODE?<br>No         | Range: No, Yes                                                                            |
|                                                          | ⇕ | REBOOT RELAY?<br>No              | Range: No, Yes                                                                            |
|                                                          | ⇕ | SERVICE COMMAND<br>0             | Range: 0, 101, 20511                                                                      |
|                                                          | ⇕ | SAVE VOLATILE DATA?<br>No        | Range: No, Yes                                                                            |
|                                                          | ⇕ | ■ POWER SUPPLY<br>■              | Range: see below                                                                          |
|                                                          | ⇕ | FRONT PANEL TYPE                 | Range: see below                                                                          |
|                                                          | ⇕ | CHANGE REDUNDANT<br>POWER SUPPLY | Range: see below                                                                          |

This menu contains commands for relay maintenance purposes. Commands for the lamp test and order code are activated by changing a command setting to *Yes* and pressing the **ENTER** key. The command setting then automatically reverts to *No*. The service command is activated by entering a numerical code and pressing the **ENTER** key.

Not all commands display in the software; use the front panel when required.

#### PERFORM LAMP TEST

Turns on all front panel LEDs and display pixels for a short duration.

### PERFORM LCD TEST

This command detects dead pixels in the display screen on the graphical front panel.

- `RED, GREEN, BLUE` is to display the solid background color in the whole screen.
- `WHITE & TEXT PATTERN` shows the white background and black texts.
- `BLACK & TEXT PATTERN` shows the black background and white texts.
- `TV TEST PATTERN` displays a standard television test pattern (SMPTE color bars). The test screen can be canceled by pressing any pushbutton or after 30 seconds of inactivity.

### PERFORM PUSHBUTTON TEST

This command tests the pushbuttons on the graphical front panel. During testing, press the corresponding pushbutton according to the prompt text. A failure message is given if the expected action is not detected in one minute. Holding the **ESCAPE** button for five seconds to interrupt the test sequence. The designated function of a specific pushbutton is bypassed in the test.

### UPDATE ORDER CODE

Use this command to read and update the order code, for example when hardware modules have been changed inside the relay. It causes the relay to scan the backplane for the modules and update the order code to match. All settings are defaulted with an update. When an update occurs, the following message displays and the relay restarts.

There is no impact if there have been no changes to the hardware modules. When an update does not occur, the `ORDER CODE NOT UPDATED` message displays.

### REBOOT RELAY

This command restarts the relay so that changes to configuration settings can take effect. In most cases, if changes are made to the configuration settings these changes do not take effect unless the relay is rebooted.

*Note:*

*With the CyberSentry option, the Administrator and Operator roles can initiate the Reboot Relay command.*

### SERVICE COMMAND

This command Performs specific Product service actions. Presently, there are two service actions available.

- Code `20511` returns all settings to their factory default value and restarts the relay (then you re-enter IP address, restart, set unit to *Programmed*).
- Code `101` is used to clear factory diagnostic information stored in the non-volatile memory. If a code other than these two is entered, the command is ignored and no action is taken. Various self-checking diagnostics are performed in the background while the Product is running, and diagnostic information is stored on the non-volatile memory from time to time based on the self-checking result. Although the diagnostic information is cleared before the Product is shipped from the factory, the user may want to clear the diagnostic information for themselves under certain circumstances. For example, you clear diagnostic information after replacement of hardware. Once the diagnostic information is cleared, all self-checking variables are reset to their initial state and diagnostics restart from scratch.

### SAVE VOLATILE DATA

Saves this data to compact flash memory prior to shutdown. This allows the saved data to be as recent as possible instead of relying on the periodic timer to save the data.

### POWER SUPPLY

**Change power supply to:** High or Low

**Update redundant power supply:** No, Yes

**FRONT PANEL TYPE**

You can change the front panel type according to the following options.

EN BASIC, EN BASIC WITH PB, ZH BASIC, ZH BASIC WITH PB, FR BASIC, FR BASIC WITH PB, RU BASIC, RU BASIC WITH PB, DE ENHANCED, DE ENHANCED WITH PB, EN ENHANCED, EN ENHANCED WITH PB, FR ENHANCED, FR ENHANCED WITH PB, RU ENHANCED, RU ENHANCED WITH PB, ZH ENHANCED, ZH ENHANCED WITH PB, TR ENHANCED, TR ENHANCED WITH PB, PL ENHANCED, PL ENHANCED WITH PB.

**10.2.5 SECURITY**

**COMMANDS > SECURITY**

|                                        |   |                             |                |
|----------------------------------------|---|-----------------------------|----------------|
| <div>■ ■ SECURITY</div> <div>■ ■</div> | ⇔ | ADMINISTRATOR<br>LOGOFF: No | Range: No, Yes |
|                                        | ⇕ | ENGINEER<br>LOGOFF: No      | Range: No, Yes |
|                                        | ⇕ | OPERATOR<br>LOGOFF: No      | Range: No, Yes |
|                                        | ↑ | CLEAR SECURITY DATA:<br>No  | Range: No, Yes |

With the CyberSentry option, this setting is available to enable or disable the following commands.

**ADMINISTRATOR LOGOFF**

Selecting *Yes* allows the Supervisor to forcefully logoff an administrator session.

**ENGINEER LOGOFF**

Selecting *Yes* allows the Supervisor to forcefully logoff an engineer session.


**OPERATOR LOGOFF**

Selecting *Yes* allows the Supervisor to forcefully logoff an operator session.

**CLEAR SECURITY DATA**

Selecting *Yes* allows the Supervisor to forcefully clear all the security logs and clears all the operands associated with the self-tests.

## 10.3 TARGETS MENU



A target enables the EnerVista UR Setup software to monitor automatically and display the status of any active target messages of all the devices inserted into that site.

Each Product element with a **TARGET** setting has a target message that when activated by its element is displayed in sequence with any other currently active target messages in the **TARGETS** menu. In the example shown, the **Phase TOC4** and **Digital Element 48** target settings are active and so have their targets displayed. The down arrow below the two elements indicates that there can be other active elements beyond these two.

For more information, see the description of target messages in the next section, and the Introduction to Elements section in the Settings chapter for instructions on **TARGET** setting.

When no targets are active, the display reads NO ACTIVE TARGETS.

### 10.3.1 TARGET MESSAGES

When there are no active targets, the first target to become active causes the display to immediately default to that message. If there are active targets and the user is navigating through other messages, and when the default message timer times out (i.e. the keypad has not been used for a determined period of time), the display again defaults back to the target message.

The range of variables for the target messages is described below. Phase information is included if applicable. If a target message status changes, the status with the highest priority displays.

| Priority | Active status | Description                              |
|----------|---------------|------------------------------------------|
| 1        | OP            | element operated and still picked up     |
| 2        | PKP           | element picked up and timed out          |
| 3        | LATCHED       | element had operated but has dropped out |

If a self test error is detected, a message appears indicating the cause of the error. For example UNIT NOT PROGRAMMED indicates that the minimal relay settings have not been programmed.

### 10.3.2 RELAY SELF-TESTS

The relay performs a number of self-test diagnostic checks to ensure device integrity. The two types of self-tests (major and minor) are listed in the following tables. When either type of error occurs, the Trouble LED Indicator turns on and a target message displays. All errors record an event in the event recorder. Latched errors can be cleared by pressing the RESET key, providing the condition is no longer present.

Major self-test errors also result in the following:

- The critical fail relay on the power supply module de-energizes
- All other output relays de-energize and are prevented from further operation
- The front panel In Service LED indicator turns off
- A RELAY OUT OF SERVICE event is recorded

To view error messages in EnerVista software:

Access **Actual Values > Records > Event Records**.

Messages display on the front panel with one or two lines of text. An example is as follows:

MAINTENANCE ALERT:  
4L Discrepancy

MAINTENANCE ALERT:  
Bad IRIG-B Signal

### 10.3.3 MAJOR SELF-TEST ERROR MESSAGES

| Error                                        | Latched?        | Description                                                                                                                                                                                                                          | Test frequency                                                                                | Action                                                                                                                                                                                                                                              |
|----------------------------------------------|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DIAGNOSTIC FAILURE :<br>Self Test Error      | No (self-reset) | This serves as a warning indicating an issue within the DSP/COP subsystem. The root cause of the problem is uncertain, attributed to several contributors. To pinpoint the likely cause, it is advisable to conduct DSP diagnostics. | Upon recovery                                                                                 | Extract a Service Report through UR Setup software. Contact technical support.                                                                                                                                                                      |
| EQUIPMENT MISMATCH:<br>2nd line detail       | No              | The number or type of installed hardware modules does not match the order code stored in the Product. For example, when a basic front panel is installed and the order code on the Product expects a graphical front panel.          | On power up. Afterwards, the backplane is checked for missing cards every five seconds        | Check all modules against the order code, ensure they are inserted properly, and cycle control power. If a module has intentionally been added or removed, refresh the order code under Device Setup. If the problem persists, contact the factory. |
| FLEXLOGIC ERROR:<br>2nd line detail          | No              | A FlexLogic equation is incorrect                                                                                                                                                                                                    | Event driven, performed whenever FlexLogic equations are modified                             | Finish all equation editing and use self tests to debug any errors.                                                                                                                                                                                 |
| RAM FILESYSTEM FAIL:<br>Self-Test Error      | Yes             | The relay failed to create the RAM file system                                                                                                                                                                                       | On relay startup                                                                              | Contact factory service                                                                                                                                                                                                                             |
| SYSTEM FAILURE:<br>2nd line detail           | Yes             | Relay system failure detected                                                                                                                                                                                                        | Continuous                                                                                    | Extract a Service Report through UR Setup software. Contact technical support.                                                                                                                                                                      |
| SYSTEM FAILURE:<br>Card F8L                  | Yes             | This signifies a DSP failure, with the message specifying both the slot and DSP type associated with the issue.                                                                                                                      |                                                                                               | The recommendation is to replace this DSP. Extract a Service Report through UR Setup software and provide it to GE customer service..                                                                                                               |
| TO INSTALL SETTINGS:<br>Check log and reboot | Yes             | Certain settings require a reboot to be applied, for example DNP settings, IEC 104 settings. After a CID file was sent to the relay, a manual reboot of the relay is required to apply those settings that require a reboot          | New CID is sent and it includes changes in settings that require a reboot to be applied       | Restart relay                                                                                                                                                                                                                                       |
| UNIT NOT PROGRAMMED:<br>Check Settings       | No              | The PRODUCT SETUP > INSTALLATION > RELAY SETTINGS setting indicates the Product is not programmed                                                                                                                                    | On power up and whenever the PRODUCT SETUP > INSTALLATION > RELAY SETTINGS setting is altered | Program all settings and then set PRODUCT SETUP > INSTALLATION > RELAY SETTINGS to "Programmed"                                                                                                                                                     |

### 10.3.4 MINOR SELF-TEST ERROR MESSAGES

| Error                                                              | Latched? | Description                                                                           | Test frequency                                | Action                                                                  |
|--------------------------------------------------------------------|----------|---------------------------------------------------------------------------------------|-----------------------------------------------|-------------------------------------------------------------------------|
| AGGREGATOR ERROR:<br>(C60, C95, D60, F60, G60, L30, L90, T60 only) | No       | The second line of this self-test error indicates the problem with the PMU Aggregator | Each time a PMU's related settings is changed | Correct the problem indicated in the second line or contact the factory |

| Error                                                                                    | Latched? | Description                                                                                                                                                                                                                                                                                                                     | Test frequency                                                                                       | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------------------------------------------------------------------------------------------|----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DIAGNOSTIC ALARM COP:<br>Self-test Error                                                 | Yes      | This is an initial alert indicating an issue with the co-processor. Despite this, the relay will continue to provide protection. However, certain functionalities, such as distance-related operations, may experience a slight delay, especially when the fast distance feature is activated and executed on the co-processor. | Module or feature dependent                                                                          | Extract a Service Report through UR Setup software and provide it to GE customer service                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| DIAGNOSTIC ALARM:<br>Card F8L                                                            | Yes      | This serves as an initial alert signaling a potential issue with a DSP. The message will specify both the slot and DSP type associated with the problem..                                                                                                                                                                       | Every protection pass                                                                                | Extract a Service Report through UR Setup software and provide it to GE customer service                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| DIAGNOSTIC ALARM:<br>Self Test Error                                                     | Yes      | This serves as an initial alert indicating a potential issue within the DSP/COP subsystem. The exact origin of the issue remains unidentified due to various contributing factors. To determine the likely cause, it is recommended to acquire DSP diagnostics.                                                                 | Every protection pass                                                                                | Extract a Service Report through UR Setup software. Contact technical support.                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| DIRECT DEVICE OFF:<br>COMM Path Incomplete                                               | No       | A direct device is configured but not connected                                                                                                                                                                                                                                                                                 | Every second                                                                                         | Check direct input and output configuration and wiring                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| DOS PARTITION ALARM:<br>SELF-TEST ERROR                                                  |          | There is a problem with the Compact Flash memory in the CPU module                                                                                                                                                                                                                                                              | On relay power-up and afterwards once every 24 hours                                                 | Contact the factory                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| FACTORY MODE ACTIVE                                                                      | No       | Factory Mode is active                                                                                                                                                                                                                                                                                                          |                                                                                                      | This is a reminder for the Supervisor (if enabled) or Administrator to disable Settings > Product Setup > Security > Supervisory > Factory Service Mode as soon as it is not needed                                                                                                                                                                                                                                                                                                                                                                         |
| LOW ON MEMORY:<br>with 2nd line detail                                                   | Yes      | The relay periodically checks the amount of free RAM memory available and the amount of free stack available for each task against pre-defined thresholds. The second line of the self-test indicates which of the tests failed. It asserts this self-test if those tests fail.                                                 | Every five seconds                                                                                   | Contact the factory                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| MAINTENANCE ALERT:<br>4L Discrepancy                                                     | No       | A discrepancy has been detected between the actual and desired state of a latching contact output of an installed type "4L" module                                                                                                                                                                                              | Upon initiation of a contact output state change                                                     | Verify the state of the output contact and contact the factory if the problem persists                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| MAINTENANCE ALERT:<br>Bad IRIG-B Signal                                                  | No       | A bad IRIG-B input signal has been detected                                                                                                                                                                                                                                                                                     | Monitored whenever an IRIG-B signal is received                                                      | Ensure the following:<br>- The IRIG-B cable is properly connected.<br>- Proper cable functionality (that is, check for physical damage or perform a continuity test).<br>- The IRIG-B receiver is functioning.<br>- Check the input signal level (it can be less than specification).<br>If none of these apply, then contact the factory.                                                                                                                                                                                                                  |
| MAINTENANCE ALERT:<br>Bad PTP Signal                                                     | No       | No PTP enabled port has good PTP signal input                                                                                                                                                                                                                                                                                   | Activated when no acceptable signal is being received                                                | Ensure the following:<br>- The Ethernet cable(s) are properly connected.<br>- At least one PTP grandmaster-capable clock is functioning.<br>- If a strict power profile (PP) is enabled, that entire network is PP compliant.<br>- The network is delivering PTP messages to the relay.                                                                                                                                                                                                                                                                     |
| MAINTENANCE ALERT:<br>Direct Ring Break                                                  | No       | Direct input and output settings are configured for a ring, but the connection is not in a ring                                                                                                                                                                                                                                 | Every second                                                                                         | Check direct input and output configuration and wiring                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| MAINTENANCE ALERT:<br>FIRST ETHERNET FAIL<br>SECOND ETHERNET FAIL<br>THIRD ETHERNET FAIL | Yes      | A link loss detection on an Ethernet port. The link loss is due to unplugging the cable or the switch port being down.                                                                                                                                                                                                          |                                                                                                      | Check the connection                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| MAINTENANCE ALERT:<br>Front Panel Trouble                                                | No       | The graphical front panel is not responsive for more than five seconds. The relay is still protecting, and the main CPU is not affected by this self-test.                                                                                                                                                                      | Every second                                                                                         | Contact the factory                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| MAINTENANCE ALERT:<br>GFP Version Mismatch                                               | No       | The graphical front panel firmware revision is not synchronized with that of the CPU module in the relay                                                                                                                                                                                                                        | Whenever connection is established between the graphical front panel and the CPU module in the relay | Perform a UR firmware upgrade with the graphical front panel connected to the CPU module in the relay. It can be done using any communication interface (Ethernet or USB). This synchronizes the graphical firmware revision with that of the relay. If trouble persists, contact the factory.                                                                                                                                                                                                                                                              |
| MAINTENANCE ALERT:<br>Oscillatory GOOSE                                                  | No       | A data item in a configurable GOOSE data set is oscillating                                                                                                                                                                                                                                                                     | Upon scanning of each configurable GOOSE data set                                                    | Evaluate all logic pertaining to this item                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| MAINTENANCE ALERT:<br>Replace Battery                                                    | Yes      | The battery is weak or not functioning. It powers the real time clock. This message displays as Battery Fail in the event records. When the battery weakness reaches a critical level, the message displays persistently on the front panel and no front panel key navigation is possible.                                      | Every five seconds. The error message displays after 60 seconds if the problem persists.             | Replace the battery as outlined in the Maintenance chapter. To minimize the disruption until battery replacement, temporarily disable the battery fail function under Settings > Product Setup > User-Programmable Self Tests.                                                                                                                                                                                                                                                                                                                              |
| MAINTENANCE ALERT:<br>SFP MODULE # FAIL                                                  | No       | A faulty small form-factor pluggable port (SFP) or unplugging of the SFP generates this self test message                                                                                                                                                                                                                       |                                                                                                      | The web page "SFP Transceiver Information" described in the previous row applies for this self test as well. The "SFP Module Fail" has higher priority and it suppresses the "Ethernet Fail" target message. The "SFP MODULE FAIL FUNCTION" setting enables/disables this self test. The target for this self test is priority-based, with the third one being the highest priority. For example, if all three SFP modules fail, then the third SFP target is activated. If the third SFP module failure resolves, then the second SFP target is activated. |
| MAINTENANCE ALERT:<br>SNTP Failure                                                       | No       | The SNTP server is not responding                                                                                                                                                                                                                                                                                               | Every 10 to 60 seconds                                                                               | Check that Ethernet cable(s) are properly connected. Check that configuration for the SNTP server corresponds to the actual server settings. Check connectivity to the server (ping the server IP address). Check that UR settings for both SNTP servers are configured with different IP addresses and port numbers.                                                                                                                                                                                                                                       |

| Error                                                                                                                                    | Latched? | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Test frequency                                                                                                                                                                                   | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------------------------------------------------------------------------------------------------------------------------------------------|----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PBEthPort-# Offline<br>(Not B90, C30, L60)                                                                                               |          | Process Bus Module Ethernet port failure.<br>Error registers when an enabled port fails.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Every five seconds                                                                                                                                                                               | Check connection to network switch/ Merging Unit and network switch                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| PB SFP Module # Fail<br>(Not B90, C30, L60)                                                                                              |          | Small form-factor pluggable port (SFP) at back of Process Bus Module is faulty or unplugged                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Every five seconds                                                                                                                                                                               | Connect or replace with same SFP type                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| PROTOTYPE FIRMWARE:<br>Self Test Error                                                                                                   |          | Seen until the build is tagged as being 'release candidate' or 'gold' build                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Seen on startup and then continuous                                                                                                                                                              | Update firmware to either of these builds                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| RRTD COMM FAIL: (Not B90)<br>Self Test Error                                                                                             | No       | Communications with remote RTD unit (RRTD) or GPM-F failed for longer than 10 seconds                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Runs only if "Com2 Usage" is set to RRTD or RRTD&GPM-F. Checked every five seconds.                                                                                                              | Check COM2 port settings, check RS485 cables                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| RxGOOSE FAIL:<br>Missing messages                                                                                                        | No       | One or more RxGOOSE messages are not being received                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | The self-test is activated when no message is received within the expected time interval, which is the time-to-live time in the previous message. This time can be from milliseconds to minutes. | Check GOOSE setup                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| RxGOOSE OFFLINE:<br>COMM Path Incomplete                                                                                                 | No       | One or more RxGOOSE messages are not responding                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Event driven. The test is performed when a device programmed to receive GOOSE messages stops receiving. This can be from 1 to 60 seconds, depending on GOOSE packets.                            | Check GOOSE setup                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| OSC FIXED GOOSE:<br>Self Test Error                                                                                                      | No       | A FlexOperand configured in DNA and UserSt bit pair is oscillating                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Upon scanning each DNA or UserSt bit pair                                                                                                                                                        | Check Fixed GOOSE oscillation history on UR web page and evaluate all logic pertaining to this item                                                                                                                                                                                                                                                                                                                                                                                                       |
| AGGR CONFIG MISMATCH<br>(N60 only)                                                                                                       | Yes      | There is a limitation when using six PMUs. The self-test trips when any of the following acceptable conditions are violated.<br>- Two aggregators are allowed when using six PMUs, IEEE C37.118, and a 120/100 reporting rate<br>- One ASDU is allowed when using six PMUs, IEC 90-5, and a 60/50 reporting rate<br>- One ASDU and one aggregator are allowed when using six PMUs, IEC 90-5, and a 120/100 reporting rate                                                                                                                                                                                              | Event driven                                                                                                                                                                                     | Reconfigure aggregators according to the rules, as follows:<br>- For C37.118 with six PMU software option, the following is acceptable:<br>a. 20/100 reporting rate: 2 aggregators are allowed<br>- For 90-5 with six PMU software option, the following are acceptable<br>a. 60/50 reporting rate: six PMUs can be supported with one ASDU only<br>b. 120/100 reporting rate: six PMUs can be supported with one ASDU and one aggregator combination only                                                |
| SETTINGS SAVE ERROR:<br>Contact Factory                                                                                                  | Yes      | The relay failed to store the settings to the flash memory                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | When a setting is changed                                                                                                                                                                        | Contact the factory                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| STORAGE MEDIA ALARM:<br>Self Test Error                                                                                                  | No       | The CPU module fails to read from or write to the Compact Flash (CF) card inside the module. The CF card stores certain non-volatile data, such as event records, oscillography and datalogger records, fault report values, and non-volatile actual values. Settings are not stored in CF and hence are unaffected by this self-test.                                                                                                                                                                                                                                                                                 | On power up. Afterwards, every time the CPU accesses the CF card for reading or writing                                                                                                          | Contact the factory                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| SV# STREAM TROUBLE ON:<br>(Not B90, C30, L60)                                                                                            | Yes      | Asserted when<br>1. "4 out of 5 lost" errors are detected<br>2. No sampled values have been received for ~2 power cycles<br>3. Mismatch of test mode or simulation bit between UR and subscribed SV streams<br>4. Merging units subscribed by UR are not synchronized to the same grandmaster and the drift is ~2 power cycles<br>5. Sampled values subscribed by the relay are not synchronized according to the SMPSYNCH CHECK setting defined in the relay<br>6. Quality of the received sampled values is not acceptable (either the quality is invalid, or questionable with Quality Check = Reject Questionable) | Every protection pass                                                                                                                                                                            | Check:<br>1. Connection between Merging Unit (MU) and relay<br>2. SV stream configuration in the relay is matching the SV stream, for example check svID and confRev fields<br>3. Check the Actual Values > PB Module > RXSV status> rxsv1(16) page in the EnerVista software to verify the Sync Status, Quality, and delays of the received sampled values and troubleshoot accordingly<br>4. Check that all merging units subscribed by the UR are synchronized according to the SMPSYNCH CHECK setting |
| SYSTEM EXCEPTION:<br>Press RESET key                                                                                                     | Yes      | Abnormal restart from modules being removed or inserted while the Product is powered-up, when there is an abnormal DC supply, or as a result of internal relay failure.                                                                                                                                                                                                                                                                                                                                                                                                                                                | Event driven                                                                                                                                                                                     | Contact the factory                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| TEMP MONITOR:<br>OVER TEMPERATURE                                                                                                        | Yes      | The ambient temperature is greater than the maximum operating temperature (+80°C)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | Every hour                                                                                                                                                                                       | Remove the Product from service and install in a location that meets operating temperature standards                                                                                                                                                                                                                                                                                                                                                                                                      |
| UNIT NOT CALIBRATED:<br>with 2nd line DSP slot number detail                                                                             | Yes      | DSP module is not calibrated or calibration data is out of range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | On relay startup                                                                                                                                                                                 | The respective DSP module has to be replaced, contact factory service                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| VOLTAGE MONITOR:<br>with 2nd line detail<br>Power Supply 12V Low<br>Power Supply 12V High<br>Power Supply 5V Low<br>Power Supply 5V High | Yes      | The relay detected a problem with the internal voltage rails for longer than 25 seconds                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Every five seconds                                                                                                                                                                               | Contact GE customer service                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| WRONG TRANSCEIVER:<br>Self Test Error                                                                                                    | Yes      | The type of SFP does not match the CPU type. The SFP is a silver device that plugs into the rear of the CPU module.<br>T-type CPU = All ports support fiber SFPs only<br>U-type CPU = Maintenance port needs RJ45 SFP and the other two ports fiber SFPs<br>V-type CPU = All ports support RJ45 SFPs only<br>The consequence of an incorrect SFP can range from damage to the Product to no power information for the Product on its web page (enter IP address in a web browser, then click the SFP Transceiver Information — only the type of SFP displays and not power data).                                      |                                                                                                                                                                                                  | A web page "SFP Transceiver Information" is provided. This page displays the type of the SFP in it. This data is to be used with the CPU type to know the cause of the problem.                                                                                                                                                                                                                                                                                                                           |

### 10.3.5 INSTANTANEOUS PROTECTION ELEMENTS TRIP SECURITY

Some self-tests are not fast enough to detect erroneous data and block protection elements, requiring additional measures. A bit-flip in program memory is typically detected during a memory scan, which may be too late to inhibit instantaneous protection element. To secure instantaneous elements, in addition to the self-tests described, there are supervising elements that validate “fault” conditions and release IOC and differential elements operation.

These trip security elements use currents samples and phasors from the same sources as supervised protection elements to detect independently true “fault” conditions from IOC or differential. Trip security elements do not have any user settings and are enabled as soon as corresponding instantaneous elements are enabled. During laboratory testing, these elements can be disabled by activating any IED test mode via the **SETTINGS > TESTING > IED MODE CONFIG** menu by setting **IED MODE** to anything except *On*.

Trip security elements do not affect protection performance in any way.

#### Instantaneous Overcurrent

All enabled Phase IOC, Negative-Sequence, and Neutral IOCs in the active setting group are supervised by the trip security element. The goals of the IOC trip security are as follows:

- Detect erroneous operate current due to wiring or data acquisition problem resulting in one phase current dropping to zero, resulting in erroneous negative-sequence and neutral currents
- Justify current phasor magnitude increase with simultaneous current changes from samples

This is achieved by comparing current values of the current phasors and samples change with the values taken two cycles before. Additionally, trip security elements monitor “pre-fault” current to detect if operate condition is happening as a result of current decrease instead of increase.

The element is armed when there are no disturbances in currents for five cycles.

#### Differential elements (if applicable to the product)

Differential trip security runs for each differential zone. It monitors if differential current increase above the pickup setting is confirmed by the disturbance detectors 50DD for each differential zone input. When a differential zone fault occurs and at least two zone inputs carry some load, at least two disturbance detectors have to be activated. Or when there is no load at any zone inputs (zone is energized but does not carry any load), at least one disturbance detector has to be activated.

Consequently:

- If there is not any disturbance detector activation in at least one zone input — Differential trip is inhibited
- If there is just one zone input disturbance detector activation but load is present in at least two zone inputs prior to the “fault”, and if IOC trip security also confirms erroneous current — Differential trip is inhibited
- If there is more than one disturbance detector zone input activation — Differential trip is allowed (normal scenario)
- If differential trip is inhibited by the trip security element — active setting group change is not allowed

Activation of the 50DDs is essential especially when there is load in at least two zone inputs prior to the zone fault. Sensitivity of the 50DD is defined by the **SETTINGS > PRODUCT SETUP > DISPLAY PROPERTIES > CURRENT CUT-OFF LEVEL** setting with a range of 0.002pu to 0.02pu of the zone input CT. In case of the high-resistive zone fault there may be enough current change in the source zone input causing sufficient differential current, but small change in the load zone input-this situation can be addressed by reducing CURRENT CUTOFF LEVEL setting to the sufficient sensitivity level. 50DD operates if there is a change at least 2 x CUTOFF in either positive-sequence, or negative sequence or zero-sequence currents.

---

### 10.3.6 HARDFIBER MAJOR SELF-TEST ERROR MESSAGES

In addition to those provided by the standard UR-series devices, the UR devices implement HardFiber self-tests. These are listed here. Any abnormal diagnostic condition indicated by the LEDs or the critical failure relay also



results in a self-test message, so troubleshooting is described here. For other relays, such as the B95Plus, see that product's instruction manual.

| Error               | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Severity                                                                               | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| EQUIPMENT MISMATCH  | The number or type of installed hardware modules does not match the order code stored in the CPU. The standard UR-series Equipment Mismatch self-test is extended to cover the possible presence of a Process Card.                                                                                                                                                                                                                                                                                                                                                                                                                                             | Protection is not available and all contact outputs and shared outputs are de-asserted | Check all modules against the order code. Ensure they are inserted properly, and cycle the control power. If a module has intentionally been added or removed use the Update Order Code command to notify the relay that the current module configuration is correct.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| MODULE FAILURE      | UR-series device module hardware failure detected                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Protection is not available and all contact outputs and shared outputs are de-asserted | Contact the factory and supply the failure code noted in the display. Text in the message identifies the failed module (for example, H81). If operated on a Process Card failure, the Module Fail self-test seals-in (latches) till the UR-series device is restarted.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| PROCESS BUS FAILURE | Mission critical data is not available via the process bus. An AC quantity is considered critical if both AC bank origins and the crosschecking settings are other than None. This self-test is also initiated by an AC input discrepancy being detected. See the description in the Crosschecking setting in the HardFiber manual for further information. In addition, this self-test can be initiated by user logic responding to loss of critical contact input/output or other data using the Process Bus Failure Operand user-programmable self-test setting. This setting is located in the Settings > Product Setup > User-Programmable Self Test menu. | Protection is not available and all contact outputs and shared outputs are de-asserted | First rectify any Process Bus Trouble and Brick Trouble self-test errors. Check the actual value of the operand referenced by the Process Bus Failure Operand setting, and if "On," determine the cause and rectify.<br><br>If the problem persists with the foregoing all clear, the cause must be an AC input discrepancy, which is typically the result of problems in the input signals to the Bricks, or faults in the Brick input conditioning hardware. If the error was annunciated the first time significant signal was encountered, suspect the former cause and check the copper connections external to the Brick. Where multiple UR-series devices have self-test errors, look for common causes.<br><br>To further isolate AC input discrepancy errors, put the relay in test-isolated mode, then one by one, temporally change an AC bank Crosschecking setting to None, until the Process Bus Failure clears. Once the problem AC bank has been identified, the values from each of the two Bricks can be examined individually by temporarily mapping each to an AC bank with a single origin. |

### 10.3.7 HARDFIBER MINOR SELF-TEST ERROR MESSAGES

| Error               | Description                                                                                                                                                                                                                                                                                    | Severity                                                                                                                                                    | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| BRICK TROUBLE       | Brick internal self-testing has detected trouble internal to the Brick                                                                                                                                                                                                                         | This self-test error does not directly inhibit protection. However, some or all of the affected Brick inputs/outputs may not be available to the UR device. | Check the Brick environment for over/under temperatures and the voltage of its power source. If the ambient temperature and supply voltage are within Brick specifications, consult the factory. Troubles resulting from a Brick output failing to respond to an output command can only be detected while the command is active, and so in this case the target is latched. A latched target can be unlatched by pressing the front panel reset key if the command has ended, however the output can still be non-functional.                                                                                                                                                                                                                                                                                                   |
| PROCESS BUS TROUBLE | Communications problems with one or more Bricks. The text of the message identifies the affected field units. This self-test is initiated by low received signal levels at either the Brick or Process Card end, and by the sustained failure to receive poll responses from the proper Brick. | This self-test error does not directly inhibit protection. However, the affected Brick inputs/outputs may not be available to the UR device.                | Check the field unit actual values. An indication of equipment mismatch means that messages are being received from a Brick, but there is a discrepancy between the settings and the actual Brick serial number, order code, and/or core number.<br><br>Check that the correct core on the correct Brick is patched through to the correct Process Card port, and that the field unit settings are correct. An indication of communications loss means that no messages are being received.<br><br>Check that the patching is correct, and that the Brick has power. If that is not the problem, use a professional optical fiber connector cleaning kit to clean both sides of all optical fiber connections from the Process Card through to the affected Brick. If the problem continues after cleaning, consult the factory. |
| RTD TROUBLE         |                                                                                                                                                                                                                                                                                                |                                                                                                                                                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Self Test Error     | The Brick is reporting that the sensed RTD field connection does not match that of an RTD or the reported DC input value is outside of the RTD temperature range, greater than 250°C (likely open sensor circuit fault) or less than -50°C (likely shorted sensor fault).                      | Not latched                                                                                                                                                 | Check field RTD settings and connections                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| TDR TROUBLE         |                                                                                                                                                                                                                                                                                                |                                                                                                                                                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Self Test Error     | The Brick is reporting that the sensed transducer field connection does not match that of a transducer, or the reported DC input value is outside of the set transducer input range, or the minimum value setting is equal to the maximum value setting.                                       | Not latched                                                                                                                                                 | Check field transducer settings and connections                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

## CHAPTER 11

# APPLICATION OF SETTINGS

---

# 11.1      CHAPTER OVERVIEW

---

This chapter contains the following sections:

|                                   |     |
|-----------------------------------|-----|
| Chapter Overview                  | 743 |
| Setting example                   | 744 |
| Application of generator settings | 749 |

## 11.2 SETTING EXAMPLE

The echo signal, which allows the relay to key the permissive channel(s) through the DCUB TX1 through DCUB TX4 transmit operands during echo conditions when the local breaker opened, keys the carrier(s) during the following conditions:

The scheme is enabled (**DCUB FUNCTION** is enabled and **DCUB BLOCK** is off), and

- the **DCUB PERMISSIVE ECHO** setting is “Enabled”, and
- the LINE PICKUP LEO PKP operand that detects the local breaker to be open picks up for a time set by **LINE END OPEN PICKUP DELAY**, and
- any permissive signal DCUB RX1 through DCUB RX4 is received and any LOG1 to LOG4 is received, and
- a fault is not seen in the forward zone 2 distance elements or ground directional forward function (if configured) for at least 100 ms, and
- the reverse zone 4 distance elements or ground directional reverse function (if configured) did not pickup to set the transient blocking.

If these conditions are met, then the scheme echoes (transmits the DCUB TX1 through DCUB TX4 operands) the received permissive DCUB RX signal(s) back to the remote relay based on the echo table.

The keying or transmit signals DCUB TX1 through DCUB TX4 consist of all normal keying or echo keying conditions.

The scheme DCUB TRIP A, DCUB TRIB B, DCUB TRIP C, and DCUB TRIP 3P output operands are hard-wired to the trip output scheme. As such, if the trip output or breaker control operands (if the breaker control function is used) are used for tripping, the scheme is fully operational. The permissive key carrier signals DCUB TX1 through DCUB TX4 must still be assigned to the tripping/operating logic, and to output contacts as per the usual Product logic/output assignments.

### 11.2.1 IN-ZONE TRANSFORMER WITH VT ON THE HIGH-VOLTAGE SIDE

Consider the generator protection system show, with an in-zone transformer with VT on the high-voltage (HV) side.




Figure 362: Typical wiring, VT on the high-voltage side of the transformer

The two sources are configured as follows

| PARAMETER | SOURCE 1 | SOURCE 2 |
|-----------|----------|----------|
| Name      | G NEUT   | G TERM   |
| Phase CT  | M1       | F1       |
| Ground CT | M1       | None     |
| Phase VT  | None     | F5       |
| Aux VT    | None     | F5       |

**Figure 363: Source configuration**

The generator step-up (GSU) transformer is lagging by  $-30^\circ$  (from the line side to the generator side). Take note of the CT polarities in wiring diagram. These are necessary to correctly meter forward power. Loss of excitation and reverse power are to be assigned to source 2.

The transformer phase shift setting must compensate the measured relay currents for both the actual phase shift of the transformer, and any phase due to the CT polarities and connections.

The difference seen by the differential is the transformer phase shift plus the CT phase shift, or  $-30^\circ + (-180^\circ) = -210^\circ$ . The transformer configuration is therefore as shown in the following figure.

| PARAMETER               | WINDING 1      | WINDING 2       |
|-------------------------|----------------|-----------------|
| Source                  | G NEUT (SRC 1) | G TERM (SRC 2)  |
| Rated MVA               | 160.000 MVA    | 160.000 MVA     |
| Nominal Phs-phs Voltage | 13.800 kV      | 25.000 kV       |
| Connection              | Delta          | Wye             |
| Grounding               | Within zone    | Not within zone |
| Angle Wrt Winding 1     | 0.0 deg        | -210.0 deg      |

**Figure 364: Transformer configuration**

### 11.2.2 IN-ZONE TRANSFORMER WITH VT ON THE LOW-VOLTAGE SIDE

Consider the generator protection system shown, with an in-zone transformer with VT on the low-voltage (LV) side.




Figure 365: Typical wiring, VT on the low-voltage side of the transformer

The two sources are configured as follows.

| PARAMETER | SOURCE 1 | SOURCE 2 |
|-----------|----------|----------|
| Name      | GEN      | LINE     |
| Phase CT  | M1       | F1       |
| Ground CT | M1       | F1       |
| Phase VT  | F5       | None     |
| Aux VT    | F5       | None     |

G30\_550.urs System Setup Screen ID: 162

Figure 366: Source configuration

The GSU is again lagging by  $-30^\circ$  (from the line side to the generator side). Loss of excitation and reverse power is to be assigned to source 1. In this case, the only phase shift that must be accounted for is the phase shift of the transformer. Winding 2 is therefore shifted by  $-30^\circ$ .

| Windings // G30_550.urs : D:\Documents and Settings\All Use... <span>Save</span> <span>Restore</span> <span>Default</span> <span>Reset</span> <span>VIEW ALL mode</span> |              |                 |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------|-----------------|
| PARAMETER                                                                                                                                                                | WINDING 1    | WINDING 2       |
| Source                                                                                                                                                                   | LINE (SRC 2) | GEN (SRC 1)     |
| Rated MVA                                                                                                                                                                | 160.000 MVA  | 160.000 MVA     |
| Nominal Phs-phs Voltage                                                                                                                                                  | 25.000 kV    | 13.800 kV       |
| Connection                                                                                                                                                               | Wye          | Delta           |
| Grounding                                                                                                                                                                | Within zone  | Not within zone |
| Angle Wrt Winding 1                                                                                                                                                      | 0.0 deg      | -30.0 deg       |
| G30_550.urs System Setup: Transformer Screen ID: 166                                                                                                                     |              |                 |

Figure 367: Transformer configuration

11.2.3 NO IN-ZONE TRANSFORMER

Consider the generator protection system shown, with no in-zone transformer.





Figure 368: Typical wiring, no in-zone transformer

The two sources are configured as follows.



The screenshot shows a software window titled 'Windings // G30\_550.urs : D:\Documents and Settings\All Use...'. It contains a table with parameters for two windings. The table has three columns: 'PARAMETER', 'WINDING 1', and 'WINDING 2'. The parameters listed are Source, Rated MVA, Nominal Phs-phs Voltage, Connection, Grounding, and Angle Wrt Winding 1. The values for Winding 1 are: LINE (SRC 2), 160.000 MVA, 25.000 kV, Wye, Within zone, and 0.0 deg. The values for Winding 2 are: GEN (SRC 1), 160.000 MVA, 13.800 kV, Delta, Not within zone, and -30.0 deg. Below the table, there is a status bar with 'G30\_550.urs', 'System Setup: Transformer', and 'Screen ID: 166'. Above the table, there are buttons for 'Save', 'Restore', 'Default', and 'Reset', and a 'VIEW ALL mode' link.

| PARAMETER               | WINDING 1    | WINDING 2       |
|-------------------------|--------------|-----------------|
| Source                  | LINE (SRC 2) | GEN (SRC 1)     |
| Rated MVA               | 160.000 MVA  | 160.000 MVA     |
| Nominal Phs-phs Voltage | 25.000 kV    | 13.800 kV       |
| Connection              | Wye          | Delta           |
| Grounding               | Within zone  | Not within zone |
| Angle Wrt Winding 1     | 0.0 deg      | -30.0 deg       |

G30\_550.urs System Setup: Transformer Screen ID: 166

**Figure 369: Source configuration**

The Product requires the use of the transformer windings settings for the differential element, even if the differential is applied only as a stator differential for the generator. These settings ensure that the differential element operates with the correct phase shifts, and applies the correct magnitude compensation. Loss of excitation and reverse power can be assigned to either source. Since there is no transformer involved, the phase shift to enter is the  $-180^\circ$  phase shift due to the CT polarities and connections.



## 11.3 APPLICATION OF GENERATOR SETTINGS


### 11.3.1 SYSTEM SETUP

Ideally, the CTs are selected so that the generator nominal current is 80 to 85% of CT primary. The following settings are entered for the example system. The M5 bank and the ground CT input on each of the groups are unused in this example.

The nominal current is given by:

$$I_{\text{nom}}(13.8 \text{ kV}) = S_{\text{nom}} / \sqrt{3} V_{\text{nom}} = (162 \times 10^6 \text{ VA}) / (\sqrt{3} \times 13.8 \times 10^3 \text{ V}) = 6800 \text{ A}$$

Make the following settings changes in the EnerVista UR Setup software or the front panel **SYSTEM SETUP > AC INPUTS > CURRENT BANK F1** and the **SYSTEM SETUP > AC INPUTS > CURRENT BANK M1** menus.



| PARAMETER           | CT F1  | CT M1  | CT M5 |
|---------------------|--------|--------|-------|
| Phase CT Primary    | 8000 A | 8000 A | 1 A   |
| Phase CT Secondary  | 5 A    | 5 A    | 1 A   |
| Ground CT Primary   | 1 A    | 1 A    | 1 A   |
| Ground CT Secondary | 1 A    | 1 A    | 1 A   |

G60\_500.urs System Setup: AC Inputs

Figure 370: Current bank menu


For the example system, the voltage settings are calculated as follows:

$$\text{PHASE VT SECONDARY} = 18000\text{V} / \sqrt{3} \times 120\text{V} / 13800\text{V} = 69\text{V}$$

$$\text{PHASE VT RATIO} = 13800\text{V} / 120\text{V} = 115$$

$$\text{NEUTRAL VT RATIO} = 13800\text{V} / (\sqrt{3} \times 240\text{V}) = 33$$

Enter the following values through the EnerVista software or the front panel **SETTINGS > SYSTEM SETUP > AC INPUTS > VOLTAGE BANK F5** menu



| PARAMETER               | VT F5   |
|-------------------------|---------|
| Phase VT Connection     | Wye     |
| Phase VT Secondary      | 69.0 V  |
| Phase VT Ratio          | 1.00 :1 |
| Auxiliary VT Connection | Vag     |
| Auxiliary VT Secondary  | 66.4 V  |
| Auxiliary VT Ratio      | 1.00 :1 |

G30\_550.urs System Setup: AC Inputs Screen II

Figure 371: Voltage bank menu

### 11.3.2 POWER SYSTEM

Always enable frequency tracking for generator applications. Make the following power system parameters changes in the EnerVista software or the front panel **SETTINGS > SYSTEM SETUP > POWER SYSTEM > VOLTAGE BANK F5** menu.




Figure 372: Power system setup

### 11.3.3 SIGNAL SOURCES

Two sources are required for this application example. The LINE source uses the phase and auxiliary VT inputs and the CT input wired to the generator output CT. The GEN source uses the phase VT inputs and the CT input wired to the generator neutral CT. Including the phase VT inputs for both sources allows the user to choose the location of elements that use both voltage and current. Elements using the auxiliary VT input are assigned to the GEN source.

Make the following changes through the EnerVista software or the front panel **SETTINGS > SYSTEM SETUP > SOURCE 1 and SETTINGS > SYSTEM SETUP > SOURCE 2** menus.




Figure 373: Signal sources menu

### 11.3.4 GENERATOR UNBALANCE

Stage 1 of the generator unbalance element is typically used to trip the generator. In this example, the  $I_2$  capability of the machine is 8% and the  $I_2^2T$  capability is 10. The generator nominal current is:

$$I_{\text{nom}}(\text{pu}) = I_{\text{nom primary}} / CT_{\text{primary}} = 6800\text{A} / 8000\text{A} = 0.85 \text{ pu}$$

The minimum operate time of stage 1 is to be set to 0.25 seconds, the maximum operating time is to be 10 minutes, and the reset time is to be set to 4 minutes.

Stage 2 is typically set lower than stage 1 with a time delay to prevent nuisance alarms for external faults that are normally cleared by system protection. For the application example, the pickup setting is:

$$\text{Pickup} = 70\% \times I_2 \text{ capability} = 0.70 \times 8\% = 5.6\%$$

Source 2 is to be chosen for this element. The settings are as follows:

| SETTING              | PARAMETER      |
|----------------------|----------------|
| Function             | Enabled        |
| Source               | NEUTRL (SRC 2) |
| Inom                 | 0.850 pu       |
| Stage 1 Pickup       | 8.00 %         |
| Stage 1 K-Value      | 10.00          |
| Stage 1 Tmin         | 0.250 s        |
| Stage 1 Tmax         | 600.0 s        |
| Stage 1 K-Reset      | 240.0 s        |
| Stage 2 Pickup       | 5.60 %         |
| Stage 2 Pickup Delay | 10.0 s         |
| Block                | OFF            |
| Target               | Latched        |
| Events               | Enabled        |

G60 77x My Box Settings: Grouped Elements: Group 1 Screen ID: 191

Figure 374: Generator unbalance settings

### 11.3.5 LOSS OF EXCITATION

For the example system, we have the following values:

$$Z_{b(\text{sec})} = (\text{base kV}^2 / \text{base MVA}) \times (\text{CT ratio} / V_{\text{Tration}}) = [(18\text{kV})^2 / 211.765 \text{ MVA}] \times 1600 / 157.5 = 15.54 \Omega$$

$$X_{d'}(\text{sec}) = X_{d'} \times Z_{b(\text{sec})} = 0.216 \times 15.54 \Omega = 3.36 \Omega$$

$$X_{d(\text{sec})} = X_d \times Z_{b(\text{sec})} = 1.96 \times 15.54 \Omega = 30.57 \Omega$$

$$\text{CENTER 1} = [Z_{b(\text{sec})} + X_{d'}(\text{sec})] / 2 = 15.54 \Omega + 3.36 \Omega / 2 = 9.45 \Omega$$

$$\text{RADIUS 1} = Z_{b(\text{sec})} / 2 = 15.54 \Omega / 2 = 7.7 \Omega$$

$$\text{PICKUP DELAY 1} = 0.06 \text{ seconds}$$

$$\text{CENTER 2} = [X_{d(\text{sec})} + X_{d'}(\text{sec})] / 2 = 30.57 \Omega + 3.36 \Omega / 2 = 16.97 \Omega$$

$$\text{RADIUS 2} = X_{d(\text{sec})} / 2 = 30.57 \Omega / 2 = 15.28 \Omega$$

The voltage supervision setting is determined by a system study and can be disabled on either element if required. VT fuse failure supervises this element.

The source used for loss of excitation produces positive power when the machine is generating. Make the following changes in the EnerVista software or the front panel **SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1 > LOSS OF**

**EXCITATION** menu.

| SETTING                 | PARAMETER            |
|-------------------------|----------------------|
| Function                | Enabled              |
| Source                  | OUTPUT (SRC 1)       |
| Center 1                | 9.45 ohm             |
| Radius 1                | 7.77 ohm             |
| UV Supervision Enable 1 | Disabled             |
| Pickup Delay 1          | 0.060 s              |
| Center 2                | 16.97 ohm            |
| Radius 2                | 15.28 ohm            |
| UV Supervision Enable 2 | Disabled             |
| Pickup Delay 2          | 0.500 s              |
| UV Supervision          | 0.700 pu             |
| Block                   | SRC1 VT FUSE FAIL OP |
| Target                  | Latched              |
| Events                  | Enabled              |

G60 77x My Box Settings: Grouped Elements: Group 1 Screen ID: 198

Figure 375: Loss of excitation menu

### 11.3.6 REVERSE POWER

The reverse power element is set at ½ the rated motoring power. The pickup is calculated as follows:

$$S_{\min} = \frac{1}{2} \times \text{Rated Motoring Power (primary watts)} / (3 \times \text{Phase CT Primary} \times \text{Phase VT Ratio} \times \text{Phase VT Secondary})$$

For the example system:

$$S_{\min} = \frac{1}{2} \times 22 \times 10^6 \text{ W} / (3 \times 8000 \text{ A} \times 115 \times 69 \text{ V}) = 0.033 \text{ pu}$$


To prevent maloperation for power swings the element is typically time delayed by 20 to 30 seconds. For sequential tripping applications the time delay is to be 2 to 3 seconds. The element can be blocked when the generator is offline. The line source is to be used for this application. Make the following changes in the EnerVista software or the front panel **SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1 > SENSITIVE DIRECTIONAL POWER > DIRECTIONAL POWER 1** menu.

| PARAMETER                               | SENS DIR POWER1 |
|-----------------------------------------|-----------------|
| Function                                | Enabled         |
| Signal Source                           | GEN (SRC 1)     |
| Sensitive Directional Power RCA         | 180 deg         |
| Sensitive Directional Power Calibration | 0.00 deg        |
| Stage 1 SMIN                            | 0.100 pu        |
| Stage 1 Delay                           | 0.50 s          |
| Stage 2 SMIN                            | 0.100 pu        |
| Stage 2 Delay                           | 20.00 s         |
| Block                                   | 52B On On(P6C)  |
| Target                                  | Self-reset      |
| Events                                  | Disabled        |

G30\_550.urs Grouped Elements: Group 1: Power: Sensitive Screen ID: 220

**Figure 376: Directional power menu**

Sequential tripping logic can be implemented in FlexLogic as follows.



**Figure 377: Sequential tripping FlexLogic**

### 11.3.7 SYSTEM BACKUP OVERCURRENT

System backup protection is implemented using a phase time overcurrent element with voltage restraint enabled. The NEUTRL source is to be chosen for this element. Set the pickup of this element at a safe margin above the maximum load expected on the machine.

$$\text{PICKUP } 1.5 \times \text{Generator Nominal Current} / \text{CT Primary} = 1.5 \times 6800 / 8000 = 1.275 \text{ pu}$$

The selection of all standard curves (and FlexCurves) is allowed for easy coordination with system relaying. For the example system, an IEEE extremely inverse curve is used and a setting is chosen such that the operate time for a three-phase fault on the high side of the transformer is 0.75 seconds. For simplicity, the power system contribution is not considered.

$$\text{Transformer Impedance} = 0.10 \times 162 / 153 = 0.106 \text{ pu on machine base}$$

$$\text{Impedance to Fault} = 0.216 + 0.106 = 0.322 \text{ pu}$$

$$\text{Fault Current} = V / X = (1 / 0.322) \times (6800 / 8000) = 2.64 \text{ pu}$$

$$\text{Fault Voltage} = \text{Nominal Voltage} \times \text{Transformer Impedance} / \text{Total Impedance} = 13.8 \text{ kV} \times 10.6 / 32.2 = 4.543 \text{ kV}$$

$$\text{Pickup Reduction} = \text{Fault Voltage} / \text{Generator Nominal Voltage} = 4543 \text{ V} / 13.8 \text{ kV} = 0.329$$

The equation for an IEEE extremely inverse curve is as follows:

$$T = \text{TDM} \times \left[ \frac{A}{\left( \frac{I}{I_{\text{pickup}} \times \text{Pickup Reduction}} \right)^p - 1} + B \right]$$

where:

- A = 28.2
- B = 0.1217
- p = 2

Solving for TDM, we have:

$$\text{TDM} = \frac{0.75}{\frac{28.2}{\left( \frac{2.64}{1.275 \times 0.329} \right)^2 - 1} + 0.1217} = 0.88$$

Since this element coordinates with system protections, a timed reset is chosen. The element must be blocked for a VT fuse failure. The neutral source is chosen. Make the following changes in the EnerVista software or the front panel **SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1 > PHASE CURRENT > PHASE TOC1** menu.





Figure 378: Phase TOC1 menu

### 11.3.8 OVEREXCITATION

This protection is to be set to coordinate with the manufacturer's excitation capability curves. For the example system, the combined generator/GSU limit curve is shown as follows.



830734A1.CDR

Figure 379: Generator/GSU limit curve

Program the volts per hertz 1 element with an inverse characteristic (curve A), a pickup of 1.05, and a TDM of 40. Program the volts per hertz 2 element with a definite time characteristic, a pickup of 1.23, and a time delay of 2 seconds. Both elements are thus set to issue a trip. The volts per hertz 1 pickup is to be used to generate an alarm. Either source can be assigned in this example. Make the following changes in the EnerVista software or the front panel **SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1 > VOLTAGE ELEMENTS > VOLTS/HZ 1(2)** menus.

| Volts Per Hertz // G60_500.urs : C:\Documents and Settings\All Users\Documents\G...                          |                   |                   |
|--------------------------------------------------------------------------------------------------------------|-------------------|-------------------|
| <div> <div>Save</div> <div>Restore</div> <div>Default</div> <div>Reset</div> <div>VIEW ALL mode</div> </div> |                   |                   |
| PARAMETER                                                                                                    | VOLTS PER HERTZ 1 | VOLTS PER HERTZ 2 |
| Function                                                                                                     | Enabled           | Enabled           |
| Source                                                                                                       | OUTPUT (SRC 1)    | OUTPUT (SRC 1)    |
| Pickup                                                                                                       | 1.05 pu           | 1.23 pu           |
| Curves                                                                                                       | Inverse A         | Definite Time     |
| TD Multiplier                                                                                                | 10.00             | 2.00              |
| T Reset                                                                                                      | 30.0 s            | 0.0 s             |
| Block                                                                                                        | OFF               | OFF               |
| Target                                                                                                       | Latched           | Latched           |
| Events                                                                                                       | Enabled           | Enabled           |
| G60_500.urs Grouped Elements: Group 1: Voltage Elements                                                      |                   |                   |

Figure 380: Volts per Herz menu

### 11.3.9 INPUTS/OUTPUTS

The following inputs and outputs are used in this example. Make the following changes in the EnerVista software or the front panel **SETTINGS > INPUTS/OUTPUTS > CONTACT INPUTS > CONTACT INPUT H7a(H7c)** menus.




Figure 381: Contact input menus

Make the following changes in the EnerVista software or the **SETTINGS > INPUTS/OUTPUTS > VIRTUAL OUTPUTS > VIRTUAL OUTPUT 1(4)** menus.





Figure 382: Virtual output menus

Make the following changes in the EnerVista software or the **SETTINGS > INPUTS/OUTPUTS > CONTACT OUTPUTS > CONTACT OUTPUT H1(H4)** menus.








Figure 383: Contact output menus

### 11.3.10 FREQUENCY

The pickup and delay settings depend on operating practices and system characteristics. In this example, two overfrequency and two underfrequency elements are to be used. The elements are to be blocked when offline. Underfrequency is to initiate a trip. Overfrequency is to alarm only. Either source can be assigned.

Make the following changes in the EnerVista software or the front panel **SETTINGS > CONTROL ELEMENTS > UNDERFREQUENCY > UNDERFREQUENCY 1(2)** and **SETTINGS > CONTROL ELEMENTS > OVERFREQUENCY** menus.






Figure 384: Overfrequency menus

### 11.3.11 ACCIDENTAL ENERGIZATION

In this example, the **ACCDNT ENRG ARMING MODE** is selected as *UV and Offline*. The **ACCDNT ENRG OC PICKUP** setting is to be set at half the minimum expected fault current, and in this case 1.0 pu (8000 A primary) is selected. In cases where it is possible to re-energize the machine through its auxiliary transformer, a lower setting can be required. The undervoltage pickup setting must be set above the maximum expected fault voltage; 0.700 pu is used here.

Make the following changes in the EnerVista software or the front panel **SETTINGS > GROUPED ELEMENTS > SETTING GROUP 1 > ACCIDENTAL ENERGIZATION** menu.



| SETTING                             | PARAMETER       |
|-------------------------------------|-----------------|
| Function                            | Enabled         |
| Source                              | OUTPUT (SRC 1)  |
| Accidental Energization Arming Mode | UV AND OFFLINE  |
| Accidental Energization OC Pickup   | 1.000           |
| Accidental Energization UV Pickup   | 0.700           |
| Accidental Energization Offline     | Offline On(H7a) |
| Block                               | OFF             |
| Target                              | Latched         |
| Events                              | Enabled         |

G60\_500.urs Grouped Elements: Group 1

Figure 385: Accidental energization menu

### 11.3.12 FLEXLOGIC

The following logic as given as an example. The logic for each specific application depends on system design, protection philosophies, and operating practices.



## CHAPTER 12

# THEORY OF OPERATION

---

# 12.1      CHAPTER OVERVIEW

---

This chapter contains the following sections:

|                                |     |
|--------------------------------|-----|
| Chapter Overview               | 761 |
| Current directional protection | 762 |
| CT saturation detection        | 764 |

## 12.2 CURRENT DIRECTIONAL PROTECTION

For better security, the relay uses the current directional protection principle to dynamically supervise the main current differential function. The directional principle is in effect permanently for low differential currents (region 1 in the Two Regions of Differential Characteristic figure) and is switched on dynamically for large differential currents (region 2 in the same figure) by the saturation detector (see the Saturation Detector section) upon detecting CT saturation.

The directional principle responds to a relative direction of the fault currents. This means that a reference signal, is not required. The directional principle declares that

- If all of the fault currents flow in one direction, the fault is internal, or
- If at least one fault current flows in an opposite direction compared with the sum of the remaining currents, the fault is external

The directional principle is implemented in two stages:


First, based on the magnitude of a given current, it is determined whether the current is a fault current. If so, its relative phase relation has to be considered. The angle check must not be initiated for the load currents as the direction is out of the protected part, even during internal faults. The auxiliary comparator of this stage applies an adaptable threshold. The threshold is a fraction of the restraining current. The current from a particular feeder is used for bus directional comparison as a contributor feeder if its magnitude is greater than:

$0.2 \times I_{\text{restraint}}$  or it is greater than 2 times its CT rating

Second, for the selected fault currents, the phase angle between a given current and the sum of all the remaining currents is checked. The sum of all the remaining currents is the differential current less the current under consideration. Therefore, for each, say the  $p$ th, current to be considered, the angle between the  $I_p$  and  $I_D - I_p$  phasors is to be checked.


There should be at least one contributor feeder in the zone, satisfying magnitude check conditions above to allow directional principle to declare internal fault and at least two contributor feeders to discriminate internal against external fault.

Ideally, during external faults, the said angle is close to  $180^\circ$  (as shown); and close to 0 degrees during internal faults.



836726A2.CDR

**Figure 387: Directional principle operation during external faults**




**Figure 388: Directional principle operation during internal faults**

The relay calculates the maximum angle for the considered currents and compares it against a fixed threshold of 90°. The flag indicating whether the directional protection principle is satisfied is available as the FlexLogic operand:

- BUS <n> DIR A/B/C (for B30 and B90)
- XFMR PCNT DIFF DIR A/B/C (for G30, T35 and T60)
- STATOR DIFF DIR A/B/C (for G60)

## 12.3 CT SATURATION DETECTION

The saturation detector takes advantage of the fact that any CT operates correctly for a short period of time, even under very large primary currents that would subsequently cause a very deep saturation. As a result, in the case of an external fault, the differential current stays very low during the initial period of linear operation of the CTs while the restraining signal develops rapidly. Once one or more CTs saturate, the differential current increases. The restraining signal, however, yields by at least a few milliseconds. During internal faults, both the differential and restraining currents develop simultaneously. This creates characteristic patterns for the differential - restraining trajectory, as shown.



**Figure 389: CT saturation detection internal and external fault patterns**

The CT saturation condition is declared by the saturation detector when the magnitude of the restraining signal becomes larger than the lower breakpoint and at the same time the differential current is below the first slope and its extension. The said condition is of a transient nature and requires a seal-in. A special logic in the form of a “state machine” is used for this purpose as depicted in the following figure on saturation detector state machine.

As the phasor estimator introduces a delay into the measurement process, the aforementioned saturation test fails to detect CT saturation occurring very fast. In order to cope with very fast CT saturation, another condition is checked that uses relations between the signals at the waveform level. The basic principle is similar to that described. Additionally, the sample-based stage of the saturation detector uses the time derivative of the restraining signal ( $di/dt$ ) to better trace the saturation pattern shown in the following figure.

The saturation detector is capable of detecting saturation occurring in approximately 3 ms from fault inception. The saturation detector, although having no dedicated settings, uses the main differential characteristic for proper operation. This must be kept in mind when setting the characteristic as its parameters must retain their original meaning.


The operation of the saturation detector is available as the FlexLogic operand:

BUS <n> SAT A/B/C (for B30 and B90)

XFMR PCNT DIFF SAT A/B/C (for G30, T35 and T60)

STATOR DIFF SAT A/B/C (for G60 and M60)





836729A1.CDR

Figure 390: Saturation detector state machine

## CHAPTER 13

# COMMISSIONING

---

# 13.1      CHAPTER OVERVIEW

---

This chapter contains the following sections:

|                                                   |     |
|---------------------------------------------------|-----|
| Chapter Overview                                  | 767 |
| Overview                                          | 768 |
| Testing underfrequency and overfrequency elements | 769 |

---

## 13.2 OVERVIEW

---

Instantaneous protection elements trip security can impact the testing of the overcurrent and differential elements. Please refer to the Instantaneous Protection Elements Trip Security section in the Commands and Targets chapter for more details on this subject and to Application note GET-20105A (UR Relays Percent Differential Element Testing) for proper testing methods.

### 13.3 TESTING UNDERFREQUENCY AND OVERFREQUENCY ELEMENTS


Underfrequency and overfrequency protection requires techniques with subtle testing implications. Whereas most protection is designed to detect changes from normal to fault conditions that occur virtually instantaneously, power system inertia requires frequency protection to pick up while the frequency is changing slowly. Frequency measurement is inherently sensitive to noise, making high precision in combination with high speed challenging for both relays and test equipment.

Injection to a particular frequency element must be to its configured source and to the channels that the source uses for frequency measurement. For frequency measurement, a source uses the first quantity configured in the following order:

- Phase voltages
- Auxiliary voltage
- Phase currents
- Ground current

For example, if auxiliary voltage and phase currents are configured, the source uses the auxiliary voltage, not the phase voltages or any of the currents.

When phase voltages or phase currents are used, the source applies a filter that rejects the zero-sequence component. As such, the same signal must not be injected to all three phases, or the injected signal is completely filtered out. For an underfrequency element using phase quantities, the phase A signal must be above the MIN VOLT/AMP setting value. Therefore, either inject into phase A only, or inject a balanced three-phase signal.



832771A1.cdr

**Figure 391: Typical underfrequency element test timing**

The static accuracy of the frequency threshold is determined by slowly adjusting the frequency of the injected signal about the set pickup. If the Product frequency metering feature is used to determine the injected frequency, verify the metering accuracy by checking it against a known standard (for example, the power system).

To accurately measure the time delay of a frequency element, a test emulating realistic power system dynamics is required. Let the injected frequency ramp smoothly through the set threshold, with the ramp starting frequency sufficiently outside the threshold so that the relay becomes conditioned to the trend before operation. For typical interconnected power systems, the recommended testing ramp rate is 0.20 Hz/s.

The required delay time is the interval from the point the frequency crosses the set threshold to the point that the element operates. Some test sets can measure only the time from the ramp start to element operation, necessitating the subtraction of the pre-threshold ramp time from the reading. For example, with a ramp rate of 0.20 Hz/s, start the ramp 0.20 Hz before the threshold and subtract 1 second from the test set time reading of ramp start to relay operation.

Note that the Product event records only show the “pickup delay” component, a definite time timer. This is exclusive of the time taken by the frequency responding component to pickup.

Product oscillography can be used to measure the time between the calculated source frequency crossing the threshold and element operation; however, this method omits the delay in the calculated source frequency. The security features of the source frequency measurement algorithm result in the calculated frequency being delayed by two to four cycles (or longer with noise on the input). In addition, oscillography resolution is 0.004 Hz, which at 0.20 Hz/s corresponds to a delay of 20 ms. Do not use the tracking frequency in timing measurements, as its algorithm involves phase locking, which purposely sets its frequency high or low to allow the Product sample clock to catch-up or wait as necessary to reach synchronism with the power system.

## CHAPTER 14

# MAINTENANCE

---

# 14.1      CHAPTER OVERVIEW

---

This chapter contains the following sections:

|                      |     |
|----------------------|-----|
| Chapter Overview     | 772 |
| Monitoring           | 773 |
| General maintenance  | 776 |
| Files and Settings   | 777 |
| Replace module       | 793 |
| Battery              | 796 |
| Repairs              | 798 |
| Storage and disposal | 799 |



## 14.2 MONITORING

Devices and data can be monitored.

### 14.2.1 DEVICES WITH SITE TARGETS

To view an overview of devices:

1. Access the Site Targets item in the Online Window area, below the list of devices. It can take a few minutes for all devices to be read.
2. Acknowledge any messages for inaccessible devices. The Site Targets window opens when done.




Figure 392: Site Targets window


### 14.2.2 DATA WITH MODBUS ANALYZER

Use the Modbus Analyzer under **Maintenance > Modbus Analyzer** to monitor the values of the UR device. Use the Modbus memory map addresses outlined in the UR Family Communications Guide for the entries.

The upper part of the window displays values. The lower part of the window is for factory service use.

The first row in the figure shows that Contact Output 1 operation is being monitored. Its Modbus address is CAFA. The actual value read from the device is 0, which means that it is off.

The second row in the figure shows the Contact Output 1 Name. It has a Modbus address of CAF0 and a default value of *Cont Op 1*. None of **Selection** column settings render this value because they present the information based on numbering systems.



**Figure 393: Modbus Analyzer used to monitor actual values on a UR**

#### Address (HEX)

- Modbus address in hexadecimal. See the Modbus memory map in the UR Family Communications Guide or in the web interface (enter IP address of UR device in a web browser). Convert the decimal address in the Modbus memory map to hexadecimal.

#### Modbus Type

- Actual Value: To read the data in the UR device
- Setting: To read a setting in the UR device
- Coil: To read a command in the UR device

#### # of

- Element, input, or output to read. An example is 1 for Contact Output 1.

#### Selection (examples demonstrate various ways to represent 0)

- Hex: A decimal numbering system based on 16 possible values, from 0 to 9 and A to F. An example is 0x0000.
- Char: A single unicode character, such as C. An example is 0.
- Int: A 32-bit number, either positive or negative. An example is 0.
- UInt: Unsigned 32-bit integer, which means that it cannot be negative but can be twice as large as a signed integer. An example is 0.
- Long: A 64-bit number, either positive or negative. An example is 0.

- ULong: Unsigned 64-bit number, which means that it cannot be negative but can be twice as large as a signed 64-bit number. An example is 0.
- Float: A numbering system with no fixed number of digits before or after the decimal point. An example is 0.000000.
- Binary: A numbering system using 0 and 1. An example is 0000-0000-0000-0000.

Entries are not saved when closing the window.

---

## 14.3 GENERAL MAINTENANCE

---

As the relay is microprocessor-based, its characteristics do not change over time. In addition, the relay has continuous self-monitoring during operation, reporting any issues detected. For these reasons, routine maintenance of the relay is not required. When used in a controlled indoor environment with electrical conditions compliant with the specifications, the expected service life is 20 years, if manufactured after June 2014.

We appreciate that some customer maintenance practices stipulate routine maintenance of products in excess of the manufacturer's recommendation. Should this be your organization's policy, you might consider the following maintenance options:

### In-service maintenance

- Visual verification of the analog values integrity, such as voltage and current (in comparison to other devices on the corresponding system).
- Visual verification of active alarms, relay display messages, and LED indications.
- LED test.
- Visual inspection for any damage, corrosion, dust, or loose wires.
- Event recorder file download with further events analysis.

### Out-of-service maintenance

- Check wiring connections for firmness.
- Analog values (currents, voltages, RTDs, analog inputs) injection test and metering accuracy verification. Calibrated test equipment is required.
- Protection elements setting verification (analog values injection or visual verification of setting file entries against relay settings schedule).
- Contact inputs and outputs verification. This test can be conducted by direct change of state forcing or as part of the system functional testing.
- Visual inspection for any damage, corrosion, or dust.
- Event recorder file download with further events analysis.
- LED Test and pushbutton continuity check.

**Note:**

*To avoid deterioration of electrolytic capacitors, power up units that are stored in a de-energized state once per year, for one hour continuously.*

### Unscheduled maintenance (system interruption)

View the event recorder and oscillography or fault report for correct operation of inputs, outputs, and elements.

## 14.4 FILES AND SETTINGS

### 14.4.1 RETRIEVE FILES

Data, oscillography, log, events, routing, ARP, and other files can be transferred using the EnerVista software when using the graphical front panel. These files can be requested by technical support staff.

To retrieve a file using EnerVista software:

1. If the CyberSentry option is enabled, log in to the EnerVista software using the Administrator role.
2. In the Online Window area of EnerVista, access **Maintenance > Retrieve File**. The window opens.
3. Note the destination folder to which the file is to be saved at the top and change it if required. You can copy the path or open the folder for convenience at this time.
4. Select the file to download from the UR device.
5. Click the **Read File** button. The file is saved to the destination folder. The EnerVista window remains open to download additional files

### 14.4.2 CYBERSENTRY SECURITY EVENT FILES

CyberSentry security events are available in the following files:

- SECURITY\_EVENTS.CSV
- SETTING\_CHANGES.LOG

The following figure shows the content for the SECURITY\_EVENTS.CSV file:

| FORMAT       | Event | Number                      | Date/Time     | Username    | IP Address | Role           | Category    | LogType | Activity Value | Change Method         | Event Result |
|--------------|-------|-----------------------------|---------------|-------------|------------|----------------|-------------|---------|----------------|-----------------------|--------------|
| EVENT_INFO_1 | 678   | Dec 03 2024 17:11:11.644127 | Administrator | 10.14.21.49 | 1          | Access Control | IE062351-14 | 14      | 5              | Role log in           |              |
| EVENT_INFO_1 | 677   | Dec 03 2024 17:11:02.746239 | Observer      | 10.14.21.49 | 0          | Access Control | IE062351-14 | 15      | 5              | Role log out          |              |
| EVENT_INFO_1 | 676   | Dec 03 2024 17:11:01.916899 | badusername   | 10.14.21.49 | 0          | Access Control | IE062351-14 | 1       | 5              | Authentication failed |              |
| EVENT_INFO_1 | 675   | Dec 03 2024 17:10:59.701680 | Observer      | 10.14.21.49 | 0          | Access Control | IE062351-14 | 14      | 5              | Role log in           |              |
| EVENT_INFO_1 | 674   | Dec 03 2024 16:24:57.355596 | Observer      | 10.14.21.49 | 0          | Access Control | IE062351-14 | 15      | 5              | Role log out          |              |
| EVENT_INFO_1 | 673   | Dec 03 2024 16:24:54.566037 | badusername   | 10.14.21.49 | 0          | Access Control | IE062351-14 | 2       | 5              | User lockout          |              |
| EVENT_INFO_1 | 672   | Dec 03 2024 16:24:54.266236 | badusername   | 10.14.21.49 | 0          | Access Control | IE062351-14 | 1       | 5              | Authentication failed |              |
| EVENT_INFO_1 | 671   | Dec 03 2024 16:24:42.414708 | Observer      | 10.14.21.49 | 0          | Access Control | IE062351-14 | 14      | 5              | Role log in           |              |
| EVENT_INFO_1 | 670   | Dec 03 2024 16:22:31.602775 | Administrator | 10.14.21.49 | 0          | Access Control | IE062351-14 | 1       | 5              | Authentication failed |              |
| EVENT_INFO_1 | 669   | Dec 03 2024 16:21:46.435157 | Observer      | 10.14.21.49 | 0          | Access Control | IE062351-14 | 15      | 5              | Role log out          |              |

Figure 394: Security events file

**Time** — Local time.

**Activity** — The actual security event.


- 1 = Authentication Failed
- 2 = User Lockout
- 3 = FW Upgrade
- 4 = FW Lock
- 5 = Settings Lock
- 6 = Settings Change, this can fill the entire event log. Hence it is supported by the already existing SETTINGS\_CHANGE.LOG file. This event is not required.
- 7 = Clear Oscillography command
- 8 = Clear Data Logger command
- 9 = Clear Demand Records command
- 10 = Clear Energy command
- 11 = Reset Unauthorized Access
- 12 = Clear Teleprotection Counters
- 13 = Clear All Records
- 14 = Role Log out

- 15 = Role Log in
- 16 = Factory Mode enabled
- 17 = Factory Mode disabled

**Change Method** — Format code F229 for the settings control change method.

- 0 = None
- 1 = Keypad
- 2 = Front port
- 3 = COM1 (not used)
- 4 = COM2 (RS485)
- 5 = Ethernet

The `SETTING_CHANGES.LOG` file stores all the setting changes. A total of 1024 events are stored in a circular buffer in volatile memory.



**Figure 395: Setting changes file**

### 14.4.3 CONVERT DEVICE SETTINGS

Settings files can be upgraded or downgraded to other firmware versions. For example, version 7.4 settings can be upgraded to version 7.6.

Settings are reset to factory default upon conversion. For a graphical front panel, for example when upgrading from version 7.6 to 7.7, single-line diagrams and cells configured for the Metering Editor are defaulted, while other graphical front panel settings are retained.

When converting a settings file from version 7.20 or earlier to 7.70 or later, any IEC 61850 settings are defaulted, and Edition 2 is used.

When converting a settings file from version since 7.30 inclusive to 7.70 or later, any IEC 61850 settings are converted and Edition 2 is used.

When converting a settings file with IEC 61850 Edition 1 to version 7.80 or later with a non-HardFiber Process Bus Module (order code 85, 86, or 87), conversion does not take place and an error message displays. The Process Bus Module does not support Edition 1.

Conversions between PBM and non-PBM order codes are not permitted.

With version 8.00 and later, when a file is converted between order codes, the logical node prefix names and instance numbers are defaulted and the respective dataset member references are removed.

To convert settings:

1. If not already in the Offline Window area, right-click the online device in the EnerVista software and select the **Add Device to Offline Window** option. This copies the settings to the Offline Window area. Any message about file repair usually means that settings were missing in the original file and have been added with default values to the new file.
2. Make a copy of the settings file in the Offline Window area by right-clicking the file and selecting **Duplicate Device**. A copy of the file is made and the file name start with *Copy of*. Optionally rename the file by right-clicking it and selecting the **Rename Device** option.
3. Convert the settings by right-clicking one of the files in the Offline Window and selecting the **Convert Device Settings** option.

If the option does not display, click the **Admin > User Management** menu item and enable the **Update Info** check box for the user, then save, or click the **Admin > User Management** menu item and enable the **Enable Security** check box, then save.

Select the **Admin > User Login** menu item. Enter *Administrator* for the user and enter the password. (Contact GE Grid Solutions if you do not know the default password.)


GE recommends converting settings in firmware steps, for example when converting from 6.0 to 7.4x, convert first to 7.0 then 7.4 in order to follow embedded conversion rules and keep settings.

The settings convert and a report generates.

**Figure 396: Upgrade settings**

4. Review the conversion report. The values of all settings that have been defaulted during conversion are not listed in the conversion report; to find the value of a setting before conversion, inspect the device backup file made before conversion.

In the example shown here, settings have been reset to factory defaults and several settings are new in firmware version 7.6 under **Settings > System Setup > Switches** and **Breakers**.



**Figure 397: Conversion report**

5. Change settings in the new file, for example by looking at the original file.
6. Write the converted file to the device, for example by dragging and dropping from the Offline Window to the Online Window.
7. Check settings and operation.

#### 14.4.4 COPY SETTINGS TO OTHER DEVICE

Settings from one Product device can be copied to another Product device for rapid deployment. The order codes and IEC 61850 edition must match. See the Settings File section at the beginning of the Interfaces chapter for a list of settings not deployed.


1. Right-click the device in the Online window and select the **Add Device to Offline Window** option. A window opens.
2. Check the file path and name the file, then click the **Receive** button. An example is to save the files in D:\Users\Public\Public Documents\GE Power Management\URPC\Data\ and to name the source device **Product\_Deployment**. At the prompt, confirm the action. The settings are saved in .cid, .icd, and .urs files, and the entry displays in the Offline window area.
3. Right-click the device in the Offline window area and select the **Duplicate Device** option. The device is copied with a prefix of **Copy of**.
4. Right-click the copied device and rename it.
5. Right-click the copied device and select the **Edit Device Properties** option. Make the changes for the new device.
6. Send the file to new device by dragging and dropping it into the Online Window area. Or right-click and select the **Write Settings to Device** option.
7. Update the remaining settings, such as IP address.

#### 14.4.5 EXPORT SETTINGS

All or specific groups of settings are exportable.

1. Right-click a device in the Offline Window area and select the **Export Settings** option. A window opens. When the **Export All Settings** option is enabled, the individual settings groups are inactive.





**Figure 398: Export settings**

- For groups of settings, enable the **Export Selected Settings** option, then enable the check boxes of the options to export. The example shows that FlexLogic equations are to be exported.
- Click the **OK** button, and specify a file name in the window that opens. The format is XML. Click the button to start the export, which takes a minute or two.

If prompted about a file being repaired, review the report. The path to the file displays, and otherwise it sits with the URS, CID, and ICD files of the device with a file name of `_Repair_Report.txt`, such as `B30 81x_Repair_Report.txt`. The example shows that some settings were added at default values. The explanation is that the EnerVista software was updated, but the offline file predates the update.

This device contains a list of settings that were missing in the original file.  
The following settings have been added to this setting file and were set to their default values.

```
INITIATE TEST MODE ON SIM,L=2039,G=1,M=1,I=1
SIM MODE CTRL VIA IEC 61850,L=3869,G=1,M=1,I=1
SIM MODE INPUT,L=3870,G=1,M=1,I=1
```

**Figure 399: Settings report**

#### 14.4.6 COMPARE SETTINGS

Settings are comparable against default values and between two UR devices.

Some of the IEC 61850 settings use floating point data, which guarantees accurate representation of real numbers up to seven digits. Numbers with more than seven digits are approximated within a certain precision. This can result in differences between what is entered and what is saved, and for example results in differences shown on a settings comparison report.

When comparing two settings files with the graphical front panel, all graphical front panel features are compared except for the single-line diagrams.

### Comparing against defaults

1. Right-click the device in the Offline Window area and select **Compare Settings With Defaults**. The file generates and the number of differences displays.
2. To save the report, click **File > Save As**, select the TXT, PDF, or CSV format from the drop-down list, and enter a name for the file.

In the figure, the first entry is from the device, while the second is the default value.

```
137, File1 , Trip Bus Input, 1__1__3, 1 (ON)
138, File2 , Trip Bus Input, 1__1__3, 0 (OFF)
139, File1 , Virtual Output Events, 1__64__1, 0 (Disabled)
140, File2 , Virtual Output Events, 1__64__1, 1 (Enabled)
141, File1 , Virtual Output Name, 1__64__1, Virt Op 64
142, File2 , Virtual Output Name, 1__64__1, Osc Trigger
```

**Figure 400: Device settings compared with default values**

### Compare two devices

Preferences are set under **File > Preferences** as follows:

#### *Comparison Report: Sequential File 1, File 2 Layout*

When disabled (default), the report shows only what differs, as shown in the previous figure. When enabled, the report indicates differences by device.

```
1, File2 , Existing 7.40 IEC61850 settings removed., ____, New IEC61850 settings added with default values.
2, File2 , Bkr Phase A Open, 1__1__1, 0 (OFF)
3, File2 , Bkr Phase B Open, 1__1__1, 0 (OFF)
4, File2 , Bkr Phase C Open, 1__1__1, 0 (OFF)
5, File2 , Breaker Restrike Block, 1__1__1, 0 (OFF)
6, File2 , Breaker Restrike Block, 1__2__1, 0 (OFF)
7, File2 , Breaker Restrike Brk Open, 1__1__1, 0 (OFF)
8, File2 , Breaker Restrike Brk Open, 1__2__1, 0 (OFF)
9, File2 , Breaker Restrike CIs Cmd, 1__1__1, 0 (OFF)
10, File2 , Breaker Restrike CIs Cmd, 1__2__1, 0 (OFF)
```

**Figure 401: Device settings compared between two devices, displayed sequentially**

To compare settings of two devices in the Offline Window area:

1. Right-click a first device in the Offline Window area and select **Compare Two Devices**.
2. In the window that opens, select a second device and click the OK button. The file generates and the number of differences displays.  
  
Alternatively, in the window that opens, enter a path/file name at the bottom of the window; users can select either a URS or a CID file. When selecting URS files users should be aware that for IEC 61850 order codes the information in a URS data file is incomplete and therefore a comparison with an IEC 61850-enabled device will show many differences.
3. To save the report, click **File > Save As**, select the TXT, PDF, or CSV format from the drop-down list, and enter a name for the file.

To compare settings between Online and Offline devices:

1. Right-click a device in the Online Window area and select **Compare with Device**.
2. In the window that opens, select an offline device and click the OK button. The file generates and the number of differences displays.

Alternatively, in the window that opens, enter a path/file name at the bottom of the window; users can select either a URS or a CID file. When selecting URS files users should be aware that for IEC 61850 order codes the information in a URS data file is incomplete and therefore a comparison with an IEC 61850-enabled device will show many differences.

3. Click the **OK** button. The file generates, and the differences are highlighted in red, which is for the first device.

---

## 14.4.7 BACK UP AND RESTORE SETTINGS

Back up a copy of the in-service settings for each commissioned UR device, so as to revert to the commissioned settings after inadvertent, unauthorized, or temporary setting changes are made, after the settings defaulted due to firmware upgrade, or when the device has to be replaced. This section describes how to backup settings to a file and how to use that file to restore the settings to the original relay or to a replacement relay.

For reference, settings can be saved with **Online > Print Device Information** and **Online > Export Device Information**. They cannot be restored using these options.

### 14.4.7.1 BACK UP SETTINGS

The following file types can be saved:

- URS — UR settings file — When the IEC 61850 option is not present
- IID — Instantiated IED capability description file — Actual settings on UR
- ICD — IED Capability Description file — Default settings on UR
- CID — Configured IED description file — Settings sent to the UR (may or may not contain the present settings)

UR device settings can be saved in a backup URS file using the EnerVista UR Setup software. The URS file is the standard UR settings file. For an introduction to settings files in the URS format, see the beginning of the Interfaces chapter.

When the IEC 61850 option is present, the settings can be saved alternatively in a backup IID file either using the EnerVista UR Setup software in online mode or by using any of the supported file transfer protocols. The IID file is one of several IEC 61850 Substation Configuration Language (SCL) file types; see the IEC 61850 chapter in the UR Series Communications Guide for an introduction to SCL.

**TBD** displays when a setting in a modeled element is configured with a non-modeled operand. For example, Phase IOC is modeled in a firmware release, while the LED operands are not modeled. If the block setting of the Phase IOC is configured with LED operands, it displays as TBD in IID and CID files, the web interface, or in an MMS client.

The options that display in the EnerVista software when right-clicking depend on device options.

Preferences are set in the **File > Preferences > IEC 61850** menu. There are two options as follows:

#### Preserve custom attributes when importing SCD/CID files

This applies to the **Add Device to Offline Window** option. When enabled, the IID file also is to be copied to the computer. The IID file that is retrieved from the relay is therefore assumed to be in synchronization with the resulting .urs file, and in fact in this situation the IID file on the computer is a copy of the IID file that was read from the online device. When disabled, the IID file on the computer is to be left unchanged. The location of the IID file is C:\ProgramData\GE Power Management\urpc\Offline, for example.

#### Do not update IID file when updating SCL files

When enabled (default), an IID file is not to be created on the computer and if one is already present there, it is neither removed nor updated. Have this option enabled when you want to keep the IID file from the UR device instead of from another tool. The location of the file is C:\ProgramData\GE Power Management\urpc\Offline, for example.

An Environment backup stores a list of sites and devices in the Online and Offline Window areas. Settings files are not contained within the environment file. If a settings file is moved, renamed, or deleted after the backup, it is removed from the Offline Window during the restore.

To save a settings file in the URS format in EnerVista Online Window:

1. In EnerVista, connect to the device in the Online Window area.
2. Right-click the device name in the Online Window area and select **Add Device to Offline** Window. A window opens.
3. Select or enter a file name and location, and click the **Receive** button. A `.urs` file is created in the Offline Window area.

To create a new settings file in the URS format in EnerVista Offline Window:

1. In EnerVista, right-click in the Offline Window area and select **New Device**. A window opens.
2. Change the file name at the end of the Path field, keeping the `.urs` extension.
3. From the **Associate File with Device** drop-down list, select the UR device. Other fields complete automatically. Otherwise, when you do not select a device from the drop-down list, all fields need to be completed manually and only devices that match the entered order code and version display in the list.
4. The **Serial # Lock** field is the serial number of the intended device. It ensures that the settings file is sent only to the specific relay that matches the serial number.
5. Click the **OK** button to create the `.urs` file in the Offline Window area.

To save settings in the IID format in EnerVista Online Window:

1. In EnerVista, connect to the device in the Online Window area.
2. Right-click the device name in the Online Window area and select **Read IID File**. The option is not present when the device does not have the IEC 61850 option. A window opens when successful.
3. Select or enter a file name and location, and click the **Receive** button. A `.iid` file is created.

To save settings in the IID format in EnerVista Offline Window:

1. In EnerVista, right-click the device in the Offline Window area.
2. Select the **Create IID File** option for firmware below 7.3. The option is not always available. Select the **Save As** option for firmware 7.3 and later, and select the IID option from drop-down list.  
No file is generated. The IID file on the computer is copied to the location specified.
3. If the **Do not update IID file when updating SCL files** preference is enabled under **File > Preferences > IEC 61850**, then a message displays to that effect. This means that there is no IID file available on the computer to be copied, so a new one is generated.

To save settings in the IID format using TFTP:

1. On a computer on the same subnetwork as the UR device, open a command window.
2. Enter

```
TFTP <IP address> GET ur.iid <destination>
```

where

- <IP address> is the IP address of the UR device
- ur.iid is the internal name of the IID file in the UR device
- <destination> is the path and file name of the IID file. If omitted, the file is saved as ur.iid in the command window default directory.

An example is

```
TFTP 192.168.1.101 GET ur.iid Feeder1.iid
```

To save settings in the ICD format in EnerVista Online Window:

1. In EnerVista, right-click the device in the Online Window area.
2. Select the **Read ICD File** option. A window opens.
3. Enter a path/name for the file, and click the **Save** button.

To save settings in the ICD format in EnerVista Offline Window:

1. In EnerVista, right-click the device in the Offline Window area.
2. Select the **Create ICD File** option. Or select the **Save As** option, and select the ICD option from drop-down list.

You can be prompted to specify if the file is for firmware version 7.12 or later.

The file is saved to the location specified.

To save settings in the CID format in EnerVista Online Window:

1. In EnerVista, right-click the device in the Online Window area.
2. Select the **Read ICD File** option. A window opens.
3. Enter a path/name for the file, and click the **Save** button.

To save settings in the CID format in EnerVista Offline Window:

1. In EnerVista, right-click the device in the Offline Window area.
2. Select the **Save As** option, which displays for firmware 7.3 and later, and select the CID option from the drop-down list.

The file is copied from the computer to the location specified.

To save list of sites and devices with an Environment backup:

In EnerVista, click **File > Environment > Backup**. A window opens.

Name and save the .ENV file.

### 14.4.7.2 RESTORE SETTINGS

UR device settings can be restored to the values they were at when a URS backup file was created using the EnerVista UR Setup software. When the IEC 61850 option is present, the settings can alternatively be to the values they were at when an IID type backup was created either using the EnerVista UR Setup software in online mode or by using any of the supported file transfer protocols. Note that TFTP cannot be used here, as TFTP *put* mode is disabled for security reasons.


To restore completely, a few settings need to be entered manually either via EnerVista UR Setup or via the UR device front panel. If the restore operation is to be via Ethernet, first the UR device must have its IP address settings entered via the front panel. These are located at **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > NETWORK 1(3)** and **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > IPv4 ROUTE TABLE 1(6) > DEFAULT IPv4 ROUTE δ GATEWAY ADDRESS**.

When importing a file, it cannot have a blank numeric value. All numeric values must be non-blank, otherwise the file is rejected.

URS and IID procedures are outlined here.

To restore settings from a URS file:

1. In EnerVista, connect to the device in the Online Window area.
2. Right-click the .urs file in the Offline Window area and select **Add Device from File** to locate a file, and/or drag-and-drop the file from the Offline Window area to the device in the Online Window area.




**Figure 402: Restoring a URS settings file**

3. Two prompts are possible, first that the URS file does not include the complete IEC 61850 configuration and that it needs to be recreated if you continue. This means that the URS file is from UR version 7.30 or higher, has the IEC 61850 software option in the order code, but any IEC 61850 content will be compromised and will need to be configured.  
 Second, a message can display that the URS file is part of a device folder and to use the device's CID file. This means that the URS file is from UR version 7.3 or higher, has the IEC 61850 software option in the order code, and is part of the device folder. The user is trying to add a URS file from inside a device's folder. Instead, the user needs to use the CID file from the device folder.  
 These messages display because the roles of the protection engineer and network engineer can be separate. The former can require a URS file, while the latter can require stored Modbus settings and protection schemes.
4. Manually copy the remaining settings, outlined as follows.

To restore settings from an IID file using EnerVista software:

1. In Windows, make a copy of the .iid backup file, and change the extension to .cid on the new copy.
2. In the Online Window area of the UR EnerVista Setup software, connect to the device to establish communication.

3. In the Offline Window area, right-click **Devices** and select **Import Devices from SCD**.



**Figure 403: Importing an SCD or CID file**

4. Navigate to and select the file with .cid extension. When prompted, enter a file name to give to an intermediate URS file. The URS file is added to the Offline Window area.
5. Drag the imported file in the Offline Window to the device in the Online Window. Note that the RELAY SETTINGS value also is written to a device, and the accepting relay is put into "Programmed" or "Not Programmed" mode as configured in the offline file.
6. Manually copy the remaining settings, outlined as follows.

To restore settings from an IID using SFTP:

1. Verify that transfer by SFTP is enabled under **SETTINGS > PRODUCT SETUP > COMMUNICATIONS > PROTOCOL > SFTP PROTOCOL**.
2. Close EnerVista UR Setup software.
3. In Windows, make a copy of the .iid backup file, and change the extension to .cid on the new copy.
4. On a computer on the same subnetwork as the UR device, open an SFTP client application, such as WinSCP. Note that TFTP cannot be used here.
5. Use the device's IP address as the host name.
6. If the device has the CyberSentry option, use the User Name of *Administrator* or *Engineer*, and the password programmed for the selected role. The default password is *ChangeMe1#* (without quotation marks). Log in to the device.
7. If the device does not have the CyberSentry option, use the User Name of *Setting*, and the password programmed for the Setting role. The default password is *ChangeMe1#* (without quotation marks). Log in to the device.
8. Upload the backup file copy with the .cid extension. WinSCP uses drag-and-drop or copy-and-paste for this file transfer.
9. Manually copy the remaining settings, outlined as follows.

To manually copy remaining settings:

1. Settings files are not transferred to the UR device with settings files. Enter them manually either via the front panel or via EnerVista UR Setup software. The values that these settings had at the time the backup was created are contained within the backup file, accessed through EnerVista UR Setup software.

To restore the list of sites and devices from an Environment backup:

1. In EnerVista, click **File > Environment > Restore**. A window opens.
2. Select the .ENV file to restore.



### 14.4.8 UPGRADE SOFTWARE

EnerVista can be used with all firmware versions. For example, EnerVista software released for UR 8.2 can be used to access multiple UR devices that have version 8.2x, 7.4x, and 6.0x firmware installed.

Existing installations do not need to be uninstalled before upgrade.

You can also downgrade the software; use the same procedure. A product can be downgraded as far as its first release.

Silent installation also is possible.

To upgrade the EnerVista software:

1. If a beta version of the EnerVista UR Setup software is installed, uninstall it.
2. Disconnect any USB cables to ensure correct USB driver installation.
3. Download the latest EnerVista software.
4. Double-click the file and complete the wizard. The software installs.
5. Access the software.

The prompt `Do you want to create device folders for all your pre-existing off line devices` determines the folder structure on the computer. Clicking **Yes** means that CID, ICD, and URS files are to be grouped together in a folder, and the URS file is also one level above. Clicking **No** leaves folder structure unchanged.

6. Check the version number under **Help > About**. If the new version does not display, try uninstalling the software and reinstalling the new version.
7. For Windows 10, to finish installing the UR USB driver, open **Device Manager > Ports**, then plug in the USB cable (to connect the relay and computer). A new port starting with "GE Virtual Serial Port" is available. If available, click the **OK** button to complete the installation.


If not available, uninstall the existing GE USB driver in the **Device Manager > Ports**. (Right-click and **Uninstall**)

When complete, unplug and re-plug the USB cable connecting the UR device. The **GE Virtual Serial Port** driver is now available.

A message can display about a version not being supported. An example is when upgrading from version 7.12K to 7.4x. The 7.12K entry is removed from the Offline Window area.

A message can display in the EnerVista software upon launch that `a device from the environment was not recognized`. This means that a device is online and its firmware version conflicts with the software version. In the example shown, a C60 with firmware version 7.5x is online, but the software version is 7.3x. Updating removed incompatible files and changed the device to version 7.3x, after which you need to make the order codes consistent as outlined next.





**Figure 404: Mismatch in order code between software and device**

To make the order codes consistent:

1. In EnerVista, click the **Device Setup** button. The window opens.
2. Expand the entry for the UR device.
3. Click the **Read Order Code** button. The order code and version of the device are populated to the software.
4. Click the **OK** button to save the change.

The silent installation is not truly silent because it invokes the user interface. The installation is silent at step 5. Double-clicking on the .exe file for installation is faster.

To install the software silently:

1. Uninstall any existing EnerVista UR Setup software.
2. In a command line window, run the executable file, such as entering `URPC810.exe -r`
3. Follow the prompts to install the software using the wizard. The action creates a setup.iss file in the C:\WINNT, C:\Windows\Setup, or other folder that records user inputs.
4. Copy the .exe and .iss files to the same folder.
5. In a command line window, enter `URPC850.exe /S /v/qn`, where `URPC810.exe` is the executable file name. The software installs and generates a setup.log file in the same folder. A result code of "0" at the end of the log file means that the installation succeeded.

#### 14.4.9 UPGRADE FIRMWARE

**Note:**

*If upgrading both firmware and EnerVista software, upgrade the software first.*

The firmware of the Product device can be upgraded locally or remotely, using the EnerVista software.

Upgrades are possible for the same release (such as 8.01 to 8.02) and from one firmware version to another (such as 7.2 to 7.3). When upgrading to another firmware version, check the release notes on the GE Vernova website for compatibility.

If you are upgrading from version 7.0 or 7.1 to 7.2 or later, some CPU modules require a new boot version. Update this first.

Address any equipment mismatch error before upgrade. For example, if you have a basic front panel attached and the order code in the device is for a graphical front panel, the upgrade only works with a graphical front panel.

You can also downgrade firmware; use the same procedure. A Product is downgradeable as far as its first release.

Upgrading the firmware takes the relay out of service. At the end of the upgrade, the relay restores the “In Service” state that existed before the upgrade.

Any DSP manufactured between 1 January 2013 and 1 December 2015 with versions 7.27, 7.28, or 7.60 and up must be sent back to the factory for updates before updating the firmware.

To upgrade the firmware using EnerVista software:

1. Download the bootcode file and/or firmware from <http://www.gegridsolutions.com/app/ViewFiles.aspx?prod=urfamily&type=7>. The firmware is a .SFD file. The boot file is a .000 file. Bootcode files 7.03 and later are for CPUs T, U, V, or W, which have 9T, 9U, 9V, or 9W on the label.
2. For a relay without the CyberSentry software option, navigate to **Settings > Product Setup > Security** and ensure that the Remote Setting Authorized and Local Setting Authorized settings are ON. On the front panel of the device, the path is **SETTINGS > PRODUCT SETUP > SECURITY > DUAL PERMISSION SECURITY ACCESS**.
3. For a relay with CyberSentry Lvl 1 software option, navigate to **Settings > Product Setup > Security > Access Supervision** or **Settings > Product Setup > Security > Supervisory** and disable the **Lock Firmware** setting. To change this setting, the Supervisor role is required, or the Administrator role if the Supervisor role is not used.
4. In EnerVista, back up the device settings by right-clicking the device and selecting **Add Device to Offline Window**. In the window that displays, select an existing file to overwrite, or enter a name for a new settings file and optionally a location for the new file. Click the **Receive** button to start the backup. If an **Incompatible device order codes or versions** message displays, it means that you are trying to overwrite a file for another product. You access the **Convert Device Settings** option by right-clicking the file in the Offline Window area at the lower left. GE recommends converting settings in firmware steps, for example when converting from 6.0 to 7.4x, convert first to 7.0 then 7.4 in order to follow embedded conversion rules and keep settings. Note that the values of all settings that have been defaulted during conversion are not listed in the conversion report; to find the value of a setting before conversion, inspect the device backups made before conversion.
5. In EnerVista, navigate to **Maintenance > Update Firmware**. First select the boot file, if applicable, locating the .000 file, and proceed with the update. Note that settings are not lost during this update. When done, the relay restarts automatically; continue with the next step.

**Note:**

When updating the boot file, ensure that power is not lost, else the relay must be returned to the factory for repair.

To update the firmware, select the firmware update by locating the .SFD file, and proceed with the update.

EnerVista software only enables users to upgrade the firmware in the relay after validating the source of the SFD file and its authenticity, by verifying the digital signature included in the file before sending it to the relay. If the digital signature validation fails, the firmware upgrade process is aborted. If the digital signature validation succeeds, EnerVista proceeds with the firmware upgrade. The relay records the outcome of the signature validation in the security events.

When asked if upgrading over the Internet, the difference is the flash memory buffer size each time the software sends data to the relay. Yes means that the flash memory buffer size is 256 bytes. No means that it is 1024 bytes, which is faster.

If a warning message displays about the firmware not being supported by the EnerVista software, it means that the firmware is a later version than the software. Upgrade the software to the same or later version as the firmware, then try again.

If an **Unable to put relay in flash mode** message displays, set the **Settings > Product Setup > Security > Dual Permission Security Access > Remote Setting Authorized** and **Local Setting Authorized** settings to ON and try again.

When the update is finished, the relay restarts automatically. The upgrade process takes about 20 minutes when using a graphical front panel because of writing to the front panel.

6. Restart the EnerVista software, and refresh the order code in EnerVista under the **Device Setup** button.
7. Verify the boot and firmware version while the device is starting up or in EnerVista under **Actual Values > Product Info > Firmware Revisions**. The **Revision** is the firmware version, for example, revision 8.20 is UR firmware release 8.20. The Boot Program Revision is the bootloader release.

| Field                        | Value                                  |
|------------------------------|----------------------------------------|
| Revision                     | 8.20                                   |
| Modification File Number     | 0                                      |
| Boot Program Revision        | 7.03                                   |
| Front Panel Program Revision | 2.01                                   |
| Compile Date                 | Wednesday, February 24, 2021 19:38:27  |
| Boot Date                    | Wednesday, September 30, 2020 12:55:37 |
| FPGA Version                 | 02.02                                  |
| FPGA Date                    | Monday, March 28, 2016 16:49:00        |
| PBM Boot Version             | 1.89                                   |

**Figure 405: Check upgrades**

8. Set the device to *programmed* under **Settings > Product Setup > Installation**. A self-test error displays on the device until this is done.
9. If you changed the **Remote Setting Authorized**, the **Local Setting Authorized** settings, or relay lock settings, return them to their previous settings.
10. If you changed the **Lock Firmware** setting, enable it again.
11. To apply any previously saved settings, right-click the saved settings file in the Offline Window area and select **Write to Device**. Optionally convert the saved settings to the new firmware version before writing to the device by right-clicking and selecting **Convert Device Settings**.

**Note:**

The field-programmable gate array (FPGA) can be upgraded under **Maintenance > Update FPGA** when the device is connected via serial cable and the firmware revision is 7.0 or higher.

Modbus addresses assigned to firmware modules, features, settings, and corresponding data items (that is, default values, minimum/maximum values, data type, and item size) can change slightly from version to version of firmware. The addresses are rearranged when new features are added or existing features are enhanced or modified. The EEPROM DATA ERROR message displayed after upgrading/downgrading the firmware is a resettable, self-test message intended to inform users that the Modbus addresses have changed with the upgraded firmware. This message does not signal any problems when appearing after firmware upgrades.

## 14.4.10 UNINSTALL AND CLEAR FILES AND DATA

The unit can be decommissioned by turning off power to the unit and disconnecting the wires to it.

To clear files and settings in the UR:

1. On the UR front panel, navigate to **COMMANDS > RELAY MAINTENANCE > SERVICE COMMAND**, enter the value 20511, and press the **ENTER** key. The relay restarts and clears the UR.
2. Clear the flash memory using the **SETTINGS > PRODUCT SETUP > CLEAR RELAY RECORDS** command.

To clear files and settings on the computer:

1. Uninstall the EnerVista UR Setup software.
2. Find and delete the following UR files:
  - .URS, .CID, and .ICD settings
  - .EVT event records
  - .CFG and .DAT COMTRADE

## 14.5 REPLACE MODULE

**Warning:**

Withdraw or insert a module only when control power has been removed from the unit, and be sure to insert only the correct module type into a slot, else personal injury, damage to the unit or connected equipment, or undesired operation can result.

**Note:**

To avoid damage to the equipment, use proper electrostatic discharge protection (for example, a static strap) when coming in contact with modules while the relay is energized.

The relay, being modular in design, allows for the withdrawal and insertion of modules. Replace modules only with like modules in their original factory configured slots.

Two procedures follow: replace a module with the same module, and upgrade a module.

To replace a module with the same module:


1. Open the enhanced front panel to the left once the thumb screw has been removed. This allows for easy access of the modules for withdrawal. The new wide-angle hinge assembly in the enhanced front panel opens completely and allows easy access to all modules in the Product.



842812A1.CDR

**Figure 406: Modules inside relay with front cover open (enhanced front panel)**

The basic front panel can be opened to the left once the black plastic sliding latch on the right side has been pushed up, as shown below.



B42760A1.CDR

**Figure 407: Removing module (basic front panel)**

2. With power to the unit off, disconnect individually the connections at the front and back of the module before removing the module from the chassis. For any Process Bus Module in slot H for use with a HardFiber Brick, also remove the two screws at the back that attach the module to the chassis.
3. To properly remove a module, pull simultaneously the ejector/inserter clips, located at the top and bottom of the module.
4. Record the original location of the module to ensure that the same or replacement module is inserted into the correct slot. While modules with current input provide automatic shorting of external CT circuits, for CT/VT modules it is recommended to short/isolate external circuits accordingly for maximum safety.
5. To properly insert a module, ensure that the correct module type is inserted into the correct slot position. The ejector/inserters located at the top and at the bottom of each module must be in the disengaged position as the module is smoothly inserted into the slot. Once the clips have cleared the raised edge of the chassis, engage the clips simultaneously. When the clips have locked into position, the module is fully inserted.

**Note:**

When adding a module (versus replacing a module), check that settings have not changed. Depending on the module, settings can reset to default values.

**Note:**

For applicable models, the new CT/VT modules can only be used with new CPUs; similarly, old CT/VT modules can only be used with old CPUs. In the event that there is a mismatch between the CPU and CT/VT module, the relay does not function and a DSP ERROR or HARDWARE MISMATCH error displays.

An upgrade example is replacing the CPU module with a more recent one, such as swapping 9G/9H/9N with 9T/9U/9V/9W. A power supply module upgrade does not affect an order code.

To upgrade a module:

1. Back up settings by sending the device to the Offline Window area. C
2. Convert the settings to the new order code by right-clicking in the Offline Window area.
3. Replace the module as outlined in the previous procedure.

4. In the Online Window area, reset all settings to factory defaults and read the new order code from the device using **Commands > Relay Maintenance > Update Order Code**.
5. Send the saved settings from the Offline Window area to the online device.
6. Refresh the order code in the **Device Setup** window and set the device to "*Programmed*" under **Settings > Product Setup > Installation**.



## 14.6 BATTERY

For the SH and SL models and earlier, a battery provides backup power for the real-time clock. The TH and TL models do not contain a battery, they use a supercapacitor to provide backup power for the relay's real time clock.

For the SH and SL models, the battery can be replaced when required. The battery type is 3 V cylindrical. Lithium metal primary (non-rechargeable) batteries, Panasonic BR-2/3A or Varta CR-2/3A. Due to shipping restrictions GE no longer sells replacement batteries, but they can be purchased through retail vendors such as Digikey.

**Note:**

*GE Vernova reserves the right to replace the current battery for an equivalent model and/or vendor*

For the TH and TL models, no maintenance is required.

**Note:**

*The power supply modules were upgraded in in the past from RH/RL to SH/SL. However, the order code when purchasing a UR with redundant power supply remained as RH/RL so that customers can continue to use the same order codes. The order code can read RH or RL, while the module inside the unit reads SH, SL, TH, or TL. The order code remains RH for power supplies RH/SH/TH and RL for power supplies RL/SL/TL.*

This does not apply to replacement modules. The order code for replacement redundant power supply modules is SH, SL, TH, or TL.

### 14.6.1 REPLACE BATTERY

Depending on the type, the power supply module may contain a battery. If applicable and when required, the battery can be replaced. If you need to replace the battery, follow the instructions below.



**Warning:**

**To avoid injury, ensure that the unit has been powered off for a minimum of three minutes before replacing the battery.**


**Warning:**

**There is a risk of fire if the battery is replaced with an incorrect type or polarity.**

1. Turn off the power to the unit.
2. Wait a minimum of three minutes to ensure that there is no power to the battery.
3. Open the unit by sliding up the plastic latch on the right side of the front panel (basic front panel) or unscrewing the panel (enhanced front panel).
4. For the basic front panel, it needs to be removed in order to access the power supply module, which is typically in the first slot on the left side and blocked by the hinge of the front panel. To remove the front panel, unscrew the bracket on the left side of the unit.
5. Remove the power supply module by simultaneously pulling the ejector clips at the top and bottom of the module and sliding it out.
6. Unscrew all four screws that attach the metal cover to the module. The fourth screw is at the back end of the module, on the opposite side from the clips, beside the white electronics part (see figure).
7. Slide the metal cover away from the clips about 0.5 cm (1/8 inch) and remove the cover.
8. Unclip the black plastic holder that keeps the battery in place. The plastic clips into the socket at the bottom on both sides.



9. Pull the plastic away from the battery. Use a flat-head screwdriver if you cannot unclip the plastic with your fingers.
10. Replace the battery with the identical make and model. Observe the + and - polarity of the battery and replace it with the same polarity as marked on the battery holder.



859717A1.cdr

**Figure 408: Battery location on power supply module**

11. Reinstall the battery holder and the metal cover, and reinsert the power supply module into the unit.
12. Power on the unit.

### 14.6.2 DISPOSE OF BATTERY

This product may contain a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling return the battery to your supplier or to a designated collection point. For more information see: [www.recyclethis.info](http://www.recyclethis.info).

---

## 14.7 REPAIRS

---

The battery and modules inside the case can be replaced without return of the device to the factory. The firmware and software can be upgraded without return of the device to the factory.

Fuses in the power supply module are not field-replaceable.

Files can be requested for use by technical support staff, for example the Service Report or under ***Maintenance > Retrieve File***, as outlined elsewhere in this document.

For issues not solved by troubleshooting, the process to return the device to the factory for repair is as follows:

1. Contact a GE Vernova Technical Support Center. Contact information is found in the first chapter.
2. Obtain a Return Materials Authorization (RMA) number from the Technical Support Center.
3. Verify that the RMA and Commercial Invoice received have the correct information.
4. Tightly pack the unit in a box with bubble wrap, foam material, or styrofoam inserts or packaging peanuts to cushion the item(s). You may also use double boxing whereby you place the box in a larger box that contains at least 5 cm of cushioning material.
5. Ship the unit by courier or freight forwarder, along with the Commercial Invoice and RMA, to the factory.

GE Vernova

650 MARKLAND STREET

MARKHAM, ONTARIO

CANADA L6C 0M1

ATTN: SERVICE DEPT.

RMA# : \_\_\_\_\_

Customers are responsible for shipping costs to the factory, regardless of whether the unit is under warranty.

Use the detailed return procedure outlined at

<https://www.governova.com/grid-solutions/return-procedures>

The current warranty and return information are outlined at:

<https://www.governova.com/grid-solutions/multilin/warranty>

---

## 14.8 STORAGE AND DISPOSAL

---

Store the unit indoors in a cool, dry place. If possible, store in the original packaging. Follow the storage temperature range outlined in the Specifications.

*Note:*

*To avoid deterioration of electrolytic capacitors, power up units that are stored in a de-energized state once per year, for one hour continuously.*

Other than the battery, there are no special requirements for disposal of the unit at the end its service life. For customers located in the European Union, dispose of the battery as outlined earlier. To prevent non-intended use of the unit, remove the modules as outlined earlier, dismantle the unit, and recycle the metal when possible. See the UR Family Recycling and Disposal Instructions (GET-20096).

## CHAPTER 15

# APPENDICES

## 15.1 ABBREVIATIONS

| Abbreviation | Meaning                                     |
|--------------|---------------------------------------------|
| A            | Ampere                                      |
| AC           | Alternating Current                         |
| A/D          | Analog to Digital                           |
| AE           | Accidental Energization, Application Entity |
| AMP          | Ampere                                      |
| ANG          | Angle                                       |
| ANSI         | American National Standards Institute       |
| APDU         | Application Protocol Data Unit              |
| AR           | Automatic Reclosure                         |
| ARP          | Address Resolution Protocol                 |
| ASDU         | Application-layer Service Data Unit         |
| ASYM         | Asymmetry                                   |
| AUTO         | Automatic                                   |
| AUX          | Auxiliary                                   |
| AVG          | Average                                     |
| AWG          | American Wire Gauge                         |
|              |                                             |
| BCD          | Binary-Coded Decimal                        |
| BCS          | Best Clock Selector                         |
| BER          | Bit Error Rate                              |
| BF           | Breaker Fail                                |
| BFI          | Breaker Failure Initiate                    |
| BKR          | Breaker                                     |
| BLK          | Block                                       |
| BLKG         | Blocking                                    |
| BNC          | Bayonet Neill-Concelman                     |
| BPNT         | Breakpoint of a characteristic              |
| BRKR         | Breaker                                     |
|              |                                             |
| CA           | Certificate Authority                       |
| CAP          | Capacitor                                   |
| CC           | Coupling Capacitor                          |
| CCVT         | Coupling Capacitor Voltage Transformer      |
| CFG          | Configure / Configurable                    |
| .CFG         | Filename extension for oscillography files  |
| CHK          | Check                                       |
| CHNL         | Channel                                     |
| CID          | Configured IED Description                  |
| CLS          | Close                                       |
| CLSD         | Closed                                      |
| CMND         | Command                                     |

| Abbreviation | Meaning                             |
|--------------|-------------------------------------|
| CMPRSN       | Comparison                          |
| CO           | Contact Output                      |
| COM          | Communication                       |
| COMM         | Communications                      |
| COMP         | Compensated, Comparison             |
| ConfRev      | Configuration Revision              |
| CONN         | Connection                          |
| CONT         | Continuous, Contact                 |
| CO-ORD       | Coordination                        |
| CPU          | Central Processing Unit             |
| CRC          | Cyclic Redundancy Code/Check        |
| CRL          | Certificate Revocation List         |
| CRT, CRNT    | Current                             |
| CSA          | Canadian Standards Association      |
| CT           | Current Transformer                 |
| CVT          | Capacitive Voltage Transformer      |
|              |                                     |
| D/A          | Digital to Analog                   |
| DA           | Data Attribute                      |
| DANH         | Doubly Attached Node with HSR       |
| DANP         | Doubly Attached Node with DANP      |
| DC (dc)      | Direct Current                      |
| DCE          | Data Communications Equipment       |
| DCS          | Distributed Control System          |
| DD           | Disturbance Detector                |
| DFLT         | Default                             |
| DGNST        | Diagnostics                         |
| DIFF         | Differential                        |
| DIR          | Directional                         |
| DISCREP      | Discrepancy                         |
| DIST         | Distance                            |
| DMD          | Demand                              |
| DNP          | Distributed Network Protocol        |
| DPO          | Dropout                             |
| DPS          | Double-Point Status                 |
| DSP          | Digital Signal Processor            |
| DST          | Daylight Savings Time               |
| dt           | Rate of Change                      |
| DTT          | Direct Transfer Trip                |
| DUTT         | Direct Under-reaching Transfer Trip |
|              |                                     |
| EAD          | Expert Arc Detector                 |
| EGD          | Ethernet Global Data                |

| Abbreviation | Meaning                                     |
|--------------|---------------------------------------------|
| ENCRMNT      | Encroachment                                |
| EPRI         | Electric Power Research Institute           |
| .EVT         | Filename extension for event recorder files |
| EXT          | Extension, External                         |
|              |                                             |
| F            | Field                                       |
| FAIL         | Failure                                     |
| FCDA         | Functional Constraint Data Attributes       |
| FD           | Fault Detector                              |
| FDH          | Fault Detector high-set                     |
| FDL          | Fault Detector low-set                      |
| FIR          | Finite Impulse Response                     |
| FLA          | Full Load Current                           |
| FO           | Fiber Optic                                 |
| FPGA         | Field-programmable Gate Array               |
| FREQ         | Frequency                                   |
| FSK          | Frequency-Shift Keying                      |
| FTP          | File Transfer Protocol                      |
| FxE          | FlexElement™                                |
| FWD          | Forward                                     |
|              |                                             |
| G            | Generator                                   |
| GCM          | Galois Counter Mode                         |
| GDOI         | Group Domain of Interpretation              |
| GFP          | Graphical Front Panel                       |
| GIS          | Gas Insulated Switchgear                    |
| GND          | Ground                                      |
| GNTR         | Generator                                   |
| GoCB         | GOOSE Control Block                         |
| GOOSE        | General Object Oriented Substation Event    |
| GPS          | Global Positioning System                   |
| GSU          | Generator Step-Up                           |
|              |                                             |
| HARM         | Harmonic / Harmonics                        |
| HCT          | High Current Time                           |
| HGF          | High-Impedance Ground Fault (CT)            |
| HIZ          | High-Impedance and Arcing Ground            |
| HMI          | Human-Machine Interface                     |
| HSR          | High-availability Seamless Redundancy       |
| HTTP         | Hyper Text Transfer Protocol                |
| HV           | High Voltage                                |
| HYB          | Hybrid                                      |
| Hz           | Hertz                                       |

| Abbreviation   | Meaning                                          |
|----------------|--------------------------------------------------|
| I              | Instantaneous                                    |
| I <sub>0</sub> | Zero Sequence current                            |
| I <sub>1</sub> | Positive Sequence current                        |
| I <sub>2</sub> | Negative Sequence current                        |
| IA             | Phase A current                                  |
| IAB            | Phase A minus B current                          |
| IB             | Phase B current                                  |
| IBC            | Phase B minus C current                          |
| IC             | Phase C current                                  |
| ICA            | Phase C minus A current                          |
| ICD            | IED Capability Description                       |
| ID             | Identification                                   |
| IED            | Intelligent Electronic Device                    |
| IEC            | International Electrotechnical Commission        |
| IEEE           | Institute of Electrical and Electronic Engineers |
| IG             | Ground (not residual) current                    |
| Igd            | Differential Ground current                      |
| IGMP           | Internet Group Management Protocol               |
| IID            | Instantiated IED Capability Description          |
| IN             | CT Residual Current (3I <sub>0</sub> ) or Input  |
| INC SEQ        | Incomplete Sequence                              |
| INIT           | Initiate                                         |
| INST           | Instantaneous                                    |
| INV            | Inverse                                          |
| I/O            | Input/Output                                     |
| IOC            | Instantaneous Overcurrent                        |
| IOV            | Instantaneous Overvoltage                        |
| IRC            | Inter-Relay Communication                        |
| IRIG           | Inter-Range Instrumentation Group                |
| ISO            | International Standards Organization             |
| IUV            | Instantaneous Undervoltage                       |
|                |                                                  |
| K <sub>0</sub> | Zero Sequence Current Compensation               |
| kA             | kiloAmpere                                       |
| KDC            | Key Distribution Center                          |
| kV             | kiloVolt                                         |
|                |                                                  |
| LCD            | Liquid Crystal Display                           |
| LDBN           | Bias Neutral Level Detector                      |
| LED            | Light Emitting Diode                             |
| LEO            | Line End Open                                    |
| LFT BLD        | Left Blinder                                     |



| Abbreviation | Meaning                                 |
|--------------|-----------------------------------------|
| LOOP         | Loopback                                |
| LPU          | Line Pickup                             |
| LRA          | Locked-Rotor Current                    |
| LTC          | Load Tap-Changer                        |
| LV           | Low Voltage                             |
|              |                                         |
| M            | Machine                                 |
| M2M          | Machine to Machine                      |
| mA           | MilliAmpere                             |
| MAG          | Magnitude                               |
| MAN          | Manual / Manually                       |
| MAX          | Maximum                                 |
| Mb           | Megabit                                 |
| MIC          | Model Implementation Conformance        |
| MIN          | Minimum, Minutes                        |
| MMI          | Man Machine Interface                   |
| MMS          | Manufacturing Message Specification     |
| MRT          | Minimum Response Time                   |
| MSG          | Message                                 |
| MTA          | Maximum Torque Angle                    |
| MTR          | Motor                                   |
| MU           | Merging Unit                            |
| MVA          | MegaVolt-Ampere (total 3-phase)         |
| MVA_A        | MegaVolt-Ampere (phase A)               |
| MVA_B        | MegaVolt-Ampere (phase B)               |
| MVA_C        | MegaVolt-Ampere (phase C)               |
| MVAR         | MegaVar (total 3-phase)                 |
| MVAR_A       | MegaVar (phase A)                       |
| MVAR_B       | MegaVar (phase B)                       |
| MVAR_C       | MegaVar (phase C)                       |
| MVARH        | MegaVar-Hour                            |
| MW           | MegaWatt (total 3-phase)                |
| MW_A         | MegaWatt (phase A)                      |
| MW_B         | MegaWatt (phase B)                      |
| MW_C         | MegaWatt (phase C)                      |
| MWH          | MegaWatt-Hour                           |
|              |                                         |
| N            | Neutral                                 |
| N/A, n/a     | Not Applicable                          |
| NCIT         | Non-conventional instrument transformer |
| NEG          | Negative                                |
| NMPLT        | Nameplate                               |
| NOM          | Nominal                                 |

| Abbreviation | Meaning                                         |
|--------------|-------------------------------------------------|
| NTR          | Neutral                                         |
|              |                                                 |
| O            | Over                                            |
| OC, O/C      | Overcurrent                                     |
| OCSP         | Online Certificate Status Protocol              |
| OF           | Overload Factor                                 |
| O/P, Op      | Output                                          |
| OP           | Operate                                         |
| OPER         | Operate                                         |
| OPERATG      | Operating                                       |
| O/S          | Operating System                                |
| OSI          | Open Systems Interconnect                       |
| OSB          | Out-of-Step Blocking                            |
| OUT          | Output                                          |
| OV           | Overvoltage                                     |
| OVERFREQ     | Overfrequency                                   |
| OVL          | Overload                                        |
|              |                                                 |
| P            | Phase                                           |
| PB           | Process Bus                                     |
| PBM          | Process Bus Module                              |
| PC           | Phase Comparison, Personal Computer             |
| PCNT         | Percent                                         |
| PF           | Power Factor (total 3-phase)                    |
| PF_A         | Power Factor (phase A)                          |
| PF_B         | Power Factor (phase B)                          |
| PF_C         | Power Factor (phase C)                          |
| PFLL         | Phase and Frequency Lock Loop                   |
| PHS          | Phase                                           |
| PICS         | Protocol Implementation & Conformance Statement |
| PKI          | Public Key Infrastructure                       |
| PKP          | Pickup                                          |
| PLC          | Power Line Carrier                              |
| POS          | Positive                                        |
| POTT         | Permissive Over-reaching Transfer Trip          |
| PP           | Power Profile                                   |
| PPP          | Point-to-Point                                  |
| PPS          | Pulse per Second                                |
| PRESS        | Pressure                                        |
| PRI          | Primary                                         |
| PROT         | Protection                                      |
| PRP          | Parallel Redundancy Protocol                    |
| PSEL         | Presentation Selector                           |

| Abbreviation | Meaning                                  |
|--------------|------------------------------------------|
| PTP          | Precision Time Protocol                  |
| pu           | Per Unit                                 |
| PUIB         | Pickup Current Block                     |
| PUIT         | Pickup Current Trip                      |
| PUSHBTN      | Pushbutton                               |
| PUTT         | Permissive Under-reaching Transfer Trip  |
| PWM          | Pulse Width Modulated                    |
| PWR          | Power                                    |
|              |                                          |
| QUAD         | Quadrilateral                            |
|              |                                          |
| R            | Rate, Reverse                            |
| RA           | Registration Authority                   |
| RCA          | Reach Characteristic Angle               |
| RedBox       | Redundancy Box                           |
| REF          | Reference                                |
| REM          | Remote                                   |
| REV          | Reverse                                  |
| R-GOOSE      | Routable GOOSE                           |
| RI           | Reclose Initiate                         |
| RIP          | Reclose In Progress                      |
| RGT BLD      | Right Blinder                            |
| RMA          | Return Materials Authorization           |
| RMS          | Root Mean Square                         |
| ROCOF        | Rate of Change of Frequency              |
| ROD          | Remote Open Detector                     |
| RRTD         | Remote Resistance Temperature Detector   |
| RST          | Reset                                    |
| RSTR         | Restrained                               |
| RTD          | Resistance Temperature Detector          |
| RTU          | Remote Terminal Unit                     |
| RX (Rx)      | Receive, Receiver                        |
|              |                                          |
| s            | second                                   |
| S            | Sensitive                                |
| SAN          | Singly Attached Node                     |
| SAT          | CT Saturation                            |
| SBO          | Select Before Operate                    |
| SCADA        | Supervisory Control and Data Acquisition |
| SCC          | Serial Communication Controller          |
| SCD          | System Configuration Description         |
| SCL          | Substation Configuration Language        |
| SCEP         | Simple Certificate Enrollment Protocol   |

| Abbreviation | Meaning                                                                  |
|--------------|--------------------------------------------------------------------------|
| SEC          | Secondary                                                                |
| SEL          | Select / Selector / Selection                                            |
| SENS         | Sensitive                                                                |
| SEQ          | Sequence                                                                 |
| SFTP         | Secure Shell (SSH) File Transfer Protocol, Secure File Transfer Protocol |
| SIR          | Source Impedance Ratio                                                   |
| SmpSynch     | Samples Synchronized                                                     |
| SNTP         | Simple Network Time Protocol                                             |
| SRC          | Source                                                                   |
| SSB          | Single Side Band                                                         |
| SSEL         | Session Selector                                                         |
| STATS        | Statistics                                                               |
| SUPN         | Supervision                                                              |
| SUPV         | Supervise / Supervision                                                  |
| SV           | Supervision, Service, Sampled Value                                      |
| SYNC         | Synchrocheck                                                             |
| SYNCHCHK     | Synchrocheck                                                             |
|              |                                                                          |
| T            | Time, transformer                                                        |
| TC           | Thermal Capacity                                                         |
| TCP          | Transmission Control Protocol                                            |
| TCU          | Thermal Capacity Used                                                    |
| TD MULT      | Time Dial Multiplier                                                     |
| TEMP         | Temperature                                                              |
| TFTP         | Trivial File Transfer Protocol                                           |
| TGFD         | Transient Ground Fault Detection                                         |
| THD          | Total Harmonic Distortion                                                |
| TMR          | Timer                                                                    |
| TOC          | Time Overcurrent                                                         |
| TOV          | Time Overvoltage                                                         |
| TRANS        | Transient                                                                |
| TRANSF       | Transfer                                                                 |
| TSEL         | Transport Selector                                                       |
| TUC          | Time Undercurrent                                                        |
| TUV          | Time Undervoltage                                                        |
| TX (Tx)      | Transmit, Transmitter                                                    |
|              |                                                                          |
| U            | Under                                                                    |
| UC           | Undercurrent                                                             |
| UCA          | Utility Communications Architecture                                      |
| UDP          | User Datagram Protocol                                                   |
| UL           | Underwriters Laboratories                                                |
| UNBAL        | Unbalance                                                                |

| Abbreviation | Meaning                               |
|--------------|---------------------------------------|
| UR           | Universal Relay                       |
| URC          | Universal Recloser Control            |
| .URS         | Filename extension for settings files |
| UV           | Undervoltage                          |
|              |                                       |
| V/Hz         | Volts per hertz                       |
| V_0          | Zero Sequence voltage                 |
| V_1          | Positive Sequence voltage             |
| V_2          | Negative Sequence voltage             |
| VA           | Phase A voltage                       |
| VAB          | Phase A to B voltage                  |
| VAG          | Phase A to Ground voltage             |
| VARH         | Var-hour voltage                      |
| VB           | Phase B voltage                       |
| VBA          | Phase B to A voltage                  |
| VBG          | Phase B to Ground voltage             |
| VC           | Phase C voltage                       |
| VCA          | Phase C to A voltage                  |
| VCG          | Phase C to Ground voltage             |
| VF           | Variable Frequency                    |
| VIBR         | Vibration                             |
| VT           | Voltage Transformer                   |
| VTFF         | Voltage Transformer Fuse Failure      |
| VTLOS        | Voltage Transformer Loss Of Signal    |
|              |                                       |
| WDG          | Winding                               |
| WH           | Watt-hour                             |
| w/ opt       | With Option                           |
| WGS          | World Geodetic System                 |
| WRT          | With Respect To                       |
|              |                                       |
| X            | Reactance                             |
| XDUCER       | Transducer                            |
| XFMR         | Transformer                           |
|              |                                       |
| Z            | Impedance, Zone                       |

---

## 15.2 FLEXLOGIC OPERANDS

---

FlexLogic operands are digital parameters used to help design scheme logic.

The data items are kept in files attached to this PDF. Depending on the file type, the files may be opened using Microsoft Excel, or free web-based software such as Google Sheets, or PDF viewer capable of opening attachments, such as Adobe Acrobat Reader or Nitro PDF.

Please note that this manual must be opened with a PDF viewer capable of opening attachments, such as Adobe Acrobat Reader or Nitro PDF. Browsers like Microsoft Edge or Google Chrome do not support PDF attachments, although Firefox does. If using Nitro PDF, attachments are shown in the Attachment Pane. To show or hide the Attachments pane, look in the sidebar and click the Attachments tab.

An **Open File** dialog box may open with a warning message about potential harm from programs, macros or viruses. The files supplied do not contain any harmful content, and may be safely opened.

If using Adobe Acrobat Reader, click on the button below to open the spreadsheet. Some older versions of Adobe Acrobat Reader have a bug and do not support this button functionality. If the button does not work, upgrade your Adobe Acrobat Reader for free, to the latest version.

**FlexOperand G30 88x**

---

## 15.3 FLEXANALOG ITEMS

---

A FlexAnalog parameter is an analog parameter.

FlexAnalog items specific to your device are viewable in a web browser. Enter the IP address of the UR, access the **DeviceInformation** Menu option, then the **FlexAnalog Parameter** Listing option. Entries displayed online depend on order code.

Each FlexAnalog address is the Modbus memory map address prefixed with 0004. For example, with Modbus address of 1638, the FlexAnalog address is 00041638.

The data items are kept in files attached to this PDF. Depending on the file type, the files may be opened using Microsoft Excel, or free web-based software such as Google Sheets, or PDF viewer capable of opening attachments, such as Adobe Acrobat Reader or Nitro PDF.

Please note that this manual must be opened with a PDF viewer capable of opening attachments, such as Adobe Acrobat Reader or Nitro PDF. Browsers like Microsoft Edge or Google Chrome do not support PDF attachments, although Firefox does. If using Nitro PDF, attachments are shown in the Attachment Pane. To show or hide the Attachments pane, look in the sidebar and click the Attachments tab.

An **Open File** dialog box may open with a warning message about potential harm from programs, macros or viruses. The files supplied do not contain any harmful content, and may be safely opened.

If using Adobe Acrobat Reader, click on the button below to open the spreadsheet. Some older versions of Adobe Acrobat Reader have a bug and do not support this button functionality. If the button does not work, upgrade your Adobe Acrobat Reader for free, to the latest version.

**FlexAnalog G30 88x**

## 15.4 VERSION HISTORY

| Manual P/N    | FW revision | Release date      | ECO     |
|---------------|-------------|-------------------|---------|
| 1601-0166-J1  | 4.4x        | 15 September 2004 | URX-156 |
| 1601-0166-J2  | 4.4x        | 05 January 2005   | URX-173 |
| 1601-0166-K1  | 4.6x        | 15 February 2005  | URX-176 |
| 1601-0166-L1  | 4.8x        | 05 August 2005    | URX-202 |
| 1601-0166-M1  | 4.9x        | 15 December 2005  | URX-208 |
| 1601-0166-M2  | 4.9x        | 27 February 2006  | URX-214 |
| 1601-0166-N1  | 5.0x        | 31 March 2006     | URX-217 |
| 1601-0166-N2  | 5.0x        | 26 May 2006       | URX-220 |
| 1601-0166-P1  | 5.2x        | 23 October 2006   | URX-230 |
| 1601-0166-P2  | 5.2x        | 24 January 2007   | URX-232 |
| 1601-0166-R1  | 5.4x        | 26 June 2007      | URX-242 |
| 1601-0166-R2  | 5.4x        | 31 August 2007    | URX-246 |
| 1601-0166-R3  | 5.4x        | 17 October 2007   | URX-251 |
| 1601-0166-S1  | 5.5x        | 7 December 2007   | URX-253 |
| 1601-0166-S2  | 5.5x        | 22 February 2008  | URX-258 |
| 1601-0166-S3  | 5.5x        | 12 March 2008     | URX-260 |
| 1601-0166-T1  | 5.6x        | 27 June 2008      | 08-0390 |
| 1601-0166-U1  | 5.7x        | 29 May 2009       | 09-0938 |
| 1601-0166-U2  | 5.7x        | 30 September 2009 | 09-1165 |
| 1601-0166-V1  | 5.8x        | 29 May 2010       | 09-1457 |
| 1601-0166-V2  | 5.8x        | 04 January 2011   | 11-2237 |
| 1601-0166-W1  | 5.9x        | 12 January 2011   | 11-2227 |
| 1601-0166-X1  | 6.0x        | 21 December 2011  | 11-2840 |
| 1601-0166-X2  | 6.0x        | 5 April 2012      | 12-3254 |
| 1601-0166-Y1  | 7.0x        | 30 September 2012 | 12-3529 |
| 1601-0166-Y2  | 7.0x        | 11 November 2012  | 12-3601 |
| 1601-0166-Z1  | 7.1x        | 30 March 2013     | 13-0126 |
| 1601-0166-AA1 | 7.2x        | 1 August 2013     | 13-0401 |
| 1601-0166-AB1 | 7.3x        | 7 November 2014   | 14-1408 |
| 1601-0166-AB2 | 7.3x        | 1 September 2015  | 15-2215 |
| 1601-0166-AC1 | 7.40x       | 8 December 2016   | 16-3319 |
| 1601-0166-AE1 | 7.41x       | 31 January 2017   | 17-3427 |
| 1601-0166-AE3 | 7.4x        | 28 April 2017     | 17-3561 |
| 1601-0166-AF1 | 7.6x        | 30 June 2017      | 17-3779 |
| 1601-0166-AF2 | 7.6x        | 31 October 2017   | 17-3935 |
| 1601-0166-AG1 | 7.7x        | 31 March 2018     | 18-4430 |
| 1601-0166-AG2 | 7.7x        | 4 May 2018        | 18-4517 |
| 1601-0166-AH1 | 7.8x        | 17 December 2018  | 18-4703 |
| 1601-0166-AI1 | 7.9x        | 24 October 2019   | 19-5181 |
| 1601-0166-AJ1 | 8.0x        | 30 October 2019   | 19-5182 |
| 1601-0166-AJ2 | 8.0x        | 12 June 2020      | 20-5580 |



| Manual P/N          | FW revision | Release date     | ECO     |
|---------------------|-------------|------------------|---------|
| 1601-0166-AK1       | 8.1x        | 20 November 2020 | 20-6096 |
| 1601-0166-AL1       | 8.2x        | 16 February 2021 | 21-6228 |
| 1601-0166-AL2       | 8.2x        | 23 July 2021     | 21-6482 |
| 1601-0166-AM1       | 8.3x        | 6 May 2022       | 22-6815 |
| 1601-0166-AM2       | 8.3x        | 14 October 2022  | 22-7224 |
| 1601-0166-AN1       | 8.4x        | 14 December 2022 | 22-7333 |
| 1601-0166-AN2       | 8.4x        | 28 June 2023     | 23-7692 |
| 1601-0166-AP1       | 8.5x        | 30 November 2023 | 23-7922 |
| G30-1601-0166-860-1 | 8.60        | 8 October 2024   | 24-0338 |
| G30-1601-0166-86x-2 | 8.6x        | 24 February 2025 | 25-0084 |
| G30-1601-0166-86x-3 | 8.6x        | 31 July 2025     | 25-0291 |
| G30-1601-0166-87x-1 | 8.70        | 31 October 2025  | 25-0484 |
| G30-1601-0166-87x-2 | 8.71        | 10 February 2026 | 26-0057 |
| G30-1601-0166-88x-1 | 8.80        | 24 July 2026     | 26-0254 |
| G30-1601-0166-88x-2 | 8.80        | 18 August 2026   | 26-0320 |





# GE VERNOVA

© 2025 General Electric. All rights reserved. Information contained in this document is indicative only. No representation or warranty is given or should be relied on that it is complete or correct or will apply to any particular project. This will depend on the technical and commercial circumstances. It is provided without liability and is subject to change without notice. Reproduction, use or disclosure to third parties, without express written authority, is strictly prohibited.