

Anark Core MBEWeb

GE Gas Power

July 22, 2020

History


Date	Author	Description of Changes	Revision
1/17/20	Kena Yokoyama	Initial Release	1.0
2/26/20	Kena Yokoyama	Updated Why Anark Core MBEWeb slide	1.1
5/28/20	Kena Yokoyama	Updated for Production MBEWeb External	1.2
6/22/20	Kena Yokoyama	Updated for posting to external Supplier website	1.3



Why Anark Core MBEWeb?

3D-PDF to Anark Core MBEWeb

Feedback	3D-PDF Status	Anark Core MBEWeb Capability
Files too big	3MB-1.2GB download	Preview & navigate w/o full download
Navigation too slow	Slower the bigger the file	10x+ faster, 2D option
Can't search	Not in our template	By PMI type, text, point name, eCAV Balloon #, Rev Triangle
Can't open on my device	Computers need Adobe Reader XI	Viewable on business computer, tablet, smartphone
Difficult to navigate	1 view at a time	Side by side w/ hyperlinks, thumbnails, search
Too much paper	1 view per sheet	Flexible # of views/order, MBD Layout
Printing too slow	1 page at a time	Printing now from saved 2D images
Markups impossible	Tedious	Collaborative, searchable, 2D option
New functionality	Need to republish	New functionality quickly applied to content w/o the need to republish
Support documents	Posted on Box	Linked in content and collaboration





Allowed Data

- GE Internal Users and External Supply Chain users.
- Class II Non-Export Controlled content only. Restricted Class II such as PSM and Class
 III are allowed. Class IV and Export Controlled are not allowed in Anark Core MBEWeb.
 Markups, comments and pictures added to Anark Core MBEWeb Collaboration must
 not include Class IV or Export Controlled information.
- PLM/SDX Access and an Active PO, RFQ or SDX folder are required. Because the content translated into Anark Core MBEWeb is managed by PLM, Anark Core MBEWeb access authenticates in PLM. If you have access to the CAD model and can download the 3DPDF from PLM/SDX, you will have access in Anark Core MBEWeb.



Accessing Anark Core MBEWeb

Content link in the PDDR for each Model-Based CAD Model

Part Definition Data Report for - 100T0001G0001 rev 000 Wed Feb 13 16:46:						Wed Feb 13 16:46:52 EST 2019								
evel F/	N BOM Prefi	x Part Number	Part Rev	Qty	UOM	EID	Document Name	Doc Rev	Description	Туре	State	Original / Replacement Part	Part Attributes	MBEWEB External Link
1		100T0001G0001	0)	EA (each)				NIST TEST PART	Part	Release			
						CADModel	100T0001G0001		NIST TEST PART	UG Model	Release			https://mbe-ext.gepower
						COMDOC	348A9200	M	APPLIED PRACTICES GENERAL MACHINING	GE Technical Document	Release			
2 1	1	100T0001P0001	0	1	EA (each)				NIST	Part	Release			
						CADModel	100T0001P0001		NIST	UG Model	Release			
						COMDOC	348A9200	M	APPLIED PRACTICES GENERAL MACHINING	GE Technical Document	Release			
2 2	2	100T0002P0001	0	1	EA (each)				NIST	Part	Release			
						CADModel	100T0002P0001	(NIST	UG Model	Release			
						COMDOC	348A9200	M	APPLIED PRACTICES GENERAL MACHINING	GE Technical Document	Release			
2	3	100T0003P0001	0	1	EA (each)				NIST	Part	Release			
						CADModel	100T0003P0001	(NIST	UG Model	Release			
						COMDOC	348A9200	M	APPLIED PRACTICES GENERAL MACHINING	GE Technical Document	Release			
2 4	4	100T0004P0001	0	1	EA (each)				NIST	Part	Release			
						CADModel	100T0004P0001	(NIST	UG Model	Release			
						COMDOC	348A9200	M	APPLIED PRACTICES GENERAL MACHINING	GE Technical Document	Release			

404 Not Found


nginx/1.12.2

If the Anark Core MBEWeb link results in an error, contact GE. The PDDR may have out of date links.



Anark Core MBEWeb Content

- Title block including name, rev, description, date published to Anark Core MBEWeb, classification, export status, copyright.
- ? Link to Help Documentation
- Search to filter to views that contain the searched content
- Quick Print to print to physical printer or 2DPDF
- Thumbnails for quick browsing. Click on a thumbnail to open the 3D interactive view
- Show 2D to navigate with slower connections







Anark Core MBEWeb

July 22, 2020

Anark Core MBEWeb 3D Views

- Arrows, Xs and buttons to navigate, open/close, expand/reduce, show/hide, orient and change display mode for views, bodies, background geometry, eCAV balloons
- X in upper right corner to return to thumbnails
- Secondary Canvas to open side-by-side views
- MBD and See Note Hyperlinks to open related section view, parent view, notes view in secondary canvas
- Select PMI to highlight associated objects just like in 3DPDF. Select eCAV balloons to highlight related PMI and referenced geometry.
- Select from parts list to highlight listed component
- Rotate the view with the right mouse button, zoom in or out with the scroll button and pan by holding down the scroll button.









Anark Core MBEWeb July 22, 2020

Anark Core MBEWeb Collaboration

Click on the Anark logo from any page to get to the Anark Core MBEWeb Collaboration Homepage





Activity Feed, includes activities, conversations and comments, newest to oldest.

GE will invite External Supply Chain users to collaborate



Training Video

https://www.ge.com/power/about/suppliers

Includes MBEWeb Training video and how get access to PLM/SDX



Future Updates

- Streamlining collaboration workflows and email notifications (2020)
- Integration with new PLM version (2021)
- Measurement capability (2021)



Please provide feedback

- What is working, not working?
- What recommendations do you have?

