



RENEWAL PARTS

Type IFCV Time-Overcurrent Relay With Voltage Restrain

Ordering Instructions

1. **Always specify the complete nameplate data of the relay.**
2. Specify the quantity, catalog number (if listed), reference number (if listed), description, and this bulletin number.
3. Standard hardware, such as screws, bolts, nuts, washers, etc., is not listed in this bulletin. Such items should be purchased locally.
4. For prices, refer to the nearest office of the General Electric Company.
5. **The upper or lower terminal block will be supplied with contact fingers in all positions and loose shorting bars. These parts are to be used as required.**

How to Use this Bulletin

1. Relay models covered by this bulletin are listed in the left-hand column of the tabulation beginning on page 2.
2. To find the catalog number of a renewal part:
 - A. Referring to the illustrations on page 1, find the reference letter for the required part.
 - B. Locate the reference letter and/or description of the part in the column headings at the top of the tabulation.
 - C. Note the numeral at the intersection of the reference letter column and model number line. This numeral, when added to the reference letter, provides the key to the catalog number of the part, which is listed in the table on the page indicated.

Example:

To find the catalog number of the Seal-in Unit for the Model 121FCV51AD1A relay:

- A. Figure 1 on page 1 indicates that the reference letter for the Seal-in Unit is "A".
- B. Locate reference letter "A" in the column headings on page 2.
- C. At intersection of the "A" column and Model IFCV51AD1A line find the numeral 1. The complete reference symbol is therefore, "A-1". Referring to page 2 in the catalog, the number is found to be 721-185B6204G1 (one required per relay).




Fig. 1. Type 121FCV51BD relay, removed from case, front view




Fig. 2. Type 121FCV51BD relay, removed from case, rear view

GEF-4645, TYPE IFCV RELAYS

[illegible]

* Recommended for stock for normal maintenance.

† Not shown.

Ref. Symbol	Fig. No.	Catalog Number	No. Per Relay
----------------	-------------	----------------	------------------

TABLE A
SEAL-IN UNIT

A-1	1	721-184B6204G1	1
A-2	1	721-184B6204G2	1

TABLE B
INSTANTANEOUS UNIT

B-1	1	721-184B6205G9	1
-----	---	----------------	---

TABLE C
OPERATING COIL ASSEMBLY

C-1	2	721-891B0450G164	1
-----	---	------------------	---

TABLE D
RESTRAINT COIL ASSEMBLY

D-1	2	721-6293206G164	1
D-2	2	721-6293206G165	1

TABLE E
RESISTOR

E-1	2	721-403A321P12	1
E-2	2	721-403A321P30	1

TABLE F
DISK AND SHAFT ASSEMBLY

F-1	1	721-183B7976G3	1
-----	---	----------------	---

Ref. Symbol	Fig. No.	Catalog Number	No. Per Relay
----------------	-------------	----------------	------------------

TABLE G
TOP BEARING STUD

G-1	1	721-6209409G1	1
-----	---	---------------	---

TABLE H
JEWEL BEARING ASSEMBLY

H-1	1	721-6209457G1	1
-----	---	---------------	---

TABLE J
MOVING CONTACT AND HUB ASSEMBLY

J-1	1	721-227A8083G1	1
-----	---	----------------	---

TABLE K
CONTROL SPRING

K-1	1	721-6079898P2	1
-----	---	---------------	---

TABLE L
STATIONARY CONTACT ASSEMBLY

L-1	1	721-6209430G1	1
-----	---	---------------	---

TABLE M
DRAG MAGNET

M-1	1	721-152C5876G3 (1650 Pts)	1
-----	---	------------------------------	---

TABLE N
COVER ASSEMBLY

N-1	-	721-183B7970G1	1
-----	---	----------------	---



GE VERNOVA

650 Markland Street
Markham, Ontario
Canada L6C 0M1
Worldwide telephone: +1 905 927 7070
North America toll-free: 1 800 547 8629
Website: <https://www.gevernova.com/grid-solutions>