

# Grid Automation Industrial Communications

# Firmware/Software Release Note

Date: Jul 2021 Distribution: Public Reference: S20-FW-RN-EN-1

### S20 Firmware

v 07A07.00 - Jul 2021

#### Key new feature

- Digital Diagnostics Monitoring (DDM) functionality for optical SFP transceivers
- New alarms using the dry-contact relay or SNMP traps were add based on DDM measurements

#### **Cybersecurity fixes**

- Web interface user session was preserved after switch reboot
- User with "read-only" privilege level could clear equipment log

#### **Notable bug fixes**

- Fixed unexpected reset during equipment power on
- Local user authentication not working with RADIUS authentication enabled
- Fixed SFP identification: 1 Gbps 80 km single mode SFP transceiver
- Syslog would log "HTTP protocol" for users authenticating through "HTTPS protocol"

#### Hardware compatibility

• Firmware 07A07 is compatible with hardware version B and C.

#### **Upgrade procedure**

- Upgrade directly from firmware 06A02.00 or newer
- Follow process outlined in S20 technical manual, chapter 7, section 2.3.
- When performing firmware upgrade, please make sure to save the running configuration to the startup between each upgrade.
- After firmware upgrade, please clear the web browser's cache for changes to take effect.

#### **Upgrade impact**

• Firmware downgrades are not allowed.

## v 07A06.00 - Sep 2020

#### **Key new features**

• Configurable persistence of alarms (dry-contact relay / LEDs), so user may decide whether an alarm to persist once triggered or to deactivate once the situation is cleared.

#### Other new features

Added physical port label in CLI spanning-tree command: "show spanning-tree"



#### **Notable bug fixes**

- Fixed cross-site scripting vulnerability in web interface
- Failsafe relay and LED wound incorrectly activate

#### Hardware compatibility

• Firmware 07A06.00 is compatible with hardware version B and C.

#### **Upgrade procedure**

- Upgrade directly from firmware 06A02.00 or newer
- Follow process outlined in S20 technical manual, chapter 7, section 2.3.
- When performing firmware upgrade, please make sure to save the running configuration to the startup between each upgrade.

#### **Upgrade impact**

• Firmware downgrades are not allowed.

----

For questions or further product support, please contact the GE support team using:

Region	E-mail	Telephone
Global Contact Centre	GA.support@GE.com	+44 1785 250070
Central, East Asia, Pacific	GA.supportCEAP@GE.com	+61 414 730 964
India	GA.supportIND@GE.com	+91 44 2264 8000
Middle East, North Africa, Turkey	GA.supportMENAT@GE.com	+971 42929467
Europe, Russia, CIS, Sub-Saharan Africa	GA.supportERCIS@GE.com	+34 94 4858854
North America	GA.supportNAM@GE.com	+1 877 605 6777
Latin America	GA.supportLAM@GE.com	+55 48 2108 0300

