## 1.40 TO 1.51 - Nov. 4, 2002

- 1. A1 / Local Relay Output status now fully functional
- 2. Changed digital inputs format to OFF, General and Digital counter.
- 3. A5/Relay Information/Calibration Date now displays correct date.
- 4. Removed unsupported communication mode.
- 5. Removed S4/Digital Inputs/Block From Start menu, as it is for 369 only.
- 6. Corrected the order code string in setpoint files and prints.
- 7. Added last build time in *about* box.

## 1.20 TO 1.40 - Feb. 18, 2000

1. Added *Refresh RRTD* commands that send setpoints from the master to specified Remote RTD Modules.

## 1.10 TO 1.20 - Dec. 17, 1999

- 1. The order code for Control Power is now displayed as "XX" since it is unknown when working in edit mode
- 2. Clear RTD Maximums command now fully functional.